



Cisco Firepower 4100/9300 FXOS Command Reference

First Published: 2021-12-01

Last Modified: 2022-11-30

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on standards documentation, or language that is used by a referenced third-party product.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2017–2022 Cisco Systems, Inc. All rights reserved.



About the FXOS CLI Command Reference Guide

This guide represents an on-going effort to document the many CLI commands in FXOS, and as such, should be viewed as a work-in-progress. The guide will be republished periodically as new command descriptions are added and existing descriptions updated or corrected.



CLI Overview

- [Managed Objects, on page 4](#)
- [Command Modes, on page 5](#)
- [FXOS CLI Connects Diagram, on page 7](#)
- [Object Commands, on page 8](#)
- [Complete a Command, on page 9](#)
- [Command History, on page 10](#)
- [Commit, Discard, and View Pending Commands, on page 11](#)
- [Inline Help for the CLI, on page 12](#)
- [CLI Session Limits, on page 13](#)

Managed Objects

The FXOS uses a managed object model, where managed objects are abstract representations of physical or logical entities that can be managed. For example, chassis, security modules, network modules, ports, and processors are physical entities represented as managed objects, and licenses, user roles, and platform policies are logical entities represented as managed objects.

Managed objects may have one or more associated properties that can be configured.

Command Modes

The CLI is organized into a hierarchy of command modes, with EXEC mode being the highest-level mode of the hierarchy. Higher-level modes branch into lower-level modes. You use **create**, **enter**, and **scope** commands to move from higher-level modes to modes in the next lower level, and you use the **up** command to move up one level in the mode hierarchy. You can also use the **top** command to move to the top level in the mode hierarchy.



Note Most command modes are associated with managed objects, so you must create an object before you can access the mode associated with that object. You use **create** and **enter** commands to create managed objects for the modes being accessed. The **scope** commands do not create managed objects and can only access modes for which managed objects already exist.

Each mode contains a set of commands that can be entered in that mode. Most of the commands available in each mode pertain to the associated managed object.

The CLI prompt for each mode shows the full path down the mode hierarchy to the current mode. This helps you to determine where you are in the command mode hierarchy, and it can be an invaluable tool when you need to navigate through the hierarchy.

The following table lists the main command modes, the commands used to access each mode, and the CLI prompt associated with each mode.

Table 1: Main Command Modes and Prompts


Mode Name	Commands Used to Access	Mode Prompt
EXEC	top command from any mode	#
Adapter	scope adapter command from EXEC mode	/adapter #
Cabling	scope cabling command from EXEC mode	/cabling #
Chassis	scope chassis command from EXEC mode	/chassis #
Ethernet server domain	scope eth-server command from EXEC mode; this command and all subcommands are currently not supported	/eth-server #
Ethernet uplink	scope eth-uplink command from EXEC mode	/eth-uplink #
Fabric interconnect	scope fabric-interconnect command from EXEC mode	/fabric-interconnect #
Firmware	scope firmware command from EXEC mode	/firmware #

Mode Name	Commands Used to Access	Mode Prompt
Host Ethernet interface	<p>scope host-eth-if command from EXEC mode</p> <p>Note This command and all subcommands are not supported at this level; the Host Ethernet interface commands are available in <code>/adapter #</code> mode.</p>	/host-eth-if #
License	scope license command from EXEC mode	/license #
Monitoring	scope monitoring command from EXEC mode	/monitoring #
Organization	scope org command from EXEC mode	/org #
Packet capture	scope packet-capture command from EXEC mode	/packet-capture #
Security	scope security command from EXEC mode	/security #
Server	scope server command from EXEC mode	/server #
Service profile	<p>scope service-profile command from EXEC mode</p> <p>Note Do not alter or configure service profiles; that is, do not use the create, set, or delete subcommand sets.</p>	/service-profile #
SSA	scope ssa command from EXEC mode	/ssa #
System	scope system command from EXEC mode	/system #
Virtual HBA	<p>scope vhba command from EXEC mode</p> <p>Note This command and all subcommands are currently not supported.</p>	/vhba #
Virtual NIC	scope vnic command from EXEC mode	/vnic #

FXOS CLI Connects Diagram

The following diagram outlines the various commands that can be executed from the FXOS CLI top level to access the FXOS command shell, local management command shell, network adapter, CIMC, and security module CLI.

Figure 1: Firepower 4100/9300 FXOS CLI Connects Diagram



Object Commands

Four general commands are available for object management:

- **create** *object*
- **delete** *object*
- **enter** *object*
- **scope** *object*

You can use the **scope** command with any managed object, whether a permanent object or a user-instantiated object. The other commands allow you to create and manage user-instantiated objects. For every **create** *object* command, a corresponding **delete** *object* and **enter** *object* command exists.

In the management of user-instantiated objects, the behavior of these commands depends on whether the object exists, as described in the following tables:

Table 2: Command Behavior If The Object Does Not Exist

Command	Behavior
create <i>object</i>	The object is created and its configuration mode, if applicable, is entered.
delete <i>object</i>	An error message is generated.
enter <i>object</i>	The object is created and its configuration mode, if applicable, is entered.
scope <i>object</i>	An error message is generated.

Table 3: Command Behavior If The Object Exists

Command	Behavior
create <i>object</i>	An error message is generated.
delete <i>object</i>	The object is deleted.
enter <i>object</i>	The configuration mode, if applicable, of the object is entered.
scope <i>object</i>	The configuration mode of the object is entered.

Complete a Command

You can use the **Tab** key in any mode to complete a command. Partially typing a command name and pressing **Tab** causes the command to be displayed in full or to the point where you must enter another keyword or an argument value.

Command History

The CLI stores all commands used in the current session. You can step through the previously used commands by using the up-arrow or down-arrow keys. The up-arrow key moves to the previous command in the history, and the down-arrow key moves to the next command in the history. When you get to the end of the history, pressing the down-arrow key does nothing.

You can enter any command in the history again by stepping through the history to recall that command and then pressing **Enter**. The command is entered as if you had manually typed it. You can also recall a command and change it before you press **Enter**.

Commit, Discard, and View Pending Commands

When you enter a configuration command in the CLI, the command is not applied until you enter the **commit-buffer** command. Until committed, a configuration command is pending and can be discarded by entering a **discard-buffer** command.

You can accumulate pending changes in multiple command modes and apply them together with a single **commit-buffer** command. You can view the pending commands by entering the **show configuration pending** command in any command mode.



Note All pending commands are checked for validity. However, if any queued command fails during commit, the remaining commands are applied; failed commands are reported in an error message.

While any commands are pending, an asterisk (*) appears before the command prompt. The asterisk disappears when you enter the **commit-buffer** command.

The following example shows how the prompts change during the command entry process:

```
Firepower# scope system
Firepower /system # scope services
Firepower /system/services # create ntp-server 192.168.200.101
Firepower /system/services* # show configuration pending
  scope services
+   create ntp-server 192.168.200.101
  exit
Firepower /system/services* # commit-buffer
Firepower /system/services #
```

Inline Help for the CLI

At any time, you can enter the ? character to display the options available at the current state of the command syntax.

If you have not entered anything at the prompt, entering ? lists all available commands for the mode you are in. With a partially entered command, entering ? lists all keywords and arguments available at your current position in the command syntax.

CLI Session Limits

FXOS limits the number of CLI sessions that can be active at one time to 32 total sessions. This value is not configurable.



Filter and Save Show Output

- [Save and Filter Show Command Output, on page 16](#)

Save and Filter Show Command Output

You can save the output of **show** commands by redirecting the output to a text file. You can filter the output of **show** commands by piping the output to filtering commands.

Saving and filtering output are available with all **show** commands but are most useful when dealing with commands that produce a lot of text. For example, you can show all or parts of the configuration by using the **show configuration** command. Copying the configuration output provides a way to backup and restore a configuration.



Note Show commands do not show the secrets (password fields), so if you want to paste a configuration into a new device, you will have to modify the show output to include the actual passwords.

Filter Show Command Output

To filter the output of a **show** command, use the following subcommands. Note that in the following syntax description, the initial vertical bar `|` after the **show** command is the pipe character and is part of the command, not part of the syntax description. The filtering options are entered after the command's initial `|` character.

show command | {**begin** *expression* | **count** | **cut** *expression* | **egrep** *expression* | **end** *expression* | **exclude** *expression* | **grep** *expression* | **head** | **include** *expression* | **last** | **less** | **no-more** | **sort** *expression* | **tr** *expression* | **uniq** *expression* | **wc**}

Filtering Options

These are the filtering subcommands:

- **begin**—Finds the first line that includes the specified pattern, and display that line and all subsequent lines.
- **count**—Counts the number of lines.
- **cut**—Removes (“cut”) portions of each line.
- **egrep**—Displays only those lines that match the extended-type pattern.
- **end**—Ends with the line that matches the pattern.
- **exclude**—Excludes all lines that match the pattern and show all other lines.
- **grep**—Displays only those lines that match the pattern.
- **head**—Displays the first lines.
- **include**—Displays only those lines that match the pattern.
- **last**—Displays the last lines.
- **less**—Filters for paging.
- **no-more**—Turns off pagination for command output.
- **sort**—Sorts the lines (stream sorter).

- **tr**—Translates, squeezes, and/or deletes characters.
- **uniq**—Discards all but one of successive identical lines.
- **wc**—Displays a count of lines, words, and characters.

expression

An expression, or pattern, is typically a simple text string. Do not enclose the expression in single or double-quotes—these will be seen as part of the expression. Also, trailing spaces will be included in the expression.



Note Several of these subcommands have additional options that let you further control the filtering. For example, with **show configuration | head** and **show configuration | last**, you can use the **lines** keyword to change the number of lines displayed; the default is 10. As another example, with **show configuration | sort**, you can add the option **-u** to remove duplicate lines from the output. (Complete descriptions of these options is beyond the scope of this document; refer to the FXOS help output for the various commands, and to the appropriate Linux help, for more information.)

Examples

The following example shows how to determine the number of lines currently in the system event log:

```
FP9300-A# show sel 1/1 | count
3008
FP9300-A#
```

The following example shows how to display lines from the system event log that include the string “error”:

```
FP9300-A# show sel 1/1 | include error
968 | 05/15/2016 16:46:25 | CIMC | System Event DDR4_P2_H2_EC
C #0x99 | Upper critical - going high | Asserted | Reading 20
000 >= Threshold 20000 error
FP9300-A#
```

Related Topics

[Save Show Command Output, on page 17](#)

Save Show Command Output

You can save the output of **show** commands by redirecting the output to a text file.

```
show command [ > { ftp: | scp: | sftp: | tftp: | volatile: | workspace: } ] | [ >> { volatile: | workspace: } ]
```

Syntax Description

> { **ftp:** | **scp:** | **sftp:** | **tftp:** | **volatile:** | **workspace:** }

Redirects the **show** command output to a specified text file using the selected transport protocol.

After you enter the command, you are queried for remote server name or IP address, user name, file path, and so on.

If you press **Enter** at this point, the output is saved locally.

>> {**volatile:** | **workspace:**} Appends the **show** command output to the appropriate text file, which must already exist.

Example

The following example attempts to save the current configuration to the system workspace; a configuration file already exists, which you can choose to overwrite or not.

```
FP9300-A# show configuration > workspace
File already exists, overwrite (y/n)?[n]n
Reissue command with >> if you want to append to existing file
```

```
FP9300-A#
```

Related Topics

[Filter Show Command Output, on page 16](#)



Unsupported and Restricted Commands

- [Unsupported Commands, on page 20](#)
- [Restricted Commands, on page 24](#)

Unsupported Commands

The following commands, while visible in the CLI, are not supported. Entering any of these commands has no effect.

EXEC (Top-level) Commands

```
# restore-check
# scope eth-server (and all subcommands)
# scope host-eth-if (the host-eth-if subcommands are available in /adapter mode)
# scope nh-test (and all subcommands)
# set nh-test
# show nh-test
# show registry-repository
# show ucspe-tech-support
# ucspe-copy
# vhma (and all subcommands)
```

Chassis Mode Commands

```
/chassis # scope iom
/chassis # show iom
/chassis # show post
```

Fabric Interconnect Mode Commands

```
/fabric-interconnect # scope fan
/fabric-interconnect # scope fan-module
/fabric-interconnect # scope psu
/fabric-interconnect # scope sw-uplink
/fabric-interconnect # show fan
/fabric-interconnect # show fan-module
/fabric-interconnect # show lan-neighbors
/fabric-interconnect # show psu
/fabric-interconnect # show san-neighbors
/fabric-interconnect # show sw-uplink
```

Organization Mode Commands

```
/org # recommission server
```

```
/org # scope auth-profile
/org # scope fc-policy
/org # scope iqn-pool
/org # scope iscsi-policy
/org # scope kvm-mgmt-policy
/org # scope rackserver-disc-policy
/org # scope rackserver-mgmt-policy
/org # scope san-connectivity-policy
/org # scope storage-connection-policy
/org # scope uddl-link-policy
/org # scope uddl-system-settings
/org # scope uuid-suffix-pool
/org # scope vhba-beh-policy
/org # scope vhba-templ
/org # scope vmq-conn-policy
/org # scope wwn-pool
/org # show fc-policy
/org # show fc-zone
/org # show iqn-pool
/org # show rackserver-disc-policy
/org # show rackserver-mgmt-policy
/org # show san-connectivity-policy
/org # show uddl-link-policy
/org # show uddl-system-settings
/org # show uuid-suffix-pool
/org # show vhba-beh-policy
/org # show vhba-templ
/org # show vmq-conn-policy
/org # show wwn-pool
```

Packet Capture Mode Commands

```
/packet-capture # show nh-test
```

Security Mode Commands

```
/security # create role
```

```
/security # delete role
```

Server Mode Commands

```
/server # show flexflash-controller
```

Service Profile Mode Commands

```
/service-profile # disassociate  
/service-profile # rename-to  
/service-profile # scope dynamic-vnic-conn  
/service-profile # scope ext-pooled-ip  
/service-profile # scope ext-static-ip  
/service-profile # scope fc-zone  
/service-profile # scope iscsi-boot  
/service-profile # scope vhba  
/service-profile # set dynamic-vnic-conn-policy  
/service-profile # set ext-mgmt-ip-pool-name  
/service-profile # set ext-mgmt-ip-state  
/service-profile # set iscsi-identity  
/service-profile # set kvm-mgmt-policy  
/service-profile # set san-connectivity-policy-name  
/service-profile # set src-templ-name  
/service-profile # show dynamic-vnic-conn  
/service-profile # show dynamic-vnic-conn-policy  
/service-profile # show ext-pooled-ip  
/service-profile # show ext-static-ip  
/service-profile # show fc-zone  
/service-profile # show initiator-group  
/service-profile # show iscsi-boot  
/service-profile # show iscsi-identity  
/service-profile # show mgmt-iface  
/service-profile # show vhba  
/service-profile # show vnic-iscsi
```

System Mode Commands

```
/system # scope control-ep  
/system # scope environment-features
```



```
/system # scope storage-features
```

```
/system # scope vm-mgmt
```

```
/system # set virtual-ip
```

```
/system # show control-ep
```

Restricted Commands

Use of the following commands is restricted. Do not use any of these commands unless instructed to do so by a member of the Cisco Technical Assistance Center (TAC).

Service Profile Mode Commands

Do not change any service profile configurations; specifically do not use any of the `/service-profile # create`, `/service-profile # delete` or `/service-profile # set` subcommands.



PART I

A – R Commands

- [A – C Commands, on page 27](#)
- [D – R Commands, on page 117](#)



A – C Commands

- [acknowledge fault](#), on page 29
- [acknowledge server](#), on page 30
- [acknowledge slot](#), on page 31
- [activate firmware](#), on page 32
- [backup sel](#), on page 33
- [cancel](#), on page 34
- [clear lock-status](#), on page 35
- [clear message](#), on page 36
- [clear password-history](#), on page 37
- [clear sel](#), on page 38
- [commit-buffer](#), on page 39
- [connect adapter](#), on page 40
- [connect asa](#), on page 42
- [connect cimc](#), on page 44
- [connect ftd](#), on page 46
- [connect fxos](#), on page 48
- [connect local-mgmt](#), on page 50
- [connect module](#), on page 52
- [connect vdp](#), on page 54
- [create app-instance](#), on page 56
- [create bootstrap-key FIREWALL_MODE](#), on page 57
- [create bootstrap-key MANAGEMENT_TYPE](#), on page 58
- [create bootstrap-key PERMIT_EXPERT_MODE](#), on page 59
- [create bootstrap-key MANAGEMENT_TYPE](#), on page 60
- [create bootstrap-key-secret PASSWORD](#), on page 61
- [create bootstrap-key-secret REGISTRATION_KEY](#), on page 62
- [create bootstrap-key DNS_SERVERS](#), on page 63
- [create bootstrap-key FIREPOWER_MANAGER_IP](#), on page 64
- [create bootstrap-key SEARCH_DOMAINS](#), on page 65
- [create breakout](#), on page 66
- [create certreq](#), on page 68
- [create class](#), on page 70
- [create connection](#), on page 72

- [create destination](#), on page 73
- [create dns](#), on page 75
- [create hw-crypto](#), on page 76
- [create ip-block](#), on page 77
- [create ipv6-block](#), on page 79
- [create keyring](#), on page 81
- [create local-user](#), on page 82
- [create member-port](#), on page 84
- [create ntp-server](#), on page 86
- [create policy \(callhome\)](#), on page 87
- [create policy \(flow control\)](#), on page 90
- [create port-channel](#), on page 92
- [create pre-login-banner](#), on page 94
- [create profile](#), on page 96
- [create property](#), on page 98
- [create resource-profile](#), on page 100
- [create server \(scope ldap\)](#), on page 102
- [create snmp-trap](#), on page 104
- [create snmp-user](#), on page 106
- [create ssh-server](#), on page 107
- [create stats-threshold-policy](#), on page 108
- [create subinterface](#), on page 110
- [create threshold-value](#), on page 113
- [create trustpoint](#), on page 115
- [cycle](#), on page 116

acknowledge fault

To acknowledge a system fault, use the **acknowledge fault** command.

```
acknowledge fault id
```

Syntax Description	fault id	The fault identification number. The range of valid values is 0 to 18446744073709551615.
Command Modes	Multiple modes	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use the acknowledge fault command to acknowledge the existence of a fault.	

Example

The following example shows how to acknowledge a fault:

```
firepower # acknowledge fault 11347599
firepower* # commit-buffer
firepower #
```

Related Commands	Command	Description
	acknowledge server	Acknowledges a server on the device.
	acknowledge slot	Acknowledges the existence of a slot in the device.
	show fault	Shows fault policy information.

acknowledge server

To acknowledge a server, use the **acknowledge server** command.

acknowledge server {*id* | *chassis/blade_id*}

Syntax Description

server { <i>id</i> <i>chassis/blade_id</i> }	To use the server identification number to identify the server to acknowledge, provide the <i>id</i> . To use the chassis and blade identification numbers to identify the server to acknowledge, enter <i>chassis/blade_id</i> in n/n format. Note The chassis ID number is always 1 .
--	---

Command Modes

EXEC
scope chassis/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use the **acknowledge server** command to verify the existence of a server in your network. For example, you can acknowledge a server that was recently commissioned to ensure that it exists.

In chassis mode, you can use only the *id* variable to identify the server to be acknowledged.

Example

The following example shows how to acknowledge a server in module 2 while in chassis mode:

```
firepower# scope chassis 1
firepower /chassis # acknowledge server 2
firepower /chassis* # commit-buffer
firepower /chassis #
```

Related Commands

Command	Description
acknowledge fault	Acknowledges a system fault.
acknowledge slot	Verifies the existence of a slot that was recently commissioned.
show server	The show server commands display a variety of server-related configuration information.

acknowledge slot

To acknowledge a slot, use the **acknowledge slot** command.

acknowledge slot {*id* | *chassis/blade_id*}

Syntax Description

In EXEC mode, use the chassis and blade identification numbers to identify the slot to acknowledge; enter *chassis/blade_id* in n/n format.

Note The chassis ID number is always **1**.

Command Modes

EXEC
scope chassis/
scope fabric-interconnect/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use the **acknowledge slot** command to verify the existence of a slot that was recently commissioned to ensure that it exists.

In chassis and fabric-interconnect mode, you can use only the *id* variable to identify the slot to be acknowledged.

In EXEC mode, you can use only the chassis and blade identification (*chassis/blade_id*) numbers to identify the slot to be acknowledged.

Example

The following example shows how to acknowledge a slot while in chassis mode:

```
firepower# scope chassis 1
firepower /chassis # acknowledge slot 2
firepower /chassis* # commit-buffer
firepower /chassis #
```

Related Commands

Command	Description
acknowledge fault	Acknowledges a system fault.
acknowledge server	Acknowledges the existence of a server in your network.

activate firmware

To activate a firmware package, use the **activate firmware** command.

activate firmware *version*

Syntax Description	<i>version</i>	Use its version number to specify the firmware package to be activated.
Command Modes	scope system/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	As part of the activation process, all CLI sessions will be terminated.	

Example

This example shows how to activate a firmware package:

```
firepower# scope system
firepower /system # activate firmware 2.4(1.52)
As part of activation, all cli sessions will be terminated.
Continue with activation? (yes/no)
```

Related Commands	Command	Description
	show firmware	Shows system firmware versions and status information.
	show server firmware	Shows server firmware versions and status information.

backup sel

To back up the system event log (SEL), use the **backup sel** command.

backup sel {*id*|*chassis/blade_id*}

Syntax Description	<i>id</i>	The server ID. On 9300 devices, there may be up to 3 servers.
	<i>chassis/blade_id</i>	The appliance chassis number and blade number in x/y format. Note The chassis ID number is always 1.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to back up the system event log (SEL) for a server.
In the command mode of a specific server (/chassis/server), you can run this command without any options.

Example

This example shows how to back up the SEL for server 2 in chassis 1:

```
firepower# backup sel 1/2
firepower* # commit-buffer
firepower#
```

Related Commands	Command	Description
	clear sel	Clears the system event log (SEL) for a server.

cancel

To cancel a reservation request, use the **cancel** command.

cancel

Syntax Description

This command has no arguments or keywords.

Command Modes

scope license/scope reservation/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

If you have already generated the authorization code, you must install it.

Example

This example shows how to cancel a reservation request:

```
firepower# scope license
firepower /license # scope reservation
firepower /license/reservation # cancel
Warning : If you have already generated the authorization code from CSSM, please abort the
cancellation by issuing discard-buffer and then install the authorization code.
firepower /license/reservation* #
```

Related Commands

Command	Description
enable reservation	Enables permanent license reservation.
show license	Shows current license information.

clear lock-status

To clear a user's locked-out status, use the **clear lock-status** command in local user mode.

clear lock-status

Syntax Description

This command has no arguments or keywords.

Command Modes

Local user (/security/local-user)

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

If any user (including admin users) exceeds the specified maximum number of login attempts, the user is locked out of the system and must wait the specified amount of time before being allowed to log in, unless you clear the user's locked-out status.

Example

This example shows how to enter local user mode and specify the amount of time that must pass before a locked-out user can log in.

```
FP9300-A # scope security
FP9300-A # scope local-user test_user1
FP9300-A /security/local-user # clear lock-status
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Related Commands

Command	Description
set max-login-attempts	Specifies the maximum number of failed login attempts before the user is locked out of the system.
set user-account-unlock-time	Specifies the amount of time a user remains locked out of the system after reaching the maximum number of login attempts.

clear message

To clear the current pre-login banner text, use the **clear message** command; the pre-login banner object itself is not deleted.

clear message

Syntax Description

This command has no arguments or keywords.

Command Modes

scope security/scope banner/scope pre-login-banner/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

When you enter this command, the text in the pre-login banner is cleared; the pre-login banner object itself is not deleted.

Example

This example shows you how to view the current pre-login banner, how to clear it, and then commit and confirm your change:

```
firepower # scope security
firepower /security # scope banner
firepower /security/banner # scope pre-login-banner
firepower /security/banner/pre-login-banner # show

Pre login banner:
  Message
  -----
  Firepower-9300-2
  Western Data Center

firepower /security/banner/pre-login-banner # clear message
firepower /security/banner/pre-login-banner* # commit
firepower /security/banner/pre-login-banner # show

Pre login banner:
  Message
  -----

firepower /security/banner/pre-login-banner #
```

Related Commands

Command	Description
create pre-login-banner	Creates a banner to be presented prior to the log-in screen; the banner object is initially empty.
set message	Adds or replaces the lines of text presented as the pre-login banner.

clear password-history

To clear the password history for a local user, use the **clear password-history** command.

clear password-history

Syntax Description

This command has no arguments or keywords.

Command Modes

Local user (/security/local-user) mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You must be a user with admin or AAA privileges to use this command.

Example

This example shows how to enter local user mode and clear the password history for the user.

```
FP9300-A # scope security
FP9300-A /security # scope local-user test_user
FP9300-A /security/local-user # clear password history
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Command	Description
create local-user	Creates a new local user account.
set password	Specifies the password for a user account.

clear sel

To clear the system event log (SEL) for a server, use the **clear sel** command.

clear sel {*id* | *chassis_id/blade_id*}

Syntax Description		
<i>id</i>	(Optional) The server ID. The 9300 devices have a maximum of 3 servers.	
<i>chassis_id/blade_id</i>	(Optional) The chassis number and blade number in n/n format.	
	Note	The chassis ID number is always 1.

Command Modes Any command mode

Command History	Release	Modification
	1.4(1)	Command added.

Usage Guidelines Use this command to clear the system event log (SEL) for a server. In the command mode for a specific server (/chassis/server), you can run this command without specifying a server.

Example

This example shows how to clear system event logs for server 1 in chassis 1 while in organization mode.

```
FP9300-A # scope org Test
FP9300-A /org # clear sel 1/1
FP9300-A /org* # commit-buffer
FP9300-A /org #
```

Related Commands	Command	Description
	backup sel	Backs up the system event log (SEL).

commit-buffer

To save or verify configuration changes, use the **commit-buffer** command.

commit-buffer [**verify-only**]

Syntax Description	verify-only	(Optional) Verifies/validates buffer contents only; the contents are not committed.
---------------------------	--------------------	---

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to execute or verify all pending configuration changes. While any configuration changes are pending, an asterisk (*) appears before the command prompt. When you enter the **commit-buffer** command, the pending commands are committed and the asterisk disappears.

Example

This example shows how to save configuration changes:

```
FP9300-A# create org 3
FP9300-A /org* # commit-buffer
FP9300-A /org #
```

Related Commands	Command	Description
	discard-buffer	Cancels and discards all uncommitted configuration changes.
	show configuration pending	Shows all pending configuration changes.

connect adapter

To connect to the adapter command shell, use the **connect** command.

connect adapter { *chassis/server/id* | *rack_server/id* }

Syntax Description		
<i>chassis/server/id</i>	Specifies the chassis, server (module) and adapter IDs (entered in n/n/n format). On the Firepower 9300, the module number can be 1, 2, or 3. On the Firepower 4100, it is 1.	Note The chassis ID number is always 1 .
<i>rack_server/id</i>	Specifies the rack number and module ID (entered in n/n format).	

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use **help** to list available mezzanine adapter commands; use **help** *command* to view information about an individual command.

Refer to [connect adapter: Command List, on page 690](#) for additional information.



Note When you connect to an adapter command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to `adapter n/n/n`, where `n/n/n` is the adapter's chassis/server/ID combination you entered to connect.

To exit the adapter mode, type **exit**.

Example

The following example shows how to connect to the adapter command shell, and view available commands:

```
firepower# connect adapter 1/1/1
adapter 1/1/1 # help
Available commands:
  connect          - Connect to remote debug shell
  exit             - Exit from subshell
  help             - List available commands
  history          - Show command history
  show-fwlist      - Show firmware versions on the adapter
  show-identity    - Show adapter identity
  show-phyinfo     - Show adapter phy info
  show-systemstatus - Show adapter status
adapter 1/1/1 # exit
```

```
firepower#
```

Related Commands

Command	Description
exit	Returns you to the previous CLI mode.

connect asa

To connect to the ASA CLI, use the **connect asa** command.

connect asa [*name*]

Syntax Description	<i>name</i>	(Optional) Specifies the ASA application instance name, which is the same as the logical device name.
--------------------	-------------	---

Command Modes	connect module/
---------------	-----------------

Command History	Release	Modification
	2.4(1)	Added the <i>name</i> argument.
	1.1(4)	Command added.

Usage Guidelines See the ASA documentation for commands available from the CLI.

To exit the ASA console, enter **Ctrl-a, d**

Return to the supervisor level of the FXOS CLI:

Exit the console:

Enter ~, then **quit** to exit the Telnet application.

Example:

```
asa> Ctrl-a, d
Firepower-module1> ~
telnet> quit
firepower#
```

Exit the Telnet session:

Enter **Ctrl-], .**

Example:

```
asa> Ctrl-a, d
Firepower-module1> Ctrl-], .
firepower#
```

Example

This example shows how to connect to the ASA CLI on module 1:

```
firepower# connect module 1 console
Telnet escape character is '~'.
Trying 127.5.1.1...
Connected to 127.5.1.1.
```

Escape character is '~'.

CISCO Serial Over LAN:
Close Network Connection to Exit

```
Firepower-module1> connect asa  
asa>
```

Related Commands	Command	Description
	connect ftd	Connects to the threat defense CLI.
	connect module	Connects to the module CLI.
	connect vdp	Connects to the vDP CLI.

connect cimc

To connect to the Cisco Integrated Management Controller (CIMC) command shell, use the **connect cimc** command.

connect cimc {*chassis_id/blade_id* | *rack_id*}

Syntax Description	<i>chassis_id/blade_id</i>	Specifies the chassis and module numbers (entered in n/n format). Note The chassis ID number is always 1 .
	<i>rack_id</i>	Specifies the rack number.
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Enter help to list available CIMC firmware debug utility commands; enter help <i>command</i> to view information about an individual command.	



Note When you connect to the CIMC command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to [*xxx*], where *xxx* is the last command you entered; see the following example.

Type **exit** to terminate the utility.

Do not use this utility unless instructed to do so by Cisco TAC. Refer to [connect cimc: Command List, on page 694](#) for additional information.

Example

The following example shows how to connect to CIMC mode and then list the available commands:

```
firepower# connect cimc 1/1
Trying 127.5.1.1...
Connected to 127.5.1.1.
Escape character is '^'.

CIMC Debug Firmware Utility Shell [ support ]
[ help ]# help

Debug Firmware Utility

Command List

alarms
cores
```

```

dimmb1
exit
i2cstats
images
mctools
memory
messages
mrcout
network
obfl
post
power
programmables
sensors
sel
fru
tasks
top
update
users
version
cert
sldp
help
help [COMMAND]

```

Notes:

"enter Key" will execute last command
"COMMAND ?" will execute help for that command

```

[ help ]# exit
Connection closed by foreign host.
firepower#

```

Related Commands

Command	Description
exit	Returns you to the previous CLI mode.

connect ftd

To connect to the threat defense CLI, use the **connect ftd** command.

connect ftd *name*

Syntax Description	<i>name</i>	Specifies the threat defense application instance name, which is the same as the logical device name. If you have multiple application instances for an application type, you must specify the name of the instance. To view the instance names, enter the command without a name.
---------------------------	-------------	--

Command Modes	connect module/
----------------------	-----------------

Command History	Release	Modification
	2.4(1)	Added the <i>name</i> argument. The escape character was changed to exit from Ctrl-a, d .
	1.1(4)	Command added.

Usage Guidelines See the threat defense documentation for commands available from the CLI.

To exit the threat defense console, enter **exit**. For pre-2.4(1) versions, enter **Ctrl-a, d**

Return to the supervisor level of the FXOS CLI:

Exit the console:

Enter ~, then **quit** to exit the Telnet application.

Example:

```
> exit
Firepower-module1> ~
telnet> quit
firepower#
```

Exit the Telnet session:

Enter **Ctrl-], .**

Example:

```
> exit
Firepower-module1> Ctrl-], .
firepower#
```

Example

This example shows how to connect to the threat defense CLI on module 1:


```
firepower# connect module 1 console
Telnet escape character is '~'.
Trying 127.5.1.1...
Connected to 127.5.1.1.
Escape character is '~'.

CISCO Serial Over LAN:
Close Network Connection to Exit

Firepower-module1> connect ftd
>
```

Related Commands

Command	Description
connect asa	Connects to the ASA CLI.
connect module	Connects to the module CLI.
connect vdp	Connects to the vDP CLI.

connect fxos

To connect to the FXOS command shell, use the **connect fxos** command.

connect fxos [**a**]

Syntax Description

a

(Optional) Connects to fabric a.

Note The fabric ID is always **a**. If you omit the fabric ID, you are connected to fabric A.

Command Modes

Any command mode

Command History

Release

Modification

1.1(1)

Command added.

Usage Guidelines

Type **?** to list available FXOS shell commands; enter *command* **?** to view information about an individual command.



Note When you connect to the FXOS command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to the default prompt with (*fxos*) appended; see the following example.

To exit the FXOS shell, type **exit**.

Example

The following example shows how to connect to the FXOS command shell, and view available commands:

```
firepower# connect fxos
firepower(fxos)# ?
  clear          Reset functions
  cli            CLI commands
  debug         Debugging functions
  debug-filter  Enable filtering for debugging functions
  ethanalyzer   Configure cisco packet analyzer
  no            Negate a command or set its defaults
  ntp           NTP configuration
  show         Show running system information
  system      System management commands
  terminal    Set terminal line parameters
  test       Test command
  undebg    Disable Debugging functions (See also debug)
  end       Go to exec mode
  exit     Exit from command interpreter
  pop     Pop mode from stack or restore from name
  push   Push current mode to stack or save it under name
  where  Shows the cli context you are in
```

```
firepower (fxos)# exit  
firepower#
```

Related Commands	Command	Description
	connect local-mgmt	Connects to a remote debug shell while connected to a specific adapter.
	exit	Returns you to the previous CLI mode.

connect local-mgmt

To connect to the local-management command shell, use the **connect local-mgmt** command.

connect local-mgmt [a]

Syntax Description

a

(Optional) Connects to fabric a.

Note The fabric ID is always **a**. If you omit the fabric ID, you are connected to fabric A.

Command Modes

Any command mode

Command History

Release

Modification

1.1(1)

Command added.

Usage Guidelines

Type **?** to list available local-management shell commands; enter *command* **?** to view information about an individual command.

Refer to [connect local-mgmt: Command List, on page 712](#) for additional information.



Note When you connect to the local-management command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to the default prompt with (local-mgmt) appended; see the following example.

To exit the local-management mode, type **exit**.

Example

The following example shows how to connect to the local-management command shell, and view available commands:

```
firepower# connect local-mgmt
firepower(local-mgmt)# ?
  cd                Change current directory
  clear             Clear managed objects
  cluster           Cluster mode
  connect           Connect to Another CLI
  copy              Copy a file
  cp                Copy a file
  delete            Delete managed objects
  dir               Show content of dir
  enable            Enable
  end               Go to exec mode
  erase             Erase
  erase-log-config  Erase the mgmt logging config file
  exit              Exit from command interpreter
  fips              FIPS compliance
  ls                Show content of dir
```

```

mgmt-port      Management Port
mkdir          Create a directory
move          Move a file
mv            Move a file
ping          Test network reachability
ping6        Test IPv6 network reachability
pwd           Print current directory
reboot       Reboots Fabric Interconnect
restore-check Check if in restore mode
rm           Remove a file
rmdir        Remove a directory
run-script   Run a script
show         Show system information
shutdown     Shutdown
ssh          SSH to another system
tail-mgmt-log tail mgmt log file
telnet       Telnet to another system
terminal     Terminal
top          Go to the top mode
traceroute   Traceroute to destination
traceroute6  Traceroute to IPv6 destination
verify       Verify Application Image

```

```

firepower(local-mgmt)# exit
firepower#

```

Related Commands

Command	Description
connect fxos	Connects to the FXOS command shell.
exit	Returns you to the previous CLI mode.

connect module

To connect to a module command shell, use the **connect module** command.

connect module *module_id* { **console** | **telnet** }

Syntax Description	console	Connects to the serial console. The benefit of a console connection is that it is persistent.
	<i>module_id</i>	On 9300 devices the module number can be 1, 2, or 3; on 4100 devices it is 1.
Syntax Description	telnet	Connects using a Telnet connection. The benefits of using a Telnet connection is that you can have multiple sessions to the module at the same time, and the connection speed is faster.
Command Modes	Any command mode	
Command History	Release	Modification
	2.4(1)	Telnet support added.
	1.1(1)	Command added.

Usage Guidelines From the module CLI, you can connect to the application CLI using the **connect application** command. Type **help** to list available module shell commands; enter **help command** to view information about an individual command. You also can use **?** in place of **help** to view help information.



Note When you connect to a module command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to `Firepower-modulen`, where *n* is the number of the module to which you connected; see the following example.

Refer to [connect module: Command List, on page 718](#) for additional information.

Examples

The following example shows how to connect to the module 1 console, and view available commands:

```
firepower# connect module 1 console
Telnet escape character is '~'.
Trying 127.5.1.1...
Connected to 127.5.1.1.
Escape character is '~'.

CISCO Serial Over LAN:
Close Network Connection to Exit

Firepower-module1>?
  secure-login      => Enable blade secure login
```

```

show          => Display system information. Enter show ? for options
config        => Configure the system. Enter config ? for options
terminalLength => Terminal settings. Enter terminal ? for options
ping          => Ping a host to check reachability
nslookup      => Look up an IP address or host name with the DNS servers
traceroute    => Trace the route to a remote host
connect       => Connect to specific csp console (asa, etc)
support       => System file operations
help         => Get help on command syntax

```

```

Firepower-module1> ~
telnet> close
Connection closed.
firepower#

```

The following example shows how to connect to the module 1 using Telnet, and view available commands:

```

firepower# connect module 1 telnet
Type exit or Ctrl-] followed by . to quit.
Firepower-module1>?
secure-login   => Enable blade secure login
show           => Display system information. Enter show ? for options
config         => Configure the system. Enter config ? for options
terminalLength => Terminal settings. Enter terminal ? for options
ping           => Ping a host to check reachability
nslookup       => Look up an IP address or host name with the DNS servers
traceroute     => Trace the route to a remote host
connect        => Connect to specific csp console (asa, etc)
support        => System file operations
exit           => Exit the session
help           => Get help on command syntax
Firepower-module1> <Ctrl-], .>
firepower#

```

Related Commands

Command	Description
connect asa	Connects to the ASA CLI.
connect ftd	Connects to the threat defense CLI.
connect vdp	Connects to the vDP CLI.

connect vdp

To connect to the Radware DefensePro (vDP) CLI, use the **connect vdp** command.

connect vdp [*name*]

Syntax Description	<i>name</i>	(Optional) Specifies the vDP application instance name, which is the same as the main application logical device/application instance name.
---------------------------	-------------	---

Command Modes	connect module/
----------------------	-----------------

Command History	Release	Modification
	2.4(1)	Added the <i>name</i> argument.
	1.1(4)	Command added.

Usage Guidelines See the vDP documentation for commands available from the CLI.

To exit the vDP console, enter **Ctrl-], .**

Return to the supervisor level of the FXOS CLI:

Exit the console:

Enter ~, then **quit** to exit the Telnet application.

Example:

```
> Ctrl-], .
Firepower-module1> ~
telnet> quit
firepower#
```

Exit the Telnet session:

Enter **Ctrl-], .**

Example:

```
> Ctrl-], .
Firepower-module1> Ctrl-], .
firepower#
```

Example

This example shows how to connect to the vDP CLI on module 1:

```
firepower# connect module 1 console
Telnet escape character is '~'.
Trying 127.5.1.1...
Connected to 127.5.1.1.
```


Escape character is '~'.

CISCO Serial Over LAN:
Close Network Connection to Exit

Firepower-module1> connect vdp

Related Commands

Command	Description
connect asa	Connects to the ASA CLI.
connect ftd	Connects to the threat defense CLI.
connect module	Connects to the module CLI.

create app-instance

To define an application instance, use the **create app-instance** command.

```
create app-instance app_type app_name
```

Syntax Description	Parameter	Description
	<i>app_name</i>	The name of the application instance, between 1 and 64 characters. You will use this device name when you create the logical device for this instance.
	<i>app_type</i>	The application type, either asa , ftd , or vdp .

Command Modes scope ssa/scope slot/

Command History	Release	Modification
	2.4(1)	The <i>app_name</i> argument is now required.
	1.1(1)	Command added.

Usage Guidelines You can set many parameters for this application instance, including the the image version, deployment type, resource profile and mode. You can also enable, disable and restart the application.

Example

The following example shows how to set the image version for an threat defense application instance:

```
firepower# scope ssa
firepower /ssa # scope slot 1
firepower /ssa/slot # create app-instance ftd MyDevice1
firepower /ssa/slot/app-instance* # set deploy-type container
firepower /ssa/slot/app-instance* # set resource-profile-name silver 1
firepower /ssa/slot/app-instance* # set startup-version 6.3.0
firepower /ssa/slot/app-instance* #
```

Related Commands	Command	Description
	show app-attri	Shows current application attributes.

create bootstrap-key FIREWALL_MODE

To specify the firewall mode, routed or transparent, in the bootstrap configuration for the threat defense and ASA, use the **create bootstrap-key FIREWALL_MODE** command.

create bootstrap-key FIREWALL_MODE

Command Modes scope ssa/create logical-device/create mgmt-bootstrap/

Command Default The default mode is routed.

Command History	Release	Modification
	2.4(1)	Added support for the ASA.
	1.1(4)	Command added for FTD.

Usage Guidelines Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.

Example

The following example shows how to set the mode to routed mode:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key FIREWALL_MODE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value routed
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands	Command	Description
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.
	set value	Sets the value for this command.

create bootstrap-key MANAGEMENT_TYPE

To specify the manager, FMC, FDM, or CDO in the bootstrap configuration for the threat defense, use the **create bootstrap-key MANAGEMENT_TYPE** command.

create bootstrap-key MANAGEMENT_TYPE

Command Modes scope ssa/create logical-device/create mgmt-bootstrap/

Command Default The default manager is FMC.

Command History	Release	Modification
	2.7(1)	Command added for FTD.

Usage Guidelines Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.

Example

The following example shows how to set the manager to FDM:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key MANAGEMENT_TYPE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value LOCALLY_MANAGED
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

The following example shows how to set the manager to CDO:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key MANAGEMENT_TYPE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value CDO
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands	Command	Description
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.
	set value	Sets the value for this command.

create bootstrap-key PERMIT_EXPERT_MODE

To permit Expert Mode from FTD SSH sessions for the threat defense, use the **create bootstrap-key PERMIT_EXPERT_MODE** command.

create bootstrap-key PERMIT_EXPERT_MODE

Command Modes scope ssa/create logical-device/create mgmt-bootstrap/

Command Default The default is no.

Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines Expert Mode provides FTD shell access for advanced troubleshooting. By default for container instances, Expert Mode is only available to users who access the FTD CLI from the FXOS CLI. This limitation is only applied to container instances to increase isolation between instances. Use Expert Mode only if a documented procedure tells you it is required, or if the Cisco Technical Assistance Center asks you to use it. To enter this mode, use the expert command in the FTD CLI.

Example

The following example shows how to enable Expert Mode from SSH:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key PERMIT_EXPERT_MODE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value yes
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands	Command	Description
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.
	set value	Sets the value for this command.

create bootstrap-key MANAGEMENT_TYPE

create bootstrap-key-Secret CDO_ONBOARD

Command Modes scope ssa/create logical-device/create mgmt-bootstrap/

Command History	Release	Modification
	2.13(1)	Command added for FTD.

Usage Guidelines Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.

Example

The following example shows how to set the CDO onboard value for the FTD device:

```
Firepower /SSA-5 /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key-secret CDO_ONBOARD
Firepower /SSA-5 /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value
Firepower /SSA-5 /ssa/logical-device/mgmt-bootstrap/bootstrap-key* #
Enter a value:(the string "configure manager add cisco-sapphire.app.staging.cdo.cisco.com
TuNDBm6peReVDbU kOpZCgtJ1GqWKbD30 o9B064UXEwmr3AYAEpuflf4qE2E3JKY5 <display_name>" should
be
entered)
Confirm the value: (repeat the string)
Firepower /SSA-5 /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # commit-buffer
```

Related Commands	Command	Description
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.
	set value	Sets the value for this command.

create bootstrap-key-secret PASSWORD

To specify the admin password in the bootstrap configuration for the threat defense and ASA, use the **create bootstrap-key-secret PASSWORD** command.

create bootstrap-key-secret PASSWORD

Command Modes scope ssa/create logical-device/create mgmt-bootstrap/

Command Default When the admin password is not set.

Command History	Release	Modification
	1.1(4)	Command added for FTD.
	2.4(1)	Added support for the ASA.

Usage Guidelines The pre-configured ASA admin user and enable password is useful for password recovery; if you have FXOS access, you can reset the admin user password if you forget it.

Example

The following example shows how to set the mode to routed mode:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # create bootstrap-key-secret
PASSWORD
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value
Enter a value: floppylampshade
Confirm the value: floppylampshade
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key-secret* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands	Command	Description
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.
	set value	Sets the value for this command.

create bootstrap-key-secret REGISTRATION_KEY

To specify a registration key to be shared between the threat defense device and management center in the bootstrap configuration, use the **create bootstrap-key-secret REGISTRATION_KEY** command.

create bootstrap-key-secret REGISTRATION_KEY

Command Modes scope ssa/create logical-device/create mgmt-bootstrap/

Command Default The registered key is not generated.

Command History	Release	Modification
	1.1(4)	Command added for FTD.

Usage Guidelines You can choose any passphrase for this registration key between 1 and 37 characters; you will enter the same key on the FMC when you add the FTD. Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.

Example

The following example shows how to set the value for the registration key:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # create bootstrap-key-secret
REGISTRATION_KEY
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key-secret* # set value
Enter a value: gratuitousapples
Confirm the value: gratuitousapples
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key-secret* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands	Command	Description
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.
	set value	Sets the value for this command.

create bootstrap-key DNS_SERVERS

To specify a comma-separated list of DNS servers for the threat defense, use the **create bootstrap-key DNS_SERVERS** command.

create bootstrap-key DNS_SERVERS

Command Modes scope ssa/create logical-device/create mgmt-bootstrap/

Command Default The default is no.

Command History

Release	Modification
2.4(1)	Command added.

Usage Guidelines The FTD uses DNS if you specify a hostname for the FMC.

Example

The following example shows how to specify a hostname:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
Firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key DNS_SERVERS
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value 10.9.8.7,10.9.6.5
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands

Command	Description
create logical-device	Creates the logical device.
create mgmt-bootstrap	Creates the bootstrap configuration for the application.
set value	Sets the value for this command.

create bootstrap-key FIREPOWER_MANAGER_IP

To specify the IP address or hostname or NAT ID of the managing Firepower Management Center, use the **create bootstrap-key FIREPOWER_MANAGER_IP** command.

create bootstrap-key FIREPOWER_MANAGER_IP

Command Modes scope ssa/create logical-device/create mgmt-bootstrap/

Command Default The default is no.

Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines Normally, you need both IP addresses (along with a registration key) for both routing purposes and for authentication: the FMC specifies the device IP address, and the device specifies the FMC IP address. However, if you only know one of the IP addresses, which is the minimum requirement for routing purposes, then you must also specify a unique NAT ID on both sides of the connection to establish trust for the initial communication and to look up the correct registration key. You can specify any text string as the NAT ID, from 1 to 37 characters. The FMC and device use the registration key and NAT ID (instead of IP addresses) to authenticate and authorize for initial registration.

Example

The following example shows how to enable Expert Mode from SSH:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
Firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key FIREPOWER_MANAGER_IP
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value 10.10.10.7
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands	Command	Description
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.
	set value	Sets the value for this command.

create bootstrap-key SEARCH_DOMAINS

To specify a comma-separated list of search domains, use the **create bootstrap-key SEARCH_DOMAINS** command.

create bootstrap-key SEARCH_DOMAINS

Command Modes scope ssa/create logical-device/create mgmt-bootstrap/

Command Default The default is no.

Command History	Release	Modification
	2.4(1)	Command added.

Example

The following example shows how to enable Expert Mode from SSH:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
Firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key SEARCH_DOMAINS
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value cisco.com,example.com
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands	Command	Description
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.
	set value	Sets the value for this command.

create breakout

To create a breakout port, use the **create breakout** command. If a breakout with the specified slot and port IDs already exists, the command will fail.

To add or enter a breakout port, utilize the **enter breakout** command. If the specified breakout does not exist, it is created and entered; if the breakout port exists, it is entered.

You also can use the **scope** form of this command to enter an existing breakout port to view properties.

To delete an existing breakout port, use the **delete** form of this command.

create breakout *slot_ID* *port_ID*

Syntax Description	<i>slot_ID</i>	Use its slot number to identify the port module to be broken out.
	<i>port_ID</i>	Assign an ID number to this breakout port.
Command Modes	scope cabling/scope fabric a/	
Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines In conjunction with the use of a breakout cable, you can use this command to “break out” a 40-Gigabit Ethernet port, creating up to four unconfigured 10-Gigabit ports.

Hardware bypass-capable interfaces cannot be configured as breakout ports.



Note Because configuring breakout on a port causes a system reboot, we recommend you break out all required ports before committing the changes.

Example

The following example shows how to create four breakout ports on slot 2:

```
firepower# scope cabling
firepower /cabling/fabric/ # scope fabric
firepower /cabling/fabric/ # create breakout 2 1
Warning: This action will reboot the system and any existing configurations on 40G port
will be erased.!
firepower /cabling/fabric/breakout* # up
firepower /cabling/fabric/ # create breakout 2 2
Warning: This action will reboot the system and any existing configurations on 40G port
will be erased.!
firepower /cabling/fabric/breakout* # up
firepower /cabling/fabric/ # create breakout 2 3
Warning: This action will reboot the system and any existing configurations on 40G port
will be erased.!
firepower /cabling/fabric/breakout* # up
firepower /cabling/fabric/ # create breakout 2 4
```

```
Warning: This action will reboot the system and any existing configurations on 40G port
will be erased.!
firepower /cabling/fabric/breakout* # commit-buffer
firepower /cabling/fabric/breakout #
```

Related Commands

Command	Description
delete breakout	Deletes an existing breakout port.
enter aggr-interface	Enters an aggregate interface where you can set parameters.

create certreq

To add a new keyring certificate request, use the **create certreq** command. If a request already exists for the current keyring, the command will fail.

To edit an existing certificate request, use the **enter certreq** command.

You also can use the **scope** form of this command to enter an existing certificate request to assign or change properties.

To delete an existing certificate request, use the **delete** form of this command.

create certreq [**ip** | **subject-name**]

delete certreq

enter certreq

scope certreq

Syntax Description		
ip <i>ip_address</i>	(Optional) Enter the ip keyword and the IPv4 address of the domain on which this device resides. You will be asked to enter and confirm a password for the request. This parameter applies only to the create certreq form of the command.	
subject-name <i>name</i>	(Optional) Enter the subject-name keyword and an identifier for this request; for example, the appliance host name. You will be asked to enter and confirm a password for the request. This parameter applies only to the create certreq form of the command.	

Command Modes scope security/scope keyring/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines When you create a new keyring certificate request, you are automatically entered into certificate request mode (security/keyring/certreq) with an asterisk indicating the new certificate request is not yet defined and committed. You also can scope into certificate request mode for an existing keyring.

Use the **set** command in certificate request mode to specify certificate request parameters.



Note Before you create or commit a new certificate request, you must set the RSA key modulus (SSL key length) using [set modulus](#), on page 314.

Example

This example shows how to create a new keyring and its certificate request:

```

firepower # scope security
firepower /security # create keyring test-ring2
firepower /security/keyring* # create certreq ip 209.165.201.20
Certificate request password:
Confirm certificate request password:
firepower /security/keyring* # scope certreq
firepower /security/keyring/certreq* #
firepower /security/keyring/certreq* # set ?
  country      Country name (2 letter code)
  dns          DNS name (subject alternative name)
  e-mail      E-mail name
  fi-a-ip     Certificate request FI A ip address
  fi-a-ipv6   Certificate request FI A ipv6 address
  fi-b-ip     Certificate request FI B ip address
  fi-b-ipv6   Certificate request FI B ipv6 address
  ip         Certificate request ip address
  ipv6       Certificate request ipv6 address
  locality    Locality name (eg, city)
  org-name    Organisation name (eg, company)
  org-unit-name Organisational Unit Name (eg, section)
  password    Certificate request password
  state      State, province or county (full name)
  subject-name Certificate request subject name

firepower /security/keyring/certreq* # set

```

Related Commands

Command	Description
delete certreq	Deletes an existing keyring certificate request.
set (certreq)	Sets keyring certificate request-related information.

create class

To add a new class of statistics to a statistics threshold policy, use the **create class** command. If a class with the specified name already exists, the command will fail.

To add or edit an statistics class, use the **enter class** command. If the specified class does not exist, it is created and entered; if the class exists, it is entered.

You also can use the **scope** form of this command to enter an existing class to assign or change properties. Generally, “scoping into” an object is more convenient than entering it, since the object’s name is usually all that is needed, whereas the **enter** form of the command often requires entering all its definition parameters.

To delete an existing class of statistics, use the **delete** form of this command.

create class *type*

delete class *type*

enter class *type*

scope class *type*

Syntax Description

type

Specify the desired statistics class.

Available classes depend on the statistics threshold policy in your current mode. For example, in `eth-server/` mode, available classes include `chassis-stats` and `ether-error-stats`. In `eth-uplink/` mode, available classes include `ether-rx-stats` and `ether-rx-stats`. In `org/` mode, available classes include `cpu-env-stats` and `ethernet-port-err-stats`.

Use the **create class ?** command to view a list of classes available for the current statistics threshold policy.

Command Modes

`scope eth-server/scope stats-threshold-policy/`

`scope eth-uplink/scope stats-threshold-policy/`

`scope org/scope stats-threshold-policy/`

Command History

Release

Modification

1.1(1)

Command added.

Usage Guidelines

Use classes to place thresholds on specific sets of statistics. For example, you might want to define a threshold on a port that raises a fault if the average number of packets dropped exceeds a certain amount. For this class, you would create threshold properties for Ethernet error statistics.

You can configure multiple classes for a statistics threshold policy.

Use the **set collection-interval** command to define how frequently statistics are collected, and use the **set reporting-interval** command to define how frequently the statistics are reported. These intervals define a statistics collection policy.



Note There is one default statistics threshold policy each for Ethernet server ports or Ethernet uplink ports. You cannot create additional statistics collection policies and you cannot delete the existing default policies for these components—you can only modify the default policies. However, you can create and delete statistics threshold policies in organization mode (`scope org/`).

Examples

This example shows how to scope into the Ethernet server statistics threshold policy class, create a chassis statistics class, create an input power (Watts) property, specify that the normal power is 8 kW, create an above normal warning threshold of 11 kW, and then commit the class:

```
firepower # scope eth-server
firepower /eth-server # scope stats-threshold-policy default
firepower /eth-server/stats-threshold-policy # create class chassis-stats
firepower /eth-server/stats-threshold-policy/class* # create property input-power
firepower /eth-server/stats-threshold-policy/class/property* # set normal-value 8000.0
firepower /eth-server/stats-threshold-policy/class/property* # create threshold-value
above-normal warning
firepower /eth-server/stats-threshold-policy/class/property/threshold-value* # set escalating
11000.0
firepower /eth-server/stats-threshold-policy/class/property/threshold-value* # commit-buffer
firepower /eth-server/stats-threshold-policy/class/property/threshold-value #
```

This example shows how to scope into organization mode, create a new statistics threshold policy for server and server component statistics, create a threshold policy class for CPU environment statistics, create a CPU temperature property, specify that the normal CPU temperature is 48.5° C, create an above normal warning threshold of 50° C, and commit the entire transaction:

```
firepower # scope org
firepower /org # create stats-threshold-policy ServStatsPolicy
firepower /org/stats-threshold-policy* # create class cpu-env-stat
firepower /org/stats-threshold-policy/class* # create property temperature
firepower /org/stats-threshold-policy/class/property* # set normal-value 48.5
firepower /org/stats-threshold-policy/class/property* # create threshold-value above-normal
warning
firepower /org/stats-threshold-policy/class/property/threshold-value* # set escalating 50.0
firepower /org/stats-threshold-policy/class/property/threshold-value* # commit-buffer
firepower /org/stats-threshold-policy/class/property/threshold-value #
```

Related Commands

Command	Description
delete class	Deletes an existing class of statistics.
enter class	Enters a statistics class. If the class does not exist, it is created.
enter property	Enters or creates a property for a class of statistics.
scope stats-threshold-policy	Enters stats-threshold-policy mode, where you manage specific statistics classes.

create connection

To add a new IPSec connection, use the **create connection** command. If a connection with the specified name already exists, the command will fail.

To add or edit an IPSec connection, use the **enter connection** command. If the specified connection does not exist, it is created and entered; if the connection exists, it is entered.

You also can use the **scope** form of this command to enter an existing connection to assign or change properties. Generally, “scoping into” an object is more convenient than entering it, since the object’s name is usually all that is needed, whereas the **enter** form of the command often requires entering all its definition parameters.

To delete an existing connection, use the **delete** form of this command.

create connection *name*

enter connection *name*

delete connection *name*

scope connection *name*

Syntax Description	<i>name</i>	The connection name; can be up to 16 alphanumeric characters.
---------------------------	-------------	---

Command Modes	scope security/scope ipsec/	
----------------------	-----------------------------	--

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines When you create a new IPSec connection, you are automatically entered into security/ipsec/connection mode with an asterisk indicating the new connection is not yet committed. You can configure the connection before committing it.

After you create a connection, the name cannot be changed. You must delete the connection and create a new one.

Example

This example shows how to create and enter a new IPSec connection:

```
firepower # scope security
firepower /security # scope ipsec
firepower /security/ipsec # enter connection ipsec_conn2
firepower /security/ipsec/connection* #
```

Related Commands	Command	Description
	set adminstate	Sets the IPSec connection administrative state to disabled or enabled.
	show connection	Shows current IPSec connection information.

create destination

To add a new Smart Call Home destination, use the **create destination** command. If a destination with the specified name already exists, the command will fail.

To add or edit a Smart Call Home destination, use the **enter destination** command. If the specified destination does not exist, it is created and entered; if the destination exists, it is entered.

You also can use the **scope** form of this command to enter an existing destination to assign or change properties. Generally, “scoping into” an object is more convenient than entering it, since the object’s name is usually all that is needed, whereas the **enter** form of the command often requires entering all its definition parameters.

To delete an existing destination, use the **delete** form of this command.

create destination *name*

delete destination *name*

enter destination *name*

scope destination *name*

Syntax Description	<i>name</i>	The name identifying the Smart Call Home destination.
Command Modes	scope monitoring/scope callhome/scope profile/	
Command History	Release	Modification
	1.4(1)	Command added.

Usage Guidelines When you create a new Smart Call Home destination, you are automatically entered into callhome/profile mode (monitoring/callhome/profile) with an asterisk indicating the new destination is not yet committed. You can set the destination parameters—transport protocol and an email address—and then commit the new destination information.



Note An email address is the only allowed destination address in a callhome profile.

After you create a Smart Call Home destination, the destination name cannot be changed. You must delete the destination and create a new one.

Example

This example shows how to create, enter and configure a Smart Call Home destination:

```
firepower # scope monitoring
firepower /monitoring # scope callhome
firepower /monitoring/callhome # scope profile SLProfile
firepower /monitoring/callhome/profile # enter destination TestDest
firepower /monitoring/callhome/profile/destination* # set address user1@test.com
firepower /monitoring/callhome/profile/destination* # set protocol email
firepower /monitoring/callhome/profile/destination* # commit-buffer
firepower /monitoring/callhome/profile/destination #
```

Related Commands	Command	Description
	delete destination	Deletes an existing Smart Call Home destination.
	enter destination	Enters a Smart Call Home destination.
	set address	Sets an email address for a Smart Call Home destination.
	set protocol	Sets the transport protocol for a Smart Call Home destination.

create dns

To create DNS name server in FXOS, use the **create dns** command.

create dns

Syntax Description	create dns	This command is used to create a DNS name server in FXOS.
Command Modes	scope system/scope services	
Command History	Release Modification 1.1(1) Command added.	
Usage Guidelines	By default, this command creates the DNS name server in FXOS.	

Example

This example shows how to create a DNS name server:

```
firepower# scope system; scope services  
firepower /system /services # create dns 192.0.2.1  
firepower /system /services* # commit
```

create hw-crypto

To create a TLS crypto acceleration configuration on a container instance, use the **create hw-crypto** command. For more information about TLS crypto acceleration, see the *Management Center Configuration Guide*.

create hw-crypto

Command Modes

connect module

Command History

Release	Modification
2.7.1	This command was introduced.

Usage Guidelines

This command deletes a TLS crypto acceleration configuration for a container instance. If TLS crypto acceleration is enabled on the container instance, the command disables it before deleting the configuration.

Examples

Following is an example of creating a TLS crypto acceleration configuration:

```
scope ssa
/ssa # show app-instance
```

App Name	Identifier	Slot ID	Admin State	Oper State	Running Version	Startup Version
Deploy Type	Turbo Mode	Profile Name	Cluster	State	Cluster	Role
ftd	FTD-FDM	1	Enabled	Online	6.5.0.1159	6.5.0.1159
	Native	No		Not Applicable	None	
ftd	ftd2	2	Enabled	Online	6.5.0.1159	6.5.0.1159
	Container	No	Default-Small	Not Applicable	None	

```
/ssa # sc slot 2
/ssa/slot # scope app-instance ftd ftd2
/ssa/slot/app-instance # create hw-crypto
/ssa/slot/app-instance* # commit-buffer
```

Related Commands

Command	Description
delete hw-crypto	Delete a TLS crypto acceleration configuration for a container instance.
scope hw-crypto	Enable or disable TLS crypto acceleration configuration on a container instance.
show hw-crypto	Display the status of TLS crypto acceleration configuration on a container instance.

create ip-block

To add a new block of IPv4 addresses for service access, use the **create ip-block** command. If an address block with the specified properties already exists, the command will fail.

To add or edit a block of IPv4 addresses, use the **enter ip-block** command. If the specified address block does not exist, it is created and entered; if the address block exists, it is entered.

You also can use the **scope** form of this command to enter an existing address block to assign or change properties.

To delete an existing address block, use the **delete** form of this command.

```
create ip-block ip_address prefix_length { https | snmp | ssh }
delete ip-block ip_address prefix_length { https | snmp | ssh }
enter ip-block ip_address prefix_length { https | snmp | ssh }
scope ip-block ip_address prefix_length { https | snmp | ssh }
```

Syntax Description

<i>ip_address</i>	The starting address for the IPv4 address block.
<i>prefix_length</i>	The prefix length; determines the number of addresses in the block. Value can be 0 to 32.
https snmp ssh	The service (HTTPS, SNMP, or SSH) to which the address block is assigned.

Command Modes

scope system/scope services/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use this command to assign a block of IPv4 addresses to provide access to a specified service (HTTPS, SNMP, or SSH).

When you create a new IP block, you are automatically entered into ip-block mode (system/services/ip-block) with an asterisk indicating the new block assignment is not yet committed.

On FXOS versions 2.3.1 and earlier, up to 25 different blocks can be configured for each service. On FXOS versions 2.4.1 and later, up to 100 different blocks can be configured for each service. An address of 0.0.0.0 and a prefix of 0 allows unrestricted access to a service. Each block of addresses is identified by its starting IPv4 address.

Example

This example shows how to create, enter and verify an IPv4 address block to provide SSH access:

```
firepower # scope system
firepower /system # scope services
firepower /system/services # enter ip-block 192.168.200.101 32 ssh
firepower /system/services/ip-block* # commit-buffer
firepower /system/services/ip-block # up
firepower /system/services # show ip-block
```

```

Permitted IP Block:
  IP Address      Prefix Length Protocol
-----
  0.0.0.0         0 https
  0.0.0.0         0 snmp
  0.0.0.0         0 ssh
  192.168.200.101 32 ssh
firepower /system/services #

```

Related Commands

Command	Description
create ipv6-block	Creates an IPv6 address block.
delete ip-block	Deletes an existing IPv4 block.

create ipv6-block

To add a new block of IPv6 addresses for service access, use the **create ipv6-block** command. If an address block with the specified properties already exists, the command will fail.

To add or edit a block of IPv6 addresses, use the **enter ipv6-block** command. If the specified address block does not exist, it is created and entered; if the address block exists, it is entered.

You also can use the **scope** form of this command to enter an existing address block to assign or change properties.

To delete an existing address block, use the **delete** form of this command.

```
create ipv6-block ipv6_address prefix_length {https | snmp | ssh}
delete ipv6-block ipv6_address prefix_length {https | snmp | ssh}
enter ipv6-block ipv6_address prefix_length {https | snmp | ssh}
scope ipv6-block ipv6_address prefix_length {https | snmp | ssh}
```

Syntax Description		
<i>ipv6_address</i>		The starting address for the IPv6 address block.
<i>prefix_length</i>		The prefix length; determines the number of addresses in the block. Value can be 0 to 128.
https snmp ssh		The service (HTTPS, SNMP, or SSH) to which the address block is assigned.

Command Modes scope system/scope services/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to assign a block of IPv6 addresses to provide access to a specified service (HTTPS, SNMP, or SSH).

When you create a new IPv6 block, you are automatically entered into ipv6-block mode (system/services/ipv6-block) with an asterisk indicating the new block assignment is not yet committed.

On FXOS versions 2.3.1 and earlier, up to 25 different blocks can be configured for each service. On FXOS versions 2.4.1 and later, up to 100 different blocks can be configured for each service. An address of 0:0:0:0:0:0:0 and a prefix of 0 allows unrestricted access to a service. Each block of addresses is identified by its starting IPv6 address.

Example

This example shows how to create, enter and verify an IPv6 address block to provide SSH access:

```
firepower # scope system
firepower /system # scope services
firepower /system/services # create ipv6-block 2001:DB8:1::1 64 ssh
firepower /system/services/ipv6-block* # commit-buffer
firepower /system/services/ipv6-block # up
firepower /system/services # show ipv6-block
```

```

Permitted IPv6 Block:
  IPv6 Address Prefix Length Protocol
  -----
  ::                          0 https
  ::                          0 snmp
  ::                          0 ssh
  2001:DB8:1::1              64 ssh
firepower /system/services #

```

Related Commands

Command	Description
create ip-block	Creates an IPv4 block.
delete ipv6-block	Deletes an existing IPv6 block.

create keyring

To add a new RSA keyring, use the **create keyring** command. If a keyring with the specified name already exists, the command will fail.

To edit an existing keyring, use the **enter keyring** command.

You also can use the **scope** form of this command to enter an existing keyring to assign or change properties.

To delete an existing keyring, use the **delete** form of this command.

create keyring *name*

delete keyring *name*

enter keyring *name*

scope keyring *name*

Syntax Description	<i>name</i>	The name identifying the keyring; can be between 1 and 16 characters.
Command Modes	scope security/	
Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines When you create a new keyring, you are automatically entered into keyring mode (security/keyring) with an asterisk indicating the new keyring is not yet committed. You can create a keyring certificate request, and set keyring parameters such as RSA key modulus and certificate authority trustpoint, and then commit the new keyring information.

Example

This example shows how to create and enter a new RSA keyring:

```
firepower # scope security
firepower /security # enter keyring test_keyring
firepower /security/keyring* # set ?
  cert      Keyring certificate
  modulus   RSA key modulus
  regenerate Regenerate keyring
  trustpoint Trustpoint CA

firepower /security/keyring* # set
```

Related Commands	Command	Description
	delete keyring	Deletes an existing RSA keyring.

create local-user

To add a new local user account, use the **create local-user** command. If a local user account with the specified name already exists, the command will fail.

To add or edit a local user account, use the **enter local-user** command. If the specified account does not exist, it is created and entered; if the account exists, it is entered.

You also can use the **scope** form of this command to enter an existing local user account to assign or change properties.

To delete an existing local user account, use the **delete** form of this command.

create local-user *user_name*

delete local-user *user_name*

enter local-user *user_name*

scope local-user *user_name*

Syntax Description

user_name

The ID to be used when logging into this local user account. Note the following guidelines and restrictions when entering a user name:

- The name can contain between 1 and 32 characters, including the following:
 - Any alphabetic character
 - Any numeral
 - _ (underscore)
 - - (dash)
 - . (dot)
- The name must be unique.
- The name must start with an alphabetic character. It cannot start with a number or a special character, such as an underscore.
- The name is case-sensitive.
- You cannot create an all-number name.

After you create a user account, you cannot change its name. You must delete the user account and create a new one.

Command Modes

scope security/

Command History

Release

Modification

1.1(1)

Command added.

Usage Guidelines

You can configure up to 48 local user accounts. Each account must have a unique user name and password.

When you create a new user account, you are automatically entered into local user mode (/security/local-user) with an asterisk indicating the new account is not yet committed. You can specify additional user account information such as password, first and last names, and so on, and then commit the new account information.

After you create the user account, the account name cannot be changed. You must delete the user account and create a new one.

Example

This example shows how to enter security mode, enter a local user account (simultaneously creating the new account since it does not exist), and then assigning first and last names to the account:

```
firepower # scope security
firepower /security # enter local-user test_user
firepower /security/local-user* # set firstname test
firepower /security/local-user* # set lastname user
firepower /security/local-user* # commit-buffer
firepower /security/local-user #
```

Related Commands

Command	Description
delete local-user	Deletes an existing local user account.
set expiration	Specifies the date on which the user account expires.
set password	Sets a password for the user account.

create member-port

To create a port-channel member port, use the **create member-port** command. If a member port with the specified ID already exists, the command will fail.

To add or enter a member port, utilize the **enter member-port** command. If the specified member port does not exist, it is created and entered; if the member port exists, it is entered.

You also can use the **scope** form of this command to enter an existing member port to assign or change properties..

To delete an existing member port, use the **delete** form of this command.

create member-port *interface_id*

Syntax Description	<i>interface_id</i>	Identify the interface to be added to this port-channel using one of the following formats: <ul style="list-style-type: none"> • <i>slot_id port_id</i> – The port location in the chassis in terms of slot number and port number. • Ethernet<i>slot_id/port_id</i> – The Ethernet port label.
---------------------------	---------------------	--

Command Modes	scope eth-uplink/scope fabric a/port-channel
----------------------	--

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines You must create or enter a port-channel before you can use this command.

When you create a new member port, you are automatically entered into member-port mode (eth-uplink/fabric/port-channel/member-port) with an asterisk indicating the new member port is not yet committed.

Example

The following example shows how to create a new port-channel, enable it and add member ports:

```
firepower # scope eth-uplink
firepower /eth-uplink/fabric # scope fabric a
firepower /eth-uplink/fabric # create port-channel 4
firepower /eth-uplink/fabric/port-channel* # enable
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # commit-buffer
firepower /eth-uplink/fabric/port-channel #
```

Related Commands	Command	Description
	create port-channel	Creates a new EtherChannel (port-channel).

create ntp-server

To create NTP server in FXOS, use the **create ntp-server** command.

create ntp-server

Syntax Description	create ntp-server	This command is used to create an NTP server in FXOS.
Command Modes	scope system/scope services/	
Command History	Release Modification 1.1(1) Command added.	
Usage Guidelines	By default, this command creates the NTP server in FXOS.	

Example

The following example shows how to create the NTP server:

```
firepower# scope system;scope services

firepower /system/services # create ntp-server 192.0.2.1
firepower /system/services # commit

firepower /system/services/ntp-server # set
ntp-sha1-key-id      NTP SHA-1 key id <===== [Optional] Configure NTP authentication
key ID
ntp-sha1-key-string NTP SHA-1 key string <===== [Optional] Configure NTP
authentication key string

firepower /system/services/ntp-server # commit
```

Related Commands	Command	Description
	show ntp-server	This command displays the NTP server.

create policy (callhome)

To add a new Smart Call Home and Smart Licensing policy, use the **create policy** command. If a policy with the specified name already exists, the command will fail.

To add or edit an IPSec connection, use the **enter policy** command. If the specified policy does not exist, it is created and entered; if the policy exists, it is entered.

You also can use the **scope** form of this command to enter an existing policy to assign or change properties.

To delete an existing policy, use the **delete** form of this command.

create policy *event*

delete policy *event*

enter policy *event*

scope policy *event*

Syntax Description	<i>event</i>	The fault or system event type. See Usage Guidelines below for event options.
---------------------------	--------------	---

Command Modes	scope monitoring/scope callhome/
----------------------	----------------------------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines When you create a new Smart Call Home policy, you are automatically entered into callhome/policy mode (monitoring/callhome/policy) with an asterisk indicating the new policy is not yet committed. You can set property values and enable/disable services, and then commit the new policy.

After you create a Smart Call Home policy, the policy name cannot be changed. You must delete the policy and create a new one.

Use this command to create an instance of a policy for an existing type of fault or system event. The available keywords for Call Home policy event types are:

- adaptor-mismatch
- arp-targets-config-error
- association-failed
- configuration-failure
- connectivity-problem
- election-failure
- equipment-degraded
- equipment-disabled
- equipment-inaccessible
- equipment-inoperable

- equipment-offline
- equipment-problem
- equipment-removed
- fru-problem
- health-led-amber
- health-led-amber-blinking
- identity-unestablishable
- inventory-failed
- license-graceperiod-expired
- limit-reached
- link-down
- management-services-failure
- management-services-unresponsive
- memory-error
- mgmtif-down
- ndisc-targets-config-error
- near-max-limit
- port-failed
- power-problem
- psu-insufficient
- psu-mixed-mode
- thermal-problem
- version-incompatible
- vif-ids-mismatch
- voltage-problem

Example

This example shows how to create, enter and enable a Call Home policy instance for link-down events:

```
firepower # scope monitoring
firepower /monitoring # scope callhome
firepower /monitoring/callhome # enter policy link-down
firepower /monitoring/callhome/policy* # set admin-state enabled
firepower /monitoring/callhome/policy* # commit-buffer
```

```
firepower /monitoring/callhome/policy #
```

Related Commands

Command	Description
delete policy	Deletes an existing Smart Call Home policy.
set admin-state	Enables or disables the administrative state for a Smart Call Home policy.

create policy (flow control)

To add a new named flow-control policy, use the **create policy** command. If a policy with the specified name already exists, the command will fail.

To add or edit a named flow-control policy, use the **enter policy** command. If the specified policy does not exist, it is created and entered; if the policy exists, it is entered.

You also can use the **scope** form of this command to enter an existing policy to assign or change properties.

To delete an existing policy, use the **delete** form of this command.

create policy *name*

delete policy *name*

enter policy *name*

scope policy *name*

Syntax Description	<i>name</i>	A name to identify the flow-control policy. The name can be from 1 to 16 characters.
Command Modes	scope eth-uplink/scope flow-control/	
Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines

Flow-control policies determine whether the uplink Ethernet ports in an appliance domain send and receive IEEE 802.3x pause frames when the receive buffer for a port reaches full capacity. These pause frames request that the transmitting port stop sending data for a few milliseconds until the buffer clears. For flow control to work between devices, you must enable the corresponding send and receive flow-control parameters for both devices.

The `default` flow-control policy disables send and receive control, and sets the priority to auto-negotiate.

When you create a new flow-control policy, you are automatically entered into `flow-control/policy` mode (`eth-uplink/flow-control/policy`) with an asterisk indicating the new policy is not yet committed. You can set policy property values and then commit the new policy.

After you create a flow-control policy, the policy name cannot be changed. You must delete the policy and create a new one.

Example

This example shows how to create and enter a named policy for flow control:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope flow-control
firepower /eth-uplink/flow-control # enter policy FCpolicy1
firepower /eth-uplink/flow-control/policy* # commit-buffer
firepower /eth-uplink/flow-control/policy #
```

Related Commands	Command	Description
	delete policy	Deletes an existing flow-control policy.
	set	In flow-control/policy mode, sets flow-control policy properties.
	show policy	Shows property values for a flow-control policy.

create port-channel

To create an EtherChannel (also known as a port-channel), use the **create port-channel** command. If a port-channel with the specified ID already exists, the command will fail.

To add or enter a port-channel, utilize the **enter port-channel** command. If the specified port-channel does not exist, it is created and entered; if the port-channel exists, it is entered.

You also can use the **scope** form of this command to enter an existing port-channel to assign or change properties..

To delete an existing port-channel, use the **delete** form of this command.

create port-channel*id*

Syntax Description

id Assign an ID number to this port-channel.

Command Modes

scope eth-uplink/scope fabric a/

Command History

Release	Modification
1.1.1	Command added.

Usage Guidelines

When you create a new port-channel, you are automatically entered into port-channel mode (eth-uplink/fabric/port-channel) with an asterisk indicating the new port-channel is not yet committed. You can set the port-channel parameters and then commit the new port-channel.

After creating a new port-channel, enable it and add member ports.

When the Firepower 4100/9300 chassis creates an EtherChannel, the EtherChannel stays in a **Suspended** state until you assign it to a logical device, even if the physical link is up. The EtherChannel will be brought out of this **Suspended** state in the following situations:

- The EtherChannel is added as a data or management port for a standalone logical device.
- The EtherChannel is added as a management or CCL port for a logical device that is part of a cluster.
- The EtherChannel is added as a data port for a logical device that is part of a cluster and at least one security module has joined the cluster.

Note that the EtherChannel does not come up until you assign it to a logical device. If the EtherChannel is removed from the logical device or the logical device is deleted, the EtherChannel will revert to a **Suspended** state.



Note The Firepower 4100/9300 chassis only supports EtherChannels in Active Link Aggregation Control Protocol (LACP) mode. We suggest setting the connecting switch ports to Active mode for the best compatibility.

Example

The following example shows how to create a new port-channel, enable it and add member ports:

```
firepower # scope eth-uplink
firepower /eth-uplink/fabric # scope fabric a
firepower /eth-uplink/fabric # create port-channel 4
firepower /eth-uplink/fabric/port-channel* # enable
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # commit-buffer
firepower /eth-uplink/fabric/port-channel #
```

Related Commands

Command	Description
create member-port	Adds a member port to a port-channel.
set (port-channel)	Sets or changes the parameters for an existing port-channel.

create pre-login-banner

To create a banner that is presented prior to the log-in screen, use the **create pre-login-banner** command. If a pre-login banner already exists, the command will fail.

To add or edit the pre-login banner, use the **enter pre-login-banner** command. If a banner does not exist, it is created and entered; if the banner exists, it is entered.

You also can use the **scope** form of this command to enter an existing pre-login banner to set or clear the message.

To delete an existing banner, use the **delete** form of this command.

create pre-login-banner

Syntax Description

This command has no arguments or keywords.

Command Modes

scope security/scope banner/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

When you create a new pre-login banner, it is initially blank and you are automatically entered into pre-login-banner mode (security/banner/pre-login-banner) with an asterisk indicating the banner is not yet specified and committed.

Use the **set message** command to enter the pre-login banner text. You must enter `ENDOFBUF` (must be all capital letters) to terminate the banner message.

If a pre-login banner already exists when you enter this command, the command will fail with the message `Error: Managed object already exists.`

Example

This example shows how to create and specify a pre-login banner, then commit and view it:

```
firepower # scope security
firepower /security # scope banner
firepower /security/banner # create pre-login-banner
firepower /security/banner/pre-login-banner* # set message
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
Enter prelogin banner:
>Firepower-9300-2
>Western Data Center
>ENDOFBUF
firepower /security/banner/pre-login-banner* # commit
firepower /security/banner/pre-login-banner # show

Pre login banner:
  Message
  -----
  Firepower-9300-2
  Western Data Center
```



```
firepower /security/banner/pre-login-banner #
```

Related Commands	Command	Description
	clear message	Removes the text from an existing pre-login banner; the actual banner object itself is not deleted.
	set message	Specifies the text lines to be displayed as the pre-login banner.

create profile

To add a new Smart Call Home and Smart Licensing destination profile, use the **create profile** command. If a profile with the specified name already exists, the command will fail.

To add or edit a destination profile, use the **enter profile** command. If the specified profile does not exist, it is created and entered; if the profile exists, it is entered.

You also can use the **scope** form of this command to enter an existing profile to assign or change properties. If the profile does not exist, the command will fail.

To delete an existing profile, use the **delete** form of this command.

create profile *name*

delete profile *name*

enter profile *name*

scope profile *name*

Syntax Description	<i>name</i>	The name identifying the destination profile.
---------------------------	-------------	---

Command Modes	scope monitoring/scope callhome/
----------------------	----------------------------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines When you create a new Smart Call Home profile, you are automatically entered into callhome/profile mode (monitoring/callhome/profile) with an asterisk indicating the new profile is not yet committed. You can define the profile, and then commit the new profile information.

After you create a Smart Call Home destination profile, the profile name cannot be changed. You must delete the profile and create a new one.

Example

This example shows how to create and enter a Smart Call Home destination profile:

```
firepower # scope monitoring
firepower /monitoring # scope callhome
firepower /monitoring/callhome # enter profile TestProfile
firepower /monitoring/callhome/profile* # commit-buffer
firepower /monitoring/callhome/profile #
```

Related Commands	Command	Description
	delete profile	Deletes an existing Smart Call Home destination profile.
	set	In monitoring/callhome mode, sets profile properties.

Command	Description
show profile	Lists currently defined Smart Call Home and Smart Licensing profiles; available in monitoring/callhome mode.

create property

To add a new property to a network statistics threshold policy class, use the **create property** command. If a property with the specified name already exists, the command will fail.

To add or edit a statistics threshold property, use the **enter property** command. If the specified property does not exist, it is created and entered; if the property exists, it is entered.

You also can use the **scope** form of this command to enter an existing property to assign or change parameters. Generally, “scoping into” an object is more convenient than entering it, since the object’s name is usually all that is needed, whereas the **enter** form of the command often requires entering all its definition parameters.

To delete an existing property, use the **delete** form of this command.

create property *property-name*

delete property *property-name*

enter property *property-name*

scope property *property-name*

Syntax Description

property-name

Specify the desired statistics property.

Available properties depend on the current mode and the defined class of statistics. For example, for the `chassis-stats` class in `eth-server` mode, `input-power` and `output-power` options are available. In the `ether-rx-stats` class in `eth-uplink` mode, properties such as `broadcast-packets-delta` and `total-bytes-delta` are available.

Use the **create property ?** command to view a list of properties available for the current class of statistics.

Command Modes

scope eth-server/scope stats-threshold-policy/scope class/

scope eth-uplink/scope stats-threshold-policy/scope class/

scope org/scope stats-threshold-policy/scope class/

Command History

Release

Modification

1.1(1)

Command added.

Usage Guidelines

Use classes to place thresholds on specific sets of statistics. Use properties to define particular values and statistics thresholds for a policy class. For example, you might want to define a threshold on a port that raises a fault if the average number of packets dropped exceeds a certain amount. For this class, you would create threshold properties for the Ethernet error statistics class.

You can configure multiple properties for a policy class.



Note There is one default statistics threshold policy each for Ethernet server ports or Ethernet uplink ports. You cannot create additional statistics collection policies and you cannot delete the existing default policies for these components—you can only modify the default policies. However, you can create and delete statistics threshold policies in organization mode (`scope org/`).

Example

This example shows how to scope into the default Ethernet uplink statistics threshold policy, create an error statistics class, create a cyclic redundancy check (CRC) error count property, specify that the normal CRC error count per polling interval is 1000, create an above normal warning threshold of 1250, and then commit the class:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope stats-threshold-policy default
firepower /eth-uplink/stats-threshold-policy # create class ether-error-stats
firepower /eth-uplink/stats-threshold-policy/class* # create property crc-delta
firepower /eth-uplink/stats-threshold-policy/class/property* # set normal-value 1000
firepower /eth-uplink/stats-threshold-policy/class/property* # create threshold-value
above-normal warning
firepower /eth-uplink/stats-threshold-policy/class/property/threshold-value* # set escalating
1250
firepower /eth-uplink/stats-threshold-policy/class/property/threshold-value* # commit-buffer
firepower /eth-uplink/stats-threshold-policy/class/property/threshold-value #
```

Related Commands

Command	Description
delete property	Deletes an existing property.
enter property	Enters a class property. If the property does not exist, it is created.
enter property	Enters or creates a property for a class of statistics.
scope property	Enters property mode, where you manage properties for a class of statistics.

create resource-profile

To add a resource profile for use with container instances, use the **create resource-profile** command.

create resource-profile *name*

Syntax Description	<i>name</i>	Sets the name of the profile between 1 and 64 characters. Note that you cannot change the name of this profile after you add it.
Command Modes	scope ssa/	
Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines To specify resource usage per container instance, create one or more resource profiles. When you deploy the logical device/application instance, you specify the resource profile that you want to use. The resource profile sets the number of CPU cores; RAM is dynamically allocated according to the number of cores, and disk space is set to 40 GB per instance.

- The minimum number of cores is 6.
- You cannot specify 8 cores due to internal architecture.
- You can assign cores as an even number (6, 10, 12, 14 etc.) up to the maximum.
- The maximum number of cores available depends on the security module/chassis model.

The chassis includes a default resource profile called "Default-Small," which includes the minimum number of cores. You can change the definition of this profile, and even delete it if it is not in use. Note that this profile is created when the chassis reloads and no other profile exists on the system.

You cannot change the resource profile settings if it is currently in use. You must disable any instances that use it, then change the resource profile, and finally reenable the instance. If you resize instances in an established High Availability pair, then you should make all members the same size as soon as possible.

If you change the resource profile settings after you add the threat defense instance to the management center, update the inventory for each unit on the **Devices > Device Management > Device > System > Inventory** dialog box.

Example

The following example adds three resource profiles.

```
firepower# scope ssa
firepower /ssa # enter resource-profile basic
firepower /ssa/resource-profile* # set description "lowest level"
firepower /ssa/resource-profile* # set cpu-core-count 6
firepower /ssa/resource-profile* # exit
firepower /ssa # enter resource-profile standard
firepower /ssa/resource-profile* # set description "middle level"
firepower /ssa/resource-profile* # set cpu-core-count 10
```

```

firepower /ssa/resource-profile* # exit
firepower /ssa # enter resource-profile advanced
firepower /ssa/resource-profile* # set description "highest level"
firepower /ssa/resource-profile* # set cpu-core-count 12
firepower /ssa/resource-profile* # commit-buffer
firepower /ssa/resource-profile #

```

Related Commands	Command	Description
	set cpu-count	Sets the number of CPUs for the resource profile.
	set resource-profile-name	Assigned the resource profile to the application instance.
	show monitor detail	Shows resource usage for the security module/engine slot.
	show resource detail	Shows resource allocation for the application instance.
	show resource-profile user-defined	Shows resource profile assignments.

create server (scope ldap)

To create a Lightweight Directory Access Protocol (LDAP) server object, use the **create server** command in security/ldap mode. If a server with the specified name already exists, the command will fail.

To add or edit an LDAP server, use the **enter server** command in security/ldap mode. If the specified server does not exist, it is created and entered; if the server exists, it is entered.

You also can use the **scope** form of this command to enter an existing server to assign or change properties.

To delete an existing server, use the **delete** form of this command.

create server *id*

Syntax Description

id Provide the server ID, using its host name, fully qualified domain name (FQDN), or IP address (can be an IPv4 or IPv6 address).

Command Modes

scope security/scope ldap/

Command History

Release	Modification
1.1.1	Command added.

Usage Guidelines

If you use a host name or FQDN to specify the server *id*, a DNS server must also be configured.

If SSL is enabled, the server *id* must exactly match a Common Name (CN) in the LDAP server's security certificate.

When you create a new LDAP server, you are automatically entered into security/ldap/server mode with an asterisk indicating the new server is not yet committed. You can configure the server before committing it.



Note The FXOS supports a maximum of 16 LDAP providers.

Example

The following example creates a new LDAP server and commits the transaction:

```
firepower # scope security
firepower # scope ldap
firepower /security/ldap # create server 192.168.100.112
Warning: LDAP server name has to be DNS name in Secure LDAP connection. It has to match the
LDAP server certificate SAN field.
firepower /security/ldap/server* # commit-buffer
firepower /security/ldap/server #
```

Related Commands

Command	Description
create ldap-group-rule	Creates LDAP provider group rule parameters.

Command	Description
set	In security/ldap/server mode, sets a variety of LDAP server-related parameters, including enable/disable of SSL.

create snmp-trap

To create a Simple Network Management Protocol (SNMP) trap host, use the **create snmp-trap** command. If a trap with the specified name already exists, the command will fail.

To add or edit an SNMP trap, use the **enter snmp-trap** command. If the specified trap does not exist, it is created and entered; if the trap exists, it is entered.

You also can use the **scope** form of this command to enter an existing trap to assign or change properties. Generally, “scoping into” an object is more convenient than entering it, since the object’s name is usually all that is needed, whereas the **enter** form of the command often requires entering all its definition parameters.

To delete an existing trap, use the **delete** form of this command.

create snmp-trap *destination*

Syntax Description	<i>destination</i>	Specify the trap destination server, using its host name or IP address (can be an IPv4 or IPv6 address).
---------------------------	--------------------	--

Command Modes	scope monitoring/
----------------------	-------------------

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines You must enable SNMP (**enable snmp**), and create an SNMP community (**set snmp community**), before you create an SNMP trap.

When you create a new SNMP trap, you are automatically entered into monitoring/snmp-trap mode with an asterisk indicating the new trap is not yet committed.



Note You can create up to eight SNMP traps.

Example

The following example creates a new SNMP trap and commits the transaction:

```
firepower # scope monitoring
firepower /monitoring/ # enable snmp
firepower /monitoring/ # create snmp-trap 192.168.100.112
firepower /monitoring/snmp-trap* # commit-buffer
firepower /monitoring/snmp-trap #
```

Related Commands	Command	Description
	enable snmp	Enables SNMP.

Command	Description
set snmp	Sets SNMP configuration parameters: community, system contact person responsible for SNMP, and location of the host.

create snmp-user

To create a new SNMPv3 user, utilize the **create snmp-user** command. If a user with the specified name already exists, the command will fail.

To add or edit an SNMP user, utilize the **enter snmp-user** command. If the specified user does not exist, it is created and entered; if the user exists, it is entered.

You also can use the **scope** form of this command to enter an existing user to assign or change properties. Generally, “scoping into” an object is more convenient than entering it, since the object’s name is usually all that is needed, whereas the **enter** form of the command often requires entering all its definition parameters.

To delete an existing user, use the **delete** form of this command.

create snmp-user *user_name*

Syntax Description

<i>user_name</i>	Specify the SNMPv3 user name; can be a maximum of 32 alphanumeric characters, and underscore (_), dot (.), at-sign (@), and dash (-).
------------------	---

Command Modes

scope monitoring/

Command History

Release	Modification
1.1.1	Command added.

Usage Guidelines

You must enable SNMP (**enable snmp**), and create an SNMP community (**set snmp community**), before you create an SNMP user.

When you create a new SNMP user, you are asked to create a password for the user. This password must be at least eight characters long; it is not displayed as you enter it.

When you create a new SNMP user, you are automatically entered into monitoring/snmp-user mode with an asterisk indicating the new user is not yet committed.

Example

The following example shows how to create an SNMPv3 user:

```
firepower # scope monitoring
firepower /monitoring/ # enable snmp
firepower /monitoring/ # create snmp-user test1
Password:
firepower /monitoring/snmp-user* # commit-buffer
firepower /monitoring/snmp-user #
```

Related Commands

Command	Description
enable snmp	Enables SNMP.
set snmp	Sets SNMP configuration parameters: community, system contact person responsible for SNMP, and location of the host.

create ssh-server

To create a new SSH host key, use the **create ssh-server** command with the **host-key** keyword.

To delete the existing SSH host key, use the **delete ssh-server** command with the **host-key** keyword.

```
create ssh-server host-key
create ssh-server host-key
```

Syntax Description	This command has no additional arguments.	
Command Modes	scope system/scope services/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use the create form of this command to generate a new SSH host key. Use the delete form of this command to destroy an existing SSH host key before generating a new one.	

Examples

This example shows how to generate a new SSH host key:

```
firepower # scope system
firepower /system # scope services
firepower /system/services # create ssh-server host-key
firepower /system/services* # commit-buffer
firepower /system/services #
```

This example shows how to delete the existing SSH host key and confirm its deletion:

```
firepower # scope system
firepower /system # scope services
firepower /system/services # delete ssh-server host-key
firepower /system/services* # commit-buffer
firepower /system/services # show ssh-server host-key
Host Key Size: 2048
Deleted: Yes
firepower /system/services #
```

Related Commands	Command	Description
	set ssh-server	Sets the SSH server host key size.
	show ssh-server	Shows the SSH server properties.

create stats-threshold-policy

To create a new statistics threshold policy in organization mode, use the **create stats-threshold-policy** command. If a policy with the specified name already exists, the command will fail.

To add or edit an threshold policy in organization mode, use the **enter stats-threshold-policy** command. If the specified policy does not exist, it is created and entered; if the policy exists, it is entered.

You also can use the **scope** form of this command to enter an existing statistics threshold policy in organization mode to assign or change properties. Generally, “scoping into” an object is more convenient than entering it, since the object’s name is usually all that is needed, whereas the **enter** form of the command often requires entering all its definition parameters.

To delete an existing policy, use the **delete** form of this command.

create stats-threshold-policy *policy-name*

Syntax Description	<i>policy-name</i>	The name of the new statistics threshold policy.
		Note You cannot create or delete the default statistics threshold policy for Ethernet server ports (<code>scope eth-server/</code>) or Ethernet uplink ports (<code>scope eth-uplink/</code>).

Command Modes scope org/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines A statistics threshold policy monitors statistics about certain aspects of the system and generates an event if a specified threshold is crossed. You can set both minimum and maximum thresholds. For example, you can configure the policy to raise an alarm if the CPU temperature exceeds a certain value, or if a server is overutilized or underutilized.

You can create, enter and delete additional statistics threshold policies in organization mode only. You cannot create additional statistics threshold policies for Ethernet server ports or Ethernet uplink ports, and you cannot delete the existing default policies for those components—you can only modify the default policies.



Note Use the **set collection-interval** command to define how frequently statistics are collected, and use the **set reporting-interval** command to define how frequently the statistics are reported. These intervals define a statistics collection policy.

Example

This example shows how to scope into organization mode, create a new statistics threshold policy for server and server component statistics, create a threshold policy class for CPU environment statistics, create a CPU temperature property, specify that the normal CPU temperature is 48.5° C, create an above normal warning threshold of 50° C, and commit the entire transaction:

```

firepower # scope org
firepower /org # create stats-threshold-policy ServStatsPolicy
firepower /org/stats-threshold-policy* # create class cpu-env-stat
firepower /org/stats-threshold-policy/class* # create property temperature
firepower /org/stats-threshold-policy/class/property* # set normal-value 48.5
firepower /org/stats-threshold-policy/class/property* # create threshold-value above-normal
warning
firepower /org/stats-threshold-policy/class/property/threshold-value* # set escalating 50.0
firepower /org/stats-threshold-policy/class/property/threshold-value* # commit-buffer
firepower /org/stats-threshold-policy/class/property/threshold-value #

```

Related Commands

Command	Description
create class	Creates a new class of statistics.
create property	Creates a new property for a class of statistics.
create threshold-value	Specifies an above- or below-normal threshold for a class property.
scope org	Enters organizations mode.

create subinterface

To add a subinterface to a physical or EtherChannel interface for use with container instances, use the **create subinterface** command.

create subinterface *id*

Syntax Description	<i>id</i>	Sets the ID between 1 and 4294967295. This ID will be appended to the parent interface ID as <i>interface_id.subinterface_id</i> . For example, if you add a subinterface to Ethernet1/1 with the ID of 100, then the subinterface ID will be: Ethernet1/1.100. This ID is not the same as the VLAN ID, although you can set them to match for convenience.
---------------------------	-----------	---

Command Modes	scope eth-uplink/scope fabric a/scope interface/ scope eth-uplink/scope fabric a/create port-channel/
----------------------	--




Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines You can add up to 500 subinterfaces to your chassis.

For standalone instances, subinterfaces are supported on data or data-sharing type interfaces only. For multi-instance clustering, you can only add subinterfaces to the Cluster-type interface; subinterfaces on data interfaces are not supported.

VLAN IDs per interface must be unique, and within a container instance, VLAN IDs must be unique across all assigned interfaces. You can reuse VLAN IDs on *separate* interfaces as long as they are assigned to different container instances. However, each subinterface still counts towards the limit even though it uses the same ID.

For native instances, you can create VLAN subinterfaces within the application only. For container instances, you can also create VLAN subinterfaces inside the application on interfaces that do not have FXOS VLAN subinterfaces defined, and these subinterfaces are not subject to the FXOS limit. Choosing in which operating system to create subinterfaces depends on your network deployment and personal preference. For example, to share a subinterface, you must create the subinterface in FXOS. Another scenario that favors FXOS subinterfaces comprises allocating separate subinterface groups on a single interface to multiple instances. For example, you want to use Port-Channel1 with VLAN 2-11 on instance A, VLAN 12-21 on instance B, and VLAN 22-31 on instance C. If you create these subinterfaces within the application, then you would have to share the parent interface in FXOS, which may not be desirable. See the following illustration that shows the three ways you can accomplish this scenario:

Scenario 1 (recommended)**Scenario 2 (not recommended, worse performance)****Scenario 3 (recommended, but lacks EtherChannel redundancy)**

You cannot add a subinterface to a physical interface that is currently allocated to a logical device. If other subinterfaces of the parent are allocated, you can add a new subinterface as long as the parent interface itself is not allocated.

Example

The following example creates 3 subinterfaces on Ethernet 1/1, and sets them to be data-sharing interfaces.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # scope interface Ethernet1/1
firepower /eth-uplink/fabric/interface # create subinterface 10
```

create subinterface

```

firepower /eth-uplink/fabric/interface/subinterface* # set vlan 10
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # create subinterface 11
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 11
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # create subinterface 12
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 12
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # commit-buffer
firepower /eth-uplink/fabric/interface/subinterface #

```

Related Commands

Command	Description
create port-channel	Creates an EtherChannel (port channel).
scope interface	Enters the physical interface object.
set port-type	Sets the interface type.
set vlan	Sets the VLAN ID for a subinterface.

create threshold-value

To add an above- or below-normal threshold for a class property, use the **create threshold-value** command. If a threshold with the specified name already exists, the command will fail.

To add or edit a threshold value, use the **enter threshold-value** command. If the specified threshold value does not exist, it is created and entered; if the threshold exists, it is entered.

You also can use the **scope** form of this command to enter an existing threshold value to assign or change parameters. Generally, “scoping into” an object is more convenient than entering it, since the object’s name is usually all that is needed, whereas the **enter** form of the command often requires entering all its definition parameters.

To delete an existing threshold value, use the **delete** form of this command.

create threshold-value { **above-normal** | **below-normal** *event_type* }

Syntax Description

above-normal | **below-normal** Specify the type of threshold: above-normal or below-normal. This determines whether the specified *event_type* is logged when the monitored value (set separately) increases or decreases sufficiently relative to the related normal value (also set separately).

event_type

Specify the type of event logged:

- cleared
- condition
- critical
- info
- major
- minor
- warning

Command Modes

scope eth-server/scope stats-threshold-policy/scope class/scope property/
 scope eth-uplink/scope stats-threshold-policy/scope class/scope property/
 scope org/scope stats-threshold-policy/scope class/scope property/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use classes to place thresholds on specific sets of statistics. Use properties to define particular values, including normal values and threshold values, for a policy class. For example, you might want to define a threshold on a port that raises a fault if the average number of packets dropped exceeds a certain amount. For this class, you would create threshold properties for the Ethernet error statistics class.

You can configure multiple properties for a policy class, and you can create multiple threshold values for a property.



Note There is one default statistics threshold policy each for Ethernet server ports or Ethernet uplink ports. You cannot create additional statistics collection policies and you cannot delete the existing default policies for these components—you can only modify the default policies. However, you can create and delete statistics threshold policies in organization mode (`scope org/`).

Example

This example shows how to scope into the default Ethernet server statistics threshold policy class, create a chassis statistics class, create an input power (Watts) property, specify that the normal power level is 8 kW, create an above normal warning threshold of 11 kW, and then commit the class:

```
firepower # scope eth-server
firepower /eth-server # scope stats-threshold-policy default
firepower /eth-server/stats-threshold-policy # create class chassis-stats
firepower /eth-server/stats-threshold-policy/class* # create property input-power
firepower /eth-server/stats-threshold-policy/class/property* # set normal-value 8000.0
firepower /eth-server/stats-threshold-policy/class/property* # create threshold-value
above-normal warning
firepower /eth-server/stats-threshold-policy/class/property/threshold-value* # set escalating
11000.0
firepower /eth-server/stats-threshold-policy/class/property/threshold-value* # commit-buffer
firepower /eth-server/stats-threshold-policy/class/property/threshold-value #
```

Related Commands

Command	Description
enter class	Enters or creates a class of statistics.
enter property	Enters or creates a property for a class of statistics.
scope stats-threshold-policy	Enters stats-threshold-policy mode, where you manage statistics classes.
set normal-value	Sets the normal value for a class property.

create trustpoint

To add a new trustpoint for validation of a certificate during Internet Key Exchange (IKE) authentication, use the **create trustpoint** command. If a connection with the specified name already exists, the command will fail.

To add or edit a trustpoint, use the **enter trustpoint** command. If the specified trustpoint does not exist, it is created and entered; if the trustpoint exists, it is entered.

You also can use the **scope** form of this command to enter an existing trustpoint to assign or change properties.

To delete an existing trustpoint, use the **delete** form of this command.

create trustpoint *name*

delete trustpoint *name*

enter trustpoint *name*

scope trustpoint *name*

Syntax Description	<i>name</i>	The trustpoint name; can be up to 32 alphanumeric characters.
---------------------------	-------------	---

Command Modes	scope security/
----------------------	-----------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to identify trustpoints that will be used to validate certificates during Internet Key Exchange (IKE) authentication.

When you create a new trustpoint, you are automatically entered into security/trustpoint mode with an asterisk indicating the new trustpoint is not yet committed. After you create a trustpoint, the name cannot be changed. You must delete the trustpoint and create a new one.

Example

This example shows how to create and enter a trustpoint:

```
firepower # scope security
firepower /security # enter trustpoint tPoint4
firepower /security/trustpoint* #
```

Related Commands	Command	Description
	set certchain	Sets certificate information for a trustpoint.
	show trustpoint	Shows current trustpoint information.

cycle

To power-cycle a security module/server, use one of the **cycle** commands.

cycle {**cycle-immediate** | **cycle-wait**}

Syntax Description	cycle-immediate	Power-cycles the module immediately.
	cycle-wait	The system waits up to five minutes for the application running on the module to shut down before power-cycling the module.

Command Modes scope service-profile/

Command History	Release	Modification
	1.1(1)	This command was introduced.

Example

This example shows how to power-cycle a module after its running application is shut down:

```
firepower # scope service-profile server 1/1
firepower /org/service-profile # cycle cycle-wait
firepower /org/service-profile* # commit-buffer
firepower /org/service-profile #
```

Related Commands	Command	Description
	set adminstate	Takes a network module offline or online.



D – R Commands

- decommission, on page 119
- decommission-secure, on page 120
- delete hw-crypto, on page 121
- delete, on page 122
- delete decommissioned server, on page 124
- deregister, on page 125
- disable (app-instance), on page 126
- disable (export-configuration), on page 127
- disable (interface), on page 128
- disable (port-channel), on page 129
- disable (security modes), on page 130
- disable reservation, on page 131
- disable snmp, on page 132
- discard-buffer, on page 133
- download image, on page 134
- enable (app-instance), on page 136
- enable (CC and FIPS security modes), on page 137
- enable (export-configuration), on page 139
- enable (interface), on page 140
- enable (port-channel), on page 141
- enable reservation, on page 142
- enable snmp, on page 143
- end, on page 144
- enter, on page 145
- erase, on page 147
- exit, on page 149
- export-config, on page 150
- generate password, on page 152
- import-config, on page 153
- install, on page 156
- install firmware, on page 157
- install platform, on page 159
- mgmt-port (connect local-mgmt), on page 160

- ping (connect local-mgmt), on page 161
- ping6 (connect local-mgmt), on page 163
- power, on page 165
- reboot, on page 166
- reinstall, on page 168
- register, on page 169
- reinitialize, on page 170
- remove server, on page 171
- renew, on page 172
- reset-password, on page 173
- request universal, on page 174
- restart, on page 175
- return, on page 176

decommission

To decommission a server, use the **decommission server** command.

decommission server {*id* | *chassis_id/blade_id*}

Syntax Description	<i>id</i>	The server identification number. This is a value between 1 and 255.
	<i>chassis_id/blade_id</i>	The chassis and blade identification numbers in n/n format.

Command Modes Any command mode

Command History	Release	Modification
	2.3(1)	Command added.

Usage Guidelines Depending on the type of device hosting the module to be decommissioned, identify it using its module ID (4100 series), or the chassis number and module number (9300 devices).

When you decommission a security module, the module object is deleted from the configuration and the module becomes unmanaged. Any logical devices or software running on the module becomes inactive.

Example

This example shows how to decommission a server:

```
firepower# decommission server 1/1
firepower* # commit-buffer
firepower #
```

Related Commands	Command	Description
	delete decommissioned	Deletes a decommissioned server.
	show server decommissioned	Shows any decommissioned servers.

decommission-secure

To securely decommission a server, use the **decommission-secure server** command.

decommission-secure server *chassis_id/blade_id*

Syntax Description	<i>chassis_id/blade_id</i>	The chassis and blade identification numbers in n/n format.
Command Modes	Any command mode	
Command History	Release	Modification
	2.7(1)	Command added.
Usage Guidelines	This command securely erases the specified module. That is, data is not just deleted—the physical storage is “wiped” (completely erased). After a security module is erased, it remains down until acknowledged (similar to a module that is decommissioned).	

Example

This example shows how to securely decommission a server:

```
firepower# decommission-secure server 1/2
Warning:
1.Secure decommissioning of the service module may take some time. Please use the CLI command
'show slot status [n/n] detail' to check for completion.
2.All of the application data on the service module will be lost. Please back up the
application's configuration files before executing the commit-buffer command.
firepower* #
```

Related Commands	Command	Description
	decommission server	Decommissions a server—the module object is deleted from the configuration but the physical storage is not completely erased.
	erase secure	Securely erases the specified system component.

delete hw-crypto

To delete a TLS crypto acceleration configuration on a container instance, use the **delete hw-crypto** command. For more information about TLS crypto acceleration, see the *Firepower Management Center Configuration Guide*.

delete hw-crypto

Command Modes connect module

Command History	Release	Modification
	2.7.1	This command was introduced.

Usage Guidelines This command deletes a TLS crypto acceleration configuration for a container instance. If TLS crypto acceleration is enabled on the container instance, the command disables it before deleting the configuration.

Examples

Following is an example of deleting a TLS crypto acceleration configuration:

```
scope ssa
/ssa # show app-instance

App Name      Identifier Slot ID   Admin State Oper State      Running Version Startup Version
Deploy Type  Turbo Mode Profile Name Cluster State  Cluster Role
-----
ftd          FTD-FDM    1           Enabled   Online           6.5.0.1159     6.5.0.1159
Native      No
           Not Applicable None
ftd          ftd2      2           Enabled   Online           6.5.0.1159     6.5.0.1159
Container   No
           Default-Small Not Applicable None

/ssa # sc slot 2
/ssa/slot # scope app-instance ftd ftd2
/ssa/slot/app-instance # delete hw-crypto
/ssa/slot/app-instance* # commit-buffer
```

Related Commands	Command	Description
	create hw-crypto	Create a TLS crypto acceleration configuration for a container instance.
	scope hw-crypto	Enable or disable TLS crypto acceleration configuration on a container instance.
	show hw-crypto	Display the status of TLS crypto acceleration configuration on a container instance.

delete

To delete an existing managed object, use the relevant **delete** command in the appropriate command mode.

delete *object_type name* [*parameters*]

Syntax Description

<i>object_type</i>	The type of object to be deleted. Examples include local user account and organization.
<i>name</i>	The name of the specific object to be deleted.
<i>parameters</i>	(Optional) Any additional properties or parameters needed to identify the object. Refer to the description of the create command for the specific object type for more information.

Command Modes

Depends on the type of object being deleted; refer to the description of the **create** command for the specific object type for more information.

Command History

Refer to the description of the **create** command for the specific object type for history information.

Usage Guidelines

Objects are abstract representations of physical components or logical entities that can be managed. For example, the chassis, security modules, network modules, ports, and processors are physical components represented as managed objects, while licenses, user roles, and platform policies are logical entities represented as managed objects.

FXOS provides four general commands for managing objects: **create**, **delete**, **enter**, and **scope**. For example, you can create a local user account, you can delete a local user account, and you can enter a local user account to assign or change properties for that account; you also can “scope into” the local user account to assign or change properties.

Generally, the keywords and options available to each of these object-management commands are the same, so we detail only the **create** version of the various object commands. In other words, for information about the **delete** command for a particular object, refer to the description of the **create** command for that object. For example, refer to [create local-user, on page 82](#) for information related to deleting an existing local user account.

Examples

This example shows how to enter security mode and then delete a local user account:

```
firepower # scope security
firepower /security # delete local-user test_user
firepower /security/local-user* # commit-buffer
firepower /security/local-user #
```

This example shows how to enter a local-user account and then delete a user role:

```
firepower # scope security
firepower /security # enter local-user test_user
firepower /security/local-user # delete role aaa
Warning: Change of privileges will terminate active sessions (CLI and Web) of user 'test_user'
```

```
firepower /security/local-user* # commit-buffer  
firepower /security/local-user #
```

Related Commands	Command	Description
	create local-user	Creates a new local user account.
	enter local-user	Adds or edits a local user account.
	delete local-user	Deletes an existing local user account.
	scope local-user	Enters a existing local user account.

delete decommissioned server

To delete a decommissioned server, use the **delete decommissioned server** command.

delete decommissioned server *vendor model serial_number*

Syntax Description		
	<i>vendor</i>	The name of the company that manufactured the server; can be no more than 510 characters.
	<i>model</i>	The module's model name; can be no more than 510 characters.
	<i>serial_number</i>	The module's serial number; can be no more than 510 characters.

Command Modes Any command mode

Command History	Release	Modification
	1.4(1)	Command added.

Example

This example shows how to delete a decommissioned server.

```
FP9300-A # delete decommissioned server Cisco Systems, Inc.
Cisco Firepower 9000 Series Security Module
FLM1949C6J1
FP9300-A* # commit-buffer
```

Related Commands	Command	Description
	decommission server	Decommissions a server.

deregister

To remove this Firepower 4100/9300 device from your Cisco Smart Software License account, use the **deregister** command.

deregister

Syntax Description

This command has no arguments or keywords.

Command Modes

License mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Deregistration removes the device from your account, and all license entitlements and certificates on the device are removed. You can use this to free up a license for a new Firepower 4100/9300, or you can remove the device from the Smart Software Manager.

Example

This example shows how to deregister this device.

```
FP9300-A # scope license
FP9300-A /license # deregister
FP9300-A /license #
```

Related Commands

Command	Description
register	Registers a Smart Software Manager account on this Firepower 4100/9300 device.

disable (app-instance)

To disable an existing application instance, use the **disable** command in app-instance mode.

Syntax Description This command has no arguments or keywords.

Command Modes scope ssa/scope slot/scope app-instance

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to disable an application instance without removing it from the system.

Example

This example shows how to display current application instances, including their status, then enter application instance mode and disable an application instance:

```
firepower # scope ssa
firepower /ssa # scope slot 2
firepower /ssa/slot # show app-instance
```

```
Application Instance:
  App Name   Identifier Admin State Oper State   Running Version Startup Version
Deploy Type Profile Name Cluster State  Cluster Role
-----
  ftd1      IFT-63    Enabled   Online    6.3.0.12    6.3.0.12
Native      In Cluster Slave
```

```
Application Instance:
  App Name   Identifier Admin State Oper State   Running Version Startup Version
Deploy Type Profile Name Cluster State  Cluster Role
-----
  ftd2      FTD-2     Enabled   Online    6.3.0.12    6.3.0.12
Container  bronze    Not Applicable None
firepower /ssa/slot # scope app-instance ftd2 FTD-2
firepower /ssa/slot/app-instance # disable
firepower /ssa/slot/app-instance* # commit-buffer
firepower /ssa/slot/app-instance #
```

Related Commands

Command	Description
enable	Enables an existing application instance.
scope app-instance	Enters application mode for a specific application instance.

disable (export-configuration)

To disable an existing export-configuration object, use the **disable** command in export-config mode.

To disable an existing application instance, use the **disable** command in app-instance mode.

To disable an existing export-configuration object, use the **disable** command in export-config mode.

Syntax Description

This command has no arguments or keywords.

Command Modes

scope system/scope export-config

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

In export-configuration mode, use this command to disable an existing export-configuration object without removing it from the system.

Example

This example shows how to scope into an existing exported configuration object and disable it:

```
firepower # scope system
firepower /system # scope export-config 192.168.1.2
firepower /system/export-config #disable
firepower /system/export-config* #commit-buffer
```

Related Commands

Command	Description
enable	In export-config mode, enables an existing export-configuration object.
scope export-config	Enters an existing export-configuration object.

disable (interface)

To disable the current interface, use the **disable** command in interface mode.

Syntax Description	This command has no arguments or keywords.	
Command Modes	scope eth-uplink/scope fabric/interface	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command to disable the current interface.	

Example

This example shows how to disable an interface and confirm its status:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope fabric
firepower /eth-uplink #/fabric # scope interface Ethernet1/5
firepower /eth-uplink/fabric/interface # disable
firepower /eth-uplink/fabric/interface* # commit-buffer
firepower /eth-uplink/fabric/interface # show
```

```
Interface:
  Port Name      Port Type      Admin State Oper State      Allowed Vlan State
Reason
-----
  Ethernet1/5    Data           Disabled    Up              All
firepower /eth-uplink/fabric/interface #
```

Related Commands	Command	Description
	enable	Enables the current interface.
	set	In interface mode, sets interface configuration parameters.
	show interface	Displays interface configuration and status information.

disable (port-channel)

To disable the current port-channel (EtherChannel), use the **disable** command in port-channel mode.

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	scope eth-uplink/scope fabric/port-channel
----------------------	--

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines	Use this command to disable the current port-channel.
-------------------------	---

Example

This example shows how to disable a port-channel and confirm its status:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope fabric
firepower /eth-uplink #/fabric # scope port-channel 4
firepower /eth-uplink/fabric/port-channel # disable
firepower /eth-uplink/fabric/port-channel* # commit-buffer
firepower /eth-uplink/fabric/port-channel # show
```

```
Port Channel:
  Port Channel Id Name          Port Type          Admin State Oper State      Port
Channel Mode Allowed Vlan State Reason
-----
  4              Port-channel4    Data              Disabled   Failed           Active
              All              Admin config change
firepower /eth-uplink/fabric/port-channel #
```

Related Commands	Command	Description
	enable	Enables the current port-channel.
	show port-channel	Displays port-channel configuration and status information.

disable (security modes)

To disable Common Criteria mode, or FIPS (Federal Information Processing Standard) mode, use the **disable** command in the security scope.

disable { **cc-mode** | **fips-mode** }

Syntax Description	Keyword	Description
	cc-mode	Use this keyword to disable Common Criteria mode.
	fips-mode	Use this keyword to disable FIPS mode.

Command Modes scope security/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines A reboot of the system will be required after this command is committed.

Example

This example shows how to enter security mode and disable FIPS mode:

```
firepower # scope security
firepower /security # disable fips-mode
Warning: A reboot of the system is required in order for the system to be
operating in a non-FIPS approved mode.
firepower /security* #
```

Related Commands	Command	Description
	enable (security modes)	Enables CC or FIPS mode.
	show cc-mode	Shows current Common Criteria mode administrative and operational states.
	show fips-mode	Shows current FIPS mode administrative and operational states.

disable reservation

To disable permanent license reservation, use the **disable reservation** command.

disable reservation

Syntax Description

This command has no arguments or keywords.

Command Modes

License (/license) mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Enable license reservation before attempting to assign a permanent license to your Firepower 4100/9300 chassis.

Example

This example shows how to enter license mode and disable reservation mode:

```
FP9300-A # scope license
FP9300-A /license # disable reservation
Warning: If you have already generated the authorization code from CSSM
and have not installed it on the device, please abort this command by
issuing discard-buffer and complete the installation.
FP9300-A /license* #
```

Related Commands

Command	Description
enable reservation	Enables permanent license reservation.
show license	Shows current license information.

disable snmp

To disable Simple Network Management Protocol (SNMP) processing on this device, use the **disable snmp** command.

disable snmp

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	scope monitoring/
----------------------	-------------------

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines	Use this command to disable the SNMP agent on this device. The current SNMP community setting is discarded, the other SNMP configuration settings are not removed.
-------------------------	--

Example

The following example shows you how to scope into monitoring mode, disable SNMP processing, and then use the **show snmp** command to confirm it is disabled:

```
firepower # scope monitoring
firepower /monitoring # disable snmp
firepower /monitoring* # commit-buffer
firepower /monitoring # show snmp
Name: snmp
  Admin State: Disabled
  Port: 161
  Is Community Set: No
  Sys Contact: R_Admin
  Sys Location:
firepower /monitoring #
```

Related Commands	Command	Description
	enable snmp	Enables SNMP.
	set snmp	Sets SNMP configuration parameters: community, system contact person responsible for SNMP, and location of the host.
	show snmp	Shows current SNMP configuration.

discard-buffer

To cancel pending configuration changes, use the **discard-buffer** command.

discard-buffer

Syntax Description	This command has no arguments or keywords.	
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command to cancel and discard all uncommitted configuration changes. While any configuration commands are pending, an asterisk (*) appears before the command prompt. When you enter the discard-buffer command, the commands are discarded and the asterisk disappears.	

Example

This example shows how to discard pending configuration changes:

```
FP9300-1# scope chassis 1
FP9300-1 /chassis # enable locator-led
FP9300-1 /chassis* # show configuration pending
  scope chassis 1
+   enable locator-led
  exit
FP9300-1 /chassis* # discard-buffer
FP9300-1 /chassis #
```

Related Commands	Command	Description
	commit-buffer	Saves or verifies configuration changes.
	show configuration pending	Shows uncommitted configuration changes.

download image

To copy an FXOS firmware image to the Firepower 4100/9300 chassis, use the **download image** command in firmware mode.

To copy a logical device software image to the Firepower 4100/9300 chassis, use the **download image** command in application software (/ssa/app-software) mode.

download image { **ftp:** | **scp:** | **sftp:** | **tftp:** | **usbA:** | **usbB:** }

Syntax Description	
ftp://server-ip-addr/path	(Optional) Specifies the URI of an image file to be imported via FTP (File Transfer Protocol).
scp://username@server-ip-addr/path	(Optional) Specifies the URI of an image file to be imported via SCP (Secure Copy Protocol).
sftp://username@server-ip-addr/path	(Optional) Specifies the URI of an image file to be imported via SFTP (SSH File Transfer Protocol or Secure File Transfer Protocol).
tftp://username@server-ip-addr:port-num/path	(Optional) Specifies the URI of an image file to be imported via TFTP (Trivial File Transfer Protocol).
	Note TFTP has a file size limitation of 32 MB. Because firmware bundles can be much larger than that, we recommend that you do not use TFTP for firmware downloads.
usbA:/path	(Optional) Specifies the path to an image file to be imported from a connected USB Type A device.
usbB:/path	(Optional) Specifies the path to an image file to be imported from a connected USB Type B device.

Command Modes
scope firmware/ scope ssa/scope app-software/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Be sure you have the location address and authentication credentials for image file access, as well as the fully qualified name of the file.

FXOS stores firmware images in bootflash on the fabric interconnect.

In firmware mode, you can use the **show package image_name detail** command to monitor the image download process. The output display does not refresh automatically, so you may have to enter the command multiple times until the task State is “Downloaded.”

In firmware mode, and in application software mode, you can use the **show download-task** command to monitor the image download process. The output display does not refresh automatically, so you may have to enter the command multiple times.

Examples

This example shows how to download a firmware image file using the SCP protocol, and monitor the download progress:

```
FP9300-A# scope firmware
FP9300-A /firmware # download image scp://user@192.168.1.1/images/fxos-k9.1.1.1.119.SPA
FP9300-A /firmware # show package fxos-k9.1.1.1.119.SPA detail
Download task:
File Name: fxos-k9.1.1.1.119.SPA
Protocol: scp
Server: 192.168.1.1
Userid:
Path:
Downloaded Image Size (KB): 5120
State: Downloading
Current Task: downloading image fxos-k9.1.1.1.119.SPA from
192.168.1.1 (FSM-STAGE:sam:dme:FirmwareDownloaderDownload:Local)
```

This example shows how to download a software image file using the SCP protocol, and monitor the download progress:

```
firepower# scope ssa
firepower /ssa # scope app-software
firepower /ssa/app-software # download image
scp://user@192.168.1.1/images/cisco-asa.9.4.1.65.csp
firepower /ssa/app-software # show download-task
Downloads for Application Software:
  File Name                Protocol  Server          Userid          State
  -----
  cisco-asa.9.4.1.65.csp   Scp      192.168.1.1    user            Downloaded
```

Related Commands

Command	Description
show download-task	Shows progress of the image file download.
show package	Shows progress of the firmware file download.
verify platform-pack	Verifies a specified FXOS platform image.

enable (app-instance)

To enable an existing application instance, use the **enable** command in app-instance mode.

Syntax Description This command has no arguments or keywords.

Command Modes scope ssa/scope slot/scope app-instance

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to re-enable an application instance that was previously disabled.

Example

This example shows how to display current application instances, including their status, then enter application instance mode and enable a disabled application:

```
firepower # scope ssa
firepower /ssa # scope slot 2
firepower /ssa/slot # show app-instance

Application Instance:
  App Name   Identifier Admin State Oper State   Running Version Startup Version
Deploy Type Profile Name Cluster State  Cluster Role
-----
  ftd1      IFT-63     Enabled   Online    6.3.0.12    6.3.0.12
Native                               In Cluster  Slave

Application Instance:
  App Name   Identifier Admin State Oper State   Running Version Startup Version
Deploy Type Profile Name Cluster State  Cluster Role
-----
  ftd2      FTD-2     Disabled  Online    6.3.0.12    6.3.0.12
Container  bronze    Not Applicable None
firepower /ssa/slot # scope app-instance ftd2 FTD-2
firepower /ssa/slot/app-instance # enable
firepower /ssa/slot/app-instance* # commit-buffer
firepower /ssa/slot/app-instance #
```

Related Commands	Command	Description
	disable	In app-instance mode, disables an existing application instance.
	scope app-instance	Enters application mode for a specific application instance.

enable (CC and FIPS security modes)

To enable Common Criteria mode, or FIPS (Federal Information Processing Standard) mode, use the **enable** command in the security scope.

```
enable { cc-mode | fips-mode }
```

Syntax Description	cc-mode	Use this keyword to enable Common Criteria mode.
	fips-mode	Use this keyword to enable FIPS mode.
Command Modes	scope security/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Connectivity to one or more services may be denied when this command is committed. Also, a reboot of the system will be required.	



Important Prior to FXOS release 2.0.1, the existing SSH host key created during first-time setup of a device was hard-coded to 1024 bits. To comply with FIPS and Common Criteria certification requirements, you must destroy this old host key and generate a new one (see [create ssh-server, on page 107](#) for information about creating and deleting SSH host keys). If you do not perform these additional steps, you will not be able to connect to the Supervisor using SSH after the device has rebooted with Common Criteria mode enabled. If you performed initial setup using FXOS 2.0.1 or later, you do not have to generate a new host key.

Example

This example shows how to enter security mode and enable FIPS mode:

```
firepower # scope security
firepower /security # enable fips-mode
Warning: Connectivity to one or more services may be denied when committed.
Please consult the product's FIPS Security Policy documentation.
WARNING: A reboot of the system is required in order for the system to be operating in a
FIPS approved mode.

firepower /security* #
```

Related Commands	Command	Description
	disable (security modes)	Disables CC or FIPS mode.
	show cc-mode	Shows current Common Criteria mode administrative and operational states.

enable (CC and FIPS security modes)

Command	Description
show fips-mode	Shows current FIPS mode administrative and operational states.

enable (export-configuration)

To re-enable an existing export-configuration object, use the **enable** command in export-config mode.

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	scope system/scope export-config
----------------------	----------------------------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines	Use this command to re-enable a previously backed-up export-configuration object, prior to exporting the configuration again. The current system configuration is exported according to the object parameters when you issue the commit-buffer command.
-------------------------	--

Example

This example shows how to scope into a previously exported configuration object, enable it, initiate configuration back-up, and then confirm the export is underway:

```
firepower # scope system
firepower /system # scope export-config 192.168.1.2
firepower /system/export-config #enable
firepower /system/export-config* #commit-buffer
firepower /system/export-config #show
```

```
Export Configuration Task:
  Hostname   User      Protocol Admin State Status   Description
  -----
  192.168.1.2
                user1     Scp      Enabled  Exporting
```

Related Commands	Command	Description
	disable	Disables an existing export-configuration object.
	scope export-config	Enters an existing export-configuration object.

enable (interface)

To enable the current interface, use the **enable** command in interface mode.

Syntax Description This command has no arguments or keywords.

Command Modes scope eth-uplink/scope fabric/interface

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to enable or re-enable an interface.

Example

This example shows how to enable an interface and confirm its status:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope fabric
firepower /eth-uplink #/fabric # scope interface Ethernet1/5
firepower /eth-uplink/fabric/interface # enable
firepower /eth-uplink/fabric/interface* # commit-buffer
firepower /eth-uplink/fabric/interface # show
```

```
Interface:
  Port Name      Port Type      Admin State Oper State      Allowed Vlan State
Reason
-----
  Ethernet1/5    Data           Enabled      Up              All
firepower /eth-uplink/fabric/interface #
```

Related Commands	Command	Description
	disable	Disables the current interface.
	set	In interface mode, sets interface configuration parameters.
	show interface	Displays interface configuration and status information.

enable (port-channel)

To enable the current port-channel (EtherChannel), use the **enable** command in port-channel mode.

Syntax Description	This command has no arguments or keywords.	
Command Modes	scope eth-uplink/scope fabric/port-channel	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command to enable or re-enable a port-channel.	

Example

The following example shows how to create a new port-channel, enable it and add member ports:

```
firepower # scope eth-uplink
firepower /eth-uplink/fabric # scope fabric a
firepower /eth-uplink/fabric # create port-channel 4
firepower /eth-uplink/fabric/port-channel* # enable
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # commit-buffer
firepower /eth-uplink/fabric/port-channel #
```

Related Commands	Command	Description
	create member-port	Adds a member port to a port-channel.
	disable	Disables the current port-channel.
	set (port-channel)	Sets or changes the parameters for an existing port-channel.
	show port-channel	Displays port-channel configuration and status information.

enable reservation

To enable permanent license reservation, use the **enable reservation** command.

enable reservation

Syntax Description

This command has no arguments or keywords.

Command Modes

License (/license) mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Enable license reservation before attempting to assign a permanent license to your Firepower 4100/9300 chassis.

Example

This example shows how to enter license mode and enable reservation mode:

```
FP9300-A # scope license
FP9300-A /license # enable reservation
FP9300-A /license #
```

Related Commands

Command	Description
disable reservation	Disables permanent license reservation.
show license	Shows current license information.

enable snmp

To enable Simple Network Management Protocol (SNMP) processing on this device, use the **enable snmp** command.

enable snmp

Syntax Description

This command has no arguments or keywords.

Command Modes

scope monitoring/

Command History

Release	Modification
1.1.1	Command added.

Usage Guidelines

After using this command to enable the SNMP agent on this device, you can create an SNMP community, and create SNMP users and traps.

Example

The following example shows you how to scope into monitoring mode and enable SNMP processing:

```
firepower # scope monitoring
firepower /monitoring # enable snmp
firepower /monitoring* # commit-buffer
firepower /monitoring #
```

Related Commands

Command	Description
disable snmp	Disables SNMP.
set snmp	Sets SNMP configuration parameters: community, system contact person responsible for SNMP, and location of the host.
show snmp	Shows current SNMP configuration.

end

To return to the EXEC (top level) mode of the CLI, use the **end** command.

end

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to return to the highest-level mode of the CLI from service profile mode.

```
FP9300-A # scope org Test
FP9300-A /org # scope service-profile Sample
FP9300-A /org/service-profile # end
FP9300-A #
```

Related Commands

Command	Description
top	Enters top level mode from any mode.

enter

To enter a managed object, use the relevant **enter** command in the appropriate command mode. Generally, if the specified object does not exist, it is created.

```
enter object_type name [parameters]
```

Syntax Description	<i>object_type</i>	The type of object to be entered. Examples include local user account and organization.
	<i>name</i>	The name of the specific object to be entered.
	<i>parameters</i>	(Optional) Any additional properties or parameters needed to identify the object. Refer to the description of the create command for the specific object type for more information.
Command Modes	Depends on the type of object being entered; refer to the description of the create command for the specific object type for more information.	
Command History	Refer to the description of the create command for the specific object type for history information.	
Usage Guidelines	Objects are abstract representations of physical components or logical entities that can be managed. For example, the chassis, security modules, network modules, ports, and processors are physical components represented as managed objects, while licenses, user roles, and platform policies are logical entities represented as managed objects.	

FXOS provides four general commands for managing objects: **create**, **delete**, **enter**, and **scope**. For example, you can create a local user account, you can delete a local user account, and you can enter a local user account to assign or change properties for that account; you also can “scope into” the local user account to assign or change properties.

Generally, the keywords and options available to each of these object-management commands are the same, so we detail only the **create** version of the various object commands. In other words, for information about the **delete** command for a particular object, refer to the description of the **create** command for that object. For example, refer to [create local-user, on page 82](#) for information related to entering an existing local user account.

Example

This example shows how to enter security mode, enter a local user account and display account details:

```
firepower # scope security
firepower /security # enter local-user test_user
firepower /security/local-user # show detail
Local User test_user:
  First Name: test
  Last Name: user
  Email: test_user@testuser.com
  Phone:
  Expiration: Never
  Password: ****
```

```

User lock status: Not Locked
Account status: Active
User Roles:
  Name: admin
  Name: read-only
User SSH public key:
firepower /security/local-user #

```

Related Commands	Command	Description
	create local-user	Creates a new local user account.
	enter local-user	Adds or edits a local user account.
	delete local-user	Deletes an existing local user account.
	scope local-user	Enters a existing local user account.

erase

To erase all user configuration from the appliance, or to securely erase elements of the appliance, use the **erase** command.

```
erase { configuration | secure { chassis | security_module supervisor } }
```

Syntax Description	configuration	Use this keyword to erase all user-configuration information on the chassis, restoring it to its original factory-default configuration.
	secure	Use this option to securely erase the specified appliance component: <ul style="list-style-type: none"> • chassis – Use this keyword to securely erase the chassis. • security_module <i>module_id</i> – Use this option to securely erase the specified module. • supervisor – Use this keyword to securely erase the chassis supervisor.

Command Modes connect local-mgmt/

Command History	Release	Modification
	2.0.1	Command added.
	2.7(1)	secure option added.

Usage Guidelines The **erase configuration** command removes all user-configuration information on the chassis, restoring it to its original factory-default configuration.

The **erase secure** command securely erases the specified appliance component. That is, data is not just deleted—the physical storage is “wiped” (completely erased). This is important when transferring or returning the appliance as hardware storage components do not retain residual data or stubs.



Note The device reboots during secure erase, which means SSH connections are terminated. Therefore, we recommend performing secure erase over a serial console-port connection.

Examples

This example shows how to erase all user-configuration information on the chassis, restoring it to its original factory-default configuration:

```
firepower# connect local-mgmt
firepower(local-mgmt)# erase configuration
All configurations will be erased and system will reboot. Are you sure? (yes/no):
```

This example shows how to securely erase security module 2:

```
firepower# connect local-mgmt
firepower# erase secure security_module 2
The physical storages in security module will be securely erased.
ALL DATA AND IMAGES WILL BE LOST AND CANNOT BE RECOVERED!
After the erase the module will reboot and need to be re-initialized.
DO NOT POWER OFF THE DEVICE IF YOU DECIDE TO PERFORM THIS TASK!
Are you sure? (yes/no):
```

Related Commands

Command	Description
<code>decommission-secure</code>	Securely erases the specified module.

exit

To exit the current CLI session and disconnect from the device, or to exit from a connected object mode and return to the EXEC level, use the **exit** command.

exit

Syntax Description	This command has no arguments or keywords.	
Command Modes	Any command mode.	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to exit the current top level CLI session and disconnect from this device.

```
FP9300-A # exit
```

This example shows how to enter and exit a local management connection.

```
FP9300-A # connect local-mgmt
FP9300-A(local-mgmt) # exit
FP9300-A #
```

Related Commands	Command	Description
	connect	Connects to another managed object.
	end	Returns to the highest level mode of the CLI.

export-config

To export the current system configuration to a remote server as an XML file, use the **export-config** command.

export-config {*URL* **disabled** | **enabled**}

Syntax Description

URL

Provide the full path to the remote system, including user-account name, transport protocol and file name, for the exported XML image file. The following transport protocols can be used:

- **ftp** : //username@hostname/path/image_name
- **scp** : //username@hostname/path/image_name
- **sftp** : //username@hostname/path/image_name
- **tftp** : //username@hostname/path/image_name

disabled

Disables the policy administrative state; configuration file is not exported.

enabled

Enables the policy administrative state; configuration file is exported immediately.

Command Modes

scope system/

Command History

Release

Modification

1.1.3

Command added.

Usage Guidelines

You can use the configuration export feature to export an XML file containing logical device and platform configuration settings for your Firepower 4100/9300 chassis to a remote server. You can later import that configuration file to quickly apply the configuration settings to your Firepower 4100/9300 chassis to return to a known good configuration or to recover from a system failure.

Please note the following:

- Beginning with FXOS 2.6.1, you must specify a key for use when encrypting sensitive information such as passwords and other secret keys during configuration export, and you must have specified it before you attempt to export the configuration.

Also, the same key used during export must be set on the target system when you import an exported configuration, unless the file was exported from an FXOS release prior to 2.6.1, in which case the target system will not check the encryption key and will allow the import.

- Do not modify the contents of the configuration file. If a configuration file is modified, configuration import using that file might fail.
- Application-specific configuration settings are not contained in the configuration file. You must use the configuration backup tools provided by the application to manage application-specific settings and configurations.

- To avoid overwriting existing back-up files, please be sure to change the file name in the export operation, or copy the existing file to another location.

Depending on the transport protocol, and the remote server configuration, you may have to enter the user's password for connection.

When you export a new configuration file, you are automatically entered into export-config mode (system/export-config) with an asterisk indicating the new file has not yet been exported; enter **commit-buffer** to begin the process.

Example

This example shows how to export an XML file containing logical device and platform configuration settings to a remote server:

```
firepower # scope system
firepower /system # export-config scp://user1@192.168.1.2:/export/cfg-backup.xml enabled
Password:
firepower /system/export-config* # commit-buffer
firepower /system/export-config #
```

Related Commands	Command	Description
	cfg-export-policy	Configures a configuration export policy.
	import-config	Copies a previously exported XML configuration file to this appliance.
	set password-encryption-key	Specifies a key used when encrypting sensitive information during configuration export.

generate password

To generate a fixed-length random password with or without special characters, use the **generate password** command.

generate password *password*

Syntax Description	<i>password</i>	The password to be used by the user when logging in.
Command Modes	scope security	
Command History	Release	Modification
	2.10(1)	Command added.
Usage Guidelines	You can generate a fixed-length random password with or without special characters.	

Example

This example shows how to enter security mode, generate a fixed-length random password with or without special characters:

```
firepower # scope security
firepower # create local-user admin2
firepower /security/local-user #

firepower /security/local-user # generate password
      8-127 Password length

firepower /security/local-user # generate password 10 with
      with-special-char      With Special Char
      without-special-char   Without Special Char

firepower /security/local-user # generate password 10 with-special-char
@!D4%v1wCN
```

Related Commands	Command	Description
	set password	Sets a password for the user account.

import-config

To import a previously exported XML configuration file, use the **import-config** command.

import-config { *URL* **disabled** | **enabled** }

Syntax Description	<i>URL</i>	Provide the full path to the remote system, including transport protocol and file name, for the XML image file to be imported. The following transport protocols can be used: <ul style="list-style-type: none"> • ftp: //username@hostname/path/image_name • scp: //username@hostname/path/image_name • sftp: //username@hostname/path/image_name • tftp: //username@hostname/path/image_name
	disabled	Disables the policy administrative state; configuration file is not imported.
	enabled	Enables the policy administrative state; configuration file is imported immediately.

Command Modes scope system/

Command History	Release	Modification
	2.0.1	Command added.

Usage Guidelines You can use the configuration export feature to export an XML file containing logical device and platform configuration settings for your Firepower 4100/9300 chassis to a remote server. You can later import that configuration file to quickly apply the configuration settings to your Firepower 4100/9300 chassis to return to a known good configuration or to recover from a system failure.

Please note the following:

- Beginning with FXOS 2.6.1, you must specify a key for use when encrypting sensitive information such as passwords and other secret keys during configuration export, and you must have specified it before you attempt to export the configuration.

Also, the same key used during export must be set on the target system when you import an exported configuration, unless the file was exported from an FXOS release prior to 2.6.1, in which case the target system will not check the encryption key and will allow the import.
- Do not modify the contents of the configuration file. If a configuration file is modified, configuration import using that file might fail.
- Application-specific configuration settings are not contained in the configuration file. You must use the configuration backup tools provided by the application to manage application-specific settings and configurations.

- When you import a configuration to a Firepower 4100/9300 chassis, all existing configuration on the chassis (including any logical devices) will be deleted and completely replaced by the configuration contained in the import file.
- We recommend that you only import a configuration file to the same Firepower 4100/9300 chassis from which the configuration was exported.
- The platform software version of the Firepower 4100/9300 chassis to which you are importing should be the same version as when the export was taken. If not, the import operation is not guaranteed to be successful. We recommend that you export a back-up configuration whenever the Firepower 4100/9300 chassis is upgraded or downgraded.
- The Firepower 4100/9300 chassis to which you are importing must have the same Network Modules installed in the same slots as when the export was taken.
- The Firepower 4100/9300 chassis to which you are importing must have the correct software application images installed for any logical devices defined in the export file that you are importing.
- If the configuration file being imported contains a logical device whose application has an End-User License Agreement (EULA), the EULA for that application must be accepted on the Firepower 4100/9300 chassis before importing the configuration or the operation will fail.

Depending on the transport protocol, and the remote server configuration, you may have to enter the remote user password for connection.

You can check the import status and follow its progress by entering the **show fsm status** command; see the following example. You may have to enter the command multiple times as the task progresses.

Example

This example shows how to import an XML file containing logical device and platform configuration settings from a remote server:

```
firepower # scope system
firepower /system # import-config scp://user1@192.168.1.2:/export/cfg-backup.xml enabled
Password:
Warning: After configuration import any changes on the breakout port configuration will
cause the system to reboot
firepower /system* # commit-buffer
firepower /system # show fsm status
```

```
Hostname: 192.168.1.2
```

```
FSM 1:
```

```
Remote Result: Not Applicable
Remote Error Code: None
Remote Error Description:
Status: Import Wait For Switch
Previous Status: Import Config Breakout
Timestamp: 2016-01-03T15:45:03.963
Try: 0
Progress (%): 97
Current Task: updating breakout port
```

```
configuration (FSM-STAGE:sam:dme:MgmtImporterImport:configBreakout)
```

Related Commands	Command	Description
	cfg-export-policy	Configures an export policy.
	export-config	Exports the current system configuration to a remote server as an XML file
	set password-encryption-key	Specifies a key used when encrypting sensitive information during configuration export.

install

To install a reservation authorization code, use the **install** command.

install *code*

Syntax Description	<i>code</i>	The reservation authorization code acquired from the Smart Software Manager.
Command Modes	Reservation (/license/reservation) mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	If you have already generated the authorization code, you must install it.	

Example

This example shows how to install a reservation authorization code:

```
FP9300-A# scope license
FP9300-A /license # scope reservation
FP9300-A /license/reservation # install <code>
FP9300-A /license/reservation* #
```

Related Commands	Command	Description
	request universal	Generates a reservation request code.
	show license	Shows current license information.

install firmware

To install a previously downloaded firmware upgrade package, use the **install firmware** command.

```
install firmware pack-version version_number
```

Syntax Description

pack-version
version_number

Specifies the version of the firmware package to install.

Note The package *version_number* is not the image file name (although it is usually part of the file name). You can use the **show** command to determine the package *version_number*.

Command Modes

Firmware installation mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You must have administrator privileges to use this command. The upgrade installation process typically takes between 20 and 30 minutes, and the system will reboot during the process.

Before initiating installation, review the current critical/major faults and back up the current configuration.

Upgrade is a two-step process: verification of the package, followed by installation. You are asked at the beginning of each step if you want to proceed. If you enter **no** at either prompt, the process is terminated.

You can use the **show detail** command to monitor the installation process.

Example

This example shows how to install a previously downloaded firmware upgrade package:

```
FP9300-A# scope firmware
FP9300-A /firmware # scope firmware-install
FP9300-A /firmware/firmware-install # install firmware pack-version 1.0.16
Verifying FXOS firmware package 1.0.16. Verification could take several minutes.
Do you want to proceed? (yes/no):yes

FXOS SUP ROMMON: Upgrade from 1.0.10 to 1.0.10
FXOS SUP FPGA : Upgrade from 1.04 to 1.05
This operation upgrades SUP firmware on Security Platform.
Here is the checklist of things that are recommended before starting the install operation
(1) Review current critical/major faults
(2) Initiate a configuration backup
Attention:
  The system will be reboot to upgrade the SUP firmware.
  The upgrade operation will take several minutes to complete.
  PLEASE DO NOT POWER RECYCLE DURING THE UPGRADE.
Do you want to proceed? (yes/no):yes
Upgrading FXOS SUP firmware software package version 1.0.10
command executed
```

Related Commands	Command	Description
	scope firmware-install	Enters firmware-installation mode.
	show download-task	Shows information about firmware-package downloads.
	show (firmware-install)	In firmware-installation mode, shows firmware package information.

install platform

To upgrade firmware and software on the security platform components, use the **install platform** command.

install platform **platform-vers** *version_number*

Syntax Description	platform-vers <i>version_number</i>	Specifies the version of the platform package to install.
Command Modes	Auto install (/firmware/auto-install) mode	
Command History	Release	Modification
	1.4(1)	Command added.

Usage Guidelines

You must have administrator privileges to use this command. The upgrade process typically takes between 20 and 30 minutes.

Before initiating installation, review the current critical/major faults and back up the current configuration.

You can use the **show fsm status expand** command in auto-install mode to monitor the installation process.

To complete the upgrade installation process, you must acknowledge the pending reboot of the primary fabric-interconnect.

Example

This example shows how to install a platform upgrade package:

```
FP9300-A# scope firmware
FP9300-A /firmware # scope auto-install
FP9300-A /firmware/auto-install # install platform platform-vers 2.3(1.51)
The currently installed FXOS platform software package is 2.2(2.19)
```

```
INFO: There is no service impact to install this FXOS platform software 2.3(1.51)
```

```
This operation upgrades firmware and software on Security Platform Components
Here is the checklist of things that are recommended before starting Auto-Install
(1) Review current critical/major faults
(2) Initiate a configuration backup
Do you want to proceed? (yes/no):
```

Related Commands	Command	Description
	download image	Downloads an FXOS software image to the Firepower 4100/9300 chassis.
	show validate-task	Displays the status of the image verification process.

mgmt-port (connect local-mgmt)

To display and configure the administrative status of the management port information, use the **mgmt-port** command.

mgmt-port

Syntax Description	mgmt-port	Displays management port information.
Command Modes	connect local-mgmt	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command displays management port information.	

Example

This example shows how to view management port information:

```
firepower#
firepower# connect local-mgmt...

firepower(local-mgmt) #mgmt-port
  <CR>
  no-shut Management port up <===== Administratively enable the chassis management
  interface.
  shut Management port down <===== Administratively disable/shutdown the chassis
  management interface.
```

ping (connect local-mgmt)

To test basic network connectivity by pinging another device on the network with its IPv4 address, use the **ping** command.

```
ping {hostname | IPv4_address} [count number_packets] | [deadline seconds] | [interval
seconds] | [packet-size bytes]
```

Syntax Description		
hostname <i>IPv4_address</i>		The host name or IP address of the network device to be contacted. The maximum number of characters allowed for the host name is 510.
count <i>number_packets</i>		(Optional) The number of ping packets to be sent. The range is 1 to 2147483647 packets.
deadline <i>seconds</i>		(Optional) The maximum time to continue sending packets when no response packets are received; pinging is terminated after this amount of time. The range is 1 to 60 seconds.
interval <i>seconds</i>		(Optional) The interval in seconds between ping packets. The range is 1 to 60 seconds; the default is 1 second.
packet-size <i>bytes</i>		(Optional) The number of data bytes to be added to the ping packet. The range is 1 to 65468 bytes. The default is 56 bytes, which results in a 64-byte packet when added to the 8-byte ICMP header.

Command Modes connect local-mgmt

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to test basic IP connectivity from the chassis management interface to an external network by sending ICMP echo request packets to a specified host.

Example

This example shows how to connect to the local management shell and then ping another device on the network twelve times:

```
firepower# connect local-mgmt
firepower(local-mgmt)# ping 198.51.100.10 count 12
PING 198.51.100.10 (198.51.100.10) from 203.0.113.5 eth0: 56(84) bytes of data.
64 bytes from 198.51.100.10: icmp_seq=1 ttl=61 time=0.264 ms
64 bytes from 198.51.100.10: icmp_seq=2 ttl=61 time=0.219 ms
64 bytes from 198.51.100.10: icmp_seq=3 ttl=61 time=0.234 ms
64 bytes from 198.51.100.10: icmp_seq=4 ttl=61 time=0.205 ms
64 bytes from 198.51.100.10: icmp_seq=5 ttl=61 time=0.216 ms
64 bytes from 198.51.100.10: icmp_seq=6 ttl=61 time=0.251 ms
64 bytes from 198.51.100.10: icmp_seq=7 ttl=61 time=0.223 ms
64 bytes from 198.51.100.10: icmp_seq=8 ttl=61 time=0.221 ms
64 bytes from 198.51.100.10: icmp_seq=9 ttl=61 time=0.227 ms
```

ping (connect local-mgmt)

```

64 bytes from 198.51.100.10: icmp_seq=10 ttl=61 time=0.224 ms
64 bytes from 198.51.100.10: icmp_seq=11 ttl=61 time=0.261 ms
64 bytes from 198.51.100.10: icmp_seq=12 ttl=61 time=0.261 ms

--- 198.51.100.10 ping statistics ---
12 packets transmitted, 12 received, 0% packet loss, time 11104ms
rtt min/avg/max/mdev = 51.005/51.062/51.164/0.064 ms
firepower(local-mgmt)#

```

Related Commands

Command	Description
ping6	Tests basic network connectivity by pinging another device on the network with its IPv6 address.
traceroute	Traces the route to a specified destination (IPv4 address).

ping6 (connect local-mgmt)

To ping another device on the network using its IPv6 address, use the **ping6** command.

```
ping6 {hostname|IPv6_address} [count number_packets] | [deadline seconds] | [interval
seconds] | [mtu-hint {do|dont|want}] | [packet-size bytes]
```

Syntax	Description
hostname <i>IPv6_address</i>	The host name or IP address of the network device to be contacted. The maximum number of characters allowed for the host name is 510.
count <i>number_packets</i>	(Optional) The number of ping packets to be sent. The range is 1 to 2147483647 packets.
deadline <i>seconds</i>	(Optional) The maximum time to continue sending packets when no response packets are received; pinging is terminated after this amount of time. The range is 1 to 60 seconds.
interval <i>seconds</i>	(Optional) The interval in seconds between ping packets. The range is 1 to 60 seconds; the default is 1 second.
mtu-hint { do dont want }	(Optional) Path MTU discovery strategy; hint may be: <ul style="list-style-type: none"> • do—Prohibits fragmentation, even for local packets; sets a do-not-fragment (DF) flag. • dont—Prohibits fragmentation; however, does not set DF flag. • want—Performs PMTU discovery, fragments locally when packet size is large.
packet-size <i>bytes</i>	(Optional) The number of data bytes to be added to the ping packet. The range is 1 to 65468 bytes. The default is 56 bytes, which results in a 64-byte packet when added to the 8-byte ICMP header.

Command Modes	connect local-mgmt
---------------	--------------------

Command History	Release	Modification
	1.1(4)	Command added.

Usage Guidelines Use this command to test basic IPv6 connectivity from the chassis management interface to an external network by sending ICMP echo request packets to a specified host.

Example

This example shows how to connect to the local management shell and then ping another device on the network twelve times:

```
firepower# connect local-mgmt
firepower(local-mgmt)# ping6 2001:DB8:0:ABCD::1 count 12
```

ping6 (connect local-mgmt)

```

PING 2001:DB8:0:ABCD::1 (2001:DB8:0:ABCD::1) from 2001:DB8:1::1 eth0: 56(84) bytes of data.
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=1 ttl=61 time=0.264 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=2 ttl=61 time=0.219 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=3 ttl=61 time=0.234 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=4 ttl=61 time=0.205 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=5 ttl=61 time=0.216 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=6 ttl=61 time=0.251 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=7 ttl=61 time=0.223 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=8 ttl=61 time=0.221 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=9 ttl=61 time=0.227 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=10 ttl=61 time=0.224 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=11 ttl=61 time=0.261 ms
64 bytes from 2001:DB8:0:ABCD::1: icmp_seq=12 ttl=61 time=0.261 ms

--- 2001:DB8:0:ABCD::1 ping statistics ---
12 packets transmitted, 12 received, 0% packet loss, time 11104ms
rtt min/avg/max/mdev = 51.005/51.062/51.164/0.064 ms
firepower(local-mgmt)#

```

Related Commands

Command	Description
ping	Tests basic network connectivity by pinging another device on the network with its IPv4 address.
traceroute6	Traces the route to a specified destination (IPv6 address).

power

To power a module off or on, use the **power** command.

power { **down** [**soft-followed-by-hard** | **soft-shut-down**] | **up** }

Syntax Description

soft-followed-by-hard	(Optional) You can use this keyword to “gracefully” power down the module, waiting up to 45 minutes for the SSP operating system to shut down, after which the module is powered down regardless of the OS shut-down state.
soft-shut-down	(Optional) You can use this keyword to gracefully power down the module, with the system waiting indefinitely for the SSP operating system to shut down. The module is powered down only after the SSP OS is successfully shut down.

Command Modes

Service profile mode

Command History

Release	Modification
---------	--------------

1.1(1)	Command added.
--------	----------------

Usage Guidelines

If you do not include one of the optional keywords with the **power down** command, the module is powered down immediately, without gracefully shutting down the module’s operating system.

We recommend backing up the module configuration before powering down.

Example

This example shows how to enter service profile mode and then power down the module with a soft shut-down:

```
FP9300-A # scope service-profile server 1/1
FP9300-A /org/service-profile # power down soft-shut-down
FP9300-A /org/service-profile* # commit-buffer
FP9300-A /org/service-profile #
```

Related Commands

Command	Description
shutdown	Shuts down the device.

reboot

To restart the chassis or the fabric-interconnect, use the **reboot** command.

```
(local-mgmt) # reboot
```

```
/chassis # reboot [no-prompt|reason]
```

Syntax Description

In local management mode, this command has no arguments or keywords.

no-prompt

(Optional) In chassis mode, you can use this keyword to initiate reboot immediately. Otherwise, a **commit-buffer** is required to initiate reboot.

reason

(Optional) In chassis mode, you can enter a text string to be appended to the reboot log; can be up to 510 characters.

Command Modes

Chassis mode

Local management mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

We recommend backing up the system configuration before rebooting.

In local management mode, this command has no keywords or options.



Note We recommend using this command in chassis mode, as it performs a “graceful” system shut-down and restart.

Examples

This example shows how to enter a local management shell and reboot the system:

```
FP9300-A # connect local-mgmt
FP9300-A (local-mgmt) # reboot
Before rebooting, please take a configuration backup.
Do you still want to reboot? (yes/no)::yes
nohup: ignoring input and appending output to `nohup.out'

Broadcast message from root (Fri Apr 13 17:12:49 2018):

All shells being terminated due to system /sbin/reboot
```

This example shows how to enter chassis mode and reboot the system:

```
FP9300-A # scope chassis 1
FP9300-A /chassis # reboot
This command will reboot the chassis when committed
```



```
FP9300-A /chassis* # commit-buffer
Starting chassis shutdown. Monitor progress with the command "show fsm status"
System is safe to power off after "System halted." message is seen
FP9300-A /chassis #
Broadcast message from root@DOC-FP9300-A (Fri Apr 13 16:27:04 2018):

All shells being terminated due to system /sbin/shutdown
```

Related Commands

Command	Description
shutdown	Shuts down the device.

reinstall

To modify bootstrap settings for a logical device, reinstall the application instance using the **reinstall** command.

reinstall

Syntax Description

This command has no arguments or keywords.

Command Modes

scope slot/scope app/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You can modify bootstrap settings for a logical device. You can reinstall the application instance using those new settings or save the changes and reinstall the application instance using those new settings at a later time.

Example

This example shows how to enter license/licdebug mode and manually renew the Smart Software ID certificate and license entitlement.

```
FP9300-A # scope slot 2
FP9300-A /slot # scope app-instance asa cluster1
FP9300-A /slot/app-instance # reinstall app
FP9300-A /slot/app-instance # Do you want to reinstall the app now [Y/N]? Y
...
```

Related Commands

Command	Description
register	Modifies bootstrap settings for a logical device to restart the application instance.

register

To register a Smart Software Manager account on this Firepower 4100/9300 device, use the **register** command.

```
register idtoken id_token
```

Syntax Description	<i>id_token</i>	The registration token acquired from the Smart Software Manager Satellite.
Command Modes	License (/license) mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Request and copy the registration token from the Smart Software Manager or the Smart Software Manager Satellite. See the Cisco Smart Software Manager Satellite User Guide for more information.	

Example

This example shows how to register this device.

```
FP9300-A # scope license
FP9300-A /license # register idtoken ZGFmNWM5NjgtYmNjYS00ZWl3L
WE3NGItMWJkOGExZjIxNGQ0LTE0NjI2NDYx%0AMDIZNT
V8N3R0dXMlZ0NjWkdP214eFZhMldBOS9CVnNEYnVKMl
FP9300-A /license #
```

Related Commands	Command	Description
	deregister	Deregistering removes the device from your account; all license entitlements and certificates on the device are removed.

reinitialize

To completely reformat a module, use the **reinitialize** command.

reinitialize

Syntax Description	This command has no arguments or keywords.	
Command Modes	Slot mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Reinitializing a module completely erases all stored application data. Please back up all running configuration files before issuing the commit-buffer command.	

Example

This example shows how to reinitialize the module in slot 2.

```
FP9300-A # scope ssa
FP9300-A /ssa # scope slot 2
FP9300-A /ssa/slot # reinitialize
Warning: Reinitializing blade takes a few minutes. All the application data on blade will
get lost. Please backup application running config files before commit-buffer.
FP9300-A /ssa/slot* #
```

Related Commands	Command	Description
	decommission	Decommissions a server.

remove server

To remove a previously decommissioned server from the device inventory, use the **remove server** command.

```
remove server {id | chassis_id/blade_id}
```

Syntax Description

id The slot number. The range of valid values is 1 to 255.

chassis_id/blade_id The server chassis and blade numbers, in n/n format.

Note The chassis number is always 1.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

When using this command in chassis mode, you need to specify only the slot ID number.

Example

This example shows how to remove a decommissioned server:

```
FP9300-A# remove server 1/1
FP9300-A* # commit-buffer
FP9300-A#
```

Related Commands

Command	Description
decommission server	Decommissions a server.
show server decommissioned	Shows decommissioned server(s).

renew

To manually renew the Smart Software registration certificate and update the entitlements on all security modules, use the **renew** command.

renew

Syntax Description

This command has no arguments or keywords.

Command Modes

License debug (/license/licdebug) mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

By default, the ID certificate is automatically renewed every six months, and the license entitlement is renewed every 30 days. You might manually renew the registration for either of these items if you have a limited window for Internet access, for example, or if you make any licensing changes in the Smart Software Manager.

Example

This example shows how to enter license/licdebug mode and manually renew the Smart Software ID certificate and license entitlement.

```
FP9300-A # scope license
FP9300-A /license # scope licdebug
FP9300-A /license/licdebug # renew
FP9300-A /license/licdebug #
```

Related Commands

Command	Description
register	Registers a Smart Software Manager account on this Firepower 4100/9300 device.

reset-password

To enforce the user to change the user password, use the **reset-password** command.

reset-password *password*

Syntax Description	<i>password</i>	The password to be used by the user when logging in.
Command Modes	scope security	
Command History	Release	Modification
	2.10(1)	Command added.
Usage Guidelines	You can enforce the user to change the user password at the next login.	

Example

This example shows how to enter security mode and then reset the password:

```
firepower# scope security
firepower# create local-user admin2
firepower /security/local-user # set
  account-status Account status
  email           Email
  expiration      User account expiration
  firstname       FirstName
  lastname        LastName
  password        Password
  phone           Phone
  reset-password  Change password at next login

firepower /security/local-user # set reset-password
no No
yes Yes
```

Related Commands	Command	Description
	set password	Sets a password for the user account.
	generate password	Generates a password for the user account.

request universal

To generate a reservation request code, use the **request universal** command.

request universal

Syntax Description	This command has no arguments or keywords.	
Command Modes	Reservation (/license/reservation) mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	<p>Before you begin, you must purchase the permanent licenses so they are available in Smart Software Manager. Not all accounts are approved for permanent license reservation. Make sure you have approval from Cisco for this feature before you attempt to configure it.</p> <p>Enable license reservation before attempting to assign a permanent license to your Firepower 4100/9300 chassis.</p> <p>After issuing this command, use show license resvcode to view the generated reservation request, authorization and return codes.</p>	

Example

This example shows how to generate a reservation request code and view the generated codes:

```

FP9300-A# scope license
FP9300-A /license # scope reservation
FP9300-A /license/reservation # request universal
FP9300-A /license/reservation # show license resvcode
Warning : generating the reservation code takes a few seconds.
Please run the 'show license resvcode' again if the code is not available.
Reservation request code :
<empty>
Reservation authorization code :
<empty>
Reservation return code :
<empty>

```

Related Commands	Command	Description
	enable reservation	Enables permanent license reservation.
	show license	Shows current license information.

restart

To modify bootstrap settings for a logical device, restart the application instance using the **restart** command.

restart

Syntax Description

This command has no arguments or keywords.

Command Modes

scope slot/scope app/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You can modify bootstrap settings for a logical device. You can then immediately restart the application instance using those new settings or save the changes and restart the application instance using those new settings at a later time.

This example shows how to restart an application:

```
FP9300-A # scope slot 2
FP9300-A /slot # scope app-instance asa cluster1
FP9300-A /slot /app-instance # restart app
FP9300-A /slot /app-instance # Do you want to restart now [Y/N]? Y
```

Related Commands

Command	Description
reinstall	Reinstalls the application instance.

return

To generate a permanent license return code, use the **return** command.

return [*code*]

Syntax Description

code (Optional) A license code acquired from the Smart Software Manager.

Command Modes

Reservation (/license/reservation) mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

If you no longer need a permanent license, you must officially return it to the Smart Software Manager. If you do not, the license stays in an in-use state and cannot be used elsewhere.

When you enter this command, the Firepower 4100/9300 chassis immediately becomes unlicensed and moves to the Evaluation state.

To complete the return, go to <https://software.cisco.com/#SmartLicensing-Inventory>, locate your Firepower 4100/9300 chassis using its universal device identifier (UDI), and then remove the product instance.

Example

This example shows how to return a permanent license:

```
FP9300-A# scope license
FP9300-A /license # scope reservation
FP9300-A /license/reservation # return
FP9300-A /license/reservation #
```

Related Commands

Command	Description
show license udi	Shows the FXOS universal device identifier (UDI) so you can find your FXOS instance in the Smart Software Manager.



PART II

S Commands

- [scope Commands, on page 179](#)
- [set Commands, on page 247](#)
- [sh Commands, on page 379](#)



scope Commands

- [scope](#), on page 181
- [scope adapter](#), on page 183
- [scope app-software](#), on page 184
- [scope auto-install](#), on page 185
- [scope auto-macpool](#), on page 186
- [scope banner](#), on page 188
- [scope cabling](#), on page 189
- [scope callhome](#), on page 190
- [scope card](#), on page 191
- [scope cfg-export-policy](#), on page 192
- [scope cfg-export-reminder](#), on page 193
- [scope chassis](#), on page 194
- [scope cloud-connector](#), on page 195
- [scope default-auth](#), on page 196
- [scope environment-features](#), on page 197
- [scope eth-uplink](#), on page 198
- [scope export-config](#), on page 199
- [scope fabric](#), on page 200
- [scope fabric-interconnect](#), on page 201
- [scope fan-module](#), on page 202
- [scope faulty-policy](#), on page 203
- [scope firmware](#), on page 204
- [scope firmware-install](#), on page 205
- [scope flow-control](#), on page 206
- [scope health monitoring policy](#), on page 207
- [scope hw-crypto](#), on page 209
- [scope import-config](#), on page 211
- [scope info-policy](#), on page 212
- [scope interface](#), on page 213
- [scope ipsec](#), on page 215
- [scope ipv6-config](#), on page 216
- [scope ldap](#), on page 217
- [scope licdebug](#), on page 218

- [scope license](#), on page 219
- [scope mem-leak-logging](#), on page 220
- [scope monitoring](#), on page 221
- [scope network-features](#), on page 222
- [scope org](#), on page 223
- [scope packet-capture](#), on page 224
- [scope password-profile](#), on page 225
- [scope profile](#), on page 226
- [scope radius](#), on page 227
- [scope reservation](#), on page 228
- [scope security](#), on page 229
- [scope server](#), on page 230
- [scope server-features](#), on page 231
- [scope service-profile](#), on page 232
- [scope services](#), on page 233
- [scope slot](#), on page 234
- [scope ssa](#), on page 235
- [scope stats-collection-policy](#), on page 236
- [scope stats-threshold-policy](#), on page 238
- [scope storage-features](#), on page 240
- [scope system](#), on page 241
- [scope tacacs](#), on page 242
- [scope telemetry](#), on page 243
- [scope vnic](#), on page 244
- [sub scopes \(scope fabric-interconnect\)](#), on page 245

scope

To “scope into” (enter) an existing managed object, use the relevant **scope** command in the appropriate command mode.

```
scope object_type name [parameters]
```

Syntax Description	<p><i>object_type</i> The type of object to be entered. Examples include local user account and organization.</p> <p><i>name</i> The name of the specific object to be entered.</p> <p><i>parameters</i> (Optional) Any additional properties or parameters needed to identify the object. With this command, the <i>name</i> is generally sufficient to identify an object. Refer to the description of the create command for the specific object type for more information.</p>
Command Modes	Depends on the type of object being scoped into; refer to the description of the create command for the specific object type for more information.
Command History	Refer to the description of the create command for the specific object type for history information.
Usage Guidelines	<p>Objects are abstract representations of physical components or logical entities that can be managed. For example, the chassis, security modules, network modules, ports, and processors are physical components represented as managed objects, while licenses, user roles, and platform policies are logical entities represented as managed objects.</p> <p>FXOS provides four general commands for managing objects: create, delete, enter, and scope. For example, you can create a local user account, you can delete a local user account, and you can enter a local user account to assign or change properties for that account; you also can “scope into” the local user account to assign or change properties.</p> <p>Generally, the keywords and options available to each of these object-management commands are the same, so we detail only the create version of the various object commands. In other words, for information about the delete command for a particular object, refer to the description of the create command for that object. For example, refer to create local-user, on page 82 for information related to scoping into an existing local user account.</p>

Example

This example shows how to enter security mode, scope into a local user account and display account details:

```
firepower # scope security
firepower /security # scope local-user test_user
firepower /security/local-user # show detail
Local User test_user:
  First Name: test
  Last Name: user
  Email: test_user@testuser.com
  Phone:
```

```
Expiration: Never
Password: ****
User lock status: Not Locked
Account status: Active
User Roles:
  Name: admin
  Name: read-only
User SSH public key:
firepower /security/local-user #
```

Related Commands

Command	Description
create local-user	Creates a new local user account.
enter local-user	Adds or edits a local user account.
delete local-user	Deletes an existing local user account.

scope adapter

To enter adapter mode, use the **scope adapter** command.

scope adapter {*rack_server/id* | *chassis/server/id*}

Syntax Description		
<i>rack_server/id</i>		The adapter location specified using the rack-server and adapter IDs entered in n/n format.
<i>chassis/server/id</i>		The adapter location specified using the chassis, server and adapter IDs entered in n/n/n format.
	Note	The chassis ID is always 1.

Command Modes EXEC mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines In adapter mode, you can activate or update a firmware version, view a variety of adapter-specific data, and scope into host and external Ethernet interfaces.

Example

This example shows how to enter adapter mode using the chassis, server and adapter IDs:

```
firepower# scope adapter 1/1/1
firepower /chassis/server/adapter #
```

Related Commands	Command	Description
	connect adapter	Connects to the command shell for a specific adapter.
	scope chassis	Enters chassis mode.

scope app-software

To enter application software mode, use the **scope app-software** command.

scope app-software

Syntax Description

This command has no arguments or keywords.

Command Modes

scope ssa/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You can use the **download image** command in application software mode to copy a logical device software image to the Firepower 4100/9300 chassis.

Example

This example shows how to enter application software mode:

```
firepower# scope ssa
firepower /ssa # scope app-software
firepower /ssa/app-software #
```

Related Commands

Command	Description
download image	Copies a logical device software image to the Firepower 4100/9300 chassis.
show download-task	Shows progress of the image file download.

scope auto-install

To enter automatic installation mode for infrastructure updates, use the **scope auto-install** command.

scope auto-install

Syntax Description

This command has no arguments or keywords.

Command Modes

Firmware (/firmware) mode

Command History

Release	Modification
1.4(1)	Command added.

Usage Guidelines

None

Example

This example shows how to enter firmware mode and then auto-install mode:

```
FP9300-A# scope firmware
FP9300-A /firmware # scope auto-install
FP9300-A /firmware/auto-install #
```

Related Commands

Command	Description
install platform	Upgrades UCS Infra components (UCSM, FI and IOM) to infra version specified.

scope auto-macpool

To manage the MAC address pool for container instance interface , use the **scope auto-macpool** command.

scope auto-macpool

Syntax Description	This command has no arguments or keywords.	
Command Modes	scope ssa/	
Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines The FXOS chassis automatically generates MAC addresses for container instance interfaces, and guarantees that a shared interface in each instance uses a unique MAC address.

If you manually assign a MAC address to a shared interface within the application, then the manually-assigned MAC address is used. If you later remove the manual MAC address, the autogenerated address is used. In the rare circumstance that the generated MAC address conflicts with another private MAC address in your network, we suggest that you manually set the MAC address for the interface within the application.

Because autogenerated addresses start with A2, you should not start manual MAC addresses with A2 due to the risk of overlapping addresses.



Note Even if you are not sharing a subinterface, if you manually configure MAC addresses, make sure you use unique MAC addresses for all subinterfaces on the same parent interface to ensure proper classification.

The FXOS chassis generates the MAC address using the following format:

A2xx.yyzz.zzzz

Where *xx.yy* is a user-defined prefix or a system-defined prefix, and *zz.zzzz* is an internal counter generated by the chassis. The system-defined prefix matches the lower 2 bytes of the first MAC address in the burned-in MAC address pool that is programmed into the IDPROM. Use **connect fxos**, then **show module** to view the MAC address pool. For example, if the range of MAC addresses shown for module 1 is b0aa.772f.f0b0 to b0aa.772f.f0bf, then the system prefix will be f0b0.

The user-defined prefix is an integer that is converted into hexadecimal. For an example of how the user-defined prefix is used, if you set a prefix of 77, then the chassis converts 77 into the hexadecimal value 004D (yyxx). When used in the MAC address, the prefix is reversed (xxyy) to match the chassis native form:

A24D.00zz.zzzz

For a prefix of 1009 (03F1), the MAC address is:

A2F1.03zz.zzzz

Example

This example shows how to enter mac-pool mode:

```
firepower# scope ssa
firepower /ssa # scope auto-macpool
firepower /ssa/auto-macpool #
```

Related Commands

Command	Description
scope ssa	Enters ssa mode.
set prefix	Sets the MAC address prefix.
show mac-address	Shows the assigned MAC addresses.

scope banner

To enter banner-management mode, use the **scope banner** command.

scope banner

Syntax Description

This command has no arguments or keywords.

Command Modes

scope security/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

In this mode, you can manage the banner presented by the appliance prior to user log-in.

Example

This example shows you how to enter banner mode and view the current pre-login banner:

```
firepower # scope security
firepower /security # scope banner
firepower /security/banner # show pre-login-banner

Pre login banner:
  Message
  -----
  Firepower-9300-2
  Western Data Center

firepower /security/banner #
```

Related Commands

Command	Description
clear message	Removes the text from an existing pre-login banner; the actual banner object itself is not deleted.
create pre-login-banner	Creates a banner to be presented prior to the log-in screen; the banner object is initially empty.
set message	Adds or replaces the lines of text presented as the pre-login banner.

scope cabling

To enter cabling mode, use the **scope cabling** command.

scope cabling

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You can access fabric mode from cabling mode, where you can view and manage port breakouts.

Example

This example shows how to enter cabling mode:

```
FP9300-A # scope cabling
FP9300-A /cabling #
```

Related Commands

Command	Description
scope fabric-interconnect	Enter fabric interconnect mode.

scope callhome

To enter callhome mode, use the **scope callhome** command.

scope callhome

Syntax Description

This command has no arguments or keywords.

Command Modes

Monitoring mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter callhome mode from monitoring mode:

```
FP9300-A#scope monitoring
FP9300-A /monitoring # scope callhome
FP9300-A /monitoring/callhome #
```

Related Commands

Command	Description
show callhome	Shows Call Home configuration and status information.

scope card

To enter administrative mode for a specific fabric card, use the **scope card** command.

scope card *card_ID*

Syntax Description	<i>card_ID</i>	The fabric card's numeric identifier.
Command Modes	scope fabric-interconnect/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	In card mode, you can take the fabric card offline or online.	

Example

This example shows how to enter card mode and view available commands:

```
firepower# scope fabric-interconnect
firepower /fabric-interconnect # scope card 2
firepower /fabric-interconnect/card # ?
  acknowledge  Acknowledge
  scope        Changes the current mode
  set          Set property values
  show         Show system information

firepower /fabric-interconnect/card #
```

Command	Description
set adminstate	Takes a fabric card offline or online.

scope cfg-export-policy

To enter the configuration export policy, use the **scope cfg-export-policy** command.

scope cfg-export-policy*name*

Syntax Description	<i>name</i>	The name of the configuration export policy to enter. You cannot create or delete a configuration export policy. You can only configure the existing default policy; enter default as the policy name.
---------------------------	-------------	--

Command Modes	scope org/
----------------------	------------

Command History	Release	Modification
	2.0.1	Command added.

Usage Guidelines	You cannot create or delete a configuration export policy; you can only configure the existing default policy.
-------------------------	--

Example

This example shows how to enter the configuration export policy and view the details of its current settings:

```
firepower # scope org
firepower /org # scope cfg-export-policy default
firepower /org/cfg-export-policy # show detail
Config Export policy:
  Name: default
  Description: Configuration Export Policy
  Admin State: Enable
  Protocol: Ftp
  Hostname: 192.168.1.2
  User: user1
  Remote File: /export/cfg-backup.xml
  Schedule: Daily
  Port: Default
  Current Task:
firepower /org/cfg-export-policy #
```

Related Commands	Command	Description
	export-config	Exports the current system configuration to a remote server as an XML file; creates an export-configuration object.
	import-config	Copies a previously exported XML configuration file to this appliance.
	set password-encryption-key	Specifies a key used when encrypting sensitive information during configuration export.

scope cfg-export-reminder

To enter the configuration-export reminder object, use the **scope cfg-export-reminder** command.

scope cfg-export-reminder

Syntax Description	This command has no arguments or keywords.	
Command Modes	scope org/	
Command History	Release	Modification
	2.0.1	Command added.
Usage Guidelines	You cannot create or delete a configuration-export reminder object; you can only configure the existing reminder object.	

Example

This example shows how to enter the configuration-export reminder object and view its current settings:

```
firepower # scope org
firepower /org # scope cfg-export-reminder
firepower /org/cfg-export-reminder # show
```

```
Config Export Reminder:
  Config Export Reminder (Days): 30
  AdminState: Enable
firepower /org/cfg-export-reminder #
```

Related Commands	Command	Description
	import-config	Copies a previously exported XML configuration file to this appliance.
	scope cfg-export-policy	Enters the configuration export policy.
	set password-encryption-key	Specifies a key used when encrypting sensitive information during configuration export.

scope chassis

To enter chassis mode, use the **scope chassis** command.

scope chassis *chassis_id*

Syntax Description	<i>chassis_id</i>	Chassis identification number. This value is always 1 .
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter chassis mode:

```
firepower# scope chassis 1
firepower /chassis #
```

Related Commands	Command	Description
	show chassis	Shows chassis information.

scope cloud-connector

To enter cloud connector mode, use the **scope cloud-connector** command.

scope cloud-connector

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to enter cloud connector mode:

```
FP9300-A # scope cloud-connector  
FP9300-A /cloud-connector #
```

Related Commands

Command	Description
show cloud-connector	Shows cloud connector configuration information.

scope default-auth

To enter default authentication mode, use the **scope default-auth** command.

scope default-auth

Syntax Description

This command has no arguments or keywords.

Command Modes

Security mode

Authentication domain (/security/auth-domain)

Command History

Release	Modification
1.4(1)	Command added.

Usage Guidelines

Use the **set** commands in this mode to configure default authentication parameters such as authentication service and session timeout values.

An authentication domain must be created prior to using this command to enter the default authentication mode for a domain.

Example

This example shows how to enter security mode and then default authentication mode:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth #
```

Related Commands

Command	Description
set realm	Sets the default authentication service.
show	Shows default authentication settings.

scope environment-features

To enter environment features in configuration mode, use the **scope environment-features** command.

scope environment-features

Syntax Description	This command has no arguments or keywords.	
Command Modes	Scope system	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	

Example

This example shows how to enter environment features mode:

```
firepower # scope system
firepower /system # scope environment-features
firepower /system/environment-features # show
```

Related Commands	Command	Description
	show	Shows the information about the domain environment features.

scope eth-uplink

To enter Ethernet uplink mode, use the **scope eth-uplink** command.

scope eth-uplink

Syntax Description	This command has no arguments or keywords.	
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter Ethernet uplink mode:

```
firepower#scope eth-uplink
firepower /eth-uplink #
```

Related Commands	Command	Description
	show	Shows Ethernet uplink information.

scope export-config

To enter an existing export-configuration object, use the **scope export-config** command.

scope export-config*hostname*

Syntax Description	<i>hostname</i>	The identifier of the export-configuration object; this is the name or IP address of the remote server on which the configuration was backed up.
---------------------------	-----------------	--

Command Modes	scope system/
----------------------	---------------

Command History	Release	Modification
	1.1.(1)	Command added.

Usage Guidelines An export-configuration object is created when you issue an **export-config** command to back up the current logical device and platform configuration, and **scope export-config** is used to enter the object and edit its parameters—there are no **create** or **enter** commands associated with export-configuration objects. There is a **delete** command available which you can use to delete an export-configuration object.

Example

This example shows how to scope into a previously exported configuration object:

```
firepower # scope system
firepower /system # scope export-config 192.168.1.2
firepower /system/export-config #
```

Related Commands	Command	Description
	cfg-export-policy	Configures a configuration export policy.
	delete export-config	Deletes an existing export-configuration object.
	export-config	Exports the current system configuration to a remote server as an XML file; creates an export-configuration object.

scope fabric

To enter fabric mode, use the **scope fabric** command.

scope fabric [**a**]

Syntax Description	a	Specifies Fabric A. There is only one fabric on Firepower devices. Use of this keyword is optional.
--------------------	---	---

Command Modes scope eth-uplink/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines In fabric mode, you can manage interfaces, port-channels, aggregate interfaces, and VLANs.

Example

This example shows how to enter fabric mode:

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric #
```

Related Commands	Command	Description
	show interface	In fabric mode, lists information for all device interfaces.
	show port-channel	In fabric mode, lists information and status for all port-channels.

scope fabric-interconnect

To enter fabric interconnect mode, use the **scope fabric-interconnect** command.

scope fabric-interconnect a

Syntax Description	a	Specifies Fabric A. There is only one fabric on Firepower devices.
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter fabric interconnect mode:

```
firepower# scope fabric-interconnect a
firepower /fabric-interconnect #
```

Related Commands	Command	Description
	show fabric-interconnect	Shows fabric interconnect information.

scope fan-module

To enter a specific fan module, use the **scope fan-module** command in chassis mode.

scope fan-module {**1** *module_id*}

Syntax Description		
<i>tray_id</i>		The <i>tray_id</i> is always 1 .
<i>module_id</i>		Identifies the specific fan module to enter; value can be 1 through 8.

Command Modes scope chassis/

Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to scope into fan-module mode:

```
firepower# scope chassis
firepower /chassis # scope fan-module 1 2
firepower /chassis/fan-module #
```

Related Commands	Command	Description
	scope fan	Scopes into a specific fan.

scope faulty-policy

To enter the fault policy for one of the functional areas of the system, use the **scope faulty policy** command.

scope faulty policy

Syntax Description	This command has no arguments or keywords.	
Command Modes	scope monitoring	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	
Related Commands	Command	Description
	Show detail	Shows the detailed fault policy information of the system.
	Set Ack-action	Specifies acknowledge action.
	Set Clear-action	Specifies Clear action.
	Set Clear-interval	Specifies Clear interval.
	Set Flap-interval	Specifies Flap interval.
	Set Retention-interval	Specifies Retention interval. (dd:hh:mm:ss)

scope firmware

To enter firmware mode, use the **scope firmware** command.

scope firmware

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter firmware mode:

```
firepower# scope firmware
firepower /firmware #
```

Related Commands

Command	Description
show server firmware	Shows server firmware information.
show server version	Shows server firmware version.

scope firmware-install

To enter firmware-installation mode, use the **scope firmware-install** command.

scope firmware-install

Syntax Description	This command has no arguments or keywords.	
Command Modes	Firmware mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this scope to update system firmware with a previously downloaded firmware package.	

Example

This example shows how to enter firmware-installation mode:

```
FP9300-A# scope firmware
FP9300-A /firmware # scope firmware-install
FP9300-A /firmware-install #
```

Related Commands	Command	Description
	download image	Downloads a firmware package.
	install firmware	Installs a firmware package.

scope flow-control

To enter flow-control mode, use the **scope flow-control** command.

scope flow-control

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	scope eth-uplink/
----------------------	-------------------

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines	Flow-control policies determine whether the Ethernet ports send and receive IEEE 802.3x pause frames when the receive buffer for a port fills. These pause frames request that the transmitting port stop sending data for a few milliseconds until the buffer clears. For flow control to work between devices, you must enable the corresponding send and receive flow-control parameters for both devices.
-------------------------	---

The `default` flow-control policy disables send and receive control, and sets the priority to auto-negotiate.

Example

The following example shows how to scope into flow-control mode and view current policy information:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope flow-control
firepower /eth-uplink/flow-control # show policy detail
Flowctrl policy:
  Name: default
  receive: Off
  send: Off
  Prio: Auto
firepower /eth-uplink/flow-control #
```

Related Commands	Command	Description
	create policy	Adds a new named flow-control policy.
	set	In flow-control/policy mode, sets flow-control policy properties.
	show policy	Shows property values for a flow-control policy.

scope health monitoring policy

Memory usage metrics

Memory stats collected can be enabled or disabled using the cli under **scope** 'stats-collection-memory'. By default, it is enabled.

Also fault threshold can be set for all memory monitoring faults. The threshold-value can range between 50-99. By default, it is set at 95%.

```
scope health-monitoring-policy
scope stats-collection-memory
enable | disable
set fault-threshold <threshold-value>
```

Command Modes	Monitoring mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>2.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	2.11.1	This command was introduced.
Release	Modification				
2.11.1	This command was introduced.				
Usage Guidelines	This command enables or disables memory monitoring and also changes the fault threshold value for all the memory monitoring faults.				

Example

```
firepower# scope monitoring
firepower /monitoring # scope health-monitoring-policy
firepower /monitoring/health-monitoring-policy # scope stats-collection-memory
firepower /monitoring/health-monitoring-policy/stats-collection-memory # set fault-threshold
75
firepower /monitoring/health-monitoring-policy/stats-collection-memory # disable
firepower /monitoring/health-monitoring-policy/stats-collection-memory* # commit-buffer
firepower /monitoring/health-monitoring-policy/stats-collection-memory # show
Memory stats collection policy:
Admin State Fault-Threshold (%)
-----
Disabled 75
firepower /monitoring/health-monitoring-policy/stats-collection-memory # show detail
Admin State: Disabled
Fault Threshold (%): 75
```

CPU usage metrics

CPU stats collected can be enabled or disabled using the cli under scope 'stats-collection-cpu'. By default it is enabled.

Also fault threshold can be set for all cpu monitoring faults. The threshold-value can range between 50-99. By default it is set at 90%.

```
scope health-monitoring-policy
scope stats-collection-cpu
```

enable | disable
set fault-threshold <threshold-value>

Command Modes Monitoring mode

Command History	Release	Modification
	2.11.1	This command was introduced.

Usage Guidelines This command enables or disables CPU monitoring and also changes the fault threshold value for all the CPU monitoring faults.

Example

```
firepower# scope monitoring
firepower /monitoring # scope health-monitoring-policy
firepower /monitoring/health-monitoring-policy # scope stats-collection-cpu
firepower /monitoring/health-monitoring-policy/stats-collection-cpu # set fault-threshold
85
firepower /monitoring/health-monitoring-policy/stats-collection-cpu # enable
firepower /monitoring/health-monitoring-policy/stats-collection-cpu * # commit-buffer
firepower /monitoring/health-monitoring-policy/stats-collection-cpu # show
Cpu stats collection policy:
Admin State Fault-Threshold (%)
-----
Enabled 85
firepower /monitoring/health-monitoring-policy/stats-collection-cpu # show detail
Admin State: Enabled
Fault Threshold (%): 85
```

scope hw-crypto

To enable or disable TLS crypto acceleration on a container instance, use the **scope hw-crypto** command. For more information about TLS crypto acceleration, see the *Management Center Configuration Guide*.

scope hw-crypto

Command Modes connect module

Command History	Release	Modification
	2.7.1	This command was introduced.

Usage Guidelines This command enables or disables TLS crypto acceleration on a container instance.

Examples

Following is an example of enabling TLS crypto acceleration on a container instance:

```
scope ssa
/ssa # show app-instance
```

App Name	Identifier	Slot ID	Admin State	Oper State	Running Version	Startup Version
Deploy Type	Turbo Mode	Profile	Name	Cluster State	Cluster Role	
ftd	FTD-FDM	1	Enabled	Online	6.5.0.1159	6.5.0.1159
	Native	No		Not Applicable	None	
ftd	ftd2	2	Enabled	Online	6.5.0.1159	6.5.0.1159
	Container	No	Default-Small	Not Applicable	None	

```

/ssa # sc slot 2
/ssa/slot # scope app-instance ftd ftd2
/ssa/slot/app-instance # scope hw-crypto
/ssa/slot/app-instance/hw-crypto # set admin-state enabled
/ssa/slot/app-instance/hw-crypto* # commit-buffer

```

Following is an example of disabling TLS crypto acceleration on a container instance:

```
scope ssa
/ssa # show app-instance
```

App Name	Identifier	Slot ID	Admin State	Oper State	Running Version	Startup Version
Deploy Type	Turbo Mode	Profile	Name	Cluster State	Cluster Role	
ftd	FTD-FDM	1	Enabled	Online	6.5.0.1159	6.5.0.1159
	Native	No		Not Applicable	None	
ftd	ftd2	2	Enabled	Online	6.5.0.1159	6.5.0.1159
	Container	No	Default-Small	Not Applicable	None	

```

/ssa # sc slot 2
/ssa/slot # scope app-instance ftd ftd2
/ssa/slot/app-instance # scope hw-crypto
/ssa/slot/app-instance/hw-crypto # set admin-state disbled
/ssa/slot/app-instance/hw-crypto* # commit-buffer

```

Related Commands	Command	Description
	create hw-crypto	Create a TLS crypto acceleration configuration for a container instance.
	delete hw-crypto	Delete a TLS crypto acceleration configuration for a container instance.
	show hw-crypto	Displays status of TLS crypto acceleration configuration on a container instance.

scope import-config

To enter an existing import-configuration object, use the **scope import-config** command.

scope import-config*hostname*

Syntax Description	<i>hostname</i>	The identifier of the import-configuration object; this is the name or IP address of the remote server on which the configuration resides.
---------------------------	-----------------	--

Command History	Release	Modification
	1.1.(1)	Command added.

Usage Guidelines An export-configuration object is created when you issue an **export-config** command to back up the current logical device and platform configuration; the **import-config** command is used to import a previously exported configuration file, while simultaneously creating an import-configuration object.

You can use **scope import-config** to enter an existing import-configuration object and edit its parameters. There are no **create** or **enter** commands associated with import-configuration objects. There is a **delete** command available which you can use to delete an import-configuration object.

Example

This example shows how to scope into an existing import-configuration object:

```
firepower # scope system
firepower /system # scope import-config 192.168.1.2
firepower /system/import-config #
```

Related Commands	Command	Description
	cfg-export-policy	Configures a configuration export policy.
	delete import-config	Deletes an existing import-configuration object.
	import-config	Imports previously exported system configuration from a remote server; creates an import-configuration object.

scope info-policy

To enter system info policies in configuration mode, use the **scope info-policy** command.

scope info-policy

Syntax Description

This command has no arguments or keywords.

Command Modes

Scope system

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object

Example

This example shows how to enter info policy mode:

```
firepower # scope system
firepower /system # scope info-policy
firepower /system/info-policy #
```

Related Commands

Command	Description
Show	Shows the information about the info policies.

scope interface

To enter configuration mode for a specific interface, use the **scope interface** command.

```
scope interface { Ethernetslot_id/port_id | slot_num }
```

Syntax Description	Ethernetslot_id/port_id	The Ethernet port name.
	<i>slot_num</i>	The interface slot number.
Command Modes	scope eth-uplink/scope fabric a/	
Command History	Release	Modification
	1.1.1	Command added.

Example

This example shows how to scope into configuration mode for a specific interface and view its current configuration:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # scope interface Ethernet1/5
firepower /eth-uplink/fabric/interface # show detail
```

```
Interface:
  Port Name: Ethernet1/5
  User Label:
  Port Type: Data
  Admin State: Enabled
  Oper State: Up
  State Reason:
  flow control policy: default
  Auto negotiation: No
  Admin Speed: 1 Gbps
  Oper Speed: 1 Gbps
  Admin Duplex: Full Duplex
  Oper Duplex: Full Duplex
  Ethernet Link Profile name: default
  Oper Ethernet Link Profile name: fabric/lan/eth-link-prof-default
  Uddld Oper State: Admin Disabled
  Inline Pair Admin State: Enabled
  Inline Pair Peer Port Name:
  Allowed Vlan: All
  Network Control Policy: default
  Current Task:
firepower /eth-uplink/fabric/interface #
```

Related Commands	Command	Description
	disable	Disables the current interface.

Command	Description
enable	Enables the current interface.
set	In interface mode, sets interface configuration parameters.
show interface	Displays interface configuration and status information.

scope ipsec

To enter IPsec mode, use the **scope ipsec** command.

scope ipsec

Syntax Description	This command has no arguments or keywords.	
Command Modes	Security mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter IPsec mode:

```
FP9300-A# scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec #
```

Related Commands	Command	Description
	show connection	Shows information about the IPsec connection.

scope ipv6-config

To enter IPv6 configuration mode, where you can configure the fabric's IPv6 management interface, use the **scope ipv6-config** command in fabric interconnect mode.

scope ipv6-config

Syntax Description

This command has no arguments or keywords.

Command Modes

Fabric interconnect mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter IPv6 configuration mode:

```
FP9300-A# scope fabric-interconnect a
FP9300-A /fabric-interconnect # scope ipv6-config
FP9300-A /fabric-interconnect/ipv6-config #
```

Related Commands

Command	Description
show ipv6-if	Shows IPv6 management-interface information.

scope ldap

To enter Lightweight Directory Access Protocol (LDAP) configuration mode, use the **scope ldap** command.

scope ldap

Syntax Description

This command has no arguments or keywords.

Command Modes

scope security/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter LDAP mode:

```
firepower# scope security
firepower /security # scope ldap
firepower /security/ldap #
```

Related Commands

Command	Description
create ldap-group-rule	Creates LDAP provider group rule parameters.
create server	In security/ldap mode, creates a new LDAP server.
set	In security/ldap/server mode, sets a variety of LDAP server-related parameters, including enable/disable of SSL.

scope licdebug

To enter license debug mode from license mode, use the **scope licdebug** command.

scope licdebug

Syntax Description

This command has no arguments or keywords.

Command Modes

License mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to enter license debug mode from license mode:

```
FP9300-A # scope license
FP9300-A /license # scope licdebug
FP9300-A /license/licdebug #
```

Related Commands

Command	Description
scope license	Enters license mode.

scope license

To enter license mode, use the **scope license** command.

scope license

Syntax Description	This command has no arguments or keywords.	
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter license mode from EXEC level:

```
FP9300-A# scope license
FP9300-A /license #
```

Related Commands	Command	Description
	show license	Shows the usage of some or all license packages.

scope mem-leak-logging

To enable the stack trace state to detect the memory leak of each UCSM process, use the **scope mem-leak-logging** command.

scope mem-leak-logging *set*

Syntax Description

set set memory leak logging for the knob.

Command Modes

scope monitoring/scope sysdebug

Usage Guidelines

Use this command to enable the memory leak feature to debug memory leak issues for the specified process and to enable the stack trace.

Example

This example shows how to set the knob state and enable stack trace mode:

```
Firepower#scope monitoring
Firepower /monitoring# scope sysdebug
Firepower /monitoring/sysdebug# scope mem-leak-logging
Firepower /monitoring/sysdebug/mem-leak-logging # set ?
  appag-log           Memory Leak Logging for appAG
  bladeag-log         Memory Leak Logging for bladeAG
  dcosag-log          Memory Leak Logging for dcosAG
  dme-log             Memory Leak Logging for dme
  extvmmag-log        Memory Leak Logging for extvmmAG
  hostagentag-log     Memory Leak Logging for hostagentAG
  licenseag-log       Memory Leak Logging for licenseAG
  nicag-log           Memory Leak Logging for nicAG
  portag-log          Memory Leak Logging for portAG
  rsdag-log           Memory Leak Logging for rsdagAG
  serviceorchag-log   Memory Leak Logging for serviceOrchAG
  sessionmgrag-log    Memory Leak Logging for sessionmgrAG
  statsag-log         Memory Leak Logging for statsAG
  svcmonag-log        Memory Leak Logging for svcmonAG
Firepower /monitoring/sysdebug/mem-leak-logging # set statsag-log enable ?
  <CR>
  stacktrace Stacktrace for Memory Leak Report
Firepower /monitoring/sysdebug/mem-leak-logging # set statsag-log enable stacktrace ?
  off Off
  on On
```

scope monitoring

To enter system monitoring mode, use the **scope monitoring** command.

scope monitoring

Syntax Description	This command has no arguments or keywords.	
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter monitoring mode:

```
FP9300-A#scope monitoring
FP9300-A /monitoring #
```

Related Commands	Command	Description
	show server status	Shows information about the status of a server.

scope network-features

To enter network features in configuration mode, use the **scope network-features** command.

scope network-features

Syntax Description

This command has no arguments or keywords.

Command Modes

Scope system

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object

Example

This example shows how to enter network features mode:

```
firepower # scope system
firepower /system # scope network-features
firepower /system/network-features* # show
```

Related Commands

Command	Description
show	Shows the information about the domain network features.

scope org

To enter organization mode, use the **scope org** command.

```
scope org [org_name]
```

Syntax Description	<i>org_name</i>	(Optional) The organization name.
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter organization mode:

```
FP9300-A# scope org org100
FP9300-A /org #
```

Related Commands	Command	Description
	show org	Lists currently defined organizations.

scope packet-capture

To enter packet capture mode, use the **scope packet-capture** command.

scope packet-capture

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines	You do not have to enter this mode with a managed object.
-------------------------	---

Example

This example shows how to enter packet capture mode:

```
FP9300-A#scope packet-capture
FP9300-A /monitoring #
```

Related Commands	Command	Description
	traceroute	Traces the route to another device on the network.

scope password-profile

To enter password profile mode, use the **scope password-profile** command.

scope password-profile

Syntax Description	This command has no arguments or keywords.	
Command Modes	Security mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter password profile security mode:

```
FP9300-A # scope security
FP9300-A /security # scope password-profile
FP9300-A /security/password-profile #
```

Related Commands	Command	Description
	show password-profile	Shows password-profile information.

scope profile

To enter Smart Call Home and Smart Licensing destination profile mode, use the **scope profile** command.

scope profile *profile_name*

Syntax Description	<i>profile_name</i>	The name of the destination profile; between 1 and 16 characters.
Command Modes	Callhome (/monitoring/callhome/) mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter profile mode and then display the destination configured for the profile:

```
FP9300-A /monitoring/callhome # scope profile SLProfile
FP9300-A /monitoring/callhome/profile # show destination
```

Destination:

```

Name          Transport Protocol Email or HTTP/HTTPS URL Address
-----
SLDest        Https
https://tools.cisco.com/its/service/oddce/services/DDCEService
FP9300-A /monitoring/callhome/profile #
```

Related Commands	Command	Description
	show profile	Lists currently defined Smart Call Home and Smart Licensing profiles; available in monitoring/callhome mode.

scope radius

To enter Remote Authentication Dial-In User Service (RADIUS) configuration mode, use the **scope radius** command.

scope radius

Syntax Description	This command has no arguments or keywords.	
Command Modes	Scope security	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	

Example

This example shows how to enter radius mode:

```
firepower # scope security
firepower /security # scope radius
firepower /security/radius #
```

scope reservation

To enter license reservation mode, use the **scope reservation** command.

scope reservation

Syntax Description

This command has no arguments or keywords.

Command Modes

License mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to enter reservation mode from license mode:

```
FP9300-A# scope license
FP9300-A /license # scope reservation
FP9300-A /license/reservation #
```

Related Commands

Command	Description
request universal	Generates a reservation request code.
show license	Shows the usage of some or all license packages.

scope security

To enter security mode, use the **scope security** command.

scope security

Syntax Description	This command has no arguments or keywords.	
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter security mode:

```
firepower# scope security
firepower /security #
```

Related Commands	Command	Description
	show security	In EXEC mode, shows information about current security policies.

scope server

To enter server mode, use the **scope server** command.

scope server { *id* | *dynamic_uuid* | *chassis_id/blade_id* }

Syntax Description		
<i>id</i>		The server ID; an integer between 1 and 255.
<i>dynamic_uuid</i>		The server's dynamic universally unique ID (UUID).
<i>chassis_id/blade_id</i>		The server specified using chassis and blade IDs; must be entered in n/n format.
	Note	The chassis ID is always 1 .

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter server mode:

```
FP9300-A# scope server 1/1
FP9300-A /chassis/server #
```

Related Commands	Command	Description
	show server adapter	Shows information about the network adapters in a server.
	show server identity	Shows identity information about a server.

scope server-features

To enter server features in configuration mode, use the **scope server-features** command.

scope server-features

Syntax Description	This command has no arguments or keywords.	
Command Modes	Scope system	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	

Example

This example shows how to enter server features mode:

```
firepower # scope system
firepower /system # scope server-features
firepower /system/server-features* # show
```

Related Commands	Command	Description
	show	Shows the information about the domain server features.

scope service-profile

To enter service profile mode, use the **scope service-profile** command.

scope service-profile {*dynamic_uuid* | *org* | *server*}

Syntax Description		
<i>dynamic_uuid</i>		The dynamic UUID of the service profile.
<i>org</i>		The name of the organization for which the service profile was created; between 1 and 16 characters.
<i>server</i>		The ID of the server for which the service profile was created.

Command Modes EXEC mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines

To use this command with the *org* option, an organization and a service profile for that organization must already exist.

To use this command with the *server* option, the server can be specified with its server ID, or the chassis ID and blade ID (n/n format). The chassis ID is always **1**.

Example

This example shows how to enter service profile mode:

```
firepower # scope service-profile server 1/1
firepower /org/service-profile #
```

Related Commands	Command	Description
	show service-profile	Shows service-profile information.

scope services

To enter system services in configuration mode, use the **scope services** command.

scope services

Syntax Description

This command has no arguments or keywords.

Command Modes

Scope system

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object

Example

This example shows how to enter services mode:

```
firepower # scope system
firepower /system # scope services
firepower /system/services #
```

Related Commands

Command	Description
Show	Shows the information about the services.

scope slot

To enter slot mode for a specific SSP module, use the **scope slot** command.

scope slot *slot_ID*

Syntax Description	<i>slot_ID/id</i>	Identifies the module slot. For the FP9300, this value can be 1, 2, or 3; on the FP4100, this value is 1.
---------------------------	-------------------	---

Command Modes	scope ssa/
----------------------	------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines In slot mode, you can update the application image on the logical device.

Example

This example shows how to enter slot mode:

```
firepower# scope ssa
firepower /ssa # scope slot 2
firepower /ssa/slot #
```

Related Commands	Command	Description
	show security	Shows security information.

scope ssa

To enter security services (ssa) mode, use the **scope ssa** command.

scope ssa

Syntax Description	This command has no arguments or keywords.	
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter ssa mode:

```
FP9300-A# scope ssa
FP9300-A /ssa #
```

Related Commands	Command	Description
	show security	Shows security information.

scope stats-collection-policy

To enter the statistics collection policy for one of the functional areas of your system, use the **scope stats-collection-policy** command.

scope stats-collection-policy *policy-area*

Syntax Description

policy-area

The specific collection policy area:

- **Adapter** – statistics related to the adapters.
- **Chassis** – statistics related to the blade chassis.
- **FEX** – statistics related to configured Fabric Extender(s).
- **Host** – this policy is a placeholder for future support.
- **Port** – statistics related to the ports, including server ports, uplink Ethernet ports, and uplink Fibre Channel ports.
- **Server** – statistics related to servers.

Command Modes

scope monitoring/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Statistics can be collected and reported for several of the functional areas of your system.

Use the **set collection-interval** command to define how frequently statistics are collected, and use the **set reporting-interval** command to define how frequently the statistics are reported. These intervals define a statistics collection policy.

Reporting intervals are longer than collection intervals so that multiple statistical data points can be collected during the reporting interval, which provides sufficient data to calculate and report minimum, maximum, and average values.



Note There is one default statistics collection policy for each of the functional areas. You cannot create additional statistics collection policies and you cannot delete the existing default policies. You can only modify the default policies.

Example

This example shows how to enter the statistics collection policy for ports, set the collection interval to one minute, set the reporting interval to 30 minutes, and then commit the transaction:

```
firepower # scope monitoring
firepower /monitoring # scope stats-collection-policy port
```

```
firepower /monitoring/stats-collection-policy # set collection-interval 1minute
firepower /monitoring/stats-collection-policy* # set reporting-interval 30minute
firepower /monitoring/stats-collection-policy* # commit-buffer
firepower /monitoring/stats-collection-policy #
```

Related Commands

Command	Description
set collection-interval	Specifies how frequently statistics are collected.
set reporting-interval	Specifies how frequently statistics are reported.

scope stats-threshold-policy

To enter the statistics threshold policy for one of the components of your system, use the **scope stats-threshold-policy** command.

scope stats-threshold-policy *policy-name*

Syntax Description	<i>policy-name</i>	The name of the specific threshold policy to enter. You cannot create or delete a statistics threshold policy for Ethernet server ports or Ethernet uplink ports. You can only configure the existing default policy, so for these policies, enter default as the <i>policy-name</i> .
---------------------------	--------------------	--

Command Modes	scope eth-server/ scope eth-uplink/ scope org/
----------------------	--

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines A statistics threshold policy monitors statistics about certain aspects of the system and generates an event if a specified threshold is crossed. You can set both minimum and maximum thresholds. For example, you can configure the policy to raise an alarm if the CPU temperature exceeds a certain value, or if a server is overutilized or underutilized.

There is one default statistics threshold policy each for Ethernet server ports or Ethernet uplink ports. You cannot create additional statistics threshold policies and you cannot delete the existing default policies for these components—you can only modify the default policies.

However, you can create and delete statistics threshold policies in organization mode (`scope org/`). See the **create stats-threshold-policy** command for more information.



Note Use the **set collection-interval** command to define how frequently statistics are collected, and use the **set reporting-interval** command to define how frequently the statistics are reported. These intervals define a statistics collection policy.

Examples

This example shows how to scope into the default Ethernet uplink statistics threshold policy, create an error statistics class, create a cyclic redundancy check (CRC) error count property, specify that the normal CRC error count per polling interval is 1000, create an above normal warning threshold of 1250, and then commit the class:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope stats-threshold-policy default
firepower /eth-uplink/stats-threshold-policy # create class ether-error-stats
```



```

firepower /eth-uplink/stats-threshold-policy/class* # create property crc-delta
firepower /eth-uplink/stats-threshold-policy/class/property* # set normal-value 1000
firepower /eth-uplink/stats-threshold-policy/class/property* # create threshold-value
above-normal warning
firepower /eth-uplink/stats-threshold-policy/class/property/threshold-value* # set escalating
1250
firepower /eth-uplink/stats-threshold-policy/class/property/threshold-value* # commit-buffer
firepower /eth-uplink/stats-threshold-policy/class/property/threshold-value #

```

This example shows how to scope into organization mode, create a new statistics threshold policy for server and server component statistics, create a threshold policy class for CPU environment statistics, create a CPU temperature property, specify that the normal CPU temperature is 48.5° C, create an above normal warning threshold of 50° C, and commit the entire transaction:

```

firepower # scope org
firepower /org # create stats-threshold-policy ServStatsPolicy
firepower /org/stats-threshold-policy* # create class cpu-env-stat
firepower /org/stats-threshold-policy/class* # create property temperature
firepower /org/stats-threshold-policy/class/property* # set normal-value 48.5
firepower /org/stats-threshold-policy/class/property* # create threshold-value above-normal
warning
firepower /org/stats-threshold-policy/class/property/threshold-value* # set escalating 50.0
firepower /org/stats-threshold-policy/class/property/threshold-value* # commit-buffer
firepower /org/stats-threshold-policy/class/property/threshold-value #

```

Related Commands

Command	Description
create class	Creates a new class of statistics.
create property	Creates a new property for a class of statistics.
create threshold-value	Specifies an above- or below-normal threshold for a class property.
scope stats-collection-policy	Enters stats-collection-policy mode, where you manage statistics collection and reporting intervals.

scope storage-features

To enter storage features in configuration mode, use the **scope storage-features** command.

scope storage-features

Syntax Description

This command has no arguments or keywords.

Command Modes

Scope system

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object

Example

This example shows how to enter storage features mode:

```
firepower # scope system
firepower /system # scope environment-features
firepower /system/environment-features # show
```

Related Commands

Command	Description
show	Shows the information about the domain storage features.

scope system

To enter system-management mode, use the **scope system** command.

scope system

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

In this mode, you can manage the system configuration, including exporting and importing a configuration file.

Example

This example shows how to enter system-management mode:

```
firepower# scope system
firepower /system #
```

Related Commands

Command	Description
show system	Shows information about the systems configured on this device.

scope tacacs

To enter Terminal Access Controller Access Control System (TACACS) configuration mode, use the **scope tacacs** command.

scope tacacs

Syntax Description	This command has no arguments or keywords.	
Command Modes	Scope security	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	

Example

This example shows how to enter tacacs mode:

```
firepower # scope security
firepower /security # scope tacacs
firepower /security/tacacs #
```

scope telemetry

To enter telemetry mode, use the **scope telemetry** command.

scope telemetry

Syntax Description

This command has no arguments or keywords.

Command Modes

scope system, scope services

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You can use the enable or disable and show commands

Related Commands

Command	Description
show detail	Shows the telemetry information of the system.

scope vnic

To enter virtual NIC mode, use the **scope vnic** command.

scope vnic *dynamic_mac*

Syntax Description	<i>dynamic_mac</i>	The virtual NIC's dynamic MAC address.
Command Modes	EXEC mode Service profile mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter virtual NIC mode while in organization mode:

```
FP9300-A # scope org org10
FP9300-A /org # scope service-profile sp10
FP9300-A /org/service-profile # scope vnic vNIC10
FP9300-A /org/service-profile/vnic #
```

Related Commands	Command	Description
	show server adapter	Shows information about the available network adapters.

sub scopes (scope fabric-interconnect)

To enter switch uplink mode, use the **scope sw-uplink** command in scope fabric interconnect mode.

scope sw-uplink

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC mode

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter sw-uplink mode:

```
firepower# scope fabric-interconnect
firepower /fabric-interconnect # scope sw-uplink
firepower /fabric-interconnect/sw-uplink #
```

Related Commands

Command	Description
show	Shows the information about the sw-uplink.



set Commands

- [set absolute-session-timeout](#), on page 250
- [set account-status](#), on page 251
- [set address](#), on page 252
- [set admin-state](#), on page 253
- [set auth-server-group](#), on page 254
- [set authentication](#), on page 255
- [set auto-negotiation](#), on page 256
- [set cert](#), on page 257
- [set certchain](#), on page 259
- [set \(certreq\)](#), on page 261
- [set \(cfg-export-policy\)](#), on page 263
- [set \(cfg-export-reminder\)](#), on page 265
- [set cli](#) , on page 266
- [set clock](#) , on page 268
- [set cluster-control-link network](#), on page 269
- [set collection-interval](#), on page 270
- [set con-absolute-session-timeout](#), on page 272
- [set con-session-timeout](#), on page 273
- [set cpu-core-count](#), on page 274
- [set deploy-type](#), on page 276
- [set descr](#), on page 278
- [set duplex](#), on page 279
- [set email](#), on page 280
- [set enforce-strong-password](#), on page 281
- [set expiration](#), on page 283
- [set \(export-config\)](#), on page 284
- [set firstname](#), on page 286
- [set flow-control-policy](#), on page 287
- [set \(flow-control policy\)](#), on page 288
- [set frequency](#), on page 290
- [set http-proxy-server-enable](#), on page 291
- [set http-proxy-server-port](#), on page 292
- [set http-proxy-server-url](#), on page 293

- [set https](#), on page 294
- [set \(interface\)](#), on page 297
- [set ipv6](#), on page 300
- [set ipv6-auto eui64](#), on page 301
- [set ipv6-auto stablesec](#), on page 302
- [set ipv6-ready](#), on page 303
- [set keyring-name](#), on page 304
- [set lastname](#), on page 305
- [set link-state-sync](#), on page 306
- [set local-address](#), on page 307
- [set log-level](#), on page 308
- [set max-login-attempts](#), on page 309
- [set message](#), on page 310
- [set min-password-length](#), on page 312
- [set mode](#), on page 313
- [set modulus](#), on page 314
- [set nd](#), on page 315
- [set out-of-band](#), on page 316
- [set password](#), on page 318
- [set password-encryption-key](#), on page 319
- [set \(password-profile\)](#), on page 321
- [set phone](#), on page 323
- [set \(port-channel\)](#), on page 324
- [set port-channel-mode](#), on page 327
- [set port-type](#), on page 329
- [set port-type \(aggr-interface\)](#), on page 333
- [set prefix](#), on page 336
- [set protocol](#), on page 338
- [set realm](#), on page 340
- [set refresh-period](#), on page 341
- [set regenerate](#), on page 342
- [set remote-address](#), on page 343
- [set remote-ike-ident](#), on page 344
- [set remote-subnet](#), on page 345
- [set remote-user](#), on page 346
- [set reporting-interval](#), on page 347
- [set resource-profile-name](#), on page 349
- [set session-timeout](#), on page 351
- [set snmp](#), on page 352
- [set \(snmp-trap\)](#), on page 354
- [set \(snmp-user\)](#), on page 356
- [set speed](#), on page 358
- [set speed \(aggr-interface\)](#), on page 360
- [set ssh-server](#), on page 363
- [set sshkey](#), on page 364
- [set startup-version](#), on page 365

- [set timezone](#), on page 366
- [set trustpoint](#), on page 368
- [set use-2-factor](#), on page 369
- [set user-account-unlock-time](#), on page 370
- [set user-label](#), on page 371
- [set value \(create bootstrap-key FIREWALL_MODE\)](#), on page 373
- [set value \(create bootstrap-key MANAGEMENT_TYPE\)](#), on page 374
- [set value \(create bootstrap-key PERMIT_EXPERT_MODE\)](#), on page 375
- [set vlan](#), on page 376

set absolute-session-timeout

To set the absolute session timeout, use the **set absolute-session-timeout** command.

set absolute-session-timeout *seconds*

Syntax Description	<i>seconds</i>	Absolute session timeout for Web, SSH, and Telnet sessions; value can be 0 to 3600 seconds. To disable this timeout, set the value to 0.
---------------------------	----------------	--

Command Modes	Default authentication (/security/default-auth) mode
----------------------	--

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines	The absolute session timeout closes user sessions after the specified timeout period has passed, regardless of session use. This absolute timeout is global across all forms of access including serial console, SSH, and HTTPS.
-------------------------	--

Example

This example shows how to enter default authentication mode and then set the absolute timeout for all sessions to four minutes:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set absolute-session-timeout 240
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

Related Commands	Command	Description
	set refresh-period	Sets the Web session refresh period.
	show detail	Displays the current session and absolute session timeout settings.

set account-status

To specify whether a local user account is active or inactive, use the **set account-status** command.

```
set account-status { active | inactive }
```

Syntax Description	active	Specifies that the local user account is active.
	inactive	Specifies that the local user account is disabled.

Command Modes Local user (/security/local-user) mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines You must be a user with admin or AAA privileges to use this command.
The admin account is always set to active. It cannot be modified.

Example

This example shows how to enter local user mode and deactivate a local user account:

```
FP9300-A # scope security
FP9300-A /security # scope local-user test_user
FP9300-A /security/local-user # set account-status inactive
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Related Commands	Command	Description
	set expiration	Specifies the date on which the user account expires.

set address

To set an email or URL address for a Smart Call Home or Smart Licensing destination, use the **set address** command.

set address *address*

Syntax Description	<i>address</i>	The email address or URL of the Smart Call Home or Smart Licensing destination.
--------------------	----------------	---

Command Modes scope monitoring/scope callhome/scope profile/scope destination/

Command History	Release	Modification
	1.4(1)	Command added.

Usage Guidelines Each Firepower 4100/9300 chassis must be registered with the Smart Call Home License Authority or Smart License satellite server. Use this command to set an email or HTTP/HTTPS URL address as the licensing destination.

License Authority example: `https://tools.cisco.com/its/service/oddce/services/DDCEService`

Satellite server example: `https://ip_address/Transportgateway/services/DeviceRequestHandler`

Example

This example shows how to create and enter a Smart Call Home destination:

```
firepower # scope monitoring
firepower /monitoring # scope callhome
firepower /monitoring/callhome # scope profile SLProfile
firepower /monitoring/callhome/profile # scope destination SLDest
firepower /monitoring/callhome/profile/destination # set address
https://tools.cisco.com/its/service/oddce/services/DDCEService
firepower /monitoring/callhome/profile/destination* # commit-buffer
firepower /monitoring/callhome/profile/destination #
```

Related Commands	Command	Description
	create destination	Creates a new Smart Call Home destination.
	delete destination	Deletes an existing Smart Call Home destination.
	set protocol	Sets the transport protocol for a Smart Call Home destination.

set admin-state

To enable or disable the administrative state of a Smart Call Home policy, use the **set admin-state** command.

set admin-state { **disabled** | **enabled** }

Syntax Description	disabled	enabled
	Sets the policy administrative state to disabled.	Sets the policy administrative state to enabled.

Command Modes scope monitoring/scope callhome/policy/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to enable or disable the Call Home policy when a fault or system event matching the associated cause is encountered.

Example

This example shows how to enter and enable a Call Home policy instance for link-down events:

```
firepower /monitoring/callhome # enter policy link-down
firepower /monitoring/callhome/policy* # set admin-state enabled
firepower /monitoring/callhome/policy* # commit-buffer
firepower /monitoring/callhome/policy #
```

Related Commands	Command	Description
	enter policy	Enters a Smart Call Home policy.
	delete policy	Deletes an existing Smart Call Home policy.
	scope policy	Scopes into a Smart Call Home policy.
	show	Displays Call Home configuration or policy information.

set auth-server-group

To specify a default authentication server group, use the **set auth-server-group** command.

```
set auth-server-group admin
```

Syntax Description	<i>admin</i>	The name of the authentication server group.
Command Modes	Default authentication mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to specify the default authentication server group:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set auth-server-group admin_server
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

Related Commands	Command	Description
	set realm	Specifies the default authentication service.

set authentication

To set the default authentication method for the user during login and when connecting to the FXOS CLI via the console port, use the **set authentication** command.

set authentication

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	scope security
----------------------	----------------

Command History	Release	Modification
	2.10(1)	Command added.

Usage Guidelines	You can set the default method by which a user is authenticated during login and when connecting to the FXOS CLI via the console port.
-------------------------	--

Example

This example shows how to enter security mode and set default authentication method:

```
firepower# scope security
firepower /security # set authentication
    console Console authentication
    default Default authentication
```

Related Commands	Command	Description
	show authentication	Displays the existing authentication service.

set auto-negotiation

To enable or disable the autonegotiation of an interface, use the **set auto-negotiation** command.

set auto-negotiation { **on** | **off** }

Syntax Description	on	(Optional) Auto-Negotiation is turned on.
	off	(Optional) Auto-Negotiation is turned off.

Command Modes scope eth-uplink/scope fabric a/scope interface/

Command History	Release	Modification
	2.1.1	Command added.

Usage Guidelines This command works only on specific port types.

Example

This example shows how to enable or disable autonegotiation:

```
Firepower-9300 # scope eth-uplink
Firepower-9300 /eth-uplink # scope fabric a
Firepower-9300 /eth-uplink #/fabric # scope interface Ethernet2/1
Firepower-9300 /eth-uplink/fabric/interface* # set auto-negotiation on
Firepower-9300 /eth-uplink/fabric/interface* # commit-buffer
Firepower-9300 /eth-uplink/fabric/interface #
```

Related Commands	Command	Description
	scope interface	Displays the Ethernet interface information of the interface.

set cert

To add an RSA certificate to a keyring, use the **set cert** command.

set cert

Syntax Description	This command has no arguments or keywords.	
Command Modes	Keyring mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	After entering the command, you are prompted to enter the certificate text, which must end with ENDOFBUEF .	

Example

This example shows how to enter the certificate text for a keyring:

```

FP9300-A /security/keyring # set cert
Enter lines one at a time. Enter ENDOFBUEF to finish. Press ^C to abort.
Keyring certificate:
>-----BEGIN CERTIFICATE-----
MIIFqDCCA5CgAwIBAgIBBDANBgkqhkiG9w0BAQsFADBwMQswCQYDVQGEwJVUzEL
MAkGA1UECAwCQ0ExDDAKBgNVBACMA1NKQzEOMAwGA1UECgwFQ21zY28xDTALBgNV
BAsMBFNUQ1UxXzAxBG9NBAMMAkNBMR0wGAYJKoZIhvcNAQkBFgtzc3Bac3NwLm51
dDAeFw0xNjEyMTUyMTM0NTRaFw>0yNjEyMTMyMTM0NTRaMHwxZAJBgNVBAYTA1VT
MQswCQYDVQQLIDAJDQTEPMA0GA1UECgwGbmV3c3RnMRAdDgYDVQQLDAdzXzdzdGJ1
MRMwEQYDVQQDDAppbnRlcm0xLWNhMSgwJgYJKoZIhvcNAQkBFhlpbnRlcm0xLWNh
QGludGVybTETeY2EubmV0MlIClCIjANBgkqhkiG9w0BAQEFAAOCAg8AMIICCgKCAgEA
wLpNnyEx5I4P8uDoW>KWF3IZsegjhLANsodxuAUmhmwKekd0OpZZxHMw1wSO4IBX5
4itJS0xyXFzPmeptG3OXvNqCcsT+4BXl3DoGgPMULccc4NesHeg2z8+q3SPA6uZh
iseWNvKfnUjixbQEBtcrWB1SKnZuOz1cpuBn34gtgeFFoCEXN+EZVpPESiandVh
8pCFlipC/08ZJ3o9GW2j0eHJN84sguIEDL812ROejQvpmfGUGu11stkIIuh+wB+V
VRhUBVG7p>v57I6DHeeRp6cDMLXaM3iMTelhdShyo5YUaRJMaK/t8kCqhtGXfuLLI
E2AkxKXeeveR9n6cpQd5JiNzCT/t9IQL/T/CCqMICRXLfPLCS9o5S502B6QFgcTZ
yKR6hsmwe22wpK8QI7/5oWNX1o1b96hHJ7RPbG7RXYqmcLiXY/d2j9/RuNoPJawI
hLkfhoidPA28xlnfIB1azCmMmdPcBO6cbUQfCj5hSmk3StVQKgcJaujz55TGGd1
G>jnxDMX9twwz7Ee51895Xmtr24qqaCXJoW/dPhcIIXRdJPMsTJ4yPG0BieuRwd0p
i8w/rFwbHzv4C9Fthw1JrRxH1yeHJHrLLZgJ5txSaVUIgrgVCJaf6/jrRRWoRJwt
AzvzYq12dZPCcEAYgP7JcaQpvdpuDgq++NgBtygiqECAwEAANBMD8wDAYDVR0T
BAUwAwEB/zAvBgNVHR8EKDAMCScGtqAghh5odHRwOi8vMTkyLjE2OC40LjI5L2L2lu
dGVybzS5jcmwwDQYJKoZIhvcNAQELBQADggIBAG/XujJh5G5UWo+cwTSitAezWbJA
h1dAiXZ/OYWZSxkFRliErKdupLqL0ThjnX/wRFfEXbrBQwm5kWAUUDr97D1Uz+2A
8LC5I8SWKXmyf0jUtsnEQbDZb33oVL7yXJk/A0SF0jihpPheMA+YRazalT9xj9KH
PE7nHCJmbb2ptrHUyvBrKSYrSeEqOpQU2+otnFyV3rS9aelgV>juaWyaWoc3lZl0i
CC2tJvY3NnM56j5iesxUCeY/SZ2/ECXN7RRBViLHMa3gFKmWf3xeNiKkxmJCxOaa
UWPC1x2V66I8DG9uUz1WyD7902dy52aAphAHC6hqlzb6v+gw1Tld7UxaqVd8CD5W
ATjNs+ifkJS1h5ERxHjgcurZXOpR+NWpwF+UDzbMXxx+KAAXCI61tCd8Pb3wOUC3
PKVwEXaTcCcxGx71eRlpWPZFyEoi4N2NGE9OXRjz0>K/KERZgNhsIW3bQMjcw3aX6
OXskEuKgsayctnWyxVqNnqpuz06kqyubh4+ZgGKZ5LNEXYmGNz3oED1rUN636Tw
SjGAPHgErozyTFDixCei6aR0lGdP/Hwvb0/+uThIe89g8W20djTKFUM8uB03f+II
/cbuyB01+JrDMq8NkAjxKlJlp1c3WbfCue/qcwtcfUBYZ4i53a56UNF5Ef0rpy/8
B/+07Me/p2y9Luqa
-----END CERTIFICATE-----

```

```
ENDOFBUF  
FP9300-A /security/keyring* #
```

Related Commands	Command	Description
	set modulus	Specifies the RSA key modulus (SSL key length) in bits.
	set regenerate	Regenerates the RSA keys in the default keyring.
	set trustpoint	Specifies whether the keyring certificate can be regenerated.

set certchain

To enter a list (or chain) of certificates for the current trustpoint, use the **set certchain** command.

set certchain [*cert_chain*]

Syntax Description	<i>cert_chain</i>	(Optional) The certificate chain obtained from a Certificate Authority. If this variable is omitted, you are prompted to enter the certificate information manually.
Command Modes	Trustpoint mode	
Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines

The certificates must be in Base64 encoded X.509 (CER) format.

If you do not specify the certificate chain with the command, you are prompted to enter a certificate or a list of trust points defining a certification path to the root Certificate Authority (CA). Type `ENDOFBUF` to finish the entry.

See “Certificates, Key Rings, and Trusted Points” in the *Cisco FXOS CLI Configuration Guide* for information about obtaining a trust certificate.

Example

This example shows how to create and enter a new trustpoint, and then paste a certificate chain into the trustpoint :

```
FP9300-A # scope security
FP9300-A /security # enter trustpoint tPoint4
FP9300-A /security/trustpoint* # set certchain
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
Trustpoint Certificate Chain:
> -----BEGIN CERTIFICATE-----
> MIIDMCCApmgAwIBAgIBADANBgkqhkiG9w0BAQQFADB0MQswCQYDVQQGEwJVUzEL
> BxMMU2FuIEpvc2UsIENBMRUwEwYDVQQKEwxFeGFtcGx1IEluYy4xEzARBgNVBASt
> ClRlc3QgR3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xHzAdBgkqhkiG
> 9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
> AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YcCYU
> ZgAMivvyCsKgb/6CjQtsofvtrmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgd4VBNKOND1
> GMbkPayV1QjbG4MD2dx2+H8EH3LMtdZrgKvPxPTE+bf5wZVNAgMBAAGgJTAjBgkq
> hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcnQwDQYJKoZIhvcNAQEFBQAD
> gYEAG61CaJoJavMhzC190306Mg51zq1zXcz75+VFj2I6rH9asckClD3mkOVx5gJU
> Ptt5CVQpNgNLdvbDPSsXretysOhqHmp9+CLv8FDuy1CDYfuaLtv1WvfhevskV0j6
> jtcEMyZ+f7+3yh42lido3nO4MIGeBgnVHSMegZYwgZOAFLLnjtcEMyZ+f7+3yh42
> lido3nO4oXikdjB0MQswCQYDVQQGEwJVUzELMAkGA1UECBMCQ0ExFDASBgNVBAcT
> C1NhbndhIEENsYXJhMRswCQYDVQQKEwJ0dW92YSBTenXN0ZW1zIEluYy4xFDASBgNV
> BAsTC0Vuz21uZWVyaW5nMQ8wDQYDVQQDEwZ0ZXN0Q0GCAQAwdAYDVR0TBAUwAwEB
> /zANBgkqhkiG9w0BAQQFAAOBgQAhWaRwXNR6B4g6Lsnr+fptHv+WVhB5fKqGQqXc
> wR4pYiO4z42/j9Ijenh75tCKMhW51az8copP1EBmOcyuhf5C6vasrenn1ddkkYt4
> PR0vxGc40whuiozBolesmsmjBbedUCwQgdFDWhDIZJwK5+N3x/kfa2EHU6id1avt
```

```
> 4YL5Jg==
> -----END CERTIFICATE-----
> ENDOFBUF
FP9300-A /security/trustpoint* # commit-buffer
FP9300-A /security/trustpoint #
```

Related Commands

Command	Description
enter trustpoint	Enters a trustpoint.
show trustpoint	Shows current trustpoint information.

set (certreq)

To specify parameters for a keyring certificate request, use the **set** command in certificate request mode.

```
set { country | dns | e-mail | fi-a-ip | fi-a-ipv6 | fi-b-ip | fi-b-ipv6 | ip | ipv6 | locality | org-name | org-unit-name | password | state | subject-name }
```

Syntax	Description
<i>country</i>	(Optional) Specify a two-letter country code for the request; letters must be capitalized.
<i>dns</i>	(Optional) Specify the domain name assigned to the network; common to all host names. This is an alternative to <i>subject-name</i> .
<i>e-mail</i>	(Optional) Specify the email address associated with the request.
<i>fi-a-ip</i>	Not used.
<i>fi-a-ipv6</i>	Not used.
<i>fi-b-ip</i>	Not used; there is no fabric interconnect B.
<i>fi-b-ipv6</i>	Not used; there is no fabric interconnect B.
<i>ip</i>	(Optional) Specify the IPv4 address of the device domain.
<i>ipv6</i>	(Optional) Specify the IPv6 address of the device domain.
<i>locality</i>	(Optional) Specify the city or town in which the company requesting the certificate is headquartered. Enter up to 64 characters. You can use any letters, numbers, or spaces, as well as the following special characters: , (comma), . (period), @ (at sign), ^ (carat), ((open parenthesis),) (close parenthesis), - (dash), _ (underscore), + (plus sign), : (colon), / (forward slash).
<i>org-name</i>	(Optional) Specify the name of the organization requesting the certificate. Enter up to 64 characters. You can use any letters, numbers, or spaces, as well as the following special characters: , (comma), . (period), @ (at sign), ^ (carat), ((open parenthesis),) (close parenthesis), - (dash), _ (underscore), + (plus sign), : (colon), / (forward slash).
<i>org-unit-name</i>	(Optional) Specify the name of the unit within the organization. Enter up to 64 characters. You can use any letters, numbers, or spaces, as well as the following special characters: , (comma), . (period), @ (at sign), ^ (carat), ((open parenthesis),) (close parenthesis), - (dash), _ (underscore), + (plus sign), : (colon), / (forward slash).
<i>password</i>	(Optional) You are asked to enter and then confirm a password for the request.

<i>state</i>	(Optional) Specify the state or province in which the company requesting the certificate is headquartered. Enter up to 64 characters. You can use any letters, numbers, or spaces, as well as the following special characters: , (comma), . (period), @ (at sign), ^ (carat), ((open parenthesis),) (close parenthesis), - (dash), _ (underscore), + (plus sign), : (colon), / (forward slash).
<i>subject-name</i>	(Optional) Specify the fully qualified domain name of the local fabric interconnect.

Command Modes scope security/enter keyring/scope certreq/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines After creating or entering a certificate request, use these options to specify information about the request.

Example

This example shows how to specify information about a certificate request:

```
firepower /security/keyring # enter certreq
firepower /security/keyring/certreq # set subject-name FP9300-1.testnet.com
firepower /security/keyring/certreq* # set password
Certificate request password:
Confirm certificate request password:
firepower /security/keyring/certreq* #
```

Related Commands	Command	Description
	create certreq	Creates a new keyring certificate request.
	delete certreq	Deletes an existing keyring certificate request.
	enter certreq	Enters a keyring certificate request.
	set (keyring)	Sets keyring-related information, including modulus and trustpoint.

set (cfg-export-policy)

To specify or edit the parameters for an existing configuration-export policy, use the **set** command in configuration-export-policy mode.

set { **adminstate** | **descr** | **hostname** | **password** | **port** | **protocol** | **remote-file** | **schedule** | **user** }

Syntax	Description
adminstate { disable enable }	Enables or disables policy administration. When disabled, configuration back-ups are not exported according to the policy schedule.
descr <i>description</i>	(Optional) You can add a description to the configuration object; the description can be between one and 256 characters. Most alphanumeric characters are allowed, as are dashes and underscores; the string can end with punctuation such as semi-colon, period (full stop), and exclamation point, but you cannot embed those characters in the description.
hostname <i>host_ID</i>	(Optional) Specify the IP address or host name of the remote server to which the configuration back-up is exported. This host can be a server, storage array, local drive, or any read/write media that is accessible on the network. Note To use an actual host name, a configured DNS server must be available.
password	(Optional) Specify the password used to connect to the remote server; you are asked to enter and then confirm the password.
port { <i>number</i> default }	(Optional) You can change the port on which communications with the remote server take place; if this option is not specified, the protocol's default port is used. The options are a port-ID number between zero and 4294967295, or default for the current protocol's default port.
protocol <i>name</i>	(Optional) Specify the file-transfer protocol to use. Available options are: <ul style="list-style-type: none"> • ftp • scp • sftp • tftp
remote-file <i>name</i>	(Optional) Specify the full path, including a file name, for the exported configuration; can be between one and 128 characters.
schedule { bi-weekly daily weekly }	(Optional) Specify how frequently the configuration is automatically exported: <ul style="list-style-type: none"> • bi-weekly – Export occurs every two weeks. • daily – Export occurs every day. • weekly – Export occurs once a week.

user *name* (Optional) Specify the user-account name employed to connect to the remote host; can be between zero and 510 characters.

Command Modes

scope org/scope cfg-export-policy/

Command History

Release	Modification
1.1.1	Command added.

Usage Guidelines

Changing `set adminstate` to `enable` and then issuing a `commit-buffer` command immediately triggers a configuration export.

Example

This example shows how to configure the default configuration-export policy, and then check the policy parameters:

```
firepower # scope org
firepower /org # scope cfg-export-policy default
firepower /org/cfg-export-policy # set protocol scp
firepower /org/cfg-export-policy* # set hostname 192.168.1.2
firepower /org/cfg-export-policy* # set remote-file /export/cfg-backup.xml
firepower /org/cfg-export-policy* # set user user1
firepower /org/cfg-export-policy* # set password
Enter a password:
Confirm the password:
firepower /org/cfg-export-policy* # set schedule weekly
firepower /org/cfg-export-policy* # set adminstate enable
firepower /org/cfg-export-policy* # commit-buffer
firepower /org/cfg-export-policy # show detail
Config Export policy:
  Name: default
  Description: Configuration Export Policy
  Admin State: Enable
  Protocol: Scp
  Hostname: 192.168.1.2
  User: user1
  Remote File: /export/cfg-backup.xml
  Schedule: Weekly
  Port: Default
  Current Task:
firepower /org/cfg-export-policy #
```

Related Commands

Command	Description
export-config	Exports the current system configuration to a remote server as an XML file; creates an export-configuration object.
import-config	Copies a previously exported XML configuration file to this appliance.
set password-encryption-key	Specifies a key used when encrypting sensitive information during configuration export.

set (cfg-export-reminder)

To specify or edit the parameters for the configuration-export reminder object, use the **set** command in configuration-export-reminder mode.

```
set { adminstate | frequency }
```

Syntax Description	adminstate { disable enable }	Enable or disable the export reminder. When disabled, configuration back-up reminder faults are not generated.
	frequency <i>number_of_days</i>	Specify the number of days that can pass without a configuration back-up occurring. After this period, the system will generate a reminder fault. This value can be between one and 365 days.
Command Modes	scope org/scope cfg-export-reminder/	
Command History	Release	Modification
	1.1.3	Command added.
Usage Guidelines	When the reminder is enabled, the system generates a fault when a configuration export hasn't been executed in the specified number of days.	

Example

This example shows how to enter the export-reminder object, enable it, specify how often back-ups must occur, and then view the settings:

```
firepower # scope org
firepower /org # scope cfg-export-reminder
firepower /org/cfg-export-reminder # set adminstate enable
firepower /org/cfg-export-reminder* # set frequency 30
firepower /org/cfg-export-policy* # commit-buffer
firepower /org/cfg-export-reminder # show
```

```
Config Export Reminder:
  Config Export Reminder (Days): 30
  AdminState: Enable
firepower /org/cfg-export-reminder #
```

Related Commands	Command	Description
	scope cfg-export-policy	Enters the configuration export policy.
	show	In configuration-export reminder mode, shows the current reminder object set-up.

set cli

To specify whether command output lines wrap or truncate to fit the width of the terminal window, whether table headers are displayed, and whether commas or spaces are used to separate fields in command output tables, use the **set cli** command.

```
set cli {suppress-field-spillover {off|on} |suppress-headers {off|on} |table-field-delimiter {comma|none } }
```

Syntax Description

suppress-field-spillover {off on}	Use off to wrap output lines in the terminal window. Use on to truncate output lines at the end of the terminal window.
suppress-headers {off on}	Use off to display table headers. Use on to not display table headers.
table-field-delimiter {comma none}	Use comma to separate fields in command output tables with commas. Use none to separate fields in command output tables with spaces.

Command Default

Command output lines wrap in the terminal window.
Table headers are displayed.
Spaces are used to separate fields in command output tables.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use this command to specify whether command output lines wrap or truncate to fit the width of the terminal window, whether table headers are displayed, and whether commas or spaces are used to separate fields in command output tables.

Example

This example shows how to specify that command output lines truncate, and then how to reset to wrap:

```
FP9300-A# set cli suppress-field-spillover on
FP9300-A# show fault
Severity Code Last Transition Time ID Description
-----
Warning F16520 2010-01-21T18:33:22.065 5785755 [FSM:STAGE:RETRY]: detect
mezz cards in 1/6 (FSM-STAGE:sam:dme:ComputeBladeDiscover:NicPresence)
Condition F77960 2010-01-21T18:32:31.255 1089623 [FSM:STAGE:REMOTE-ERROR]: R
esult: end-point-unavailable Code: unspecified Message: sendSamDmeAdapterInfo: i
dentify failed

FP9300-A# set cli suppress-field-spillover off
FP9300-A# show fault
```

```

Severity Code      Last Transition Time      ID      Description
-----
Warning F16520 2010-01-21T18:33:22.065 5785755 [FSM:STAGE:RETRY:]: detect
Condition F77960 2010-01-21T18:32:31.255 1089623 [FSM:STAGE:REMOTE-ERROR]: R
FP9300-A#

```

Related Commands

Command	Description
show cli	Shows current CLI settings.
terminal	Sets the number of lines, and the width of the lines, displayed in the terminal window.

set clock

To manually set the clock timing in FXOS, use the **set clock** command.

set clock

Syntax Description	set clock	Use set clock to manually set the clock in FXOS.
Command Modes	scope system/scope services	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to set the clock in FXOS:

```
firepower# scope system
firepower /system# scope services
firepower /system/services # set clock aug 23 2021 12 00 00
firepower /system/services* # commit
firepower /system/services # show clock
Tue Aug 24 12:00:02 UTC 2021
```

set cluster-control-link network

To set the cluster control link IP network in the cluster bootstrap configuration for the threat defense and ASA, use the **set cluster-control-link network** command.

set cluster-control-link network *a.b.0.0*

Syntax Description	<i>a.b.0.0</i>	Specifies any /16 network address, except for loopback (127.0.0.0/8) and multicast (224.0.0.0/4) addresses. If you set the value to 0.0.0.0, then the default network is used: 127.2.0.0.
---------------------------	----------------	---

Command Default	The default network is 127.2.0.0.
------------------------	-----------------------------------

Command Modes	scope ssa/create logical-device/create cluster-bootstrap/
----------------------	---

Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines	The chassis auto-generates the cluster control link interface IP address for each unit based on the chassis ID and slot ID: <i>a.b.chassis_id.slot_id</i> .
-------------------------	---

Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.

Example

The following example shows how to set the mode to routed mode:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 clustered
Firepower /ssa/logical-device* # create cluster-bootstrap
firepower /ssa/logical-device/cluster-bootstrap* # set cluster-control-link network 10.10.0.0
firepower /ssa/logical-device/cluster-bootstrap* #
```

Related Commands	Command	Description
	create logical-device	Creates the logical device.
	create cluster-bootstrap	Creates the cluster bootstrap configuration for the application.

set collection-interval

To define how frequently monitored statistics are collected, use the **set collection-interval** command.

set collection-interval *interval*

Syntax Description	<i>interval</i>	Length of time defining the statistics collection interval; available values are: <ul style="list-style-type: none"> • <code>1minute</code> – one-minute intervals • <code>2minutes</code> – two-minute intervals • <code>30seconds</code> – 30-second intervals • <code>5minutes</code> – five-minute intervals
---------------------------	-----------------	--

Command Modes	scope monitoring/scope stats-collection-policy/
----------------------	---

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use the **set collection-interval** command to define how frequently statistics are collected, and use the **set reporting-interval** command to define how frequently the statistics are reported. These intervals define a statistics collection policy.

Reporting intervals are longer than collection intervals so that multiple statistical data points can be collected during the reporting interval, which provides sufficient data to calculate and report minimum, maximum, and average values.

Statistics can be collected and reported for each of the following functional areas of your Firepower system; use the **scope stats-collection-policy** command to access a specific collection policy:

- `Adapter` – statistics related to the adapters.
- `Chassis` – statistics related to the blade chassis.
- `FEX` – statistics related to configured Fabric Extender(s).
- `Host` – this policy is a placeholder for future support.
- `Port` – statistics related to the ports, including server ports, uplink Ethernet ports, and uplink Fibre Channel ports.
- `Server` – statistics related to servers.



Note There is one default statistics collection policy for each of the functional areas. You cannot create additional statistics collection policies and you cannot delete the existing default policies. You can only modify the default policies.

Example

This example shows how to enter the statistics collection policy for ports, set the collection interval to one minute, set the reporting interval to 30 minutes, and then commit the transaction:

```
firepower # scope monitoring
firepower /monitoring # scope stats-collection-policy port
firepower /monitoring/stats-collection-policy # set collection-interval 1minute
firepower /monitoring/stats-collection-policy* # set reporting-interval 30minute
firepower /monitoring/stats-collection-policy* # commit-buffer
firepower /monitoring/stats-collection-policy #
```

Related Commands

Command	Description
scope stats-collection-policy	Enters stats-collection-policy mode, where you manage statistics collection and reporting intervals.
set reporting-interval	Specifies how frequently statistics are reported.

set con-absolute-session-timeout

To set the serial console absolute session timeout, use the **set con-absolute-session-timeout** command.

set con-absolute-session-timeout *seconds*

Syntax Description	<i>seconds</i>	Serial console absolute session timeout; value can be 0 to 3600 seconds. To disable this timeout, set the value to 0.
---------------------------	----------------	---

Command Modes	Default authentication mode
----------------------	-----------------------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines You can separately configure the absolute session timeout for serial console sessions. This means you can disable the serial console absolute session timeout for debugging while maintaining the absolute timeout for other forms of access.

Example

This example shows how to enter default authentication mode and then set the serial console absolute timeout to four minutes:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set con-absolute-session-timeout 240
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

Related Commands	Command	Description
	set refresh-period	Sets the Web session refresh period.
	show detail	Displays the current session and absolute session timeout settings.

set con-session-timeout

To set the serial console idle session timeout, use the **set con-session-timeout** command.

set con-session-timeout *seconds*

Syntax Description	<i>seconds</i>	Serial console idle session timeout; value can be 0 to 3600 seconds. To disable this timeout, set the value to 0.
---------------------------	----------------	---

Command Modes	Default authentication mode
----------------------	-----------------------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to specify the idle session timeout for serial console sessions.

Example

This example shows how to enter default authentication mode and then set the serial console idle timeout to four minutes:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set con-session-timeout 240
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

Related Commands	Command	Description
	set refresh-period	Sets the Web session refresh period.
	show detail	Displays the current session and absolute session timeout settings.

set cpu-core-count

To set the CPU cores for a resource profile for use with container instances, use the **set cpu-core-count** command.

set cpu-core-count *cores*

Syntax Description

cores Sets the number of cores for the profile, between 6 and the maximum, depending on your chassis, as an even number. You *cannot* specify 8 cores.

Command Modes

scope ssa/create resource-profile/

Command History

Release	Modification
2.4(1)	Command added.

Usage Guidelines

To specify resource usage per container instance, create one or more resource profiles. When you deploy the logical device/application instance, you specify the resource profile that you want to use. The resource profile sets the number of CPU cores; RAM is dynamically allocated according to the number of cores, and disk space is set to 40 GB per instance.

- The minimum number of cores is 6.
- You cannot specify 8 cores due to internal architecture.
- You can assign cores as an even number (6, 10, 12, 14 etc.) up to the maximum.
- The maximum number of cores available depends on the security module/chassis model.

The chassis includes a default resource profile called "Default-Small," which includes the minimum number of cores. You can change the definition of this profile, and even delete it if it is not in use. Note that this profile is created when the chassis reloads and no other profile exists on the system.

You cannot change the resource profile settings if it is currently in use. You must disable any instances that use it, then change the resource profile, and finally reenable the instance. If you resize instances in an established High Availability pair, then you should make all members the same size as soon as possible.

If you change the resource profile settings after you add the threat defense instance to the management center, update the inventory for each unit on the **Devices > Device Management > Device > System > Inventory** dialog box.

Example

The following example adds three resource profiles.

```
firepower# scope ssa
firepower /ssa # enter resource-profile basic
firepower /ssa/resource-profile* # set description "lowest level"
firepower /ssa/resource-profile* # set cpu-core-count 6
firepower /ssa/resource-profile* # exit
firepower /ssa # enter resource-profile standard
firepower /ssa/resource-profile* # set description "middle level"
```

```

firepower /ssa/resource-profile* # set cpu-core-count 10
firepower /ssa/resource-profile* # exit
firepower /ssa # enter resource-profile advanced
firepower /ssa/resource-profile* # set description "highest level"
firepower /ssa/resource-profile* # set cpu-core-count 12
firepower /ssa/resource-profile* # commit-buffer
firepower /ssa/resource-profile #

```

Related Commands	Command	Description
	create resource-profile	Adds a resource profile for use with container instances.
	set resource-profile-name	Assigned the resource profile to the application instance.
	show monitor detail	Shows resource usage for the security module/engine slot.
	show resource detail	Shows resource allocation for the application instance.
	show resource-profile user-defined	Shows resource profile assignments.

set deploy-type

To set the deployment type for an application instance, either native or container, use the **set deploy-type** command.

```
set deploy-type { native | container }
```

Syntax Description	container	Sets the application instance to the container type.
	native	Sets the application instance to the native type.
Command Default	The default type is native.	
Command Modes	scope ssa/scope slot/create app-instance/	
Command History	Release	Modification
	2.4(1)	Command added for threat defense.

Usage Guidelines

Application instances run in the following deployment types:

- Native instance—A native instance uses all of the resources (CPU, RAM, and disk space) of the security module/engine, so you can only install one native instance.
- Container instance—A container instance uses a subset of resources of the security module/engine, so you can install multiple container instances. Multi-instance capability is only supported for the threat defense; it is not supported for the ASA.



Note Multi-instance capability is similar to ASA multiple context mode, although the implementation is different. Multiple context mode partitions a single application instance, while multi-instance capability allows independent container instances. Container instances allow hard resource separation, separate configuration management, separate reloads, separate software updates, and full threat defense feature support. Multiple context mode, due to shared resources, supports more contexts on a given platform. Multiple context mode is not available on the threat defense.

For the Firepower 9300, you can use a native instance on some modules, and container instances on the other module(s).

Example

The following example adds an threat defense application instance, and sets it to the container type:

```
Firepower# scope ssa
Firepower /ssa # scope slot 1
Firepower /ssa/slot # enter app-instance ftd MyDevice1
```

```
Firepower /ssa/slot/app-instance* # set deploy-type container
Firepower /ssa/slot/app-instance* # set resource-profile-name silver 1
Firepower /ssa/slot/app-instance* # set startup-version 6.3.0.1
Firepower /ssa/slot/app-instance* # exit
Firepower /ssa/slot* # exit
Firepower /ssa* #
```

Related Commands

Command	Description
show app-attrib	Shows current application attributes.
create resource-profile	Creates a resource profile for use with container instances.
show resource-profile-name	Shows available resource profiles.

set descr

To set a description for the port-channel, use the **set descr** command.

set descr *description*

Syntax Description	description	(Optional) Description. Enter up to 256 characters.
Command Modes	scope eth-uplink/scope fabric a/port-channel/	
Command History	Release	Modification
	2.0.1	Command added.
Usage Guidelines	If your description includes spaces, special characters, or punctuation, you must begin and end your description with quotation marks. The quotation marks will not appear in the description field of any show command output Ethernet.	

Example

This example shows how to set the description:

```
firepower-9300 # scope eth-uplink
firepower-9300 /eth-uplink # scope fabric a
firepower-9300 /eth-uplink/fabric # create port-channel id
firepower-9300 /eth-uplink/fabric/port-channel* # enable
firepower-9300 /eth-uplink/fabric/port-channel* # set descr "link"
firepower-9300 /eth-uplink/fabric/port-channel* # commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #
```

Related Commands	Command	Description
	show interface	Displays information about the interface, which includes the duplex parameter.

set duplex

To set the duplex for all members of the port-channel, use the **set duplex** command.

```
set duplex { fullduplex | halfduplex }
```

Syntax Description	fullduplex	(Optional) Specifies the duplex mode as full.
	halfduplex	(Optional) Specifies the duplex mode as half.

Command Modes scope eth-uplink/scope fabric a/port-channel/

Command History	Release	Modification
	2.0.1	Command added.

Usage Guidelines You must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. Gigabit Ethernet is full duplex only. You cannot change the duplex mode on Gigabit Ethernet ports or on a 10/100/1000-Mbps port that is set for Gigabit Ethernet.

Example

This example shows how to set the interface duplex mode:

```
firepower-9300# scope eth-uplink
firepower-9300 /eth-uplink # scope fabric a
firepower-9300 /eth-uplink/fabric # create port-channel id
firepower-9300 /eth-uplink/fabric/port-channel* # enable
firepower-9300 /eth-uplink/fabric/port-channel* # set duplex halfduplex
firepower-9300 /eth-uplink/fabric/port-channel* # commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #
```

Related Commands	Command	Description
	show interface	Displays information about the interface, which includes the duplex parameter.

set email

To set a contact email address for a user account, use the **set email** command.

set email *email_address*

Syntax Description	<i>email_address</i>	An email address for the user account. Specify the email address in the format: <i>user_name@domain_name</i> .
--------------------	----------------------	--

Command Modes	Callhome (/monitoring/callhome) mode – to specify a primary contact email address to be included in Call Home messages. Local user (/security/local-user) mode – to specify a contact email address for the current local user.
---------------	--

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines If the email address includes special characters, such as # (hash), spaces, or & (ampersand), the email server may not be able to deliver email messages to that address. Cisco recommends using email addresses which comply with RFC2821 and RFC2822, and include only 7-bit ASCII characters.

In callhome mode, you can use a maximum of 2083 characters for the email address.

In local user mode, you can use a maximum of 510 characters for the email address.

Example

This example shows how to specify an email address for the current local user:

```
FP9300-A /security/local-user # set email admin@example.com
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Related Commands	Command	Description
	create local-user	Creates a new local user account.
	set phone-contact	Specifies a telephone contact number for a Smart Call Home account.

set enforce-strong-password

To enable and disable strong password enforcement, use the **set enforce-strong-password** command.

```
set enforce-strong-password { no | yes }
```

Syntax Description	no	Disables strong password enforcement.
	yes	Enables strong password enforcement.
Command Modes	Security mode	
Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines

A password is required for each locally authenticated user account. A user with admin or AAA privileges can configure the system to perform a password strength check on all user passwords. If password strength checking is enabled, each user must have a “strong” password.

We recommend that each user have a strong password. If password strength checking is enabled for locally authenticated users, FXOS rejects any password that does not meet the following requirements:

- Must contain a minimum of 8 characters and a maximum of 80 characters. (The [set min-password-length, on page 312](#) command can be used to specify the minimum number of characters required.)
- Must include at least one uppercase alphabetic character.
- Must include at least one lowercase alphabetic character.
- Must include at least one non-alphanumeric (special) character.
- Must not contain a character that is repeated more than three times consecutively, such as aaabbb.
- Must not contain three consecutive numbers or letters in any order, such as passwordABC or password321.
- Must not be identical to the user name or the reverse of the user name.
- Must pass a password dictionary check. For example, the password must not be based on a standard dictionary word.
- Must not contain the following symbols: \$ (dollar sign), ? (question mark), and = (equals sign).
- Must not be blank for local user and admin accounts.

Example

This example shows how to enter security mode and enable strong password enforcement:

```
FP9300-A# scope security
FP9300-A /security # set enforce-strong-password yes
FP9300-A /security* # commit-buffer
```

set enforce-strong-password

```
FP9300-A /security #
```

Related Commands

Command	Description
set min-password-length	Specifies a minimum password length.

set expiration

To set an expiration date for a local user account, use the **set expiration** command.

```
set expiration { { apr | aug | dec | feb | jan | jul | jun | mar | may | nov | oct | sep } day year }
```

Syntax Description

{ apr aug dec feb jan jul jun mar may nov oct sep }	The three-letter month abbreviation.
<i>day</i>	Numeric day of the month; valid values are 1 through 31.
<i>year</i>	Numeric year for expiration; maximum value is 2037.

Command Modes

Local user mode—to specify an expiration date for the current local user.

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

After you configure a user account with an expiration date, you cannot reconfigure the account to not expire. You can however, reconfigure the account with a different expiration date.

Example

This example shows how to enter security mode, create a new local user account and specify an expiration date for that account:

```
FP9300-A# scope security
FP9300-A /security # create local-user test_user
FP9300-A /security/local-user* # set expiration dec 31 2019
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Related Commands

Command	Description
create local-user	Creates a new local user account.
set password	Specifies a password for a user account.

set (export-config)

To edit the parameters for an existing export-configuration object, use the **set** command in export-configuration mode.

```
set { descr | password | port | protocol | remote-file | user }
```

Syntax Description		
descr <i>description</i>	(Optional) You can add a description to the configuration object; can be between one and 256 characters. Most alphanumeric characters are allowed, as are dashes and underscores; the string can end with punctuation such as semi-colon, period (full stop), and exclamation point, but you cannot embed those characters in the description.	
password	(Optional) You can change the password used to connect to the remote server; you are asked to enter and then confirm the password.	
port { <i>number</i> default }	(Optional) You can change the port on which communications with the remote server take place. The options are a port-ID number between zero and 4294967295, or default for the current protocol's default port.	
protocol <i>name</i>	(Optional) You can change the file-transfer protocol used to transmit the configuration back-up to the remote server. Available options are:	<ul style="list-style-type: none"> • ftp • scp • sftp • tftp
remote-file <i>name</i>	(Optional) You can change the name of the back-up configuration file; can be between one and 128 characters.	
user <i>name</i>	(Optional) You can change the user-account name employed to connect to the remote host; can be between zero and 510 characters.	

Command Modes scope system/scope export-config/

Command History	Release	Modification
	1.1.3	Command added.

Usage Guidelines Use these options to change the back-up options for an existing export-configuration object.

An export-configuration object is created when you issue an **export-config** command to back up the current logical device and platform configuration, and **scope export-config** is used to enter the object and edit its parameters.

Please note the following:

- Beginning with FXOS 2.6.1, you must specify a key for use when encrypting sensitive information such as passwords and other secret keys during configuration export, and you must have specified it before you attempt to export the configuration.

Also, the same key used during export must be set on the target system when you import an exported configuration, unless the file was exported from an FXOS release prior to 2.6.1, in which case the target system will not check the encryption key and will allow the import.

- Do not modify the contents of the configuration file. If a configuration file is modified, configuration import using that file might fail.
- To avoid overwriting existing back-up files, please be sure to change the file name in the export operation, or copy the existing file to another location.

Example

This example shows how to add a description to an existing export-configuration object:

```
firepower # scope system
firepower /system # scope export-config 192.168.1.2
firepower /system/export-config # set descr one-time_back-up_be_sure_to_change_file_name
firepower /system/export-config* # commit-buffer
firepower /system/export-config #
```

Related Commands

Command	Description
cfg-export-policy	Configures a configuration export policy.
export-config	Exports the current system configuration to a remote server as an XML file; creates an export-configuration object.
import-config	Copies a previously exported XML configuration file to this appliance.
set password-encryption-key	Specifies a key used when encrypting sensitive information during configuration export.

set firstname

To specify the first name of a local user, use the **set firstname** command.

set firstname *name*

Syntax Description	<i>name</i>	The user's first name; can be zero to 32 characters.
Command Modes	Local user mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter security mode, create a new local user account and specify a first name and a last name for that user:

```
FP9300-A# scope security
FP9300-A /security # create local-user test_user
FP9300-A /security/local-user* # set firstname john
FP9300-A /security/local-user* # set lastname doe
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Command	Description
create local-user	Creates a new local user account.
set lastname	Specifies the surname for a local user account.

set flow-control-policy

To assign a flow control policy to an interface or a port-channel, use the **set flow-control-policy** command.

set flow-control-policy *name*

Syntax Description	<i>name</i>	The name of the flow control policy; maximum of 16 characters.
Command Modes	scope eth-uplink/scope fabric a/scope interface/ scope eth-uplink/scope fabric a/scope port-channel/	
Command History	Release	Modification
	2.0.1	Command added.
Usage Guidelines	When you create a new flow control policy, you are automatically entered into flow-control/policy mode (eth-uplink/flow-control/policy) with an asterisk indicating the new policy is not yet committed. You can set policy property values and then commit the new policy. After you create a flow control policy, the policy name cannot be changed. You must delete the policy and create a new one.	

Example

This example shows how to assign a flow control policy to an interface:

```
firepower-9300 # scope eth-uplink
firepower-9300 /eth-uplink # scope fabric
firepower-9300 /eth-uplink #/fabric # scope interface Ethernet1/8
firepower-9300 /eth-uplink/fabric/interface* # set flow-control-policy eth1-8flowcontrol
firepower-9300 /eth-uplink/fabric/interface* # commit-buffer
firepower-9300 /eth-uplink/fabric/interface #
```

Related Commands	Command	Description
	create policy (flow control)	Creates a new flow control policy.
	show interface	Displays the interface status, which includes the speed parameters.
	show port-channel	Displays information about a port channel.

set (flow-control policy)

To specify or edit the parameters for an existing flow-control policy, use the **set** command in flow-control/policy mode.

set { **prio** | **receive** | **send** }

Syntax Description		
prio { auto on }	Sets the flow-control priority option:	<ul style="list-style-type: none"> • auto – This device and the network will negotiate whether Point-to-Point Protocol (PPP) is used on this fabric. • on – PPP is enabled on this fabric.
receive off	Specifies that pause requests from the network are ignored and traffic flow continues normally.	
send off on	Sets the flow-control send parameter:	<ul style="list-style-type: none"> • off – Traffic flows normally regardless of packet load. • on – This device sends a pause request to the network if the incoming packet buffer becomes full. The pause remains in effect for a few milliseconds while traffic returns to normal levels.

Command Modes scope eth-uplink/scope flow-control/policy/

Command History

Release	Modification
1.1.1	Command added.

Usage Guidelines

Use this command to specify flow control receive options. When you specify **off**, pause requests from the network are ignored and traffic flow continues as normal. When you specify **on**, pause requests are honored and all traffic is halted on that uplink port until the network cancels the pause request.

Use this command to specify flow control send options. When you specify **off**, traffic on the port flows normally regardless of the packet load. When you specify **on**, the FXOS sends a pause request to the network if the incoming packet rate becomes too high. The pause remains in effect for a few milliseconds before traffic is reset to normal levels.

Example

This example shows how to create and enter a named policy for flow control, and then set policy parameters:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope flow-control
firepower /eth-uplink/flow-control # enter policy FCpolicy1
firepower /eth-uplink/flow-control/policy* # set prio auto
firepower /eth-uplink/flow-control/policy* # set send on
firepower /eth-uplink/flow-control/policy* # commit-buffer
```

```
firepower /eth-uplink/flow-control/policy #
```

Related Commands	Command	Description
	show policy	In flow-control/policy mode, displays property values for the current flow-control policy. In flow-control mode, displays property values for all currently defined flow-control policies.

set frequency

To generate a fault when a configuration export hasn't been executed in a certain number of days, use the **set frequency** command.

set frequency *days*

Syntax Description	<i>days</i>	Config Export Reminder (Days).
Command Modes	scope org/scope cfg-export-reminder/	
Command History	Release	Modification
	2.0.1	Command added.

Example

This example shows how to set the configuration frequency days for export reminder:

```
firepower-9300* # scope org
firepower-9300 /org* # scope cfg-export-reminder
firepower-9300 /org/scope cfg-export-reminder* # set frequency 2
firepower-9300 /org/scope cfg-export-reminder* # commit-buffer
firepower-9300 /org/scope cfg-export-reminder* # show detail
Config Export Reminder:
Config Export Reminder (Days): 10
AdminState: Enable
```

Related Commands	Command	Description
	set adminstate	Specifies the admin state for the export reminder.

set http-proxy-server-enable

To enable or disable an HTTP/HTTPS proxy for Smart Software Licensing and Smart Call Home, use the **set http-proxy-server-enable** command.

set http-proxy-server-enable {off|on}

Syntax	Description
off	Disables the Smart Call Home HTTP/HTTPS proxy.
on	Enables the Smart Call Home HTTP/HTTPS proxy.

Command Default The HTTP/HTTPS proxy is disabled by default.

Command Modes Callhome mode

Usage Guidelines If your network uses an HTTP proxy for Internet access, you must enable the proxy and configure its address for Smart Software Licensing. This proxy is also used for Smart Call Home in general.

Example

This example shows how to enable an HTTP proxy:

```
FP9300-A# scope monitoring
FP9300-A /monitoring # scope callhome
FP9300-A /monitoring/callhome # set http-proxy-server-enable on
FP9300-A /monitoring/callhome #
```

Related Commands	Command	Description
	set http-proxy-server-url	Sets the HTTP or HTTPS address of the proxy server.
	set http-proxy-server-port	Sets the communications port for the proxy server.

set http-proxy-server-port

To set the HTTP/HTTPS proxy server port for Smart Software Licensing and Smart Call Home, use the **set http-proxy-server-port** command.

set http-proxy-server-port *port_number*

Syntax Description	<i>port_number</i>	The port for the HTTP or HTTPS proxy server; range is 1 to 65535.
Command Default	The HTTP/HTTPS proxy is disabled by default. The proxy must be enabled before you enter the server address and port number.	
Command Modes	Callhome mode	
Usage Guidelines	If your network uses an HTTP proxy for Internet access, you must enable the proxy and configure its address for Smart Software Licensing. This proxy is also used for Smart Call Home in general.	

Example

This example shows how to enter an HTTP/HTTPS proxy-server port number:

```
FP9300-A# scope monitoring
FP9300-A /monitoring # scope callhome
FP9300-A /monitoring/callhome # set http-proxy-server-port 443
FP9300-A /monitoring/callhome #
```

Related Commands	Command	Description
	set http-proxy-server-enable	Enables or disables the HTTP/HTTPS proxy for Smart Software Licensing and Smart Call Home.
	set http-proxy-server-url	Sets the HTTP/HTTPS address for the proxy server.

set http-proxy-server-url

To set the HTTP/HTTPS proxy server address for Smart Software Licensing and Smart Call Home, use the **set http-proxy-server-url** command.

set http-proxy-server-url *url*

Syntax Description	<i>url</i>	The HTTP or HTTPS address of the proxy server; can be a maximum of 2083 characters.
Command Default	The HTTP/HTTPS proxy is disabled by default. The proxy must be enabled before you enter the server address.	
Command Modes	Callhome mode	
Usage Guidelines	If your network uses an HTTP proxy for Internet access, you must enable the proxy and configure its address for Smart Software Licensing. This proxy is also used for Smart Call Home in general.	

Example

This example shows how to enter an HTTPS proxy-server address:

```
FP9300-A# scope monitoring
FP9300-A /monitoring # scope callhome
FP9300-A /monitoring/callhome # set http-proxy-server-url https://209.165.201.10
FP9300-A /monitoring/callhome #
```

Related Commands	Command	Description
	set http-proxy-server-enable	Enables or disables the HTTP/HTTPS proxy for Smart Software Licensing and Smart Call Home.
	set http-proxy-server-port	Sets the communications port for the proxy server.

set https

To specify HTTPS service parameters, use the **set https** command.

```
set https {auth-type {cert-auth | cred-auth} | cipher-suite cipher_string | cipher-suite-mode
{custom | high-strength | low-strength | medium-strength} | crl-mode {relaxed | strict} | keyring
keyring_name | port port_number}
```

Syntax Description

auth-type { cert-auth cred-auth }	(Optional) Specifies the type of authentication to use for HTTPS access: <ul style="list-style-type: none"> • cert-auth—Sets your system to use a client certificate in conjunction with LDAP to authenticate users for HTTPS access. • cred-auth—Sets the system to use credential-based user authentication for HTTPS access.
cipher-suite <i>cipher_string</i>	(Optional) Specifies the definition string for the cipher suite to be used with the custom cipher-suite-mode . The specification string can contain up to 256 characters and must conform to the OpenSSL Cipher Suite specifications. You cannot use any spaces or special characters, except ! (exclamation point), + (plus sign), - (hyphen), and : (colon). See http://httpd.apache.org/docs/2.0/mod/mod_ssl.html#sslciphersuite for additional information. Note This string is ignored if cipher-suite-mode is set to anything other than custom .
cipher-suite-mode { custom high-strength low-strength }	(Optional) Sets the level of Cipher Suite security used: <ul style="list-style-type: none"> • custom—Lets you define a custom Cipher Suite security specification string using the cipher-suite option. • high-strength—ALL:!EDH-RSA-DES-CBC3-SHA: !EDH-DSS-DES-CBC3-SHA: !DES-CBC3-SHA:!ADH:!3DES: !EXPORT40:!EXPORT56:!LOW:!MEDIUM:!eNULL:!RC4:!MD5: !IDEA:+HIGH:+EXP • low-strength—ALL:!EDH-RSA-DES-CBC3-SHA: !EDH-DSS-DES-CBC3-SHA: !DES-CBC3-SHA:!ADH:!3DES: !EXPORT40:!EXPORT56:RC4+RSA: !IDEA:+HIGH:+MEDIUM:+LOW:+EXP:+eNULL • medium-strength—ALL:!EDH-RSA-DES-CBC3-SHA: !EDH-DSS-DES-CBC3-SHA: !DES-CBC3-SHA:!ADH:!3DES:!EXPORT40:!EXPORT56: !LOW:!RC4:!MD5:!IDEA:+HIGH:+MEDIUM:+EXP:+eNULL <p>Generally, cipher strength is roughly based on the bits of security (or symmetric key size), with “low” meaning less than 128 bits of security, “medium” meaning equal to 128 bits, and “high” meaning greater than 128 bits of security.</p>

crl-mode { **relaxed** | **strict** } (Optional) Defines the level of certificate revocation list (CRL) checking for HTTPS connections:

- **relaxed**—Certificates found on a CRL may be used to allow HTTPS authentication, depending on the reason for the certificate's listing; a warning message is logged whenever this occurs. Essentially disables CRL checking.
- **strict**—Connection authentication fails for any certificate on a CRL; a warning message is logged whenever this occurs. Also, the CRL must be up to date.

keyring *keyring_name* (Optional) Specifies the name of the RSA keyring to be used for HTTPS connections.

port *port_number* (Optional) Specifies the port to be used for HTTPS connections; can be 1 to 65535. Default is 443.

Command Default

The default HTTPS authentication configuration on the Firepower 4100/9300 chassis is credential-based. The default Cipher Suite security level is medium strength.

Command Modes

Services mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

If certificate authentication is enabled, that is the only form of authentication permitted for HTTPS.

The following requirements must be met by the client certificate to use this feature:

- The user name must be included in the X509 attribute Subject Alternative Name email.
- The client certificate must be signed by a root CA which has had its certificate imported into a trustpoint on the supervisor.



Caution

When you commit most of these configuration parameters (specifically keyring, port, cipher-suite, and custom cipher-suite-mode), all current HTTP and HTTPS sessions are closed without user warning.

Example

This example shows how to enable certificate-based authentication for HTTPS access:

```
FP9300-A# scope system
FP9300-A /system # scope services
FP9300-A /system/services # set https auth-type cert-auth
FP9300-A /system/services* # commit-buffer
FP9300-A /system/services #
```

Related Commands	Command	Description
	enable https	Enables the HTTPS service.
	show https	Shows current HTTPS service configuration.

set (interface)

To specify or change the parameters for an interface, use the **set** command in interface mode.

set

{ **admin-duplex** | **admin-speed** | **auto-negotiation** | **descr** | **eth-link-profile** | **flow-control-policy** | **nw-ctrl-policy** | **port-type** | **user-label** }

Syntax	Description
admin-duplex { fullduplex halfduplex }	Defines the duplex mode for the interface: <ul style="list-style-type: none"> • fullduplex – Specifies simultaneous two-way communications. • halfduplex – Specifies one-way-at-a-time communications.
admin-speed { 100gbps 100mbps 10gbps 10mbps 1gbps 40gbps }	Specify the interface data-transfer speed: <ul style="list-style-type: none"> • 100gbps – One hundred Gigabits per second. • 100mbps – One hundred Megabits per second. • 10gbps – Ten Gigabits per second. • 10mbps – Ten Megabits per second. • 1gbps – One Gigabit per second. • 40gbps – Forty Gigabits per second.
auto-negotiation { no yes }	Enables or disables auto-negotiation of common transmission parameters such as speed, duplex and flow control. <ul style="list-style-type: none"> • no – Disables auto-negotiation. • yes – Enables auto-negotiation.
descr <i>description</i>	You can add a description to the interface; the description can be between zero and 256 characters. Most alphanumeric characters are allowed, as are dashes and underscores; spaces are not allowed. The string can end with punctuation such as semi-colon, period (full stop), and exclamation point, but you cannot embed those characters in the description.
eth-link-profile <i>name</i>	You can assign an Ethernet Link Profile to the interface, automatically configuring the interface according to the profile parameters. Provide the name of the profile; can be up to 16 alphanumeric characters.
flow-control-policy <i>name</i>	You can assign a flow-control policy to the interface; provide the policy name, which can be up to 16 alphanumeric characters.
nw-ctrl-policy <i>name</i>	You can assign a network-control policy to the interface; provide the policy name, which can be up to 16 alphanumeric characters.

port-type { cluster data data-sharing firepower-eventing mgmt }	Specify the interface type or function: <ul style="list-style-type: none"> • cluster – Specify cluster only if you want to use this interface as the cluster control link. • data – Use for regular data transmission. This is the default type. • data-sharing – Use for regular data; only supported with container instances. • firepower-eventing – Use this interface as a secondary management interface for threat defense devices. The firepower-eventing interface is used to carry all event traffic (such as Web events). • mgmt – Use to manage application instances. You can only assign one management interface per logical device.
--	--

See [set port-type, on page 329](#) for more information about this command.

user-label <i>label</i>	You can apply a descriptive label to this interface. can be between zero and 16 alphanumeric characters.
--------------------------------	--

Command Modes

scope eth-uplink/scope fabric a/interface/

Command History

Release	Modification
2.4(1)	We added the data-sharing type.
1.1(4)	We added the firepower-eventing type.
1.1(1)	Command added.

Usage Guidelines

The type `cluster` is a special interface type used for a clustered logical device. This type is automatically assigned to the cluster control link for inter-unit cluster communications. By default, the cluster control link is automatically created on port-channel 48.

Data interfaces cannot be shared between logical devices.

The type `data-sharing` is supported only with container instances, these data interfaces can be shared by one or more logical devices/container instances (threat defense-only). Each container instance can communicate over the backplane with all other instances that share this interface. Shared interfaces can affect the number of container instances you can deploy. Shared interfaces are not supported for bridge group member interfaces (in transparent mode or routed mode), inline sets, passive interfaces, or failover links.

A `firepower-eventing` interface is a secondary management interface for threat defense devices. To use this interface, you must configure its IP address and other parameters at the threat defense CLI. For example, you can separate management traffic from events (such as Web events). See the “Management Interfaces” section in the *System Configuration* chapter of the Management Center configuration guide. Firepower-eventing interfaces can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface.

Use `mgmt` interfaces to manage application instances. They can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface. You can only assign one management interface per logical device.

The interface speed that you specify can affect the duplex mode used for an interface, so you must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. If you specify a speed of 1000 Mbps (1Gbps) or faster, full duplex is automatically used.

If you edited the default flow control policy, it is already applied to interfaces. If you created a new policy, you can apply it to the interface.

Example

This example shows how to set the interface speed to 10 Gbps and the port type to data:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # enter interface Ethernet1/8
firepower /eth-uplink/fabric/interface # enable
firepower /eth-uplink/fabric/interface* # set admin-speed 10gbps
firepower /eth-uplink/fabric/interface* # set port-type data
firepower /eth-uplink/fabric/interface* # commit-buffer
firepower /eth-uplink/fabric/interface
```

Related Commands

Command	Description
enter interface	Enters an interface so you can configure and manage the interface settings.
scope interface	Scopes into an interface so you can configure and manage the interface settings.
show interface	Displays interface configuration and status information.

set ipv6

To enable or disable the IPv6 support on firepower device, use the **set ipv6** command in fabric interconnect mode.

set ipv6 [**enable** | **disable**]

Syntax Description	enable/disable	Enables or disables IPv6 support on the firepower device.
Command Modes	scope fabric-interconnect/scope ipv6-config	
Command History	Release	Modification
	2.13(1)	Command added.
Usage Guidelines	By default, IPv6 will not be set. Use this command to enable or disable IPv6.	

Example

This example shows how to enable IPv6 in a firepower device:

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6 enable
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

set ipv6-auto eui64

To generate IPv6 address based on eui64 method, use the **set ipv6-auto eui64** command in fabric interconnect mode. The lower 64 bits are derived from the hardware address identifier such as MAC.

set ipv6 auto eui64

Syntax Description	auto eui64	Generates the ipv6 address based on the hardware identifiers.
Command Modes	scope fabric-interconnect/scope ipv6-config	
Command History	Release	Modification
	2.13(1)	Command added.
Usage Guidelines	You must have a valid global address present on the management interface to set ipv6-auto eui64.	

Example

This example shows how to set the ipv6-auto eui64:

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6-auto eui64
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

set ipv6-auto stablesec

To generate ipv6 address based on stable secret seed mechanism, use the **set ipv6-auto stablesec** command in fabric interconnect mode.

set ipv6 auto stablesec

Syntax Description	auto stablesec	Generates the ipv6 address based on the stable secret seed values.
Command Modes	scope fabric-interconnect/scope ipv6-config	
Command History	Release	Modification
	2.13(1)	Command added.

Example

This example shows how to set the ipv6-auto stablesec:

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6-auto stablesec
Warning: Setting ipv6readycfg to stablesec will require reboot
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```


set ipv6-ready

To set the IPv6 address based on eui64 or stable secret seed method based on the input IPv6 address, use the **set ipv6-ready** command in fabric interconnect mode.

set ipv6-ready [**ipv6-addr** *address* **ipv6-readyconfig-eui64** **ipv6-readyprefix** *prefix* | **ipv6-addr** *address* **ipv6-readyconfig stablesec** **ipv6-readyprefix** *prefix*]

Syntax Description	ipv6-addr <address>	Input IPv6 address
	ipv6-readyconfig eui64	eui64 method to generate the ipv6 address based on the input address
	ipv6-readyconfig stablesec	stablesec method to generate the ipv6 address based on the input address
	ipv6-readyprefix <prefix>	IPv6 prefix
Command Modes	scope fabric-interconnect/scope ipv6-config	
Command History	Release	Modification
	2.13(1)	Command added.

Example

This example shows how to set the set the ipv6 address based on eui64 method :

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6-ready ipv6-addr 2003::12
ipv6-readyconfig eui64 ipv6-readyprefix 64
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

This example shows how to set the set the ipv6 address based on stablesec method :

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6-ready ipv6-addr
e2ca:83a7:eb48:8f6f:da04:949b:b701:1049 ipv6-readyconfig stablesec ipv6-readyprefix 64
Warning: Setting ipv6readycfg to stablesec will require reboot
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

set keyring-name

To assign a keyring to an IPsec connection, use the **set keyring-name** command.

set keyring-name *name*

Syntax Description	<i>name</i>	The name of a keyring to be assigned to the IPsec connection; maximum of 16 characters.
---------------------------	-------------	---

Command Modes Connection (/security/ipsec/connection) mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to add a keyring to an IPsec connection.

Example

This example shows how to add a keyring to the current IPsec connection:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set keyring-name kr22
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #
```

Command	Description
create connection	Creates a new IPsec connection.
set keyring-passwd	Specifies the passphrase for a keyring assigned to an IPsec connection.

set lastname

To specify the last name of a local user, use the **set lastname** command.

set lastname *name*

Syntax Description	<i>name</i>	The user's surname; can be 0 to 32 characters.
Command Modes	Local user mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter security mode, create a new local user account, and then specify a first name and a last name for that user.

```
FP9300-A# scope security
FP9300-A /security # create local-user test_user
FP9300-A /security/local-user* # set firstname john
FP9300-A /security/local-user* # set lastname doe
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Command	Description
create local-user	Creates a new local-user account.
set firstname	Specifies the first name for a local user account.

set link-state-sync

To synchronize the operational link state with the physical link state for data interfaces using a service state, use the **set link-state-sync** command.

set link-state-sync

Syntax Description

This command has no arguments or keywords.

Command Modes

scope ssa

Command History

Release	Modification
2.9(1)	Command added.

Usage Guidelines

Use this command to synchronize the FTD operational link state with the physical link state for data interfaces.

Example

This example shows how to enter scope ssa mode and then set the link-state-sync.

```
firepower# scope ssa
firepower /ssa # scope logical-device <logical device identifier>
firepower /ssa/logical-device # set link-state-sync ?
    disabled  Disabled
    enabled   Enabled
```

set local-address

To specify the local IP address for an IPsec connection, use the **set local-address** command.

set local-address *ip_address*

Syntax Description	<i>ip_address</i>	Provide an IPv4 or IPv6 local gateway address for the IPsec connection; maximum of 510 characters.
Command Modes	Connection mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command and the set remote-address command to define the endpoints of an IPsec connection.	

Example

This example shows how to set the local address for an IPsec connection:

```

FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set local-address 209.165.201.12
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #

```

Command	Description
create connection	Creates a new IPsec connection.
set remote-addr	Sets the remote IP address for an IPsec connection.

set log-level

To specify the IPsec logging level, use the **set log-level** command.

set log-level *log_level*

Syntax Description	<i>log_level</i>	Enter a value between 0 and 4 to specify IPsec log verbosity; default is 1. 0 – Basic auditing information; for example, SA up/down. 1 – General control flow information, with errors. 2 – More detailed control flow information; includes debugging information. 3 – Includes raw data dumps (hexadecimal). 4 – Includes sensitive information in the data dumps; for example, SA keys.
---------------------------	------------------	--

Command Modes	IPsec mode
----------------------	------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use the **show ipsec-log** command to view the logs.

Example

This example shows how to set the IPsec logging level to 2:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # set log-level 2
FP9300-A /security/ipsec* # commit-buffer
FP9300-A /security/ipsec #
```

Related Commands	Command	Description
	show ipsec-log	Shows the IPsec log file.

set max-login-attempts

To specify the maximum number of failed login attempts allowed, use the **set max-login-attempts** command.

set max-login-attempts *max_attempts*

Syntax Description	<i>max_attempts</i>	The maximum number of failed login attempts before the user is locked out of the system. The value can range from 0 to 10; the default is 0.
---------------------------	---------------------	--

Command Modes	Security mode
----------------------	---------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines If any user (including admin users) exceeds this maximum number of login attempts, the user is locked out of the system and must wait a specified amount of time before being allowed to log in again. No notification appears indicating that the user is locked out.

Example

This example shows how to enter security mode and specify a maximum number of login attempts:

```
FP9300-A# scope security
FP9300-A /security # set max-login-attempts 4
FP9300-A /security* # commit-buffer
FP9300-A /security #
```

Related Commands	Command	Description
	clear lock-status	Clears a user's locked-out status.
	set user-account-unlock-time	Specifies the amount of time a user remains locked out of the system after reaching the maximum number of login attempts.

set message

To add or replace the lines of text presented as the pre-login banner, use the **set message** command.

set message

Syntax Description

This command has no arguments or keywords.

Command Modes

scope security/scope banner/scope pre-login-banner/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

After entering the command, you are prompted to enter the lines of banner text. You must enter `ENDOFBUF` (must be all capital letters) to terminate the banner text.



Note The pre-login banner object must already exist; see [create pre-login-banner, on page 94](#).

Example

This example shows you how to create and specify a pre-login banner, then commit and view it:

```
firepower # scope security
firepower /security # scope banner
firepower /security/banner # create pre-login-banner
firepower /security/banner/pre-login-banner* # set message
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
Enter prelogin banner:
>Firepower-9300-2
>Western Data Center
>ENDOFBUF
firepower /security/banner/pre-login-banner* # commit
firepower /security/banner/pre-login-banner # show

Pre login banner:
  Message
  -----
  Firepower-9300-2
  Western Data Center

firepower /security/banner/pre-login-banner #
```

Related Commands

Command	Description
clear message	Removes the text from an existing pre-login banner; the actual banner object itself is not deleted.

Command	Description
create pre-login-banner	Creates a banner to be presented prior to the log-in screen; the banner object is initially empty.

set min-password-length

To specify a minimum length for user passwords, use the **set min-password-length** command.

set min-password-length *num_chars*

Syntax Description	<i>num_chars</i>	The minimum number of characters required for user passwords; value can range from 8 to 80.
---------------------------	------------------	---

Command Modes	Security mode
----------------------	---------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines If enabled, users must create passwords with the specified minimum number of characters or more. For example, if *num_chars* is set to 15, passwords must consist of at least 15 characters.

Example

This example shows how to enter security mode and specify a minimum password length of 15 characters:

```
FP9300-A# scope security
FP9300-A /security # set min-password-length 15
FP9300-A /security* # commit-buffer
FP9300-A /security #
```

Related Commands	Command	Description
	set enforce-strong-password	Enables and disables strong password enforcement.

set mode

To specify the IPSec connection mode, use the **set mode** command.

```
set mode {transport | tunnel}
```

Syntax Description	transport	Sets the connection mode to transport .
	tunnel	Sets the connection mode to tunnel .
Command Modes	Connection mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	In transport mode, only the payload of an IP packet is encrypted; in tunnel mode, the entire packet is encrypted. Transport mode is generally used for end-to-end sessions, and tunnel mode is used for all other types of connections (for example, between gateways).	

Example

This example shows how to set the IPSec connection mode to tunnel:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set mode tunnel
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #
```

Command	Description
create connection	Creates a new IPSec connection.
set local-addr	Sets the local IP address for an IPSec connection.
set remote-addr	Sets the remote IP address for an IPSec connection.

set modulus

To specify the RSA key modulus (SSL key length) in bits, use the **set modulus** command.

set modulus { **mod1536** | **mod2048** | **mod2560** | **mod3072** | **mod3584** | **mod4096** }

Syntax Description

RSA key modulus (SSL key length) in bits

Valid options are:

- **mod1536** – Modulus is 1536 bits
- **mod2048** – Modulus is 2048 bits
- **mod2560** – Modulus is 2560 bits
- **mod3072** – Modulus is 3072 bits
- **mod3584** – Modulus is 3584 bits
- **mod4096** – Modulus is 4096 bits

Command Modes

Keyring mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use this command to specify the key length for a keyring.

Example

This example shows how to specify a key length of 2048 bits for a keyring:

```
FP9300-A# scope security
FP9300-A /security # scope keyring test-ring
FP9300-A /security/keyring # set modulus 2048
FP9300-A /security/keyring* # commit-buffer
switch-A /security/keyring #
```

Related Commands

Command	Description
set cert	Enters an RSA certificate for a keyring.
set regenerate	Regenerates the RSA keys in the default keyring.
set trustpoint	Specifies whether the keyring certificate can be regenerated.

set nd

To enable or disable the IPv6 ND support on the firepower device, use the **set nd** command in fabric interconnect mode.

set nd [**enable** | **disable**]

Syntax Description	enable	Enables the rdnssd (ipv6 recursive dns server discovery daemon) to run, once it is set to enable.
	disable	Disables the rdnssd daemon in the firepower device.
Command Modes	scope fabric-interconnect/scope ipv6-config	
Command History	Release	Modification
	2.13(1)	Command added.
Usage Guidelines	By default, ND will not be set. Use this command to enable or disable IPv6.	

Example

This example shows how to enable ND in a firepower device:

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set nd enable
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

set out-of-band

To change the management IP address for the device, use the **set out-of-band** command.

For an IPv4 address:

```
set out-of-band { gw gateway_address | ip ip_address | netmask network_mask }
```

For an IPv6 address:

```
set out-of-band { ipv6 ipv6_address | ipv6-gw ipv6_gateway | ipv6-prefix ipv6_prefix }
```

Syntax Description

gw <i>gateway_address</i>	Provide an IPv4 gateway address.
ip <i>ip_address</i>	Provide an IPv4 address for device management access.
netmask <i>network_mask</i>	Provide a netmask for the IPv4 address.
ipv6 <i>ipv6_address</i>	Provide an IPv6 address for device management access.
ipv6-gw <i>ipv6_gateway</i>	Provide an IPv6 gateway address.
prefix <i>ipv6_prefix</i>	Provide a prefix length for the IPv6 address.
Note	Only IPv6 Global Unicast addresses are supported as the chassis's IPv6 management address.

Command Modes

IPv4 address: fabric interconnect mode

IPv6 address: IPv6 configuration (fabric-interconnect/ipv6-config) mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

After changing the management IP address, you will need to re-establish any existing connections using the new address.

You can enter the three keywords and variables, for either IP address type, in any order on one command line. See the following examples.



Note Only IPv6 Global Unicast addresses are supported as the chassis's IPv6 management address.

Examples

This example shows how to display the current IPv4 management interface and gateway addresses, and specify new addresses:

```
FP9300-A # scope fabric-interconnect a  
FP9300-A /fabric-interconnect # show
```

```

Fabric Interconnect:
ID   OOB IP Addr      OOB Gateway      OOB Netmask      OOB IPv6 Address OOB IPv6 Gateway
Prefix Operability
-----
A    192.0.2.112     192.0.2.1       255.255.255.0   ::                ::                64
Operable
FP9300-A /fabric-interconnect # set out-of-band ip 192.0.2.112 netmask 255.255.255.0 gw
192.0.2.1
Warning: When committed, this change may disconnect the current CLI session
FP9300-A /fabric-interconnect* # commit-buffer
FP9300-A /fabric-interconnect #

```

This example shows how to display the current IPv6 management interface and gateway addresses, and specify new addresses:

```

FP9300-A # scope fabric-interconnect a
FP9300-A /fabric-interconnect # scope ipv6-config
FP9300-A /fabric-interconnect/ipv6-config # show ipv6-if

Management IPv6 Interface:
IPv6 Address                Prefix      IPv6 Gateway
-----
2001::8998                  64         2001::1
FP9300-A /fabric-interconnect/ipv6-config # set out-of-band ipv6 2001::8999 ipv6-prefix 64
ipv6-gw 2001::1
FP9300-A /fabric-interconnect/ipv6-config* # commit-buffer
FP9300-A /fabric-interconnect/ipv6-config #

```

Command	Description
show	Shows the current device management IP addresses.
show ipv6-if	Shows the current device management IPv6 address.

set password

To specify the password for a user account, use the **set password** command.

set password

Syntax Description

This command has no arguments or keywords.

Command Modes

`scope security/` – to change the password for the currently logged-in user

`scope security/scope local-user/` – to specify a password for the current local user

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

After entering the **set password** command, you are prompted to enter and confirm the password. For security purposes, the password that you type does not appear in the CLI window.

This password must be a minimum of eight characters and a maximum of 80 characters. Use [set min-password-length, on page 312](#) to define a specific minimum number of characters. Use [set enforce-strong-password, on page 281](#) to require use of “strong” passwords.

Example

This example shows how to enter security mode, create a new local user account and specify a password for that user:

```
firepower# scope security
firepower /security # create local-user test_user
firepower /security/local-user* # set password
Enter a password:
Confirm the password:
firepower /security/local-user* # commit-buffer
firepower /security/local-user #
```

Command	Description
create local-user	Creates a new local-user account.
set expiration	Specifies the date on which the user account expires.

set password-encryption-key

To specify a key for use when encrypting sensitive information during configuration export, use the **set password-encryption-key** command.

set password-encryption-key

Syntax Description

This command has no arguments or keywords. After you enter the command, you are asked to enter and confirm an encryption key.

The key can be between four and 40 characters long; the key you enter is then used to generate a 128-bit MD5 hash value.

Command Modes

scope security/

Command History

Release	Modification
2.6.1	Command added.

Usage Guidelines

You can use the configuration export feature to export an XML file containing logical device and platform configuration settings for your Firepower 4100/9300 chassis to a remote server. You can later import that configuration file to quickly apply the configuration settings to your Firepower 4100/9300 chassis to return to a known good configuration or to recover from a system failure.

Beginning with FXOS 2.6.1, you must specify a key for use when encrypting sensitive information such as passwords and other secret keys during configuration export, and you must have specified it before you attempt to export the configuration.

Also, the same key used during export must be set on the target system when you import an exported configuration, unless the file was exported from an FXOS release prior to 2.6.1, in which case the target system will allow the import.

Once a password encryption key is set, it cannot be changed or deleted unless you perform a factory-reset or password-recovery. Factory-reset or password-recovery will clear the key as if it had never been set.

Example

This example shows how to specify a password encryption key prior to exporting the current configuration:

```
firepower # scope security
firepower /security # set password-encryption-key
Enter a key:
Confirm the key:
Warning: Please make note of the encryption key configured. If you change the key, importing
configurations that were exported with the previous key will fail, because Import and
Export requires the same encryption key on the system.
firepower /security* # commit-buffer
firepower /security #
```

Related Commands	Command	Description
	cfg-export-policy	Configures an export policy.
	export-config	Exports the current system configuration to a remote server as an XML file.
	import-config	Copies a previously exported XML configuration file to this appliance.

set (password-profile)

To specify or change local-user password-profile parameters, use the **set** command in password-profile mode.

set { **change-count** | **change-during-interval** | **change-interval** | **history-count** | **no-change-interval** }

Syntax Description

change-count <i>count</i>	The maximum number of times a user can change his or her password (during the time period specified with set change-interval); value can be 0 to 10.
change-during-interval { disable enable }	<p>Enable or disable restrictions on the number of password changes a locally authenticated user can make:</p> <ul style="list-style-type: none"> disable – Disables restrictions on the number of password changes. enable – Enables restrictions on the number of password changes. <p>This option must be enabled before you can specify the maximum number of times a locally authenticated user can change his or her password, and the number of hours over which that number of password changes can be made.</p>
change-interval <i>interval</i>	<p>The interval over which a user's password changes are tallied to ensure they do not exceed the maximum number specified with the set change-count command; the number of hours can be 1 to 745.</p> <p>The set change-during-interval option must be enabled before you can specify this interval.</p>
history-count <i>count</i>	<p>The number of unique passwords that a locally authenticated user must create before that user can re-use a previously used password; value can be 0 to 15.</p> <p>By default, the <i>count</i> value is zero, which disables the password history count, allowing users to re-use previously used passwords at any time.</p>
no-change-interval <i>hours</i>	<p>The length of time in hours during which a user cannot change her or his password again; value can be 1 to 745.</p> <p>The set change-during-interval option must be disabled before you set this time period, otherwise this value is ignored.</p>

Command Modes

scope security/scope password-profile/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

The **set change-during-interval** option must be enabled before you can specify the maximum number of times a locally authenticated user can change his or her password, and the number of hours over which that number of password changes can be made.

By default, the **set history-count** value is zero, which disables the password history count, allowing users to re-use previously used passwords at any time.

Examples

This example shows how to enter password profile mode, enable password-change restrictions, specify that a user can change his or her password only twice in any 48-hour period, and then view the current settings:

```
firepower # scope security
firepower /security # scope password-profile
firepower /security/password-profile # set change-during-interval enable
firepower /security/password-profile* # set change-count 2
firepower /security/password-profile* # set change-interval 48
firepower /security/password-profile* # commit-buffer
firepower /security/password-profile # show detail
```

```
Password profile:
  Password history count: 5
  No password changes allowed (in Hours): 24
  Password change during interval: Enable
  Password change interval (in Hours): 48
  Password change count: 2
firepower /security/password-profile #
```

Related Commands

Command	Description
show detail	Displays the current password-profile settings.

set phone

To set a contact telephone number for a user account, use the **set phone** command.

set phone *tel_number*

Syntax Description	<i>tel_number</i>	A contact telephone number for the user account; maximum of 20 characters.
Command Modes	Local user mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to specify an telephone number for the current local user:

```
FP9300-A /security/local-user # set phone +1-408-555-1212
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Related Commands	Command	Description
	create local-user	Creates a new local user account.
	set phone-contact	Specifies a contact telephone number for a Smart Call Home account.

set (port-channel)

To specify or edit the parameters for an existing port-channel, use the **set** command in port-channel mode.

set { **auto-negotiation** | **descr** | **duplex** | **flow-control-policy** | **lACP-policy-name** | **nw-ctrl-policy** | **port-channel-mode** | **port-type** | **speed** }

Syntax	Description
auto-negotiation { no yes }	Enables or disables auto-negotiation of common transmission parameters such as speed, duplex and flow control. <ul style="list-style-type: none"> • no – Disables auto-negotiation. • yes – Enables auto-negotiation.
descr <i>description</i>	You can add a description to the port-channel; the description can be between zero and 256 characters. Most alphanumeric characters are allowed, as are dashes and underscores; spaces are not allowed. The string can end with punctuation such as semi-colon, period (full stop), and exclamation point, but you cannot embed those characters in the description.
duplex { fullduplex halfduplex }	Defines the duplex mode for the port-channel: <ul style="list-style-type: none"> • fullduplex – Specifies simultaneous two-way communications. • halfduplex – Specifies one-way-at-a-time communications.
flow-control-policy <i>name</i>	You can assign a flow-control policy to the port-channel; provide the policy name, which can be up to 16 alphanumeric characters.
lACP-policy-name <i>name</i>	You can assign a LACP policy to the port-channel; provide the policy name, which can be up to 16 alphanumeric characters.
nw-ctrl-policy <i>name</i>	You can assign a network-control policy to the port-channel; provide the policy name, which can be up to 16 alphanumeric characters.
port-channel-mode { active on }	Define the mode for the port-channel's physical data or data-sharing interfaces: <ul style="list-style-type: none"> • active – Sends and receives LACP updates. An active port-channel can establish connectivity with either an active or a passive port-channel. You should use the active mode unless you need to minimize the amount of LACP traffic. This is the default. • on – The port-channel is always on, and LACP is not used. An “on” port-channel can only establish a connection with another “on” port-channel. <p>Non-data interfaces support only active mode.</p>

port-type { cluster data data-sharing firepower-eventing mgmt }	Specify the port-channel type or function: <ul style="list-style-type: none"> • cluster – Specify cluster only if you want to use this port-channel as the cluster control link. • data – Use for regular data transmission. This is the default type. • data-sharing – Use for regular data; only supported with container instances. • firepower-eventing – Use this port-channel as a secondary management interface for threat defense devices. The firepower-eventing port-channel is used to carry all event traffic (such as Web events). • mgmt – Use to manage application instances. You can only assign one management interface per logical device.
--	--

See [set port-type, on page 329](#) for more information about this command.

speed { 100gbps 100mbps 10gbps 10mbps 1gbps 40gbps }	Specify the port data-transfer speed: <ul style="list-style-type: none"> • 100gbps – One hundred Gigabits per second. • 100mbps – One hundred Megabits per second. • 10gbps – Ten Gigabits per second. • 10mbps – Ten Megabits per second. • 1gbps – One Gigabit per second. • 40gbps – Forty Gigabits per second.
--	--

Command Modes scope eth-uplink/scope fabric a/port-channel/

Command History

Release	Modification
2.4(1)	We added the data-sharing type.
1.1(4)	We added the firepower-eventing type.
1.1(1)	Command added.

Usage Guidelines

Assign member interfaces to the port-channel before using this command to set parameters.

The LACP port-channel mode applies to data and data-sharing interfaces only. For non-data and non-data-sharing interfaces, the mode is always *active*.

The type `cluster` is a special interface type used for a clustered logical device. This type is automatically assigned to the cluster control link for inter-unit cluster communications. By default, the cluster control link is automatically created on port-channel 48.

Data interfaces cannot be shared between logical devices.

The type `data-sharing` is supported only with container instances, these data interfaces can be shared by one or more logical devices/container instances (threat defense-only). Each container instance can communicate over the backplane with all other instances that share this interface. Shared interfaces can affect the number

of container instances you can deploy. Shared interfaces are not supported for bridge group member interfaces (in transparent mode or routed mode), inline sets, passive interfaces, or failover links.

A `firepower-eventing` interface is a secondary management interface for threat defense devices. To use this interface, you must configure its IP address and other parameters at the threat defense CLI. For example, you can separate management traffic from events (such as Web events). See the “Management Interfaces” section in the *System Configuration* chapter of the Management Center configuration guide. Firepower-eventing interfaces can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface.

Use `mgmt` interfaces to manage application instances. They can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface. You can only assign one management interface per logical device.

The interface speed that you specify can affect the duplex mode used for an interface, so you must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. If you specify a speed of 1000 Mbps (1Gbps) or faster, full duplex is automatically used.

If you edited the default flow control policy, it is already applied to interfaces. If you created a new policy, you can apply it to the port-channel.

Example

The following example creates Port-Channel 1 with four member interfaces, sets the type to data, and sets the EtherChannel to On mode.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # create port-channel 1
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # set port-type data
firepower /eth-uplink/fabric/port-channel* # set port-channel-mode on
firepower /eth-uplink/fabric/port-channel* # commit-buffer
firepower /eth-uplink/fabric/port-channel #
```

Related Commands

Command	Description
<code>create port-channel</code>	Adds an EtherChannel interface.
<code>scope interface</code>	Enters a physical interface so you can configure and manage the interface settings.

set port-channel-mode

To set the port channel mode for an EtherChannel, use the **set port-channel-mode** command.

```
set port-channel-mode {active | on}
```

Syntax Description	active	Sets the interface in an EtherChannel to be active.
	on	Sets the interface in an EtherChannel to be on. Only supported for Data or Data-sharing interfaces.
Command Default	The default mode is active.	
Command Modes	scope eth-uplink/scope fabric a/create port-channel/	
Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines	<p>You can configure each physical Data or Data-sharing interface in an EtherChannel to be:</p> <ul style="list-style-type: none"> • Active—Sends and receives LACP updates. An active EtherChannel can establish connectivity with either an active or a passive EtherChannel. You should use the active mode unless you need to minimize the amount of LACP traffic. • On—The EtherChannel is always on, and LACP is not used. An “on” EtherChannel can only establish a connection with another “on” EtherChannel.
-------------------------	---

Non-data interfaces only support active mode.

Example

The following example adds Port-Channel 1 with 4 member interfaces, sets the type to data, and sets the EtherChannel to On mode.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # create port-channel 1
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # set port-type data
firepower /eth-uplink/fabric/port-channel* # set port-channel-mode on
```

Related Commands	Command	Description
	create port-channel	Adds an EtherChannel interface.
	create member-port	Assigns a member to the EtherChannel.
	set port-type	Sets the interface type.

set port-type

To set the port type for an interface, use the **set port-type** command.

set port-type { **cluster** | **data** | **data-sharing** | **firepower-eventing** | **mgmt** }

Syntax	Description
cluster	Special interface type used for a clustered logical device. This type is automatically assigned to the cluster control link for inter-unit cluster communications. By default, the cluster control link is automatically created on port-channel 48. For multi-instance clustering, you cannot share a Cluster-type interface across devices. You can add VLAN subinterfaces to the Cluster EtherChannel to provide separate cluster control links per cluster. If you add subinterfaces to a Cluster interface, you cannot use that interface for a native cluster. device manager does not support clustering.
data	Data interfaces cannot be shared between logical devices.
data-sharing	Only supported with container instances, these data interfaces can be shared by one or more logical devices/container instances (threat defense-only). Each container instance can communicate over the backplane with all other instances that share this interface. Shared interfaces can affect the number of container instances you can deploy. Shared interfaces are not supported for bridge group member interfaces (in transparent mode or routed mode), inline sets, passive interfaces, clusters, or failover links.
firepower-eventing	This interface is a secondary management interface for threat defense devices. To use this interface, you must configure its IP address and other parameters at the threat defense CLI. For example, you can separate management traffic from events (such as web events). See the “Management Interfaces” section in the <i>System Configuration</i> chapter of the Management Center configuration guide. Firepower-eventing interfaces can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface.
mgmt	Use management interfaces to manage application instances. They can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface. You can only assign one management interface per logical device.

Command Default The default type is data.

Command Modes

```
scope eth-uplink/scope fabric a/scope interface/
scope eth-uplink/scope fabric a/scope interface/create subinterface/
scope eth-uplink/scope fabric a/create port-channel/
scope eth-uplink/scope fabric a/create port-channel/create subinterface/
```

Command History	Release	Modification
	2.8(1)	You can set the cluster type on a VLAN subinterface for use with multi-instance clustering.
	2.4(1)	We added the data-sharing type.
	1.1(4)	We added the firepower-eventing type.
	1.1(1)	Command added.

Usage Guidelines

Container instances can share data-sharing type interfaces. This capability lets you conserve physical interface usage as well as support flexible networking deployments. When you share an interface, the chassis uses unique MAC addresses to forward traffic to the correct instance. However, shared interfaces can cause the forwarding table to grow large due to the need for a full mesh topology within the chassis (every instance must be able to communicate with every other instance that is sharing the same interface). Therefore, there are limits to how many interfaces you can share.

In addition to the forwarding table, the chassis maintains a VLAN group table for VLAN subinterface forwarding. Depending on the number of parent interfaces and other deployment decisions, you can create up to 500 VLAN subinterfaces.

See the following limits for shared interface allocation:

- Maximum 14 instances per shared interface. For example, you can allocate Ethernet1/1 to Instance1 through Instance14.
- Maximum 10 shared interfaces per instance. For example, you can allocate Ethernet1/1.1 through Ethernet1/1.10 to Instance1.

See the following table for interface type support for FTD and ASA applications in standalone and cluster deployments.

Table 4: Interface Type Support

Application		Data	Data: Subinterface	Data-Sharing	Data-Sharing: Subinterface	Mgmt	Firepower Config	Cluster (EtherChannel only)	Cluster: Subinterface
FTD	Standalone Native Instance	Yes	—	—	—	Yes	Yes	—	—
	Standalone Container Instance	Yes	Yes	Yes	Yes	Yes	Yes	—	—
	Cluster Native Instance	Yes (EtherChannel only for inter-chassis cluster)	—	—	—	Yes	Yes	Yes	—
	Cluster Container Instance	Yes (EtherChannel only for inter-chassis cluster)	—	—	—	Yes	Yes	Yes	Yes
ASA	Standalone Native Instance	Yes	—	—	—	Yes	—	Yes	—
	Cluster Native Instance	Yes (EtherChannel only for inter-chassis cluster)	—	—	—	Yes	—	Yes	—

Examples

The following example adds Port-Channel 1 with 4 member interfaces, sets the type to data, and sets the EtherChannel to On mode.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # create port-channel 1
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
firepower /eth-uplink/fabric/port-channel/member-port* # exit
```

```
firepower /eth-uplink/fabric/port-channel* # set port-type data
firepower /eth-uplink/fabric/port-channel* # set port-channel-mode on
```

The following example adds three subinterfaces and sets the port type to data-sharing.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # enter interface Ethernet1/1
firepower /eth-uplink/fabric/interface # enter subinterface 10
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 10
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # enter subinterface 11
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 11
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # enter subinterface 12
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 12
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # commit-buffer
firepower /eth-uplink/fabric/interface/subinterface #
```

Related Commands

Command	Description
create port-channel	Adds an EtherChannel interface.
scope interface	Enters a physical interface so you can configure and manage the interface settings.

set port-type (aggr-interface)

To configure the port type for the interface, use the **set port-type** command.

```
set port-type { data | data-sharing | mgmt | firepower-eventing | cluster }
```

Syntax Description	
data	(Optional) Data interfaces cannot be shared between logical devices.
data-sharing	(Optional) Only supported with container instances, these data interfaces can be shared by one or more logical devices/container instances (FTD-only). Each container instance can communicate over the backplane with all other instances that share this interface. Shared interfaces can affect the number of container instances you can deploy. Shared interfaces are not supported for bridge group member interfaces (in transparent mode or routed mode), inline sets, passive interfaces, or failover links.
mgmt	(Optional) Use management interfaces to manage application instances. They can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface. You can only assign one management interface per logical device.
firepower-eventing	(Optional) This interface is a secondary management interface for FTD devices. To use this interface, you must configure its IP address and other parameters at the FTD CLI. For example, you can separate management traffic from events (such as web events). See the "Management Interfaces" section in the Management Center configuration guide System Configuration chapter. Firepower-eventing interfaces can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface.
cluster	(Optional) Special interface type used for a clustered logical device. This type is automatically assigned to the cluster control link for inter-unit cluster communications. By default, the cluster control link is automatically created on Port-channel 48.

Command Modes scope cabling/scope fabric a/

Command History	Release	Modification
	2.4(1)	Added the data-sharing type.
	1.1(4)	Added the firepower-eventing type.
	1.1(1)	Command added.

Usage Guidelines Container instances can share data-sharing type interfaces. This capability lets you conserve physical interface usage as well as support flexible networking deployments. When you share an interface, the chassis uses unique MAC addresses to forward traffic to the correct instance. However, shared interfaces can cause the forwarding table to grow large due to the need for a full mesh topology within the chassis (every instance

must be able to communicate with every other instance that is sharing the same interface). Therefore, there are limits to how many interfaces you can share.

Example

The following example shows to configure the interface port-type and then list the available commands:

```
firepower-9300* # scope cabling
firepower-9300 /cabling* # scope fabric a
firepower-9300 /cabling/fabric* # create breakout port breakout 2 1
firepower-9300 /cabling/fabric* # show config
  scope fabric a
+   enter breakout 2 3
+   exit
  exit
firepower-9300 /cabling/fabric* # exit
firepower-9300 /cabling* # exit
```

The system reboots after you use the `commit-buffer` command.

```
firepower-9300* # scope eth-uplink
firepower-9300 /eth-uplink* # scope fabric a
firepower-9300 /eth-uplink/fabric* # show
```

Fabric:

```
  Fabric ID
  -----
  Afirepower-9300 /eth-uplink/fabric* # show
<CR>
>          Redirect it to a file
>>         Redirect it to a file in append mode
aggr-interface Aggregate Interface
detail       Detail
event        Event Management
expand       Expand
fault        Fault
fsm          Fsm
interface    Interface
port-channel Port Channel
stats        statistics
|           Pipe command output to filter

firepower-9300 /eth-uplink/fabric* # show aggr-interface expand
firepower-9300 /eth-uplink/fabric* # show aggr-interface
  1-4      Slot
<CR>
>          Redirect it to a file
>>         Redirect it to a file in append mode
detail     Detail
expand     Expand
n/n        Ethernet<Slot Id>/<Aggregate Port Id>
|           Pipe command output to filter
firepower-9300 /eth-uplink/fabric* # show aggr-interface expand
firepower-9300 /eth-uplink/fabric* #
  acknowledge Acknowledge
  create       Create managed objects
  delete       Delete managed objects
  enter        Enters a managed object
  scope        Changes the current mode
  show         Show system information
```



```

firepower-9300 /eth-uplink/fabric* # scope aggr-interface
  1-4 Slot
  n/n Ethernet<Slot Id>/<Aggregate Port Id>

firepower-9300 /eth-uplink/fabric* # scope port-channel 2
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface* # create member-port
Ethernet2/1/1
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* # show config
+enter member-port 2 1
+exit
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* #
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* # exit
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface* # exit
firepower-9300 /eth-uplink/fabric/port-channel* # show config
  enter port-channel 2
    enable
+   enter aggr-interface 2 1
+     enter member-port 2 1
+     exit
+   exit
  enter member-port 1 6
    enable
  exit
  set auto-negotiation no
  set descr ""
  set duplex full duplex
  set flow-control-policy default
  set lacp-policy-name default
  set nw-ctrl-policy default
  set port-channel-mode active
  set port-type data
  set speed 1gbps
  exit

firepower-9300 /eth-uplink/fabric/port-channel* # set port-type
  cluster          Cluster
  data             Data
  data-sharing     Data Sharing
  firepower-eventing Firepower Eventing
  mgmt            Mgmt

firepower-9300 /eth-uplink/fabric/port-channel* # set port-type cluster
firepower-9300 /eth-uplink/fabric/port-channel* commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #

```

Related Commands

Command	Description
create port-channel	Adds an EtherChannel interface
scope interface	Edits a physical interface.

set prefix

To set the MAC address prefix to use when autogenerating MAC addresses for container instance interfaces, use the **set prefix** command.

set prefix *prefix*

Syntax Description	<i>prefix</i>	Specifies a decimal value between 1 and 65535. This prefix is converted to a four-digit hexadecimal number, and used as part of the MAC address.
---------------------------	---------------	--

Command Modes scope ssa/scope auto-macpool/

Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines The FXOS chassis automatically generates MAC addresses for container instance interfaces, and guarantees that a shared interface in each instance uses a unique MAC address.

If you manually assign a MAC address to a shared interface within the application, then the manually-assigned MAC address is used. If you later remove the manual MAC address, the autogenerated address is used. In the rare circumstance that the generated MAC address conflicts with another private MAC address in your network, we suggest that you manually set the MAC address for the interface within the application.

Because autogenerated addresses start with A2, you should not start manual MAC addresses with A2 due to the risk of overlapping addresses.



Note Even if you are not sharing a subinterface, if you manually configure MAC addresses, make sure you use unique MAC addresses for all subinterfaces on the same parent interface to ensure proper classification.

The FXOS chassis generates the MAC address using the following format:

A2*xx.yyzz.zzzz*

Where *xx.yy* is a user-defined prefix or a system-defined prefix, and *zz.zzzz* is an internal counter generated by the chassis. The system-defined prefix matches the lower 2 bytes of the first MAC address in the burned-in MAC address pool that is programmed into the IDPROM. Use **connect fxos**, then **show module** to view the MAC address pool. For example, if the range of MAC addresses shown for module 1 is b0aa.772f.f0b0 to b0aa.772f.f0bf, then the system prefix will be f0b0.

The user-defined prefix is an integer that is converted into hexadecimal. For an example of how the user-defined prefix is used, if you set a prefix of 77, then the chassis converts 77 into the hexadecimal value 004D (*yyxx*). When used in the MAC address, the prefix is reversed (*xyy*) to match the chassis native form:

A24D.00*zz.zzzz*

For a prefix of 1009 (03F1), the MAC address is:

A2F1.03*zz.zzzz*

Example

The following example sets the MAC prefix to 33.

```
firepower# scope ssa
firepower /ssa # scope auto-macpool
firepower /ssa/auto-macpool # set prefix 33
firepower /ssa/auto-macpool* # commit-buffer
firepower /ssa/auto-macpool
```

Related Commands	Command	Description
	scope ssa	Enters ssa mode.
	scope auto-macpool	Enter auto-macpool mode.
	show mac-address	Shows the assigned MAC addresses.

set protocol

To specify the protocol to use when communicating with the remote server for the export policy, use the **set protocol** command.

```
set protocol { ftp | scp | sftp | tftp }
```

Syntax Description

ftp	Specifies the File Transfer Protocol (FTP) for file transfer.
scp	Specifies the Secure Copy Protocol (SCP) for file transfer.
sftp	Specifies the Secure File Transfer Protocol (SFTP) for file transfer.
tftp	Specifies the Trivial File Transfer Protocol (TFTP) for file transfer.

Command Modes

Configuration export policy (/org/cfg-export-policy)

Command History

Release	Modification
2.0.1	Command added.

Usage Guidelines

Use this command to specify a file transfer protocol.

Example

This example shows how to set the port number for the export policy:

```
firepower-9300* # scope org
firepower-9300 /org* # scope cfg-export-policy default
firepower-9300 /org/cfg-export-policy* # set protocol scp
firepower-9300 /org/cfg-export-policy* # commit-buffer
firepower-9300 /org/cfg-export-policy #
```

Related Commands

Command	Description
set adminstate (/org)	Enables the export policy.
set hostname (/org)	Specifies the hostname location where the backup file must be stored.
set password (/org)	Specifies the password for the remote server username.
set port (/org)	Specifies the port number.
set protocol (/org)	Specifies the protocol to use when communicating with the remote server.
set remote-file (/org)	Specifies the full path to where you want the configuration file exported including the filename.
set schedule (/org)	Specifies the schedule on which you would like to have the configuration automatically exported.

Command	Description
set user (/org)	Specifies the username the system should use to log in to the remote server.

set realm

To specify the default authentication service, use the **set realm** command.

```
set realm { ldap | local | none | radius | tacacs }
```

Syntax Description

ldap	Specifies LDAP authentication.
local	Specifies local authentication.
none	Allows local users to log on without specifying a password.
radius	Specifies RADIUS authentication.
tacacs	Specifies TACACS+ authentication.

Command Modes

Default authentication mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to enter security/default-auth mode and set the default authentication service to Radius:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set realm radius
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

Related Commands

Command	Description
set auth-server-group	Specifies an associated authentication provider group.
set use-2-factor	Sets the authentication method to two-factor authentication for a Radius or TACACS+ realm.

set refresh-period

To set the Web session refresh period—the maximum time allowed between refresh requests for a user in this domain—use the **set refresh-period** command.

set refresh-period *seconds*

Syntax Description	<i>seconds</i>	Number of seconds after which a Web session is considered inactive. Value can be 0 to 3600 seconds; default is 600 seconds.
Command Modes	Default authentication mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	If this time limit is exceeded, FXOS considers the Web session to be inactive, but it does not terminate the session.	

Example

This example shows how to enter default authentication mode and set the session refresh interval:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set refresh-period 800
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

Related Commands	Command	Description
	set timeout values	The set absolute-session-timeout , set con-absolute-session-timeout , set con-session-timeout , and set session-timeout commands are used to set various timeout values.

set regenerate

To regenerate the keys in the default keyring, use the **set regenerate** command.

```
set regenerate { no | yes }
```

Syntax Description	no	Do not regenerate the keys.
	yes	Regenerate the keys.

Command Modes Keyring mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to regenerate the RSA keys in the default keyring. This command is accepted only in the default keyring.

Example

This example shows how to regenerate the keys in the default keyring:

```
FP9300-A# scope security
FP9300-A /security # scope keyring default
FP9300-A /security/keyring # set regenerate yes
FP9300-A /security/keyring* # commit-buffer
switch-A /security/keyring #
```

Related Commands	Command	Description
	set cert	Enters an RSA certificate for a keyring.
	set modulus	Specifies the RSA key modulus (SSL key length) in bits.
	set trustpoint	Specifies whether the keyring certificate can be regenerated.

set remote-address

To specify the remote IP address for an IPsec connection, use the **set remote-address** command.

set remote-address *ip_address*

Syntax Description	<i>ip_address</i>	Provide an IPv4 or IPv6 remote gateway address for the IPsec connection; maximum of 510 characters.
Command Modes	Connection (/security/ipsec/connection) mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command and the set local-address command to define the endpoints of an IPsec connection.	

Example

This example shows how to set the remote address for an IPsec connection:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set local-address 209.165.202.129
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #
```

Command	Description
create connection	Creates a new IPsec connection.
set local-addr	Sets the local IP address for an IPsec connection.

set remote-ike-ident

To specify the remote peer IKE identity for an IPsec tunnel connection, use the **set remote-ike-ident** command.

set remote-ike-ident *remote_ID*

Syntax Description	<i>remote_ID</i>	The IKE identification of the remote peer; maximum of 510 characters.
Command Modes	Connection (/security/ipsec/connection) mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command to specify the remote peer's IKE ID for an IPsec connection. This identification is used for peer validation during IKE negotiations.	

Example

This example shows how to specify the remote IKE ID for an IPsec connection:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set remote-ike-ident 203.0.113.12
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #
```

Command	Description
create connection	Creates a new IPsec connection.
set remote-addr	Sets the remote IP address for an IPsec connection.

set remote-subnet

To specify the remote subnet for an IPsec tunnel connection, use the **set remote-subnet** command.

```
set remote-subnet ip_address/mask_bits
```

Syntax Description	<i>ip_address/mask_bits</i>	Provide an IPv4 or IPv6 remote subnet address/mask for the IPsec connection; maximum of 510 characters.
Command Modes	Connection (/security/ipsec/connection) mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command to specify the IP address/mask of an IPsec connection's remote subnet.	

Example

This example shows how to set the remote subnet for an IPsec connection:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set remote-subnet 209.165.202.128/27
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #
```

Command	Description
create connection	Creates a new IPsec connection.
set remote-addr	Sets the remote IP address for an IPsec connection.

set remote-user

To restrict access to those users matching an established user role, use the **set remote-user** command.

set remote-user default-role { **assign-default-role** | **no-login** }

Syntax Description	assign-default-role	no-login
	When a user attempts to log in and the remote authentication provider does not supply a user role with the user's authentication information, the user is allowed to log in with a read-only user role.	When a user attempts to log in and the remote authentication provider does not supply a user role with the user's authentication information, access is denied.

Command Modes Security mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines **assign-default-role** is the default behavior.

Example

This example shows how to enter security mode and deny access to users without a user role:

```
FP9300-A# scope security
FP9300-A /security # set remote-user default-role no-login
FP9300-A /security* # commit-buffer
FP9300-A /security #
```

Related Commands	Command	Description
	set authentication	Specifies the default authentication service.

set reporting-interval

To define how frequently monitored statistics are reported, use the **set reporting-interval** command.

set reporting-interval *interval*

Syntax Description	<i>interval</i>	<p>Length of time defining the statistics reporting interval; available values are:</p> <ul style="list-style-type: none"> • <code>15minutes</code> – 15-minute intervals • <code>2hours</code> – two-hour (120-minute) intervals • <code>2minutes</code> – two-minute intervals • <code>30minutes</code> – 30-minute intervals • <code>4hours</code> – four-hour (240-minute) intervals • <code>60minutes</code> – 60-minute (one-hour) intervals • <code>8hours</code> – eight-hour (480-minute) intervals
Command Modes	scope monitoring/scope stats-collection-policy/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	<p>Use the set collection-interval command to define how frequently statistics are collected, and use the set reporting-interval command to define how frequently the statistics are reported. These intervals define a statistics collection policy.</p> <p>Reporting intervals are longer than collection intervals so that multiple statistical data points can be collected during the reporting interval, which provides sufficient data to calculate and report minimum, maximum, and average values.</p> <p>Statistics can be collected and reported for each of the following functional areas of your Firepower system; use the scope stats-collection-policy command to access a specific collection policy:</p> <ul style="list-style-type: none"> • <code>Adapter</code> – statistics related to the adapters. • <code>Chassis</code> – statistics related to the blade chassis. • <code>FEX</code> – statistics related to configured Fabric Extender(s). • <code>Host</code> – this policy is a placeholder for future support. • <code>Port</code> – statistics related to the ports, including server ports, uplink Ethernet ports, and uplink Fibre Channel ports. • <code>Server</code> – statistics related to servers. 	



Note There is one default statistics collection policy for each of the functional areas. You cannot create additional statistics collection policies and you cannot delete the existing default policies. You can only modify the default policies.

Example

This example shows how to enter the statistics collection policy for ports, set the collection interval to one minute, set the reporting interval to 30 minutes, and then commit the transaction:

```
firepower # scope monitoring
firepower /monitoring # scope stats-collection-policy port
firepower /monitoring/stats-collection-policy # set collection-interval 1minute
firepower /monitoring/stats-collection-policy* # set reporting-interval 30minute
firepower /monitoring/stats-collection-policy* # commit-buffer
firepower /monitoring/stats-collection-policy #
```

Related Commands

Command	Description
scope stats-collection-policy	Enters stats-collection-policy mode, where you manage statistics collection and reporting intervals.
set collection-interval	Specifies how frequently statistics are collected.

set resource-profile-name

To set the resource profile for an application instance, use the **set resource-profile-name** command.

set resource-profile-name *profile_name*

Syntax Description	<i>profile_name</i>	Sets the resource profile name for this application instance.
Command Modes	scope ssa/scope slot/create app-instance/	
Command History	Release	Modification
	2.4(1)	Can now be used for container instances.
	1.1(1)	Command added for use with vDP.
Usage Guidelines	<p>For vDP, resource profiles are pre-created in the FXOS configuration when you download the vDP image. For container instances, create resource profiles using the create resource-profile command. Use the show resource-profile system command to view available profiles.</p> <p>If you change the resource profile for an application instance that is running, then the instance reboots.</p>	

Example

The following example shows how to set the the resource profile for a vDP application instance:

```
firepower# scope ssa
firepower /ssa # show app
  Name          Version          Author      Supported Deploy Types CSP Type      Is Default App
-----
  asa           9.10.1           cisco      Native                Application Yes
  ftd           6.2.3           cisco      Native                Application Yes
  vdp           8.13.01.09-2    radware    Vm                    Application Yes

firepower /ssa # show resource-profile system
Profile Name      App Name  App Version  Is In Use  Security Model  CPU Logical Core Count
RAM Size (MB)    Default Profile Profile Type Description
-----
DEFAULT-4110-RESOURCE
  4                16384    Yes          System     FPR4K-SM-12
DEFAULT-RESOURCE vdp      8.13.01.09-2 No          FPR9K-SM-56, FPR9K-SM-44, FPR9K-SM-36,
FPR9K-SM-24, FPR4K-SM-44, FPR4K-SM-36, FPR4K-SM-24
  6                24576    Yes          System
VDP-10-CORES     vdp      8.13.01.09-2 No          FPR9K-SM-56, FPR9K-SM-44, FPR9K-SM-36,
FPR9K-SM-24, FPR4K-SM-44, FPR4K-SM-36, FPR4K-SM-24
  10               40960    No          System
VDP-2-CORES     vdp      8.13.01.09-2 No          all
  2                8192     No          System
```

```

VDP-4-CORES      vdp      8.13.01.09-2 No      all
4                16384 No      System
VDP-8-CORES      vdp      8.13.01.09-2 No      FPR9K-SM-56, FPR9K-SM-44, FPR9K-SM-36,
FPR9K-SM-24, FPR4K-SM-44, FPR4K-SM-36, FPR4K-SM-24

8                32768 No      System
firepower /ssa/app # exit
firepower /ssa # scope slot 1
firepower /ssa/slot # create app-instance vdp VDP1
firepower /ssa/slot/app-instance* # set resource-profile-name VDP-10-CORES
firepower /ssa/slot/app-instance* #

```

Example

The following example shows how to set the the resource profile for a threat defense container instance:

```

firepower# scope ssa
firepower /ssa # show resource-profile

Profile Name      App Name  App Version  Is In Use  Security Model  CPU Logical Core Count
RAM Size (MB)    Default Profile Profile Type Description
-----
-----
bronze            N/A      N/A          No         all
6                N/A No      Custom     low end device
silver           N/A      N/A          No         all
8                N/A No      Custom     mid-level

firepower /ssa # scope slot 1
firepower /ssa/slot # create app-instance ftd FTD1
firepower /ssa/slot/app-instance* # set resource-profile-name silver
firepower /ssa/slot/app-instance* #

```

Related Commands

Command	Description
show app-attri	Shows current application attributes.
create resource-profile	Creates a resource profile for use with constainer instances.
show resource-profile-name	Shows available resource profiles.

set session-timeout

To set the idle session timeout for Web, SSH, and Telnet sessions, use the **set session-timeout** command.

set session-timeout *seconds*

Syntax Description	<i>seconds</i>	Idle session timeout for Web, SSH, and Telnet sessions; value can be 0 to 3600 seconds.
---------------------------	----------------	---

Command Modes	Default authentication mode
----------------------	-----------------------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to specify the idle session timeout for Web, SSH, and Telnet sessions.

Example

This example shows how to enter default authentication mode and then set the idle session timeout to four minutes:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set session-timeout 240
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

Related Commands	Command	Description
	set refresh-period	Sets the Web session refresh period.
	show detail	Displays the current session and absolute session timeout settings.

set snmp

To set Simple Network Management Protocol (SNMP) configuration parameters, use the **set snmp** command.

set snmp { **community** | **syscontact** | **syslocation** }

Syntax Description

community	After you enter this command, you are asked to enter a SNMP community name, which can be between 1 and 32 alphanumeric characters. The community name is not displayed as you type; however after you press Enter , the system prompt is displayed with an asterisk indicating you need to commit the buffer.
syscontact <i>name</i>	Enter the name of the person to contact regarding SNMP on this system; can be 0 to 255 alphanumeric characters.
syslocation <i>location</i>	Enter a location for this system; can be 0 to 510 alphanumeric characters.

Command Modes

scope monitoring/

Command History

Release	Modification
1.1.1	Command added.

Usage Guidelines

Cisco recommends that you enable only the communication services needed to interact with other network applications.

You must enable the SNMP agent (**enable snmp**) before configuring SNMP on this system.

Use **set snmp community** to specify the community access string used to permit access to the SNMP trap destination. If SNMPv1 or v2c is set as the SNMP version, the community argument is used as the community string. If SNMPv3 is configured, it is used as the SNMP user name for sending trap messages.

When you specify an SNMP community name, you are also automatically enabling SNMP versions 1 and 2c for polling requests from the SNMP remote manager.



Note Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.

There can be only one community name; however, you can use **set snmp community** to overwrite the existing name. To delete an existing community name, enter **set snmp community** but do not type a community string; that is, simply press **Enter** again. After you commit the buffer, **show snmp** output will include the line `Is Community Set: No.`

Example

The following example shows you how to scope into monitoring mode, enable SNMP processing, set the SNMP community string and a system contact, commit your changes, and use the **show snmp** command to confirm the changes:

```

firepower # scope monitoring
firepower /monitoring # enable snmp
firepower /monitoring* # set snmp community
Enter a snmp community:
firepower /monitoring* # set snmp syscontact R_Admin
firepower /monitoring* # commit-buffer
firepower /monitoring # show snmp
Name: snmp
  Admin State: Enabled
  Port: 161
  Is Community Set: Yes
  Sys Contact: R_Admin
  Sys Location:
firepower /monitoring #

```

Related Commands

Command	Description
disable snmp	Disables SNMP.
enable snmp	Enables SNMP.
show snmp	Shows the current SNMP configuration.

set (snmp-trap)

To specify Simple Network Management Protocol (SNMP) trap parameters, use the **set** command in snmp-trap mode.

set { **community** | **notificationtype** | **port** | **v3privilege** | **version** }

Syntax Description		
community		Specifies the SNMPv1/v2c community string, or the SNMPv3 user name, to permit access to the trap destination. You are queried for the community name after you enter this command. The name can be up to 32 characters with no spaces; the name is not displayed as you type.
notificationtype { informs traps }		Specifies the type of SNMP notification produced by this agent: <ul style="list-style-type: none"> • informs – These are unsolicited notifications sent to notify the manager of significant local events. These messages are acknowledged. This option can be used only if version is set to vc2. • traps – These are unsolicited notifications sent to notify the manager of significant local events. These messages are not acknowledged.
port <i>port_num</i>		Use this command to change the port on which the agent receives SNMP requests; the default port is 161.
v3privilege { auth noauth priv }		Use this command to specify the Simple Network Management Protocol version 3 (SNMPv3) security level for the transmitted SNMP traps. <ul style="list-style-type: none"> • auth – Specifies keyed-hash authentication but no encryption. • noauth – Specifies no authentication or encryption. Note that while you can specify it, FXOS does not support this security level with SNMPv3. • priv – Specifies keyed-hash authentication and data encryption (privacy).
version { v1 v2c v3 }		Use this command to specify the SNMP security model used when sending trap notifications: <ul style="list-style-type: none"> • v1 – Specifies SNMP version 1. • v2c – Specifies SNMP version 2c. • v3 – Specifies SNMP version 3. <p>Note Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.</p>

Command Modes scope monitoring/snmp-trap

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines You must enable SNMP (**enable snmp**), and create an SNMP community (**set snmp community**), before you create an SNMP trap and set these parameters.

When you create a new SNMP trap, you are automatically entered into monitoring/snmp-trap mode with an asterisk indicating the new trap is not yet committed.



Note You can create up to eight SNMP traps.

If SNMPv1 or v2c is configured with **set version**, the **set community** argument is used as the community string. If SNMPv3 is configured, it is used as the user name for transmitting the notifications.

With SNMPv3, the trap's **v3privilege** setting must be compatible with the associated SNMPv3 user's security level; that is, the associated user's security configuration must be at least as secure as the trap's. For example, if authentication is enabled for the SNMPv3 user (perform authentication but not privacy encryption), then the user's priv-password would not be set. But to send notifications with privacy enabled (that is, authenticate and do privacy encryption) the user's priv-password would be set. The password associated with the SNMPv3 user is used to authenticate the user when a trap/inform is sent.

Example

The following example enables SNMP, creates an SNMP trap using an IPv4 address, sets the version to v3, sets the v3 privilege level to privacy, and commits the transaction:

```
firepower # scope monitoring
firepower /monitoring/ # enable snmp
firepower /monitoring/ # create snmp-trap 192.168.100.112
firepower /monitoring/snmp-trap* # set notificationtype traps
firepower /monitoring/snmp-trap* # set version v3
firepower /monitoring/snmp-trap* # set v3privilege priv
firepower /monitoring/snmp-trap* # commit-buffer
firepower /monitoring/snmp-trap #
```

Related Commands	Command	Description
	create snmp-trap	Creates a new SNMP trap destination.
	enable snmp	Enables SNMP.

set (snmp-user)

To specify parameters for an existing Simple Network Management Protocol (SNMP) v3 user, use the **set** command in `snmp-user` mode.

```
set { aes-128 | auth | password | priv-password }
```

Syntax Description		
aes-128	{ no yes }	Disable or enable the use of Advanced Encryption Standard (AES)-128 encryption: enter <code>no</code> or <code>yes</code> . By default, AES-128 encryption is disabled.
auth	sha	Enables authentication for SNMPv3 users based on the HMAC Secure Hash Algorithm (SHA).
password		Specify a password for this user; you are asked to enter the password, and confirm it, after you enter this command.
priv-password		Specify a user privacy password; you are asked to enter the password, and confirm it, after you enter this command. The AES privacy password must be a minimum of eight characters.

Command Modes scope monitoring/snmp-user

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines You must enable SNMP (**enable snmp** before you create an SNMP user and set these parameters.

When you create a new SNMP user, you are automatically entered into `monitoring/snmp-user` mode with an asterisk indicating the new user is not yet committed.

The privacy password, or `priv` option, offers a choice of DES or 128-bit AES encryption for SNMP security encryption. If you enable AES-128 configuration and include a privacy password for an SNMPv3 user, the Firepower chassis uses the privacy password to generate a 128-bit AES key.

Example

The following example creates an SNMPv3 user named `snmp-user14`, enables AES-128 encryption, sets a privacy password, and commits the transaction:

```
firepower # scope monitoring
firepower /monitoring/ # enable snmp
firepower /monitoring/ # create snmp-user snmp-user14
Password:
firepower /monitoring/snmp-user* # set aes-128 yes
firepower /monitoring/snmp-user* # set priv-password
Enter a password:
Confirm the password:
firepower /monitoring/snmp-user* # commit-buffer
firepower /monitoring/snmp-user #
```

Related Commands	Command	Description
	create snmp-user	Creates a new SNMPv3 user.
	enable snmp	Enables SNMP.

set speed

To set the interface speed., use the **set speed** command.



Note This command is available in port-channel scope only.

```
set speed { 10mbps | 100mbps | 1gbps | 10gbps | 40gbps | 100gbps }
```

Syntax Description

10mbps	(Optional) Sets the speed at 10 Mbps.
100mbps	(Optional) Sets the speed at 100 Mbps.
1gbps	(Optional) Sets the speed at 1 Gbps.
10gbps	(Optional) Sets the speed at 10 Gbps.
40gbps	(Optional) Sets the speed at 40 Gbps.
100gbps	(Optional) Sets the speed at 100 Gbps.

Command Modes

scope eth-uplink/scope fabric a/port-channel/

Command History

Release	Modification
2.4.1(1)	Command added.

Usage Guidelines

The interface speed that you specify can affect the duplex mode used for an interface, so you must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. If you specify a speed of 1000 Mbps (1Gbps) or faster, full duplex is automatically used.

Example

This example shows how to set the interface speed:

```
firepower-9300 # scope eth-uplink
firepower-9300 /eth-uplink # scope fabric a
firepower-9300 /eth-uplink/fabric # create port-channel id
firepower-9300 /eth-uplink/fabric/port-channel* # enable
firepower-9300 /eth-uplink/fabric/port-channel* # set speed
firepower-9300 /eth-uplink/fabric/port-channel* # set speed 1gbps
firepower-9300 /eth-uplink/fabric/port-channel* # commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #
```

Related Commands

Command	Description
duplex	Specifies the duplex mode as full or half.

Command	Description
show interface	Displays the interface status, which includes the speed parameters.

set speed (aggr-interface)

To set the speed of the interface, use the **set speed** command.

set speed { **10mbps** | **100mbps** | **1gbps** | **10gbps** | **40gbps** | **100gbps** }

Syntax Description		
	10mbps	(Optional) Sets the speed at 10 Mbps.
	100mbps	(Optional) Sets the speed at 100 Mbps.
	1gbps	(Optional) Sets the speed at 1 Gbps.
	10gbps	(Optional) Sets the speed at 10 Gbps.
	40gbps	(Optional) Sets the speed at 40 Gbps.
	100gbps	(Optional) Sets the speed at 100 Gbps.

Command Modes scope eth-uplink/scope fabric a/port-channel/

Command History	Release	Modification
	2.4.1(1)	Command added.

Usage Guidelines The interface speed that you specify can affect the duplex mode used for an interface, so you must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. If you specify a speed of 1000 Mbps (1Gbps) or faster, full duplex is automatically used.

This example shows how to set the interface speed:

```
firepower-9300* # scope cabling
firepower-9300 /cabling* # scope fabric a
firepower-9300 /cabling/fabric* # create breakout port breakout 2 1
firepower-9300 /cabling/fabric* # show config
  scope fabric a
+   enter breakout 2 3
+   exit
  exit
firepower-9300 /cabling/fabric* # exit
firepower-9300 /cabling* # exit
firepower-9300* # scope eth-uplink
firepower-9300 /eth-uplink* # scope fabric a
firepower-9300 /eth-uplink/fabric* # show

Fabric:
  Fabric ID
  -----
  A
firepower-9300 /eth-uplink/fabric* # show
<CR>
>                               Redirect it to a file
>>                             Redirect it to a file in append mode
aggr-interface Aggregate Interface
```

```

detail          Detail
event           Event Management
expand          Expand
fault           Fault
fsm             Fsm
interface       Interface
port-channel    Port Channel
stats           statistics
|              Pipe command output to filter

firepower-9300 /eth-uplink/fabric* # show aggr-interface expand
firepower-9300 /eth-uplink/fabric* # show aggr-interface
  1-4          Slot
  <CR>
  >            Redirect it to a file
  >>          Redirect it to a file in append mode
  detail       Detail
  expand        Expand
  n/n          Ethernet<Slot Id>/<Aggregate Port Id>
  |            Pipe command output to filter
firepower-9300 /eth-uplink/fabric* # show aggr-interface expand
firepower-9300 /eth-uplink/fabric* #
  acknowledge   Acknowledge
  create        Create managed objects
  delete        Delete managed objects
  enter         Enters a managed object
  scope         Changes the current mode
  show          Show system information

firepower-9300 /eth-uplink/fabric* # scope aggr-interface
  1-4          Slot
  n/n          Ethernet<Slot Id>/<Aggregate Port Id>

firepower-9300 /eth-uplink/fabric* # scope port-channel 2
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface* # create member-port
Ethernet2/1/1
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* # show config
+enter member-port 2 1
+exit
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* # exit
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface* # exit
firepower-9300 /eth-uplink/fabric/port-channel* # show config
  enter port-channel 2
    enable
  +   enter aggr-interface 2 1
  +     enter member-port 2 1
  +       exit
  +   exit
  +   enter member-port 1 6
    enable
    exit
    set auto-negotiation no
    set descr ""
    set duplex fullduplex
    set flow-control-policy default
    set lacp-policy-name default
    set nw-ctrl-policy default
    set port-channel-mode active
    set port-type data
    set speed 1gbps
  exit
firepower-9300 /eth-uplink/fabric/port-channel* # set speed
  100gbps      100 Gbps
  100mbps      100 Mbps

```

set speed (aggr-interface)

```

10gbps  10 Gbps
10mbps  10 Mbps
1gbps   1 Gbps
40gbps  40 Gbps

```

```

firepower-9300 /eth-uplink/fabric/port-channel* # set speed 1gbps
firepower-9300 /eth-uplink/fabric/port-channel* commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #

```

Related Commands

Command	Description
duplex	Specifies the duplex mode as full or half.
show interface	Displays the interface status, which includes the speed parameters.

set ssh-server

To set the SSH host key size, use the **set ssh-server** command.

```
set ssh-server host-key rsa key_size
```

Syntax Description	rsa	Specifies the host key type.
	<i>key-size</i>	The size of the host key.
Command Modes	Services mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command to set the SSH host key size.	

Example

This example shows how to set the SSH host key size to 2048 bits:

```
FP9300-A # scope system
FP9300-A /system # scope services
FP9300-A /system/services # set ssh-server host-key rsa 2048
FP9300-A /system/services* # commit-buffer
FP9300-A /system/services #
```

Related Commands	Command	Description
	create ssh-server	Creates a new SSH server host key.
	delete ssh-server	Deletes the existing SSH host key.
	show ssh-server	Shows the host key size.

set sshkey

To specify an SSH key that allows access without a password, use the **set sshkey** command.

set sshkey [**none** | *user_ssh_key*]

Syntax Description	none	(Optional) Enter the none keyword to clear the user's SSH public key.
	<i>user_ssh_key</i>	(Optional) Enter or paste the user's public SSH key.

Command Modes Local user mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines If you press **Enter** after entering **set sshkey**, you are prompted to provide the SSH key, one line at a time. Enter ENDOFBUF to finish. Press Ctrl-C to abort.

Example

This example shows how to specify a public SSH key for the current local user:

```
FP9300-A /security/local-user # set sshkey
"ssh-rsa
AAAAB3NzaC1yc2EAAAABIwAAAIEAuo9VQ2CmWBI9/S1f30k1CWjnV3lgdXMzO0WU15iPw851kdQqap+NFuNmHcb4K
iaQB8X/PDdmtlxQQcawclj+k8f4VcOelBx1sGk5luq51s1ob1VOIEwcKEL/h51rdbN1I8y3SS9I/gGiBZ9ARlop9LDpD
m8HPh2LOgyH7Ei1MI8="
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Related Commands	Command	Description
	create local-user	Creates a new local-user account.
	set password	Specifies a password for a user account.

set startup-version

To specify the startup version of an application, use the **set startup-version** command.

set startup-version

Syntax Description	startup-version	The startup software version of an application instance
Command Modes	scope ssa	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	If you press Enter after scope app-instance ftd ftd1 , you are prompted to set the startup version.	

Example

This example shows how to set the startup version for an ftd application:

```
FPR# scope ssa
FPR /ssa # scope slot 1
FPR /ssa/slot # scope app-instance ftd ftd1
FPR /ssa/slot/app-instance # set startup-version 6.6.1.91
Warning: Upgrade of ftd through FXOS is not supported. The specified version of ftd will
be installed. Please reinitialize or reinstall ftd.
```

set timezone

To set the timezone in FXOS, use the **set timezone** command.

set timezone

Syntax Description	set timezone	Use the command set timezone to set the timezone in FXOS
Command Modes	scope system/scope services	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command to set the timezone in FXOS.	

Example

This example shows how to set the timezone in FXOS:

```
firepower# scope system
firepower /system# scope services
firepower /system/services # set timezone
Please identify a location so that time zone rules can be set correctly.
Please select a continent or ocean.
1) Africa          4) Arctic Ocean    7) Australia      10) Pacific Ocean
2) Americas        5) Asia            8) Europe
3) Antarctica      6) Atlantic Ocean  9) Indian Ocean

#? 8 <===== Europe

Please select a country.
1) Aaland Islands  18) Greece         35) Norway
2) Albania          19) Guernsey       36) Poland
3) Andorra          20) Hungary        37) Portugal
4) Austria          21) Ireland        38) Romania
5) Belarus          22) Isle of Man    39) Russia
6) Belgium          23) Italy           40) San Marino
7) Bosnia & Herzegovina 24) Jersey         41) Serbia
8) Britain (UK)    25) Latvia         42) Slovakia
9) Bulgaria         26) Liechtenstein  43) Slovenia
10) Croatia         27) Lithuania      44) Spain
11) Czech Republic 28) Luxembourg     45) Sweden
12) Denmark         29) Macedonia     46) Switzerland
13) Estonia         30) Malta          47) Turkey
14) Finland         31) Moldova        48) Ukraine
15) France          32) Monaco         49) Vatican City
16) Germany         33) Montenegro
17) Gibraltar       34) Netherlands

#? 36 <=====Poland

The following information has been given:
```


Poland

```
Therefore timezone 'Europe/Warsaw' will be set.  
Local time is now:      Sun Oct 24 08:51:04 CEST 2021.  
Universal Time is now: Sun Oct 24 06:51:04 UTC 2021.  
Is the above information OK?  
1) Yes  
2) No
```

```
#? 1 <===== Yes
```

```
firepower /system/services* # commit  
firepower /system/services # show timezone  
Timezone: Europe/Warsaw <===== Timezone is set
```

To set the timezone to UTC:

```
firepower /system/services* # set timezone UTC  
firepower /system/services* # commit
```

set trustpoint

To set the certificate trustpoint for a keyring, use the **set trustpoint** command.

set trustpoint *trustpoint_name*

Syntax Description

trustpoint_name

Name of a defined trustpoint.

This name can be between 1 and 32 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period), and you cannot change this name after the object is saved.

Command Modes

scope security/scope keyring/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use this command to specify the trusted point that signed this keyring's certificate.

Example

This example shows how to regenerate the keys in the default keyring:

```
firepower# scope security
firepower /security # scope keyring test-ring
firepower /security/keyring # set trustpoint CiscoCA5
firepower /security/keyring* # commit-buffer
firepower /security/keyring #
```

Command	Description
set cert	Enters an RSA certificate for a keyring.
set modulus	Specifies the RSA key modulus (SSL key length) in bits.
set regenerate	Regenerates the RSA keys in the default keyring.

set use-2-factor

To enable and disable two-factor authentication for the authentication realm, use the **set use-2-factor** command.



Note Two-factor authentication applies only to RADIUS and TACACS+ realms.

set use-2-factor {no|yes}

Syntax Description	no	Disables two-factor authentication for the realm.
	yes	Enables two-factor authentication for the realm.

Command Modes Default authentication mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines If you set two-factor authentication for a RADIUS or TACACS+ realm, consider increasing the session-refresh and session-timeout periods so that remote users do not have to re-authenticate too frequently.

Example

This example shows how to enter default authentication mode and enable two-factor authentication:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set use-2-factor yes
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

Related Commands	Command	Description
	set authentication	Specifies the default authentication service.
	set timeout values	The set absolute-session-timeout , set con-absolute-session-timeout , set con-session-timeout , and set session-timeout commands are used to set various timeout values.

set user-account-unlock-time

To specify the amount of time a user remains locked out of the system after reaching the maximum number of login attempts, use the **set user-account-unlock-time** command.

set user-account-unlock-time *unlock_time*

Syntax Description	<i>unlock_time</i>	The amount of time in seconds a user remains locked out of the system. The value can range from 600 to 36000; the default is 1800 seconds (30 minutes).
---------------------------	--------------------	---

Command Modes	Security mode
----------------------	---------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines If any user (including admin users) exceeds the specified maximum number of login attempts, the user is locked out of the system and must wait this amount of time before being allowed to log in again. No notification appears indicating that the user is locked out.

Example

This example shows how to enter security mode and specify the amount of time that must pass before a locked-out user can log in again:

```
FP9300-A # scope security
FP9300-A /security # set user-account-unlock-time 900
FP9300-A /security* # commit-buffer
FP9300-A /security #
```

Related Commands	Command	Description
	clear lock-status	Clears a user's locked-out status.
	set max-login-attempts	Specifies the maximum number of failed login attempts before the user is locked out of the system.

set user-label

To assign a user-defined identifier to the appliance chassis, use the **set user-label** command in `chassis/` mode.

To assign a user-defined identifier to one of the installed servers, use the **set user-label** command in `server/` mode.

set user-label *user_label*

Syntax Description	<i>user_label</i>	The label you want assigned to the appliance or server; maximum of 32 characters.
Command Modes	scope chassis/ scope chassis/scope server	
Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines

You can use the **show detail** command in `chassis/` mode to view the user label currently assigned to the chassis.

You can use the **show detail** command in `chassis/server/` mode to view the user label currently assigned to the connected server.

Example

This example shows how to assign a user-defined label to the appliance chassis:

```
firepower # scope chassis 1
firepower /chassis # set user-label FP9300-4
firepower /chassis* # commit-buffer
firepower /chassis # show detail
```

```
Chassis:
  Chassis: 1
  User Label: FP9300-4
  Overall Status: Operable
  Oper qualifier: N/A
  Operability: Operable
  Conf State: Ok
  Admin State: Acknowledged
  Conn Path: A
  Conn Status: A
  Managing Instance: A
  Product Name: Cisco Firepower 9300 Security Appliance AC
  PID: FPR-C9300-AC
  VID: V02
  Part Number: 68-100280-04
  Vendor: Cisco Systems Inc
  Model: FPR-C9300-AC
  Serial (SN): JMX1950196H
  HW Revision: 0
```

```

Mfg Date: 2015-12-16T00:00:00.000
Power State: Ok
Thermal Status: Ok
SEEPROM operability status: Operable
Dynamic Reallocation: Chassis
Reserved Power Budget (W): 600
PSU Capacity (W): 0
PSU Line Mode: High Line
PSU State: Ok
Current Task:
firepower /chassis #

```

Related Commands

Command	Description
show detail	<p>In <code>chassis/</code> mode, shows detailed chassis information including the chassis' current user label.</p> <p>In <code>chassis/server/</code> mode, shows detailed server information including the connected server's user label.</p>

set value (create bootstrap-key FIREWALL_MODE)

To specify the firewall mode, routed or transparent, in the bootstrap configuration for the threat defense and ASA, use the **set value** command.

```
set value {routed | transparent}
```

Syntax Description	routed	Sets the firewall mode to routed firewall mode.
	transparent	Sets the firewall mode to transparent firewall.
Command Modes	scope ssa/create logical-device/create mgmt-bootstrap/create bootstrap-key FIREWALL_MODE/	
Command Default	The default mode is routed.	
Command History	Release	Modification
	2.4(1)	Added support for the ASA.
	1.1(4)	Command added for FTD.
Usage Guidelines	Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.	

Example

The following example shows how to set the mode to routed mode:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key FIREWALL_MODE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value routed
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands	Command	Description
	create bootstrap-key FIREWALL_MODE	Sets the firewall mode for the application.
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.

set value (create bootstrap-key MANAGEMENT_TYPE)

To specify the manager, FMC or FDM, in the bootstrap configuration for the threat defense, use the **set value** command.

```
set value {FMC | LOCALLY_MANAGED}
```

Syntax Description

FMC Sets the manager to FDM.

LOCALLY_MANAGED Sets the manager to FMC.

Command Modes

scope ssa/create logical-device/create mgmt-bootstrap/create bootstrap-key LOCALLY_MANAGED/

Command Default

The default manager is FMC.

Command History

Release	Modification
2.7(1)	Command added for FTD.

Usage Guidelines

Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.

Example

The following example shows how to set the manager to FDM:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key MANAGEMENT_TYPE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value LOCALLY_MANAGED
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands

Command	Description
create bootstrap-key FIREWALL_MODE	Sets the firewall mode for the application.
create logical-device	Creates the logical device.
create mgmt-bootstrap	Creates the bootstrap configuration for the application.

set value (create bootstrap-key PERMIT_EXPERT_MODE)

To permit Expert Mode from FTD SSH sessions for the threat defense, use the **set value** command.

set value {yes | no}

Syntax Description	no	Disallows Expert Mode from an SSH session to the threat defense.
	yes	Allows an Expert Mode from an SSH session to the threat defense.
Command Modes	scope ssa/create logical-device/create mgmt-bootstrap/create bootstrap-key PERMIT_EXPERT_MODE/	
Command Default	The default is no.	
Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines

Expert Mode provides FTD shell access for advanced troubleshooting. By default for container instances, Expert Mode is only available to users who access the FTD CLI from the FXOS CLI. This limitation is only applied to container instances to increase isolation between instances. Use Expert Mode only if a documented procedure tells you it is required, or if the Cisco Technical Assistance Center asks you to use it. To enter this mode, use the expert command in the FTD CLI.

Example

The following example shows how to enable Expert Mode from SSH:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key PERMIT_EXPERT_MODE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value yes
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

Related Commands	Command	Description
	create bootstrap-key FIREWALL_MODE	Sets the firewall mode for the application.
	create logical-device	Creates the logical device.
	create mgmt-bootstrap	Creates the bootstrap configuration for the application.

set vlan

To set the VLAN ID for a subinterface for use with container instances, use the **set vlan** command.

set vlan *id*

Syntax Description	<i>id</i>	Sets the VLAN ID between 1 and 4095.
---------------------------	-----------	--------------------------------------

Command Modes	scope eth-uplink/scope fabric a/scope interface/create subinterface/ scope eth-uplink/scope fabric a/create port-channel/create subinterface/	
----------------------	--	--

Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines

You can add between 250 and 500 VLAN subinterfaces to the chassis, depending on your network deployment. VLAN IDs per interface must be unique, and within a container instance, VLAN IDs must be unique across all assigned interfaces. You can reuse VLAN IDs on *separate* interfaces as long as they are assigned to different container instances. However, each subinterface still counts towards the limit even though it uses the same ID.

Example

The following example creates 3 subinterfaces on Ethernet 1/1, and sets them to be data-sharing interfaces.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # scope interface Ethernet1/1
firepower /eth-uplink/fabric/interface # create subinterface 10
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 10
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # create subinterface 11
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 11
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # create subinterface 12
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 12
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # commit-buffer
firepower /eth-uplink/fabric/interface/subinterface #
```

Related Commands	Command	Description
	create port-channel	Creates an EtherChannel (port channel).
	create subinterface	Adds a subinterface.

Command	Description
scope interface	Enters the physical interface object.
set port-type	Sets the interface type.



sh Commands

- [show](#), on page 383
- [show app](#), on page 384
- [show \(app-instance\)](#), on page 390
- [show audit-logs](#), on page 392
- [show auth-domain](#), on page 393
- [show auth-realm fsm status](#), on page 394
- [show authentication](#), on page 396
- [show breakout](#), on page 397
- [show callhome](#), on page 398
- [show \(card\)](#), on page 399
- [show card detail](#), on page 401
- [show cc-mode](#), on page 404
- [show certreq](#), on page 405
- [show cfg-export-policy](#), on page 407
- [show chassis](#), on page 409
- [show cli](#), on page 411
- [show clock](#), on page 412
- [show cloud-connector](#), on page 413
- [show configuration](#), on page 414
- [show connection](#), on page 415
- [show console-auth](#), on page 416
- [show controller fsm status](#), on page 417
- [show core-export-target](#), on page 419
- [show cores-detail](#), on page 421
- [show cpu](#), on page 422
- [show domain-env-feature](#), on page 424
- [show domain-nw-feature](#), on page 426
- [show domain-server-feature](#), on page 427
- [show domain-storage-feature](#), on page 428
- [show dns](#), on page 429
- [show download-task](#), on page 430
- [show enforce-strong-password](#), on page 432
- [show environment](#), on page 433

- [show eth-uplink](#), on page 469
- [show event](#), on page 471
- [show fabric](#), on page 472
- [show fabric-interconnect](#), on page 473
- [show fan-module](#), on page 475
- [show fault](#), on page 477
- [show fc](#), on page 479
- [show fips-mode](#), on page 481
- [show firmware](#), on page 482
- [show \(firmware-install\)](#), on page 484
- [show fsm status](#), on page 485
- [show fw-infra-pack](#), on page 487
- [show hardware-bypass-ports](#), on page 489
- [show https](#), on page 490
- [show hw-crypto](#), on page 491
- [show image](#), on page 492
- [show image detail](#), on page 494
- [show identity](#), on page 495
- [show interface](#), on page 498
- [show interface counter errors \(connect fxos\)](#), on page 501
- [show interface transceiver \(connect fxos\)](#), on page 508
- [show interface brief \(connect fxos\)](#), on page 509
- [show inventory](#), on page 521
- [show inventory \(connect fxos\)](#), on page 525
- [show ip-block](#), on page 526
- [show ip-pool](#), on page 528
- [show ipsec-log](#), on page 530
- [show ipv6-block](#), on page 532
- [show ipv6-if](#), on page 534
- [show keyring](#), on page 535
- [show lacp \(connect fxos\)](#), on page 537
- [show license](#), on page 541
- [show load-stats](#), on page 543
- [show local-user](#), on page 544
- [show local-user tech-support](#), on page 545
- [show logical-device](#), on page 546
- [show logical-device-template](#), on page 548
- [show mac-address](#), on page 550
- [show member-port](#), on page 552
- [show mac-pool](#), on page 554
- [show memory](#), on page 556
- [show \(management interface\)](#), on page 559
- [show mgmt-port](#), on page 560
- [show monitor](#), on page 561
- [show nfs-mount-def](#), on page 563
- [show nm-fpga-version](#), on page 565

- [show ntp-overall-status](#), on page 566
- [show ntp server](#), on page 567
- [show org](#), on page 568
- [show package](#), on page 569
- [show password-profile](#), on page 571
- [show pki fsm status](#), on page 572
- [show pmon state](#), on page 574
- [show post](#), on page 575
- [show pre-login-banner](#), on page 576
- [show provider-load-stats](#), on page 577
- [show port-channel \(connect fxos\)](#), on page 579
- [show port-channel \(scope fabric\)](#), on page 582
- [show power-control-policy](#), on page 584
- [show psu](#), on page 586
- [show psu-policy](#), on page 588
- [show registry-repository](#), on page 589
- [show remote-user](#), on page 590
- [show resource](#), on page 591
- [show resource-profile](#), on page 593
- [show role](#), on page 595
- [show \(scope fabric\)](#), on page 596
- [show schedule infra-fw](#), on page 597
- [show security](#), on page 599
- [show sel](#), on page 600
- [show server actual-boot-order](#), on page 601
- [show server adapter](#), on page 602
- [show server assoc](#), on page 604
- [show server bios](#), on page 605
- [show server boot-order](#), on page 607
- [show server cpu](#), on page 609
- [show server decommissioned](#), on page 610
- [show server environment](#), on page 611
- [show server firmware](#), on page 613
- [show server identity](#), on page 615
- [show server inventory](#), on page 617
- [show server memory](#), on page 619
- [show server status](#), on page 621
- [show server storage](#), on page 622
- [show server version](#), on page 624
- [show service-profile](#), on page 626
- [show shell-session-limits](#), on page 632
- [show \(slot\)](#), on page 633
- [show slot](#), on page 635
- [show snmp \(connect fxos\)](#), on page 637
- [show snmp \(monitoring\)](#), on page 641
- [show snmp-trap](#), on page 642

- [show snmp-user](#), on page 644
- [show ssh-server](#), on page 646
- [show stats](#), on page 647
- [show storage](#), on page 649
- [show subinterface](#), on page 650
- [show sup](#), on page 652
- [show system](#), on page 653
- [show system reset-reason](#), on page 655
- [show stats system-stats](#), on page 656
- [show system uptime \(connect fxos\)](#), on page 658
- [show tech-support](#), on page 659
- [show timezone](#), on page 664
- [show trustpoint](#), on page 665
- [show user-sessions](#), on page 667
- [show validate-task](#), on page 668
- [show version](#), on page 670
- [shutdown](#), on page 673
- [show web-session-limits](#), on page 674

show

To view information about operations and current configuration in various command modes, use the **show** command.

Many of the FXOS CLI command modes provide a general **show** command which displays a variety of information relevant to the current command mode. For example, use the **show** command in slot mode (scope ssa/scope slot) to view current SSP information.

Many of these commands are not explicitly documented in this guide. Use **show ?** to view available **show** options for the current command mode.

show app

To display a list of kickstart apps available on the system like ASA and FTD, use the **show app** command.

show app [**detail**]

Syntax Description	Detail	Displays list of detailed apps information.
Command Modes	scope ssa	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope ssa.	

Example

This example shows how to display information of all kickstart apps:

```
Firepower /fabric-interconnect # scope ssa
Firepower /ssa # show app
```

Name	Version	Author	Supported Deploy Types	CSP Type	Is
Default App					
asa	99.18.20.36	cisco	Native	Application	Yes
ftd	7.2.0.1784	cisco	Native, Container	Application	No
ftd	7.2.0.83	cisco	Native, Container	Application	No
ftd	7.3.0.1258	cisco	Native, Container	Application	No
ftd	7.3.0.1402	cisco	Native, Container	Application	Yes
	In Cluster		Data Node		

Example

This example shows how to display information of all the available apps:

```
firepower /ssa # show app detail
Application:
Name: asa
Version: 99.18.20.36
Author: cisco
Supported Deploy Types: Native
Is Default App: Yes
CSP Type: Application
Is Decorator: No
Has License Agreement: No
License Agreement has been Accepted: No
Time Stamp: 2012-01-27T11:34:37.000
Validation State: None
```

```
Validation Time Stamp: Never
Application Information:
  Deploy Type: Native
  Description: N/A
  Build Date: 12/16/2021
  Min OS: 92.12.0.122
  Data VNIC NR: 0
  Mgmt VNIC NR: 0
  Security Control: No
  Support Aggregated VNIC: No
  Can Upgrade: Yes
  Full Install: Yes
  Can Downgrade: Yes
  Is Secondary Data Disk Supported: No
  Installation Timeout (sec): 240
  Uninstallation Timeout (sec): 240
  Upgrade Timeout (sec): 360
  Recommended Data Disk (MB): 20481
  Recommended Cpu Cores: 0
  Recommended Ram (MB): 0
  Minimum Required Data Disk (MB): 20481
  Minimum Required Cpu Logical Cores: 16
  Minimum Required Ram (MB): 24576
  Required Binary Disk (MB): 171
  Net Management Bootstrap Type: Appagent
  Is App Agent Supported: Yes
  Is Clustering Supported: Yes
  Is Turbo Mode Supported: No
  Aggregator: Full
  Incompatible Apps: ftd
  Support Customized CCL IP Subnet: Yes
  Max Application Instance Count: 1
  Reboot Module On App Restart: Yes
  Hardware Crypto Version: Unsupported
Name: ftd
Version: 7.2.0.1784
Author: cisco
Supported Deploy Types: Native,Container
Is Default App: No
CSP Type: Application
Is Decorator: No
Has License Agreement: Yes
License Agreement has been Accepted: No
Time Stamp: 2012-01-26T11:16:15.000
Validation State: None
Validation Time Stamp: Never
Application Information:
  Deploy Type: Native
  Description: N/A
  Build Date: 02/28/2022
  Min OS: 92.12.0.122
  Data VNIC NR: 0
  Mgmt VNIC NR: 0
  Security Control: No
  Support Aggregated VNIC: No
  Can Upgrade: No
  Full Install: Yes
  Can Downgrade: No
  Is Secondary Data Disk Supported: Yes
  Installation Timeout (sec): 1800
  Uninstallation Timeout (sec): 600
  Upgrade Timeout (sec): 1800
  Recommended Data Disk (MB): 195313
  Recommended Secondary Disk (MB): 0
```

```

Recommended Cpu Cores: 0
Recommended Ram (MB): 0
Minimum Required Data Disk (MB): 39063
Minimum Required Secondary Disk (MB): 0
Minimum Required Cpu Logical Cores: 4
Minimum Required Ram (MB): 10
Required Binary Disk (MB): 3907
Net Management Bootstrap Type: Appagent
Is App Agent Supported: Yes
Is Clustering Supported: Yes
Is Turbo Mode Supported: No
Aggregator: Full
Incompatible Apps: asa
Support Customized CCL IP Subnet: Yes
Max Application Instance Count: 1
Reboot Module On App Restart: Yes
Hardware Crypto Version: Unsupported
Deploy Type: Container
Description: N/A
Build Date: 02/28/2022
Min OS: 92.12.0.122
Data VNIC NR: 0
Mgmt VNIC NR: 0
Security Control: No
Support Aggregated VNIC: No
Can Upgrade: No
Full Install: Yes
Can Downgrade: No
Is Secondary Data Disk Supported: Yes
Installation Timeout (sec): 1800
Uninstallation Timeout (sec): 600
Upgrade Timeout (sec): 1800
Recommended Data Disk (MB): 40960
Recommended Secondary Disk (MB): 102400
Recommended Cpu Cores: 10
Recommended Ram (MB): 32768
Minimum Required Data Disk (MB): 40960
Minimum Required Secondary Disk (MB): 0
Minimum Required Cpu Logical Cores: 6
Minimum Required Ram (MB): 10
Required Binary Disk (MB): 3907
Net Management Bootstrap Type: Appagent
Is App Agent Supported: Yes
Is Clustering Supported: Yes
Is Turbo Mode Supported: No
Aggregator: Full
Incompatible Apps: asa
Support Customized CCL IP Subnet: No
Max Application Instance Count: 0
Reboot Module On App Restart: No
Hardware Crypto Version: 2
Name: ftd
Version: 7.2.0.83
Author: cisco
Supported Deploy Types: Native,Container
Is Default App: No
CSP Type: Application
Is Decorator: No
Has License Agreement: Yes
License Agreement has been Accepted: No
Time Stamp: 2012-01-22T07:04:58.000
Validation State: None
Validation Time Stamp: Never

```

Example

This example shows how to display detailed information of all the available apps:

```
Firepower /ssa # show app expand detail
Application:
  Application:

  Name: asa
  Version: 99.18.20.36
  Author: cisco
  Supported Deploy Types: Native
  Is Default App: Yes
  CSP Type: Application
  Is Decorator: No
  Has License Agreement: No
  License Agreement has been Accepted: No
  Time Stamp: 2012-01-27T11:34:37.000
  Validation State: None
  Validation Time Stamp: Never
  Application Information:
    Deploy Type: Native
    Description: N/A
    Build Date: 12/16/2021
    Min OS: 92.12.0.122
    Data VNIC NR: 0
    Mgmt VNIC NR: 0
    Security Control: No
    Support Aggregated VNIC: No
    Can Upgrade: Yes
    Full Install: Yes
    Can Downgrade: Yes
    Is Secondary Data Disk Supported: No
    Installation Timeout (sec): 240
    Uninstallation Timeout (sec): 240
    Upgrade Timeout (sec): 360
    Recommended Data Disk (MB): 20481
    Recommended Cpu Cores: 0
    Recommended Ram (MB): 0
    Minimum Required Data Disk (MB): 20481
    Minimum Required Cpu Logical Cores: 16
    Minimum Required Ram (MB): 24576
    Required Binary Disk (MB): 171
    Net Management Bootstrap Type: Appagent
    Is App Agent Supported: Yes
    Is Clustering Supported: Yes
    Is Turbo Mode Supported: No
    Aggregator: Full
    Incompatible Apps: ftd
    Support Customized CCL IP Subnet: Yes
    Max Application Instance Count: 1
    Reboot Module On App Restart: Yes
    Hardware Crypto Version: Unsupported
    App Attribute Key for the Application:
      App Attribute Key: cluster-role
      Description: This is the role of the blade in the cluster
      App Attribute Key: mgmt-ip
      Description: This is the IP for the management interface
      App Attribute Key: mgmt-ip-virtual
      Description: This is the Virtual IP for cluster only
      App Attribute Key: mgmt-ipv6
      Description: This is the IPv6 for the management interface
      App Attribute Key: mgmt-ipv6-virtual
```

```

Description: This is the Virtual IPv6 for cluster only
App Attribute Key: mgmt-url
Description: This is the management URL for this application
App Attribute Key: mgmt-url-ipv6
Description: This is the management IPv6 URL for this application
Net Mgmt Bootstrap Key for the Application:
Bootstrap Key: FIREWALL_MODE
Key Data Type: enum:(routed, transparent)
Mandatory: No
Is the Key Secret: No
Description: This is the mode to set the firewall (transparent routed)
Key scope: Global
Bootstrap Key: PASSWORD
Key Data Type: string
Mandatory: No
Is the Key Secret: Yes
Description: The admin user password.
Key scope: Global
Port Requirement for the Application:
Port Type: Data
Max Ports: 120
Min Ports: 1
Interchassis Supported Port Types: PORT_CHANNEL
Port Type: Mgmt
Max Ports: 1
Min Ports: 0
Interchassis Supported Port Types:
Port Type: Cluster
Max Ports: 1
Min Ports: 0
Interchassis Supported Port Types:

Name: ftd
Version: 7.3.0.1258
Author: cisco
Supported Deploy Types: Native,Container
Is Default App: No
CSP Type: Application
Is Decorator: No
Has License Agreement: Yes
License Agreement has been Accepted: No
Time Stamp: 2012-03-18T13:06:33.000
Validation State: None
Validation Time Stamp: Never
Application Information:
  Deploy Type: Native
  Description: N/A
  Build Date: 04/19/2022
  Min OS: 92.13.0.100
  Data VNIC NR: 0
  Mgmt VNIC NR: 0
  Security Control: No
  Support Aggregated VNIC: No
  Can Upgrade: No
  Full Install: Yes
  Can Downgrade: No
  Is Secondary Data Disk Supported: Yes
  Installation Timeout (sec): 1800
  Uninstallation Timeout (sec): 600
  Upgrade Timeout (sec): 1800
  Recommended Data Disk (MB): 195313
  Recommended Secondary Disk (MB): 0
  Recommended Cpu Cores: 0
  Recommended Ram (MB): 0

```

```
Minimum Required Data Disk (MB): 39063
Minimum Required Secondary Disk (MB): 0
Minimum Required Cpu Logical Cores: 4
Minimum Required Ram (MB): 10
Required Binary Disk (MB): 3907
Net Management Bootstrap Type: Appagent
Is App Agent Supported: Yes
Is Clustering Supported: Yes
Is Turbo Mode Supported: No
Aggregator: Full
Incompatible Apps: asa
Support Customized CCL IP Subnet: Yes
Max Application Instance Count: 1
Reboot Module On App Restart: Yes
Hardware Crypto Version: Unsupported
App Attribute Key for the Application:
  App Attribute Key: cluster-role
  Description: This is the cluster role for this application instance
  App Attribute Key: firepower-mgmt-ip
  Description: This is the IP address used to initialize a tunnel with
Firepower Management Center
  App Attribute Key: firepower-mgmt-ipv6
  Description: This is the IPv6 address used to initialize a tunnel with
Firepower Management Center
  App Attribute Key: mgmt-url
  Description: This is the management URL for Firepower Management Center
  App Attribute Key: NAT_ID
  Description: This is the token used to associate with Firepower Management Center
Net Mgmt Bootstrap Key for the Application:
  Bootstrap Key: DNS_SERVERS
  Key Data Type: string
  Mandatory: No
  Is the Key Secret: No
  Description: Comma-separated DNS servers for the application
  Key scope: Global
  Bootstrap Key: FIREPOWER_MANAGER_IP
  Key Data Type: string
  Mandatory: No
  Is the Key Secret: No
  Description: The IP address of Cisco Firepower Management Center
  Key scope: Global
```

show (app-instance)

To display current application information, use the **show** command in app-instance mode.

show [**app** | **app-attri** | **detail** | **event** | **expand** | **fault** | **fsm** | **heartbeat** | **hotfix** | **resource**]

Syntax	Description
app	(Optional) Displays list of application packages, such as ASA or FTD that are available for installation (blade).
app-attri	(Optional) Displays current application attributes.
detail	(Optional) Displays detailed information for the current application instance. This keyword is also available with many of the other command options to display detailed information about the specified option.
event	(Optional) Displays event management information for the application.
expand	(Optional) Displays expanded information for the current application instance. This keyword is also available with many of the other command options to display expanded information about the specified option.
fault	(Optional) Displays information about faults that have occurred in this application instance. The following options are also available: <ul style="list-style-type: none"> • <i>fault_ID</i>—Shows information for the specified fault. • cause—Shows information for only the specified cause type. • detail—Shows detailed fault information. • severity—Shows information for only the specified severity level. • suppressed—Lists suppressed faults. The cause, detail and severity keywords are available with this option.
fsm { status task }	(Optional) Displays finite state machine information the current application, according to the specified keyword: <ul style="list-style-type: none"> • status—Displays FSM status information. • task—Displays FSM task information.
heartbeat	(Optional) Displays information about the last-received heartbeat.
hotfix	(Optional) Displays information about applied hotfixes. The following options are also available with this keyword: detail , expand , and <i>version</i> which you can use to display information for a specific hotfix.
resource	(Optional) Displays information about current resource allocations.

Command Modes

scope ssa/scope slot

Command History	Release	Modification
	1.1(1)	Command added.
	2.13(0)	The Cluster Role was changed from Master/Slave to Control Node/Data Node.

Usage Guidelines

By default, this command displays general application instance configuration information.

Example

This example shows how to display general application instance information:

```
firepower# scope ssa
firepower /ssa # scope slot 2
firepower /ssa/slot # scope app-instance asa cluster1
firepower /ssa/slot/app-instance # show
```

```
Application Instance:
  App Name   Identifier Admin State Oper State   Running Version Startup Version
  Deploy Type Profile Name Cluster State Cluster Role
  -----
  asa       cluster1  Enabled   Online    201.2.1.125  201.2.1.125
  Native                               In Cluster Data Node
```

Example

This example shows how to display general application information available for installation:

```
firepower# scope ssa
firepower# show app
firepower /ssa # show app
  Name      Version      Author      Supported Deploy Types CSP Type      Is Default App
  -----
  asa       9.12.3.12   cisco      Native        Application No
  asa       9.12.3.140 cisco      Native        Application No
  asa       9.12.3.9    cisco      Native        Application No
  asa       9.14.1.150 cisco      Native        Application No
  asa       9.16.2.3    cisco      Native        Application Yes
  asa       9.9.2       cisco      Native        Application No
  ftd       6.4.0.102   cisco      Native,Container Application No
  ftd       6.5.0.115   cisco      Native,Container Application No
  ftd       6.6.1.91    cisco      Native,Container Application No
  ftd       6.6.4.59    cisco      Native,Container Application Yes
  ftd       6.7.0.65    cisco      Native,Container Application No
  ftd       7.0.0.94    cisco      Native,Container Application No
```

Related Commands

Command	Description
scope app-instance	Enters application instance mode for a specific application.
show slot	Shows general configuration information for a specific SSP module.

show audit-logs

To display the user audit logs, use the **show audit-logs** command.

show audit-logs

Command Modes

scope security

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

By default, this command displays the user audit logs information.

Example

This example displays the user audit logs information:

```
firepower# scope security
firepower # /security # show audit-logs
Audit trail logs:
  Creation Time      User      ID      Action      Description
  -----
  2021-10-11T21:42:30.885
                        admin     18405523 Creation     PreLoginBanner created
  2021-10-11T21:41:07.340
                        admin     18405498 Deletion     PreLoginBanner deleted
  2021-10-11T21:40:48.222
                        internal  18405486 Deletion     Web A: user admin terminated
  session id web_34771_A
  2021-10-11T21:39:52.703
                        internal  18405463 Creation     Fabric A: remote user test1
logged in from 192.0.2.1
  2021-10-11T21:39:44.351
                        internal  18405450 Deletion     Fabric A: user test1 terminated
  session id pts_1_1_5725
firepower# /security # show audit-logs 18405523 detail
Audit trail logs:
  Creation Time: 2021-10-11T21:42:30.885
  User: admin
  Session ID: pts_0_1_24360
  ID: 18405523
  Action: Creation
  Description: PreLoginBanner created
  Affected Object: sys/user-ext/pre-login-banner
  Trigger: Admin
  Modified Properties: message:TEST
, policyOwner:local
```

show auth-domain

To display current authentication domain information, use the **show auth-domain** command in security mode.

show auth-domain [**detail** | *domain_name*]

Syntax Description	detail	(Optional) Displays detailed information for all current authentication domains.
	<i>domain_name</i>	(Optional) Displays information for the specified domain only. The detail keyword is available with this option.

Command Modes scope security/

Command History	Release	Modification
	1.4(1)	Command added.

Usage Guidelines Authentication domains are created using the **create auth-domain** or **enter auth-domain** commands.

Example

This example shows how to display detailed authentication domain information for a specific domain:

```
firepower# scope security
firepower /security # show auth-domain test_domain detail

Authentication domain:
  Authentication domain name: test_domain
  Web session refresh period(in secs): 600
  Idle Session timeout(in secs) for web, ssh, telnet sessions: 600
  Absolute Session timeout(in secs) for web, ssh, telnet sessions: 3600
  Serial Console Idle Session timeout(in secs): 600
  Serial Console Absolute Session timeout(in secs): 3600
  Default Realm: Local
  Authentication server group:
  Use of 2nd factor: No
firepower /security #
```

Command	Description
create auth-domain	Creates a new authentication domain.
scope auth-domain	Enters auth-domain mode for a specific authentication domain.

show auth-realm fsm status

To display the information of fsm status available on the system, use the **show-auth fsm status** command.

show auth-realm fsm status [**detail**]

Syntax Description	detail	(Optional) Displays expanded information for the current application instance. This keyword is also available with many of the other command options to display expanded information about the specified option.
---------------------------	---------------	--

Command Modes	scope security
----------------------	----------------

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope security.

Example

This example shows how to display fsm status information

```
Firepower # scope security
Firepower /security # show auth-realm fsm status
```

```
FSM 1:
  Status: Nop
  Previous Status: Update Realm Success
  Timestamp: 2012-07-05T23:47:54.643
  Try: 0
  Progress (%): 100
  Current Task:
```

This example shows how to display the fsm status expand details:

```
Firepower # show auth-realm fsm status expand detail
```

```
FSM Status:

  Affected Object: sys/auth-realm/fsm
  Current FSM: update Realm
  Status: Success
  Completion Time: 2012-07-05T23:47:54.643
  Progress (%): 100
  Description:
  Remote Result: Not Applicable
  Error Code: None
  Error Description:

  FSM Stage:

    Order: 1
    Stage Name: updateRealmSetRealmLocal
    Status: Success
    Try: 2
    Last Update Time: 2012-07-05T23:47:54.642
```

```
      Stage Description: realm configuration to primary (FSM-STAGE: Sam: dme:
AaaRealmUpdateRealm: SetRealmLocal)

      Order: 2
      Stage Name: updateRealmSetRealmPeer
      Status: Skip
      Try: 0
      Last Update Time: 2012-07-05T23:47:54.643
      Stage Description: realm configuration to secondary (FSM-STAGE: sam:dm e:
AaaRealmUpdateRealm: SetRealmPeer)
```

show authentication

To display the existing administrative configuration and operational status for the console and default authentication, use the **show authentication** command.

show authentication

Syntax Description

This command has no arguments or keywords.

Command Modes

scope security

Command History

Release	Modification
2.10(1)	Command added.

Usage Guidelines

You can display the existing administrative configuration and operational status for the console and default authentication.

Example

This example shows how to enter security mode and show default authentication method:

```
firepower# scope security
firepower /security # show authentication
Console authentication: Local
Operational Console authentication: Local
Default authentication: Local
Operational Default authentication: Local
Role Policy For Remote Users: Assign Default Role
```

Related Commands

Command	Description
set authentication	Sets the default authentication service.

show breakout

To view information about interface port-breakout configurations, use the **show breakout** command in fabric mode.

show breakout [*slot_id port_id* | **detail** | **expand**]

Syntax Description		
	<i>slot_id port_id</i>	(Optional) Displays breakout information for a specific port. The expand and expand keywords are available with this option.
	detail	(Optional) Displays detailed information for port breakouts. The expand keyword is available with this option.
	expand	(Optional) Displays expanded information for port breakouts. The detail keyword is available with this option.

Command Modes scope cabling/scope fabric a/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command displays breakout information for all ports.

Example

This example shows how to display expanded cabling information:

```
firepower# scope cabling
firepower /cabling # scope fabric a
firepower /cabling/fabric # show breakout

port breakout:
  Slot ID   Port ID   breakout type
  -----
           3         1 10g 4x
           3         2 10g 4x
firepower /cabling/fabric #
```

Related Commands	Command	Description
	create breakout	Creates a new interface breakout.

show callhome

To show Call Home configuration and status information, use the **show callhome** command.

show callhome [**detail** | **expand** | **fsm status**]

Syntax Description	detail	(Optional) Displays detailed Call Home information.
	expand	(Optional) Displays expanded Call Home information.
	fsm status	(Optional) Displays Call Home information and finite state machine status.

Command Modes Monitoring mode

Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to display Call Home information:

```
FP9300-A /monitoring # show callhome

Callhome:
  Admin State: Off
  Throttling State: On
  Contact Information: admin
  Customer Contact Email:
  From Email:
  Reply To Email:
  Phone Contact e.g., +1-011-408-555-1212:
  Street Address:
  Contract Id:
  Customer Id:
  Site Id:
  Switch Priority: Debugging
  Enable/Disable HTTP/HTTPS Proxy: Off
  HTTP/HTTPS Proxy Server Address:
  HTTP/HTTPS Proxy Server Port: 80
  SMTP Server Address:
  SMTP Server Port: 25

DOC-FP9300-A /monitoring #
```

Related Commands	Command	Description
	scope callhome	Enters Call Home configuration mode.

show (card)

To view current fabric card information, use the **show** command in card mode.

show [**beacon-led** | **detail** | **event** | **expand** | **fault** | **fsm task** | **port**]

Syntax Description					
beacon-led	(Optional) Displays information about the card's beacon LEDs. The following options are also available: <ul style="list-style-type: none"> • detail—Shows detailed LED information. The expand keyword is available with this option. • expand—Shows expanded LED information. The detail keyword is available with this option. • fsm status—Shows finite state machine status information. The expand keyword is available with this option. 				
detail	(Optional) Displays detailed information for the fabric card. The expand keyword is available with this option.				
event [<i>event_ID</i> detail expand]	(Optional) Displays event information for the fabric card. You can enter a numeric event ID to view information for only that event. The detail and expand keywords are also available with this option.				
expand	(Optional) Displays expanded information for the fabric card. The detail keyword is available with this option.				
fault	(Optional) Displays information about faults that have occurred on the fabric card. The following options are also available with this keyword: <ul style="list-style-type: none"> • <i>fault_ID</i>—Shows information for the specified fault. • cause—Shows information for only the specified cause type. • detail—Shows detailed fault information. • severity—Shows information for only the specified severity level. • suppressed—Lists suppressed faults. The cause, detail and severity keywords are available with this option. 				
fsm task	(Optional) Displays FSM task information for the card. The detail keyword is available with this option.				
port	(Optional) Lists port information for the card.				
Command Modes	scope fabric-interconnect/scope card				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>1.1(1)</td> <td>Command added.</td> </tr> </tbody> </table>	Release	Modification	1.1(1)	Command added.
Release	Modification				
1.1(1)	Command added.				

Usage Guidelines By default, this command displays basic card status.

Example

This example shows how to display port information for a specific fabric card:

```
firepower# scope fabric-interconnect
firepower /fabric-interconnect # scope card 1
firepower /fabric-interconnect/card # show port
```

Ether Port:

Slot	Aggr Port	Port	Oper State	Mac	Role	Xcvr
1	0	1	Up	B0:AA:77:2F:F0:B0	Network	1000BASE T
1	0	2	Up	B0:AA:77:2F:F0:B1	Network	1000BASE T
1	0	3	Up	B0:AA:77:2F:F0:B2	Network	1000BASE T
1	0	4	Up	B0:AA:77:2F:F0:B3	Network	1000BASE T
1	0	5	Up	B0:AA:77:2F:F0:B4	Network	1000BASE T
1	0	6	Up	B0:AA:77:2F:F0:B5	Network	1000BASE T
1	0	7	Failed	B0:AA:77:2F:F0:B6	Network	1000BASE T
1	0	8	Sfp Not Present	B0:AA:77:2F:F0:B7	Network	N/A

```
firepower /fabric-interconnect/card #
```

Related Commands

Command	Description
scope card	Enters administrative mode for a specific fabric card.

show card detail

To view the card information, use the **show card detail** command.

```
show card [ detail | event | expand | card-config ]
```

Syntax Description	detail	Displays detailed information for the fabric card.
	expand	(Optional) Displays expanded information for the fabric card
	card-config	(Optional) Displays information about the current card configuration

Command Modes scope fabric-interconnect a

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the command **show** in scope fabric-interconnect a.

Example

This example shows how to display information for a specific fabric card:

```
Firepower# scope fabric-interconnect a
Firepower /fabric-interconnect # show card
```

```
Fabric Card:
  Id           State
  -----
           1 Online
           2 Online
           3 Online
```

This example shows how to display detailed information for a specific fabric card:

```
Firepower /fabric-interconnect # show card detail
```

```
Fabric Card:
  Id: 1
  Description: Firepower 9300 Supervisor
  Number of Ports: 8
  State: Online
  Vendor: Cisco Systems, Inc.
  Model: FPR9K-SUP
  HW Revision: 0
  Serial (SN): JSJ18250001
  Perf: N/A
  Admin State: Online
  Power State: Online
  Presence: Equipped
  Thermal Status: N/A
  Voltage Status: N/A

  Id: 2
  Description: Firepower 8x10G SFP+ NM
```

```

Number of Ports: 8
State: Online
Vendor: Cisco Systems, Inc.
Model: FPR-NM-8X10G
HW Revision: 0
Serial (SN): JAD19510ALL
Perf: N/A
Admin State: Online
Power State: Online
Presence: Equipped
Thermal Status: N/A
Voltage Status: N/A

Id: 3
Description: Firepower 4x40G QSFP NM
Number of Ports: 16
State: Online
Vendor: Cisco Systems, Inc.
Model: FPR-NM-4X40G
HW Revision: 0
Serial (SN): JAD21040C9U
Perf: N/A
Admin State: Online
Power State: Online
Presence: Equipped
Thermal Status: N/A
Voltage Status: N/A

```

This example shows how to display expanded information of the current fabric card:

```

Firepower# scope fabric-interconnect a
Firepower /fabric-interconnect # show card detail expand

```

```

Fabric Card:
  Id: 1
  Description: Firepower 9300 Supervisor
  Number of Ports: 8
  State: Online
  Vendor: Cisco Systems, Inc.
  Model: FPR9K-SUP
  HW Revision: 0
  Serial (SN): JSJ18250001
  Perf: N/A
  Admin State: Online
  Power State: Online
  Presence: Equipped
  Thermal Status: N/A
  Voltage Status: N/A

  Id: 2
  Description: Firepower 8x10G SFP+ NM
  Number of Ports: 8
  State: Online
  Vendor: Cisco Systems, Inc.
  Model: FPR-NM-8X10G
  HW Revision: 0
  Serial (SN): JAD19510ALL
  Perf: N/A
  Admin State: Online
  Power State: Online
  Presence: Equipped
  Thermal Status: N/A
  Voltage Status: N/A

  Id: 3

```

```

Description: Firepower 4x40G QSFP NM
Number of Ports: 16
State: Online
Vendor: Cisco Systems, Inc.
Model: FPR-NM-4X40G
HW Revision: 0
Serial (SN): JAD21040C9U
Perf: N/A
Admin State: Online
Power State: Online
Presence: Equipped
Thermal Status: N/A
Voltage Status: N/A

```

This example shows how to display the information about the current card configuration:

```

Firepower# scope fabric-interconnect a
Firepower /fabric-interconnect # show card-config

```

Card Config:

Slot	Model	OperState	Presence	ConfigState
1	FPR9K-SUP	Online	Yes	Ok
2	FPR-NM-8X10G	Online	Yes	Ok
3	FPR-NM-4X40G	Online	Yes	Ok

show cc-mode

To display current Common Criteria mode status information, use the **show cc-mode** command.

show cc-mode

Syntax Description

This command has no arguments or keywords.

Command Modes

Security mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Enabling certification compliance on a Firepower 4100/9300 chassis does not automatically propagate compliance to any of its attached logical devices.

Example

This example shows how to enter security mode and display current Common Criteria mode status information:

```
FP9300-A # scope security
FP9300-A /security # show cc-mode
Common Criteria Mode Admin State: Disabled
Common Criteria Mode Operational State: Disabled
FP9300-A /security #
```

Related Commands

Command	Description
disable cc-mode	Disables Common Criteria mode.
enable cc-mode	Enables Common Criteria mode.

show certreq

To display the certificate request for a specific RSA keyring, use the **show certreq** command.

Syntax Description

This command has no arguments or keywords.

Command Modes

Keyring mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use this command to show the certificate request for the current keyring, which you can then copy and send to a trust anchor or certificate authority.

Example

This example shows how to enter an existing keyring and display its certificate request:

```

FP9300-A # scope security
FP9300-A # scope keyring test-ring
FP9300-A /security/keyring # show certreq
Certificate request subject name: SSP
Certificate request ip address: 198.168.0.111
Certificate request FI A ip address: 0.0.0.0
Certificate request FI B ip address: 0.0.0.0
Certificate request e-mail name:
Certificate request ipv6 address: ::
Certificate request FI A ipv6 address: ::
Certificate request FI B ipv6 address: ::
Certificate request country name:
State, province or county (full name): CA
Locality name (eg, city): SJC
Organisation name (eg, company): Cisco
Organisational Unit Name (eg, section): Sec
DNS name (subject alternative name):
Request:
-----BEGIN CERTIFICATE REQUEST-----
MIIDEzCCAbsCAQAwEDEOMAwGA1UEAwFzZDEWegGFjMA0GCSqGSIb3DQEBAQUA
A4IBTwwAggFKAoIBQQCDnam/ZTgX8SYXeaYIMEVPEmLv007EemP7kEAPpAqX9d6
3V5NIOlNncf7SL8gmLDFORanzZiYb9uxD7/z98xlrS3LdIB3GWCYw+IN1Hz5do/
uClI56thmN5nWgjEWGDwTnu+CD0tFn3qPg8wOpynutE+f43B4fyhWRpU5V06I3Ma
SRrR4Cp9CKju6U9l1ttqiNkt5VH3+peM+3AgF6suFF96tN2G+caIlwvf3h6EpFJ1e
NE6CHUIQAdrKPtJVcmMYIYEmEogMYD100RXY+ionucK7id4JFAKLvFXPrzHGA3g7
n+xInFC84/2kM1TtapWHRMAOYcTiQ5UR6BJOpLT1V6yXTJrv/FrknJkZJUfKvOBX
9fvZ82UH9o+gWMD8rRBvsz94zGbjBm3SpKh1MLvXjR9af3koaiWMR45BSob0XwID
AQABoD4wEwYJKoZIHvcNAQkHMqYMBHRLc3QwJwYJKoZIHvcNAQkOMRowGDAWBgNV
HREEDzANggV0ZXN0MYcEAQEBAATANBgkqhkiG9w0BAQsFAAOCAUEAClVpnjwB8KjD
Okw6k9PaBde07aleSwwMd99rR3F9SnmWQMvFXj07m3dEgNRoTCMyxZXH3diDd6/
0e9Ss91/FxORTI3ux+LxhKAOKjOJ5Urz1YLLjomHGhrhGNpITQCm7lr/fXIjPfuHx
fwaN5lbgImiLI6copKMPY+XMPsFNvIuM4dTAZLHhn5PG0jRAztMNBogw+Fb659BH
vad0QYrz2SHAiH7xETZxp3CTBX4jGhoCad8ffS4YdGQd73/jpu8Zy1nnd1jv7mEj
H9GkSm8sQQfTwQX8RgzbzegZGHu3/LxLO6XQDIRj9bTo1aa6zTuhwPyPs4MtdYbpv
mGdEB8QAMHUChdPzdPC44XRPjPyseig91j+Q1HUMFCMvzNGXksbY1rWj3T4G8gn
z/g7x+OXX/31dLJA2yLx9osUsshmqjs=
-----END CERTIFICATE REQUEST-----

```

```
FP9300-A /security/keyring #
```

Related Commands	Command	Description
	create certreq	Creates a new keyring certificate request.
	create keyring	Creates a new RSA keyring.
	delete certreq	Deletes an existing keyring certificate request.
	enter certreq	Enters a keyring certificate request.

show cfg-export-policy

To display the list of configured export policies, use the **show cfg-export-policy** command.

Syntax Description	detail	Displays detailed show configured export policies information.
Command Modes	scope org	
Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope org.

Example

This example shows how to display the schedule configured export policies information:

```
Firepower /fabric-interconnect # scope org
Firepower /org # show cfg-export-policy
Config Export policy:
  Name                Description Admin State
  -----
  default             Configuration Export Policy
                               Disable
```

Example

This example shows how to display the detailed information of all the available configured export policies

```
Firepower /org # show cfg-export-policy detail
Config Export policy:
  Name: default
  Description: Configuration Export Policy
  Admin State: Disable
  Protocol: Ftp
  Hostname:
  User:
  Remote File:
  Schedule: Daily
  Port: Default
  Current Task:
```

Example

This example shows how to display detailed information of fsm status of all the available configured export policies:

```
Firepower /org # show cfg-export-policy fsm status
Name: default
```

```
FSM 1:  
  Status: Nop  
  Previous Status: Nop  
  Timestamp: Never  
  Try: 0  
  Progress (%): 100  
  Current Task:
```

show chassis

To display chassis information, use the **show chassis** command.

```
show chassis [1] [decommissioned | detail | environment | fabric | fi-iom | firmware | fsm
status | inventory | iom | psu | version]
```

Syntax	Description
1	(Optional) The chassis ID. There is only one chassis, so entering this ID is optional.
decommissioned	(Optional) Displays information about a decommissioned chassis.
detail	(Optional) Displays detailed information about the chassis.
environment	(Optional) Displays environment information. The keywords detail , expand , fan , iom , psu , and server are also available.
fabric	(Optional) Displays information about the fabric. The keyword detail is also available.
fi-iom	(Optional) Displays fabric-interconnect I/O module information. The keyword detail is also available.
firmware	(Optional) Displays information about the firmware. The keyword detail is also available.
fsm status	(Optional) Displays information about the finite state machine. The keyword expand is also available.
inventory	(Optional) Displays vendor and identification information about the chassis. The keywords detail , expand , fabric , fan , fi-iom , iom , psu , server , and unspecified are also available.
iom	(Optional) Displays information about the input/output module. The keyword detail is also available.
psu	(Optional) Displays power-supply unit status. The keyword detail is also available.
version	(Optional) Displays the version numbers of all the devices in the chassis. The keyword detail is also available.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines You can use the **show chassis** command without any arguments or keywords to display basic chassis information.

Example

This example shows how to display basic chassis information:

```
FP9300-A# show chassis 1
Chassis:
Chassis      Overall Status          Admin State
-----
1 Accessibility Problem   Acknowledged
FP9300-A#
```

Related Commands	Command	Description
	show server environment	Shows server hardware information.

show cli

To display CLI command-related information, use the **show cli** command.

show cli { **command-status** | **history** | **mode-info** | **session-config** | **shell-type** }

Syntax Description	command-status	(Optional) Displays the status of the most-recent command. The optional keyword detail provides additional details for the previously entered command.
	history	(Optional) Displays a list of commands entered during the current session.
	mode-info	(Optional) Displays information about the current CLI mode.
	session-config	(Optional) Displays information about the current session configuration.
	shell-type	(Optional) Displays information about the current command shell type.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines This command does not require a license.

Example

This example shows how to display information about the current session configuration:

```
FP9300-A# show cli session-config
Suppress Headers: off
Suppress Field Spillover: off
Table Field Delimiter: none
Terminal Width: 61
Terminal Length: 31
Session Absolute Timeout: 3600 seconds
Session Timeout: 600 seconds
```

```
FP9300-A#
```

Related Commands	Command	Description
	set cli	Specifies whether command output lines will wrap or truncate to fit the width of the terminal window, whether table headers are displayed, and whether commas or spaces will be used to separate fields in command output tables.

show clock

To display the current system date and time, use the **show clock** command.

show clock [**detail**]

Syntax Description	detail	(Optional) Displays detailed information in list form.
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to display the current system date and time:

```
FP9300-A# show clock
Tue Apr 20 13:24:33 PDT 2010
FP9300-A#
```

Related Commands	Command	Description
	set clock	Sets the date and time manually.
	show timezone	Shows currently set time zone.

show cloud-connector

To display cloud-connector status and configuration information, use the **show cloud-connector** command.

show cloud-connector [**detail** | **expand** | **fsm**]

Syntax Description	detail	(Optional) Shows additional cloud connector details.
	expand	(Optional) Shows expanded cloud connector information.
	fsm status	(Optional) Shows current Finite State Machine (FSM) status information.

Command Modes Any command mode

Command History	Release	Modification
	2.2(2)	Command added.

Example

This example shows how to display status information for the cloud connector FSM:

```
FP9300-A# show cloud-connector fsm status
```

```

FSM 1:
  Remote Result: Not Applicable
  Remote Error Code: None
  Remote Error Description:
  Status: Nop
  Previous Status: Nop
  Timestamp: Never
  Try: 0
  Progress (%): 100
  Current Task:
FP9300-A #
```

Related Commands	Command	Description
	scope cloud-connector	Enters cloud connector mode.

show configuration

To display system configuration information, use the **show configuration** command.

show configuration [**all** | **no-diff-markers** | **no-pending** | **pending**]

Syntax Description	all	(Optional) Displays all current configuration information.
	no-diff-markers	(Optional) Doesn't include diff-markers in the displayed configuration information.
	no-pending	(Optional) Doesn't include pending (uncommitted) configuration commands.
	pending	(Optional) Shows all pending configuration commands only.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to display information about pending (uncommitted) configuration commands:

```
FP9300-A# show configuration pending
 scope services
+   create ntp-server 192.168.200.101
 exit
FP9300-A#
```

Related Commands	Command	Description
	show cli	Shows CLI-related status information.

show connection

To show configuration information for the current IPSec connections, or for a single connection, use the **show connection** command.

show connection [**detail** | *name*]

Syntax Description	detail	(Optional) Show detailed IPSec connection information.
	<i>name</i>	(Optional) The specific connection name; can be up to 16 alphanumeric characters.
Command Modes	IPSec mode	
Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to display current IPSec connection information.

Example

This example shows how to display IPSec connection information:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # show connection
```

```
IPSec Connection:
  Name      Admin State Local Address Remote Address ESP Mode  Keyring Name
  -----
  TEST      Disabled
                                     Transport
```

```
FP9300-A /security/ipsec #
```

Related Commands	Command	Description
	show ipsec-log	Shows IPSec connection logs.
	show stats	Shows IPSec statistics.

show console-auth

To show the console authentication details, use the **show console-auth** command.

show console-auth [**detail**]

Syntax Description	detail	Detailed information of console authentication.
Command Modes	scope security	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope security.	

Example

This example shows how to display console authentication information:

```
Firepower # scope security
Firepower /security # show console-auth

Console authentication:
  Admin Realm                Admin Authentication server group Use of 2nd factor
  -----
  Local                      No
```

show controller fsm status

To display a list of controllers fsm status available on the system, use the **show controller fsm status** command.

show controller fsm status [**expand**]

Syntax Description	expand	(Optional) Displays expanded information for the current application instance. This keyword is also available with many of the other command options to display expanded information about the specified option.
Command Modes	scope system	
Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope system.

Example

This example shows how to display system controller fsm status information:

```
Firepower # scope system
QPl /system # show controller fsm status

    FSM 1:
    Remote Result: Not Applicable
    Remote Error Code: None
    Remote Error Description:
    Status: Nop
    Previous Status: Nop
    Timestamp: Never
    Try: 0
    Flags: 0
    Progress (%): 100
    Current Task:

    FSM 1:
    Remote Result: Not Applicable
    Remote Error Code: None
    Remote Error Description:
    Status: Nop
    Previous Status: Nop
    Timestamp: Never
    Try: 0
    Flags: 0
    Progress (%): 100
    Current Task:
Firepower /system # show controller fsm status expand

    FSM Status:
```

```

Affected Object: sys/chassis-1/blade-1/adaptor-1/mgmt/fsm
Current FSM: nop
Status: Nop
Completion Time:
Progress (%): 100

```

```
FSM Stage:
```

```

FSM Status:
Affected Object: sys/chassis-1/blade-1/board Controller/mgmt/fsm
Current FSM: nop
Status: Nop
Completion Time:
Progress (%): 100

```

```
FSM Stage:
```

```
FSM Status:
```

```

Affected Object: sys/chassis-1/blade-1/mgmt/fsm
Current FSM: ExtMgmtIfConfig
Status: Success
Completion Time: 2012-07-27T00:42:51.248
Progress (%): 100

```

```
FSM Stage:
```

Order	Stage Name	Status	Try
1	ExtMgmtIfConfigPrimary	Success	1
2	ExtMgmtIfConfigSecondary	Skip	0

```
FSM Status:
```

```

Affected Object: sys/chassis-1/sw-slot-1/mgmt/fsm
Current FSM: nop
Status: Nop
Completion Time:
Progress (%): 100

```

```
No
```

show core-export-target

To display the information of core export target available on the system, use the **show core-export-target** command.

show connection [**detail** | **FSM**]

Syntax Description	detail	Lists detailed core export target information.
	fsm	Displays finite state machine information of the current application according to the specified keyword: status —Displays FSM status information.
Command Modes	Scope monitoring and scope sysdebug	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope monitoring and scope sysdebug.	

Example

This example shows how to display the information of all the system core export target:

```
Firepower # scope monitoring
Firepower /monitoring # scope sysdebug
Firepower /monitoring/sysdebug # show core-export-target

Core Export Target:
  Server Name Port          Path          Admin State
  -----
                69                Disabled
Firepower /monitoring/sysdebug # show core-export-target detail

Core Export Target:
Server Name:
  Port: 69
  Path:
  Admin State: Disabled
  Description:
  Current Task:
Firepower /monitoring/sysdebug # show core-export-target fsm status

Server Name:
Port: 69
Path:
Admin State: Disabled

FSM 1:
  Remote Result: Not Applicable
  Remote Error Code: None
  Remote Error Description:
  Status: Nop
```

```
Previous Status: Configure Success  
Timestamp: 2012-08-04T12:24:44.253  
Try: 0  
Progress (%): 100  
Current Task:
```

show cores-detail

To display the information of core files available on the system, use the show cores-detail command.

show cores detail

Syntax Description	detail	Lists detailed core information.
Command Modes	Scope monitoring and scope sysdebug	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope monitoring and scope sysdebug.	

Example

This example shows how to display the information of all the system core export target:

```
Firepower # scope monitoring
Firepower /monitoring # scope sysdebug
Firepower /monitoring/sysdebug # show cores detail
```

Core Files:

```
Name: 1339202710_SAM_QP1_svc_sam_portAG_log.10885.tar.gz
Fabric ID: A
Description: SAM/Fabric Interconnect Core Dump
Size: 9928624
Timestamp: 2012-06-09T00:45:23.000
URI: corefile/1339202710_SAM_QP1_svc_sam_portAG_log.10885.tar.gz
Current Task:
```

```
Name: 1339202451_SAM_QP1_svc_sam_portAG_log.6740.tar.gz
Fabric ID: A
Description: SAM/Fabric Interconnect Core Dump
Size: 9928180
Timestamp: 2012-06-09T00:41:14.000
URI: corefile/1339202451_SAM_QP1_svc_sam_portAG_log.6740.tar.gz
Current Task:
```

show cpu

To display the details of a CPU, use the **show cpu** command.

show cpu [**detail**]

Syntax Description	detail	Shows detailed version information.
Command Modes	scope chassis/scope server	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope server 1 under scope chassis 1.	

Example

This example shows how to display CPU information on a specific server:

```
Firepower # KSEC-FPR4115-3# scope chassis 1
Firepower /chassis # scope server 1
Firepower /chassis/server # show cpu
CPU:
  ID  Presence           Architecture      Socket Cores      Speed (GHz)
  ---  -
    1  Equipped           Xeon              CPU1   12              2.100000
    2  Equipped           Xeon              CPU2   12              2.100000
Firepower /chassis/server #
```

Example

This example shows how to display detailed information of CPU on a specific server:

```
Firepower# scope chassis 1
Firepower /chassis # scope server 1
Firepower /chassis/server # show cpu detail

CPU:
  ID: 1
  Presence: Equipped
  Architecture: Xeon
  Socket: CPU1
  Cores: 12
  Cores Enabled: 12
  Speed (GHz): 2.100000
  Stepping: 4
  Vendor: Intel(R) Corporation
  HW Revision: 0
  Thermal Status: OK
  Overall Status: Operable
  Operability: Operable
```



```
ID: 2
Presence: Equipped
Architecture: Xeon
Socket: CPU2
Cores: 12
Cores Enabled: 12
Speed (GHz): 2.100000
Stepping: 4
Vendor: Intel(R) Corporation
HW Revision: 0
Thermal Status: OK
Overall Status: Operable
Operability: Operable
Firepower /chassis/server #
```

show domain-env-feature

To display the domain environment feature, use the **show domain-env-feature** command.

show domain-env-feature [**detail**]

Syntax Description	detail dns	Displays detailed information on the show domain environment feature.
Command Modes	scope system (scope environment-feature)	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope system, scope environment-feature	

Example

This example shows how to display domain environment feature information:

```
Firepower /fabric-interconnect # scope system
Firepower /system/ # scope environment-feature
Firepower /system/environment-feature/ show domain-env-feature
Domain Environment Feature:
  Name                               Functional State
  -----
  DC_POWER_GROUP_FEATURE             Disabled
  ESTIMATE_IMPACT_ON_RECONNECT       Enabled
  HEALTH_REPORTING_FEATURE           Disabled
  POWER_GROUP_FEATURE                Enabled
  REMOTE_OPERATION_FEATURE           Enabled
  UCS_REGISTRATION_FEATURE           Enabled
```

Example

```
Firepower /system/environment-feature # show domain-env-feature detail
Domain Environment Feature:
  Name: DC_POWER_GROUP_FEATURE
  Feature Type: Major
  Functional State: Disabled

  Name: ESTIMATE_IMPACT_ON_RECONNECT
  Feature Type: Major
  Functional State: Enabled

  Name: HEALTH_REPORTING_FEATURE
  Feature Type: Major
  Functional State: Disabled

  Name: POWER_GROUP_FEATURE
  Feature Type: Major
  Functional State: Enabled

  Name: REMOTE_OPERATION_FEATURE
```

```
Feature Type: Major  
Functional State: Enabled
```

```
Name: UCS_REGISTRATION_FEATURE  
Feature Type: Major  
Functional State: Enabled
```

show domain-nw-feature

To display the information of network features available in the system, use the **show domain-nw-feature** command.

show domain-nw-feature [**detail**]

Syntax Description	detail dns	Displays detailed network feature's information.
Command Modes	scope system, scope network-features	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope system, scope network-features.	

Example

This example shows how to display the system network feature information:

```
Firepower /fabric-interconnect # scope system
Firepower /system/ # scope environment-feature
Firepower /system/environment-feature/ show domain-nw-feature
Domain Environment Feature:
  Domain Network Feature:
    Name: NETFLOW_FEATURE
    Feature Type: Major
    Functional State: Disabled
```

show domain-server-feature

To display the information of server features available in the system, use the **show domain-server-feature** command.

show domain-server-feature [**detail**]

Syntax Description	detail	Displays detailed network feature's information.
Command Modes	Scope system, scope server-features	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope system, scope server-features	

Example

This example shows information for all system server features:

```
Firepower # scope system
Firepower /system # scope server-features
Firepower /system/server-features # show domain-server-feature detail
Domain Server Feature:
  Name: GLOBAL_SP_FEATURE
  Feature Type: Major
  Functional State: Enabled

  Name: HEALTH_POLICY_FEATURE
  Feature Type: Major
  Functional State: Disabled

  Name: IN_BAND_MGMT_FEATURE
  Feature Type: Major
  Functional State: Enabled

  Name: POLICY_MAP_FEATURE
  Feature Type: Major
  Functional State: Enabled
```

show domain-storage-feature

To list of system domain storage feature, use the **show show domain-storage-feature** command.

show domain-storage-feature [**detail** | **Name**]

Syntax Description	detail dns	Displays detailed show domain storage feature information.
	Name	Displays information about the specific domain storage. The details keywords are also available with this option.
Command Modes	scope system/scope storage feature	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope system, scope storage feature.	

Example

This example shows how to display domain storage feature policy information:

```
Firepower /fabric-interconnect # scope system
Firepower /system # scope storage-feature
Firepower /system/storage-feature # show domain-storage-feature
Domain Storage Feature:
  Name                               Functional State
  -----
  FC_ZONING_FEATURE                  Enabled
  ISCSI_IPV6_FEATURE                 Enabled
```

Example

This example shows how to display detailed information of the available domain storage feature:

```
Firepower /system/storage-feature # show domain-storage-feature detail
Domain Storage Feature:
  Name: FC_ZONING_FEATURE
  Feature Type: Major
  Functional State: Enabled

  Name: ISCSI_IPV6_FEATURE
  Feature Type: Major
  Functional State: Enabled
Firepower /system/storage-features # show domain-storage-feature FC_ZONING_FEATURE
Domain Storage Feature:
Name Functional State
-----
FC_ZONING_FEATURE Enabled
```

show dns

To display the DNS name servers in FXOS, use the **show dns** command.

show dns

Syntax Description	show dns	This command is used to display a DNS name server in FXOS.
Command Modes	scope system/scope services	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command displays the DNS name server.	

Example

The following example shows how to display a DNS name server

```
firepower# scope system; scope services
firepower /system /services # show dns
Domain Name Servers:
IP Address: 192.0.2.1
```

show download-task

To view information about firmware-package download operations, use the **show download-task** command in firmware mode.

To view information about logical device software-image download operations, use the **show download-task** command in application software (/ssa/app-software) mode.

show download-task [**detail** | **fsm** | *file_name*]

Syntax Description	detail	(Optional) Use this keyword to display a detailed list of all downloads, or if <i>file_name</i> is supplied, detailed download information for the specified file.
	fsm status fsm task	(Optional) Use this keyword to list finite state machine (FSM)-related information for all downloads, or if <i>file_name</i> is supplied, FSM-related information for the only the specified file. Note In firmware mode, this keyword is fsm status . In application software (/ssa/app-software) mode, this keyword is fsm task .
	<i>file_name</i>	(Optional) To view information about a specific file download, provide the name of that file.

Command Modes	scope firmware/ scope ssa/scope app-software
---------------	---

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines If you do not provide a specific *file_name*, all downloads are listed.

Examples

This example shows how to show detailed firmware-download task information for a specific package:

```
firepower# scope firmware
firepower /firmware # show download-task fxos-k9-fpr9k-firmware.1.0.16.SPA detail
```

```
Download task:
  File Name: fxos-k9-fpr9k-firmware.1.0.16.SPA
  Protocol: Scp
  Server: 172.23.32.21
  Port: 0
  Userid: admin2
  Path: /auto/sspdev/bios/MIO_Firmware/release_images/fpr9k/1.0.16
  Downloaded Image Size (KB): 2118
  Time stamp: 2018-05-14T09:30:01.047
  State: Downloaded
  Status: Successful unpack the image
```



```

Transfer Rate (KB/s): 192.545456
Current Task:
firepower /firmware #

```

This example shows how to list downloaded software image files:

```

firepower# scope ssa
firepower /ssa # scope app-software
firepower /ssa/app-software # show download-task
Downloads for Application Software:
  File Name                Protocol  Server                Userid                State
-----
cisco-asa.9.4.1.65.csp    Scp       192.168.1.1          user                  Downloaded

```

Related Commands

Command	Description
download image	Copies a firmware image, or a logical device software image, to the appliance.
install firmware	Installs a firmware package.
show firmware	Shows system firmware information.

show enforce-strong-password

To view the password strength check, use the **show enforce-strong-password** command.

show enforce-strong-password

Syntax Description	Enforce-strong-password Displays the password strength check(yes/no).				
Command Modes	scope security				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>2.3.1</td> <td>Command added.</td> </tr> </tbody> </table>	Release	Modification	2.3.1	Command added.
Release	Modification				
2.3.1	Command added.				
Usage Guidelines	This is a subcommand of the show command in scope security.				

Example

This example shows how to display the password strength check:

```
firepower# scope security
firepower /security # show enforce-strong-password
Password Strength Check: No
```

show environment

To view environmental status information about the chassis, use the **show environment** command in chassis, fxos, or local management mode.

show environment [**detail** | **expand** | **fan** | **iom** | **psu** | **server** | **summary** | **verbose** | **tech**]

Syntax Description	Keyword	Description
	detail	(Optional) Use this keyword to display detailed environment information about the chassis.
	expand	(Optional) Use this keyword to display expanded status information for each component on the chassis.
	fan	(Optional) Displays extensive status information for each fan in each fan module. The keywords detail , iom , psu , and server are also available.
	iom	(Optional) Displays information about the input/output module. The keywords detail , fan , psu , and server are also available.
	psu	(Optional) Displays power-supply unit status. The keywords detail , fan , iom , and server are also available.
	server	(Optional) Lists extension status information for each hardware component of each server. The keywords detail , fan , iom , and psu are also available.
	summary	(Optional) Displays a status summary of each hardware component. The keyword detail is also available.
	verbose tech	(Optional) Use this keyword to display detailed debugging information for each component on the environment.

Command Modes scope chassis/connect fxos/connect local-mgmt

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines You can use this command without any arguments or keywords to display basic chassis environment information.

Example

This example shows how to view a summary of the chassis environment:

```

firepower# scope chassis
firepower /chassis # show environment summary

Chassis INFO :
  Total Power Consumption: 726.000000
  Inlet Temperature (C): 35.000000
  CPU Temperature (C): 46.000000
  Last updated Time: 2018-12-18T21:19:22.353

PSU 1:
  Type: AC
  Input Feed Status: Ok
  12v Output Status: Ok
  Overall Status: Operable
PSU 2:
  Type: AC
  Input Feed Status: Ok
  12v Output Status: Ok
  Overall Status: N/A

FAN 1
  Fan Speed RPM (RPM): 4268
  Speed Status: Ok
  Overall Status: Operable
FAN 2
  Fan Speed RPM (RPM): 4312
  Speed Status: Ok
  Overall Status: Operable
FAN 3
  Fan Speed RPM (RPM): 4180
  Speed Status: Ok
  Overall Status: Operable
FAN 4
  Fan Speed RPM (RPM): 4092
  Speed Status: Ok
  Overall Status: Operable

BLADE 1:
  Total Power Consumption: 258.000000
  Processor Temperature (C): 61.000000
BLADE 2:
  Total Power Consumption: 270.000000
  Processor Temperature (C): 65.500000

firepower /chassis #

```

Example

This example shows how to view the chassis environment information:

```

firepower# scope chassis
firepower /chassis # show environment expand

Chassis 1:
  Overall Status: Thermal Problem
  Operability: Operable
  Power State: Ok
  Thermal Status: Upper Critical   <<<---!!!

      CPU 1:
        Threshold Status: N/A

```

```

Overall Status: Operable
Operability: Operable
Power State: N/A
Thermal Status: OK
Voltage Status: N/A

CPU 2:
Threshold Status: N/A
Overall Status: Operable
Operability: Operable
Power State: N/A
Thermal Status: UC   <<<---!!!
Voltage Status: N/A

```



Note If the Thermal Status is UC or Upper Critical, then the device performs well without any performance loss. Whereas, if the Thermal Status shows UNR or Upper Non-Recoverable, it indicates that the device performance is getting degraded.

Example

This example shows how to view detailed debugging information:

```

firepower# connect fxos
firepower (fxos) # show environment verbose
***** Chassis Temps *****
AD7416_INLET_TEMP is 34 degrees Celsius
AD7416_OUTLET_TEMP_1 is 31 degrees Celsius

***** CPU Data *****
Core Temperature 0 is 46 degrees Celsius
Core Temperature 1 is 46 degrees Celsius
Core Temperature 2 is 46 degrees Celsius
Core Temperature 3 is 46 degrees Celsius
Core Temperature 4 is 46 degrees Celsius
Core Temperature 5 is 46 degrees Celsius
Core Temperature 6 is 46 degrees Celsius
Core Temperature 7 is 46 degrees Celsius
Core Temperature 8 is 46 degrees Celsius
Core Temperature 9 is 46 degrees Celsius
Core Temperature 10 is 46 degrees Celsius
Core Temperature 11 is 46 degrees Celsius
Core Temperature 12 is 46 degrees Celsius
Core Temperature 13 is 46 degrees Celsius
Core Temperature 14 is 46 degrees Celsius
Core Temperature 15 is 46 degrees Celsius

***** Power Supplies *****
PSU 1 input is okay
PSU 1 output is okay

-- Power Supply 1
Voltage In      : 0xf9ab Raw Hex
Current In     : 0xc878 Raw Hex
Power In       : 0x00c0 Raw Hex
Temperature 1  : 0x0022 Raw Hex
Temperature 2  : 0x0026 Raw Hex

```

show environment

```

Temperature 3      : 0x001f Raw Hex
Fan Speed         : 0x28c4 Raw Hex
Fan Status        : 0x00 Raw Hex
Voltage Out       : 0x0078 Raw Hex
Current Out       : 0x008f Raw Hex
Power Out         : 0x00ab Raw Hex

```

No detected PSU in PSU Slot 2

***** PSEQ Data *****

```

12V      Voltage Output      : 12.22 Volts
3.3V     Voltage Output      : 3.37 Volts
1.2V_FPGA Voltage Output      : 1.23 Volts
2.5V_FPGA Voltage Output      : 2.56 Volts
0.85V_KC Voltage Output      : 0.87 Volts
0.9V_KC  Voltage Output      : 0.93 Volts
1.8V_KC  Voltage Output      : 1.85 Volts
1.2V_KC  Voltage Output      : 1.23 Volts
1.8V_SW  Voltage Output      : 1.84 Volts
1.0V_SW  Voltage Output      : 1.01 Volts
SW_CORE  Voltage Output      : 1.01 Volts
1.8V_NIC Voltage Output      : 1.84 Volts
0.9V_CORE_NIC Voltage Output  : 0.93 Volts
1.0V_NIC Voltage Output      : 1.03 Volts
VDD_18_S5 Voltage Output      : 1.84 Volts
VDDCR_SOC_S5 Voltage Output  : 0.92 Volts
VDD_18   Voltage Output      : 1.84 Volts
VDD_33   Voltage Output      : 3.45 Volts
VPP_CD   Voltage Output      : 2.55 Volts
VPP_GH   Voltage Output      : 2.55 Volts
VDDIO_MEM_CD Voltage Output  : 1.23 Volts
VDDIO_MEM_GH Voltage Output  : 1.23 Volts
1.2V_MGTAVTT_KC Voltage Output : 1.23 Volts
0.9V_NTX_EN Voltage Output    : 0.00 Volts
1.5V_NTX_EN Voltage Output    : 0.00 Volts
1.8V_PHY_EN Voltage Output    : 0.00 Volts
1.0V_PHY_EN Voltage Output    : 0.00 Volts
VDDCR_SOC_EN Voltage Output    : 0.00 Volts
VDDCR_CPU_EN Voltage Output    : 0.00 Volts
VDD_3.3_S5_EN Voltage Output  : 0.00 Volts
3.3_NIC_EN Voltage Output     : 0.00 Volts
5V_EN    Voltage Output       : 0.00 Volts

```

PSEQ log

Fault Info Reg (0xb5):

```
12 9a 00 00 4f a9 33 48 7f ff ff ff ff ff ff ff 7f ff
```

Fault Rails Warning Reg (0xb6):

```
20 00 00 00 00 00 00 00 7f ff ff ff ff ff ff ff
7f ff ff ff ff ff ff ff 7f ff ff ff ff ff ff ff
```

Rails Value Reg (0xb7) page 0:

```
07 00 d0 2f 00 00 00
```

Rails Value Reg (0xb7) page 1:

```
07 00 45 34 00 00 00
```

Rails Value Reg (0xb7) page 2:

```
07 00 54 4c 00 00 00
```

Rails Value Reg (0xb7) page 3:

```
07 00 7d 4f 00 00 00

Rails Value Reg (0xb7) page 4:
07 00 10 36 00 00 00

Rails Value Reg (0xb7) page 5:
07 00 6c 39 00 00 00

Rails Value Reg (0xb7) page 6:
07 00 44 39 00 00 00

Rails Value Reg (0xb7) page 7:
07 00 18 4c 00 00 00

Rails Value Reg (0xb7) page 8:
07 00 22 39 00 00 00

Rails Value Reg (0xb7) page 9:
07 00 80 3e 00 00 00

Rails Value Reg (0xb7) page 10:
07 00 80 3e 00 00 00

Rails Value Reg (0xb7) page 11:
07 00 12 39 00 00 00

Rails Value Reg (0xb7) page 12:
07 00 a0 39 00 00 00

Rails Value Reg (0xb7) page 13:
07 00 b8 3f 00 00 00

Rails Value Reg (0xb7) page 14:
07 00 36 39 00 00 00

Rails Value Reg (0xb7) page 15:
07 00 3c 39 00 00 00

Rails Value Reg (0xb7) page 16:
07 00 22 39 00 00 00

Rails Value Reg (0xb7) page 17:
07 00 74 35 00 00 00

Rails Value Reg (0xb7) page 18:
07 00 3e 4f 00 00 00

Rails Value Reg (0xb7) page 19:
07 00 37 4f 00 00 00

Rails Value Reg (0xb7) page 20:
07 00 7c 4c 00 00 00

Rails Value Reg (0xb7) page 21:
07 00 7c 4c 00 00 00

Rails Value Reg (0xb7) page 22:
07 00 74 4c 00 00 00

Rails Value Reg (0xb7) page 23:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 24:
07 00 00 00 00 00 00
```

```
Rails Value Reg (0xb7) page 25:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 26:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 27:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 28:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 29:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 30:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 31:
07 00 01 00 00 00 00

Logged Fault Reg (0xea):
25 03 00 00 08 02 82 00 7f ff ff ff ff ff ff ff
7f ff ff ff ff ff ff ff 7f ff ff ff ff ff ff ff
00 00 00 00 00

Fault Details Index Reg (0xeb):
00 64

Fault Details Reg (0xec) index 0:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 1:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 2:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 3:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 4:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 5:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 6:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 7:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 8:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 9:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 10:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 11:
```



```
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 12:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 13:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 14:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 15:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 16:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 17:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 18:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 19:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 20:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 21:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 22:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 23:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 24:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 25:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 26:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 27:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 28:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 29:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 30:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 31:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 32:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff
```

```
Fault Details Reg (0xec) index 33:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 34:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 35:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 36:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 37:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 38:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 39:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 40:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 41:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 42:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 43:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 44:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 45:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 46:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 47:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 48:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 49:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 50:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 51:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 52:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 53:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff
```

```
Fault Details Reg (0xec) index 54:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 55:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 56:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 57:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 58:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 59:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 60:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 61:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 62:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 63:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 64:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 65:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 66:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 67:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 68:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 69:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 70:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 71:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 72:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 73:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 74:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 75:
```

```
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 76:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 77:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 78:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 79:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 80:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 81:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 82:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 83:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 84:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 85:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 86:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 87:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 88:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 89:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 90:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 91:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 92:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 93:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 94:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 95:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 96:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff
```

```
Fault Details Reg (0xec) index 97:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 98:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 99:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Logged Page Peaks Reg (0xed) page 0:
05 00 4b 31 00

Logged Page Peaks Reg (0xed) page 1:
05 00 fa 35 00

Logged Page Peaks Reg (0xed) page 2:
05 00 08 4f 00

Logged Page Peaks Reg (0xed) page 3:
05 00 25 52 00

Logged Page Peaks Reg (0xed) page 4:
05 00 fc 37 00

Logged Page Peaks Reg (0xed) page 5:
05 00 58 3b 00

Logged Page Peaks Reg (0xed) page 6:
05 00 24 3b 00

Logged Page Peaks Reg (0xed) page 7:
05 00 e8 4e 00

Logged Page Peaks Reg (0xed) page 8:
05 00 06 3b 00

Logged Page Peaks Reg (0xed) page 9:
05 00 c8 41 00

Logged Page Peaks Reg (0xed) page 10:
05 00 c8 41 00

Logged Page Peaks Reg (0xed) page 11:
05 00 16 3b 00

Logged Page Peaks Reg (0xed) page 12:
05 00 d8 3b 00

Logged Page Peaks Reg (0xed) page 13:
05 00 dc 41 00

Logged Page Peaks Reg (0xed) page 14:
05 00 10 3b 00

Logged Page Peaks Reg (0xed) page 15:
05 00 1c 3b 00

Logged Page Peaks Reg (0xed) page 16:
05 00 2a 3b 00

Logged Page Peaks Reg (0xed) page 17:
05 00 3e 37 00
```

```
Logged Page Peaks Reg (0xed) page 18:
05 00 ce 51 00

Logged Page Peaks Reg (0xed) page 19:
05 00 ce 51 00

Logged Page Peaks Reg (0xed) page 20:
05 00 4c 4f 00

Logged Page Peaks Reg (0xed) page 21:
05 00 58 4f 00

Logged Page Peaks Reg (0xed) page 22:
05 00 44 4f 00

Logged Page Peaks Reg (0xed) page 23:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 24:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 25:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 26:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 27:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 28:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 29:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 30:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 31:
05 00 00 00 00

Fault Detail Enable Reg (0xef):
25 ff ff ff f7 fd 07 07 7f ff ff ff ff ff ff ff
7f ff ff ff ff ff ff ff 7f ff ff ff ff ff ff ff
00 00 00 00 00

***** EPM Data *****
EPM0 is present
EPM0 Card power is okay
EPM0 Card is ready
EPM0 temperature is 32 degrees Celsius

***** Fans *****
FanMod 1 Fan 1 rotating
FanMod 1 Fan 1 RPM = 21720
FanMod 1 Fan 2 rotating
FanMod 1 Fan 2 RPM = 19380
FanMod 1 Fan 3 rotating
FanMod 1 Fan 3 RPM = 21900
FanMod 1 Fan 4 rotating
FanMod 1 Fan 4 RPM = 19320
FanMod 2 Fan 1 rotating
```

```

FanMod 2 Fan 1 RPM = 21720
FanMod 2 Fan 2 rotating
FanMod 2 Fan 2 RPM = 19200
FanMod 2 Fan 3 rotating
FanMod 2 Fan 3 RPM = 21540
FanMod 2 Fan 4 rotating
FanMod 2 Fan 4 RPM = 19440
Fan Controller Speed = automatic

```

Example

This example shows how to view debugging information:

```

firepower# connect fxos
firepower (fxos) # show environment tech
***** Chassis Temps *****
AD7416_INLET_TEMP is 34 degrees Celsius
AD7416_OUTLET_TEMP_1 is 31 degrees Celsius

***** CPU Data *****
Core Temperature 0 is 45 degrees Celsius
Core Temperature 1 is 45 degrees Celsius
Core Temperature 2 is 45 degrees Celsius
Core Temperature 3 is 45 degrees Celsius
Core Temperature 4 is 45 degrees Celsius
Core Temperature 5 is 45 degrees Celsius
Core Temperature 6 is 45 degrees Celsius
Core Temperature 7 is 45 degrees Celsius
Core Temperature 8 is 45 degrees Celsius
Core Temperature 9 is 45 degrees Celsius
Core Temperature 10 is 45 degrees Celsius
Core Temperature 11 is 45 degrees Celsius
Core Temperature 12 is 45 degrees Celsius
Core Temperature 13 is 45 degrees Celsius
Core Temperature 14 is 45 degrees Celsius
Core Temperature 15 is 45 degrees Celsius
Tdie is 45
Tctl is 45
Tccd3 is 45
Tccd5 is 38

***** Power Supplies *****
PSU 1 input is okay
PSU 1 output is okay

-- Power Supply 1
Voltage In      : 0xf9ab Raw Hex
Current In     : 0xc878 Raw Hex
Power In       : 0x00c0 Raw Hex
Temperature 1  : 0x0022 Raw Hex
Temperature 2  : 0x0026 Raw Hex
Temperature 3  : 0x001f Raw Hex
Fan Speed      : 0x28c5 Raw Hex
Fan Status     : 0x00 Raw Hex
Voltage Out    : 0x0078 Raw Hex
Current Out    : 0x0091 Raw Hex
Power Out      : 0x00ac Raw Hex

No detected PSU in PSU Slot 2

```

```

***** PSEQ Data *****

Common PSEQ Regs
CAPABILITY                : 0xb0 Raw Hex
STATUS_BYTE               : 0x03 Raw Hex
STATUS_WORD               : 0x1003 Raw Hex
Communication status      : 0x40 Raw Hex
MFR_ID                   : 31 37 2d 31 30 32 30 7f ff ff ff ff ff ff ff 80 Raw Hex

PMBus revision           : 0x12 Raw Hex
MFR_MODEL                 : 46 50 52 2d 33 31 30 7f ff ff ff ff ff ff ff 80 Raw Hex

MFR_REVISION              : 56 31 2e 35 a3 ff ff 7f ff ff ff ff ff ff ff 80 Raw Hex

MFR_LOCATION              : 43 69 73 63 6f 6e ff 7f ff ff ff ff ff ff ff 80 Raw Hex

MFR_DATE                  : 30 35 32 31 32 31 db 7f ff ff ff ff ff ff ff 80 Raw Hex

MFR_SERIAL                : 55 31 36 36 c5 ff ff 7f ff ff ff ff ff ff ff 80 Raw Hex

Silicon device ID        : 55 43 44 39 30 33 32 7f ff ff ff ff ff ff ff 80 Raw Hex

Silicon device revision   : 2e 30 2e 30 2e 33 30 7f ff ff ff ff ff ff ff 80 Raw Hex

12V          Voltage Output : 12.24 Volts
Page         : 0x00 Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x16 Raw Hex
VOUT command : 0x3000 Raw Hex
VOUT margin hi : 0x3266 Raw Hex
VOUT margin lo : 0x2d9a Raw Hex
VOUT scale    : 0xa2a8 Raw Hex
VOUT OV fault limit : 0x3733 Raw Hex
VOUT OV warn limit : 0x34cd Raw Hex
VOUT UV warn limit : 0x2b33 Raw Hex
VOUT UV fault limit : 0x28cd Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on   : 0x2b33 Raw Hex
Power good off  : 0x28cd Raw Hex
On delay        : 0xba00 Raw Hex
On time limit   : 0x8000 Raw Hex
Off delay       : 0xba00 Raw Hex
Off time limit  : 0x8000 Raw Hex
STATUS_VOUT     : 0x00 Raw Hex
STATUS_IOUT     : 0x00 Raw Hex
Output voltage  : 0x30e5 Raw Hex
Output current  : 0x8000 Raw Hex

3.3V          Voltage Output : 3.37 Volts
Page         : 0x01 Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x14 Raw Hex
VOUT command : 0x34cd Raw Hex
VOUT margin hi : 0x3771 Raw Hex
VOUT margin lo : 0x3229 Raw Hex
VOUT scale    : 0xb26d Raw Hex
VOUT OV fault limit : 0x3cb8 Raw Hex
VOUT OV warn limit : 0x3a14 Raw Hex

```



```

VOUT UV warn limit      : 0x2f85 Raw Hex
VOUT UV fault limit    : 0x2ce1 Raw Hex
IOUT OC fault limit    : 0x8000 Raw Hex
IOUT OC warn limit     : 0x8000 Raw Hex
Power good on          : 0x2f85 Raw Hex
Power good off         : 0x2ce1 Raw Hex
On delay               : 0xba00 Raw Hex
On time limit          : 0xda80 Raw Hex
Off delay              : 0xba00 Raw Hex
Off time limit         : 0x8000 Raw Hex
STATUS_VOUT            : 0x00 Raw Hex
STATUS_IOUT            : 0x00 Raw Hex
Output voltage         : 0x35ea Raw Hex
Output current         : 0x8000 Raw Hex

```

```

1.2V_FPGA Voltage Output : 1.23 Volts
Page          : 0x02 Raw Hex
OPERATION     : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode     : 0x12 Raw Hex
VOUT command  : 0x4ccd Raw Hex
VOUT margin hi : 0x50a4 Raw Hex
VOUT margin lo : 0x48f6 Raw Hex
VOUT scale    : 0xba00 Raw Hex
VOUT OV fault limit : 0x5852 Raw Hex
VOUT OV warn limit : 0x547b Raw Hex
VOUT UV warn limit : 0x451f Raw Hex
VOUT UV fault limit : 0x4148 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on   : 0x451f Raw Hex
Power good off  : 0x4148 Raw Hex
On delay        : 0xba00 Raw Hex
On time limit   : 0xda80 Raw Hex
Off delay       : 0xba00 Raw Hex
Off time limit  : 0x8000 Raw Hex
STATUS_VOUT    : 0x00 Raw Hex
STATUS_IOUT    : 0x00 Raw Hex
Output voltage  : 0x4ec0 Raw Hex
Output current  : 0x8000 Raw Hex

```

```

2.5V_FPGA Voltage Output : 2.56 Volts
Page          : 0x03 Raw Hex
OPERATION     : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode     : 0x13 Raw Hex
VOUT command  : 0x5000 Raw Hex
VOUT margin hi : 0x5400 Raw Hex
VOUT margin lo : 0x4c00 Raw Hex
VOUT scale    : 0xb333 Raw Hex
VOUT OV fault limit : 0x5c00 Raw Hex
VOUT OV warn limit : 0x5800 Raw Hex
VOUT UV warn limit : 0x4800 Raw Hex
VOUT UV fault limit : 0x4400 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on   : 0x4800 Raw Hex
Power good off  : 0x4400 Raw Hex
On delay        : 0xba00 Raw Hex
On time limit   : 0xda80 Raw Hex
Off delay       : 0xba00 Raw Hex
Off time limit  : 0x8000 Raw Hex
STATUS_VOUT    : 0x00 Raw Hex
STATUS_IOUT    : 0x00 Raw Hex

```

```

Output voltage           : 0x5207 Raw Hex
Output current          : 0x8000 Raw Hex

0.85V_KC      Voltage Output : 0.87 Volts
Page          : 0x04 Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x12 Raw Hex
VOUT command : 0x3666 Raw Hex
VOUT margin hi : 0x3927 Raw Hex
VOUT margin lo : 0x33b6 Raw Hex
VOUT scale    : 0xba00 Raw Hex
VOUT OV fault limit : 0x3e87 Raw Hex
VOUT OV warn limit  : 0x3bd7 Raw Hex
VOUT UV warn limit  : 0x30f6 Raw Hex
VOUT UV fault limit : 0x2e35 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit  : 0x8000 Raw Hex
Power good on      : 0x30f6 Raw Hex
Power good off     : 0x2e35 Raw Hex
On delay           : 0xba00 Raw Hex
On time limit     : 0xda80 Raw Hex
Off delay          : 0xba00 Raw Hex
Off time limit    : 0x8000 Raw Hex
STATUS_VOUT       : 0x00 Raw Hex
STATUS_IOUT       : 0x00 Raw Hex
Output voltage    : 0x37c8 Raw Hex
Output current    : 0x8000 Raw Hex

0.9V_KC      Voltage Output : 0.93 Volts
Page          : 0x05 Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x12 Raw Hex
VOUT command : 0x399a Raw Hex
VOUT margin hi : 0x3c7b Raw Hex
VOUT margin lo : 0x36b8 Raw Hex
VOUT scale    : 0xba00 Raw Hex
VOUT OV fault limit : 0x423d Raw Hex
VOUT OV warn limit  : 0x3f5c Raw Hex
VOUT UV warn limit  : 0x33d7 Raw Hex
VOUT UV fault limit : 0x30f6 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit  : 0x8000 Raw Hex
Power good on      : 0x33d7 Raw Hex
Power good off     : 0x30f6 Raw Hex
On delay           : 0xba00 Raw Hex
On time limit     : 0xda80 Raw Hex
Off delay          : 0xba00 Raw Hex
Off time limit    : 0x8000 Raw Hex
STATUS_VOUT       : 0x00 Raw Hex
STATUS_IOUT       : 0x00 Raw Hex
Output voltage    : 0x3b38 Raw Hex
Output current    : 0x8000 Raw Hex

1.8V_KC      Voltage Output : 1.85 Volts
Page          : 0x06 Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x13 Raw Hex
VOUT command : 0x399a Raw Hex
VOUT margin hi : 0x3c7b Raw Hex
VOUT margin lo : 0x36b8 Raw Hex
VOUT scale    : 0xba00 Raw Hex

```

```

VOUT OV fault limit      : 0x423d Raw Hex
VOUT OV warn limit      : 0x3f5c Raw Hex
VOUT UV warn limit      : 0x33d7 Raw Hex
VOUT UV fault limit     : 0x30f6 Raw Hex
IOUT OC fault limit     : 0x8000 Raw Hex
IOUT OC warn limit     : 0x8000 Raw Hex
Power good on           : 0x33d7 Raw Hex
Power good off          : 0x30f6 Raw Hex
On delay                : 0xba00 Raw Hex
On time limit           : 0xda80 Raw Hex
Off delay               : 0xba00 Raw Hex
Off time limit          : 0x8000 Raw Hex
STATUS_VOUT             : 0x00 Raw Hex
STATUS_IOUT             : 0x00 Raw Hex
Output voltage          : 0x3b1a Raw Hex
Output current          : 0x8000 Raw Hex

1.2V_KC      Voltage Output : 1.23 Volts
Page_        : 0x07 Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x12 Raw Hex
VOUT command : 0x4ccd Raw Hex
VOUT margin hi : 0x50a4 Raw Hex
VOUT margin lo : 0x48f6 Raw Hex
VOUT scale    : 0xba00 Raw Hex
VOUT OV fault limit : 0x5852 Raw Hex
VOUT OV warn limit : 0x547b Raw Hex
VOUT UV warn limit : 0x451f Raw Hex
VOUT UV fault limit : 0x4148 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x451f Raw Hex
Power good off : 0x4148 Raw Hex
On delay      : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay     : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT   : 0x00 Raw Hex
STATUS_IOUT   : 0x00 Raw Hex
Output voltage : 0x4e84 Raw Hex
Output current : 0x8000 Raw Hex

1.8V_SW      Voltage Output : 1.84 Volts
Page_        : 0x08 Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x13 Raw Hex
VOUT command : 0x399a Raw Hex
VOUT margin hi : 0x3c7b Raw Hex
VOUT margin lo : 0x36b8 Raw Hex
VOUT scale    : 0xba00 Raw Hex
VOUT OV fault limit : 0x423d Raw Hex
VOUT OV warn limit : 0x3f5c Raw Hex
VOUT UV warn limit : 0x33d7 Raw Hex
VOUT UV fault limit : 0x30f6 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x33d7 Raw Hex
Power good off : 0x30f6 Raw Hex
On delay      : 0xeb20 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay     : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex

```

show environment

```

STATUS_VOUT           : 0x00 Raw Hex
STATUS_IOUT           : 0x00 Raw Hex
Output voltage        : 0x3af2 Raw Hex
Output current        : 0x8000 Raw Hex

1.0V_SW      Voltage Output : 1.01 Volts
Page         : 0x09 Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x12 Raw Hex
VOUT command : 0x4000 Raw Hex
VOUT margin hi : 0x4333 Raw Hex
VOUT margin lo : 0x3ccd Raw Hex
VOUT scale    : 0xba00 Raw Hex
VOUT OV fault limit : 0x499a Raw Hex
VOUT OV warn limit : 0x4666 Raw Hex
VOUT UV warn limit : 0x399a Raw Hex
VOUT UV fault limit : 0x3666 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on   : 0x399a Raw Hex
Power good off  : 0x3666 Raw Hex
On delay        : 0xba00 Raw Hex
On time limit   : 0xda80 Raw Hex
Off delay       : 0xba00 Raw Hex
Off time limit  : 0x8000 Raw Hex
STATUS_VOUT    : 0x00 Raw Hex
STATUS_IOUT    : 0x00 Raw Hex
Output voltage  : 0x409c Raw Hex
Output current  : 0x8000 Raw Hex

SW_CORE      Voltage Output : 1.01 Volts
Page         : 0x0a Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x12 Raw Hex
VOUT command : 0x4000 Raw Hex
VOUT margin hi : 0x4333 Raw Hex
VOUT margin lo : 0x3ccd Raw Hex
VOUT scale    : 0xba00 Raw Hex
VOUT OV fault limit : 0x499a Raw Hex
VOUT OV warn limit : 0x4666 Raw Hex
VOUT UV warn limit : 0x399a Raw Hex
VOUT UV fault limit : 0x3666 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on   : 0x399a Raw Hex
Power good off  : 0x3666 Raw Hex
On delay        : 0xca80 Raw Hex
On time limit   : 0xda80 Raw Hex
Off delay       : 0xba00 Raw Hex
Off time limit  : 0x8000 Raw Hex
STATUS_VOUT    : 0x00 Raw Hex
STATUS_IOUT    : 0x00 Raw Hex
Output voltage  : 0x4094 Raw Hex
Output current  : 0x8000 Raw Hex

1.8V_NIC     Voltage Output : 1.84 Volts
Page         : 0x0b Raw Hex
OPERATION    : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode    : 0x13 Raw Hex
VOUT command : 0x399a Raw Hex
VOUT margin hi : 0x3c7b Raw Hex

```

```

VOUT margin lo           : 0x36b8 Raw Hex
VOUT scale               : 0xba00 Raw Hex
VOUT OV fault limit     : 0x423d Raw Hex
VOUT OV warn limit      : 0x3f5c Raw Hex
VOUT UV warn limit      : 0x33d7 Raw Hex
VOUT UV fault limit     : 0x30f6 Raw Hex
IOUT OC fault limit     : 0x8000 Raw Hex
IOUT OC warn limit      : 0x8000 Raw Hex
Power good on           : 0x33d7 Raw Hex
Power good off          : 0x30f6 Raw Hex
On delay                : 0xba00 Raw Hex
On time limit           : 0xda80 Raw Hex
Off delay               : 0xba00 Raw Hex
Off time limit          : 0x8000 Raw Hex
STATUS_VOUT            : 0x00 Raw Hex
STATUS_IOUT            : 0x00 Raw Hex
Output voltage          : 0x3ae8 Raw Hex
Output current          : 0x8000 Raw Hex

0.9V_CORE_NIC Voltage Output : 0.93 Volts
Page                    : 0x0c Raw Hex
OPERATION               : 0x00 Raw Hex
On Off Config           : 0x14 Raw Hex
VOUT mode               : 0x12 Raw Hex
VOUT command            : 0x399a Raw Hex
VOUT margin hi         : 0x3c7b Raw Hex
VOUT margin lo         : 0x36b8 Raw Hex
VOUT scale              : 0xba00 Raw Hex
VOUT OV fault limit    : 0x423d Raw Hex
VOUT OV warn limit     : 0x3f5c Raw Hex
VOUT UV warn limit     : 0x33d7 Raw Hex
VOUT UV fault limit    : 0x30f6 Raw Hex
IOUT OC fault limit    : 0x8000 Raw Hex
IOUT OC warn limit     : 0x8000 Raw Hex
Power good on          : 0x33d7 Raw Hex
Power good off         : 0x30f6 Raw Hex
On delay               : 0xba00 Raw Hex
On time limit          : 0xda80 Raw Hex
Off delay              : 0xba00 Raw Hex
Off time limit         : 0x8000 Raw Hex
STATUS_VOUT            : 0x00 Raw Hex
STATUS_IOUT            : 0x00 Raw Hex
Output voltage          : 0x3bc4 Raw Hex
Output current          : 0x8000 Raw Hex

1.0V_NIC Voltage Output : 1.03 Volts
Page                    : 0x0d Raw Hex
OPERATION               : 0x00 Raw Hex
On Off Config           : 0x14 Raw Hex
VOUT mode               : 0x12 Raw Hex
VOUT command            : 0x4000 Raw Hex
VOUT margin hi         : 0x4333 Raw Hex
VOUT margin lo         : 0x3ccd Raw Hex
VOUT scale              : 0xba00 Raw Hex
VOUT OV fault limit    : 0x499a Raw Hex
VOUT OV warn limit     : 0x4666 Raw Hex
VOUT UV warn limit     : 0x399a Raw Hex
VOUT UV fault limit    : 0x3666 Raw Hex
IOUT OC fault limit    : 0x8000 Raw Hex
IOUT OC warn limit     : 0x8000 Raw Hex
Power good on          : 0x399a Raw Hex
Power good off         : 0x3666 Raw Hex
On delay               : 0xba00 Raw Hex
On time limit          : 0xda80 Raw Hex

```

show environment

```

Off delay : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT : 0x00 Raw Hex
STATUS_IOUT : 0x00 Raw Hex
Output voltage : 0x41a0 Raw Hex
Output current : 0x8000 Raw Hex

VDD_18_S5 Voltage Output : 1.84 Volts
Page : 0x0e Raw Hex
OPERATION : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode : 0x13 Raw Hex
VOUT command : 0x399a Raw Hex
VOUT margin hi : 0x3c7b Raw Hex
VOUT margin lo : 0x36b8 Raw Hex
VOUT scale : 0xba00 Raw Hex
VOUT OV fault limit : 0x423d Raw Hex
VOUT OV warn limit : 0x3f5c Raw Hex
VOUT UV warn limit : 0x33d7 Raw Hex
VOUT UV fault limit : 0x30f6 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x33d7 Raw Hex
Power good off : 0x30f6 Raw Hex
On delay : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT : 0x00 Raw Hex
STATUS_IOUT : 0x00 Raw Hex
Output voltage : 0x3b02 Raw Hex
Output current : 0x8000 Raw Hex

VDDCR_SOC_S5 Voltage Output : 0.92 Volts
Page : 0x0f Raw Hex
OPERATION : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode : 0x12 Raw Hex
VOUT command : 0x399a Raw Hex
VOUT margin hi : 0x3c7b Raw Hex
VOUT margin lo : 0x36b8 Raw Hex
VOUT scale : 0xba00 Raw Hex
VOUT OV fault limit : 0x423d Raw Hex
VOUT OV warn limit : 0x3f5c Raw Hex
VOUT UV warn limit : 0x33d7 Raw Hex
VOUT UV fault limit : 0x30f6 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x33d7 Raw Hex
Power good off : 0x30f6 Raw Hex
On delay : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT : 0x00 Raw Hex
STATUS_IOUT : 0x00 Raw Hex
Output voltage : 0x3b08 Raw Hex
Output current : 0x8000 Raw Hex

VDD_18 Voltage Output : 1.84 Volts
Page : 0x10 Raw Hex
OPERATION : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode : 0x13 Raw Hex

```

```

VOUT command                : 0x399a Raw Hex
VOUT margin hi              : 0x3c7b Raw Hex
VOUT margin lo              : 0x36b8 Raw Hex
VOUT scale                   : 0xba00 Raw Hex
VOUT OV fault limit         : 0x423d Raw Hex
VOUT OV warn limit          : 0x3f5c Raw Hex
VOUT UV warn limit          : 0x33d7 Raw Hex
VOUT UV fault limit         : 0x30f6 Raw Hex
IOUT OC fault limit         : 0x8000 Raw Hex
IOUT OC warn limit          : 0x8000 Raw Hex
Power good on                : 0x33d7 Raw Hex
Power good off              : 0x30f6 Raw Hex
On delay                     : 0xb39a Raw Hex
On time limit                : 0xda80 Raw Hex
Off delay                    : 0xba00 Raw Hex
Off time limit               : 0x8000 Raw Hex
STATUS_VOUT                  : 0x00 Raw Hex
STATUS_IOUT                  : 0x00 Raw Hex
Output voltage               : 0x3aee Raw Hex
Output current               : 0x8000 Raw Hex

VDD_33      Voltage Output  :   3.45 Volts
Page        : 0x11 Raw Hex
OPERATION   : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode   : 0x14 Raw Hex
VOUT command : 0x34cd Raw Hex
VOUT margin hi : 0x3771 Raw Hex
VOUT margin lo : 0x3229 Raw Hex
VOUT scale    : 0xb266 Raw Hex
VOUT OV fault limit : 0x3cb8 Raw Hex
VOUT OV warn limit : 0x3a14 Raw Hex
VOUT UV warn limit : 0x2f85 Raw Hex
VOUT UV fault limit : 0x2ce1 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x2f85 Raw Hex
Power good off : 0x2ce1 Raw Hex
On delay      : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay     : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT   : 0x00 Raw Hex
STATUS_IOUT   : 0x00 Raw Hex
Output voltage : 0x372a Raw Hex
Output current : 0x8000 Raw Hex

VPP_CD      Voltage Output  :   2.55 Volts
Page        : 0x12 Raw Hex
OPERATION   : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode   : 0x13 Raw Hex
VOUT command : 0x5000 Raw Hex
VOUT margin hi : 0x5400 Raw Hex
VOUT margin lo : 0x4c00 Raw Hex
VOUT scale    : 0xb333 Raw Hex
VOUT OV fault limit : 0x5c00 Raw Hex
VOUT OV warn limit : 0x5800 Raw Hex
VOUT UV warn limit : 0x4800 Raw Hex
VOUT UV fault limit : 0x4400 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x4800 Raw Hex
Power good off : 0x4400 Raw Hex

```

show environment

```

On delay : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT : 0x00 Raw Hex
STATUS_IOUT : 0x00 Raw Hex
Output voltage : 0x51c1 Raw Hex
Output current : 0x8000 Raw Hex

VPP_GH Voltage Output : 2.55 Volts
Page : 0x13 Raw Hex
OPERATION : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode : 0x13 Raw Hex
VOUT command : 0x5000 Raw Hex
VOUT margin hi : 0x5400 Raw Hex
VOUT margin lo : 0x4c00 Raw Hex
VOUT scale : 0xb333 Raw Hex
VOUT OV fault limit : 0x5c00 Raw Hex
VOUT OV warn limit : 0x5800 Raw Hex
VOUT UV warn limit : 0x4800 Raw Hex
VOUT UV fault limit : 0x4400 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x4800 Raw Hex
Power good off : 0x4400 Raw Hex
On delay : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT : 0x00 Raw Hex
STATUS_IOUT : 0x00 Raw Hex
Output voltage : 0x51bc Raw Hex
Output current : 0x8000 Raw Hex

VDDIO_MEM_CD Voltage Output : 1.23 Volts
Page : 0x14 Raw Hex
OPERATION : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode : 0x12 Raw Hex
VOUT command : 0x4ccd Raw Hex
VOUT margin hi : 0x50a4 Raw Hex
VOUT margin lo : 0x48f6 Raw Hex
VOUT scale : 0xba00 Raw Hex
VOUT OV fault limit : 0x5852 Raw Hex
VOUT OV warn limit : 0x547b Raw Hex
VOUT UV warn limit : 0x451f Raw Hex
VOUT UV fault limit : 0x4148 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x451f Raw Hex
Power good off : 0x4148 Raw Hex
On delay : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT : 0x00 Raw Hex
STATUS_IOUT : 0x00 Raw Hex
Output voltage : 0x4ef4 Raw Hex
Output current : 0x8000 Raw Hex

VDDIO_MEM_GH Voltage Output : 1.23 Volts
Page : 0x15 Raw Hex
OPERATION : 0x00 Raw Hex

```



```

On Off Config                : 0x14 Raw Hex
VOUT mode                    : 0x12 Raw Hex
VOUT command                 : 0x4ccd Raw Hex
VOUT margin hi              : 0x50a4 Raw Hex
VOUT margin lo              : 0x48f6 Raw Hex
VOUT scale                   : 0xba00 Raw Hex
VOUT OV fault limit         : 0x5852 Raw Hex
VOUT OV warn limit          : 0x547b Raw Hex
VOUT UV warn limit          : 0x451f Raw Hex
VOUT UV fault limit         : 0x4148 Raw Hex
IOUT OC fault limit         : 0x8000 Raw Hex
IOUT OC warn limit          : 0x8000 Raw Hex
Power good on                : 0x451f Raw Hex
Power good off               : 0x4148 Raw Hex
On delay                     : 0xba00 Raw Hex
On time limit                : 0xda80 Raw Hex
Off delay                    : 0xba00 Raw Hex
Off time limit               : 0x8000 Raw Hex
STATUS_VOUT                  : 0x00 Raw Hex
STATUS_IOUT                  : 0x00 Raw Hex
Output voltage                : 0x4ef4 Raw Hex
Output current                : 0x8000 Raw Hex

1.2V_MGTAVTT_KC Voltage Output : 1.23 Volts
Page                          : 0x16 Raw Hex
OPERATION                     : 0x00 Raw Hex
On Off Config                 : 0x14 Raw Hex
VOUT mode                     : 0x12 Raw Hex
VOUT command                  : 0x4ccd Raw Hex
VOUT margin hi                : 0x50a4 Raw Hex
VOUT margin lo                : 0x48f6 Raw Hex
VOUT scale                     : 0xba00 Raw Hex
VOUT OV fault limit           : 0x5852 Raw Hex
VOUT OV warn limit            : 0x547b Raw Hex
VOUT UV warn limit            : 0x451f Raw Hex
VOUT UV fault limit           : 0x4148 Raw Hex
IOUT OC fault limit           : 0x8000 Raw Hex
IOUT OC warn limit            : 0x8000 Raw Hex
Power good on                  : 0x451f Raw Hex
Power good off                 : 0x4148 Raw Hex
On delay                       : 0xba00 Raw Hex
On time limit                  : 0xda80 Raw Hex
Off delay                      : 0xba00 Raw Hex
Off time limit                 : 0x8000 Raw Hex
STATUS_VOUT                    : 0x00 Raw Hex
STATUS_IOUT                    : 0x00 Raw Hex
Output voltage                  : 0x4ee0 Raw Hex
Output current                  : 0x8000 Raw Hex

0.9V_NTX_EN Voltage Output    : 0.00 Volts
Page                          : 0x17 Raw Hex
OPERATION                     : 0x00 Raw Hex
On Off Config                 : 0x14 Raw Hex
VOUT mode                     : 0x14 Raw Hex
VOUT command                  : 0x0000 Raw Hex
VOUT margin hi                : 0x0000 Raw Hex
VOUT margin lo                : 0x0000 Raw Hex
VOUT scale                     : 0xba00 Raw Hex
VOUT OV fault limit           : 0x0000 Raw Hex
VOUT OV warn limit            : 0x0000 Raw Hex
VOUT UV warn limit            : 0x0000 Raw Hex
VOUT UV fault limit           : 0x0000 Raw Hex
IOUT OC fault limit           : 0x8000 Raw Hex
IOUT OC warn limit            : 0x8000 Raw Hex

```

show environment

```

Power good on           : 0x0000 Raw Hex
Power good off          : 0x0000 Raw Hex
On delay                 : 0xba00 Raw Hex
On time limit           : 0xda80 Raw Hex
Off delay                : 0xba00 Raw Hex
Off time limit          : 0x8000 Raw Hex
STATUS_VOUT             : 0x00 Raw Hex
STATUS_IOUT             : 0x00 Raw Hex
Output voltage          : 0x0000 Raw Hex
Output current          : 0x8000 Raw Hex

1.5V_NTX_EN Voltage Output : 0.00 Volts
Page                    : 0x18 Raw Hex
OPERATION                : 0x00 Raw Hex
On Off Config           : 0x14 Raw Hex
VOUT mode                : 0x14 Raw Hex
VOUT command            : 0x0000 Raw Hex
VOUT margin hi          : 0x0000 Raw Hex
VOUT margin lo          : 0x0000 Raw Hex
VOUT scale               : 0xba00 Raw Hex
VOUT OV fault limit     : 0x0000 Raw Hex
VOUT OV warn limit     : 0x0000 Raw Hex
VOUT UV warn limit     : 0x0000 Raw Hex
VOUT UV fault limit     : 0x0000 Raw Hex
IOUT OC fault limit     : 0x8000 Raw Hex
IOUT OC warn limit     : 0x8000 Raw Hex
Power good on           : 0x0000 Raw Hex
Power good off          : 0x0000 Raw Hex
On delay                 : 0xba00 Raw Hex
On time limit           : 0xda80 Raw Hex
Off delay                : 0xba00 Raw Hex
Off time limit          : 0x8000 Raw Hex
STATUS_VOUT             : 0x00 Raw Hex
STATUS_IOUT             : 0x00 Raw Hex
Output voltage          : 0x0000 Raw Hex
Output current          : 0x8000 Raw Hex

1.8V_PHY_EN Voltage Output : 0.00 Volts
Page                    : 0x19 Raw Hex
OPERATION                : 0x00 Raw Hex
On Off Config           : 0x14 Raw Hex
VOUT mode                : 0x14 Raw Hex
VOUT command            : 0x0000 Raw Hex
VOUT margin hi          : 0x0000 Raw Hex
VOUT margin lo          : 0x0000 Raw Hex
VOUT scale               : 0xba00 Raw Hex
VOUT OV fault limit     : 0x0000 Raw Hex
VOUT OV warn limit     : 0x0000 Raw Hex
VOUT UV warn limit     : 0x0000 Raw Hex
VOUT UV fault limit     : 0x0000 Raw Hex
IOUT OC fault limit     : 0x8000 Raw Hex
IOUT OC warn limit     : 0x8000 Raw Hex
Power good on           : 0x0000 Raw Hex
Power good off          : 0x0000 Raw Hex
On delay                 : 0xba00 Raw Hex
On time limit           : 0xda80 Raw Hex
Off delay                : 0xba00 Raw Hex
Off time limit          : 0x8000 Raw Hex
STATUS_VOUT             : 0x00 Raw Hex
STATUS_IOUT             : 0x00 Raw Hex
Output voltage          : 0x0000 Raw Hex
Output current          : 0x8000 Raw Hex

1.0V_PHY_EN Voltage Output : 0.00 Volts

```

```

Page : 0x1a Raw Hex
OPERATION : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode : 0x14 Raw Hex
VOUT command : 0x0000 Raw Hex
VOUT margin hi : 0x0000 Raw Hex
VOUT margin lo : 0x0000 Raw Hex
VOUT scale : 0xba00 Raw Hex
VOUT OV fault limit : 0x0000 Raw Hex
VOUT OV warn limit : 0x0000 Raw Hex
VOUT UV warn limit : 0x0000 Raw Hex
VOUT UV fault limit : 0x0000 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x0000 Raw Hex
Power good off : 0x0000 Raw Hex
On delay : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT : 0x00 Raw Hex
STATUS_IOUT : 0x00 Raw Hex
Output voltage : 0x0000 Raw Hex
Output current : 0x8000 Raw Hex

VDDCR_SOC_EN Voltage Output : 0.00 Volts
Page : 0x1b Raw Hex
OPERATION : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode : 0x14 Raw Hex
VOUT command : 0x0000 Raw Hex
VOUT margin hi : 0x0000 Raw Hex
VOUT margin lo : 0x0000 Raw Hex
VOUT scale : 0xba00 Raw Hex
VOUT OV fault limit : 0x0000 Raw Hex
VOUT OV warn limit : 0x0000 Raw Hex
VOUT UV warn limit : 0x0000 Raw Hex
VOUT UV fault limit : 0x0000 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x0000 Raw Hex
Power good off : 0x0000 Raw Hex
On delay : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT : 0x00 Raw Hex
STATUS_IOUT : 0x00 Raw Hex
Output voltage : 0x0000 Raw Hex
Output current : 0x8000 Raw Hex

VDDCR_CPU_EN Voltage Output : 0.00 Volts
Page : 0x1c Raw Hex
OPERATION : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode : 0x14 Raw Hex
VOUT command : 0x0000 Raw Hex
VOUT margin hi : 0x0000 Raw Hex
VOUT margin lo : 0x0000 Raw Hex
VOUT scale : 0xba00 Raw Hex
VOUT OV fault limit : 0x0000 Raw Hex
VOUT OV warn limit : 0x0000 Raw Hex
VOUT UV warn limit : 0x0000 Raw Hex
VOUT UV fault limit : 0x0000 Raw Hex

```

show environment

```

IOUT OC fault limit      : 0x8000 Raw Hex
IOUT OC warn limit      : 0x8000 Raw Hex
Power good on           : 0x0000 Raw Hex
Power good off          : 0x0000 Raw Hex
On delay                : 0xba00 Raw Hex
On time limit           : 0xda80 Raw Hex
Off delay               : 0xba00 Raw Hex
Off time limit          : 0x8000 Raw Hex
STATUS_VOUT             : 0x00 Raw Hex
STATUS_IOUT             : 0x00 Raw Hex
Output voltage          : 0x0000 Raw Hex
Output current          : 0x8000 Raw Hex

VDD_3.3_S5_EN Voltage Output : 0.00 Volts
Page                    : 0x1d Raw Hex
OPERATION               : 0x00 Raw Hex
On Off Config           : 0x14 Raw Hex
VOUT mode               : 0x14 Raw Hex
VOUT command            : 0x0000 Raw Hex
VOUT margin hi         : 0x0000 Raw Hex
VOUT margin lo         : 0x0000 Raw Hex
VOUT scale              : 0xba00 Raw Hex
VOUT OV fault limit    : 0x0000 Raw Hex
VOUT OV warn limit     : 0x0000 Raw Hex
VOUT UV warn limit     : 0x0000 Raw Hex
VOUT UV fault limit    : 0x0000 Raw Hex
IOUT OC fault limit    : 0x8000 Raw Hex
IOUT OC warn limit     : 0x8000 Raw Hex
Power good on          : 0x0000 Raw Hex
Power good off         : 0x0000 Raw Hex
On delay               : 0xba00 Raw Hex
On time limit          : 0xda80 Raw Hex
Off delay              : 0xba00 Raw Hex
Off time limit         : 0x8000 Raw Hex
STATUS_VOUT            : 0x00 Raw Hex
STATUS_IOUT            : 0x00 Raw Hex
Output voltage         : 0x0000 Raw Hex
Output current         : 0x8000 Raw Hex

3.3_NIC_EN Voltage Output : 0.00 Volts
Page                    : 0x1e Raw Hex
OPERATION               : 0x00 Raw Hex
On Off Config           : 0x14 Raw Hex
VOUT mode               : 0x14 Raw Hex
VOUT command            : 0x0000 Raw Hex
VOUT margin hi         : 0x0000 Raw Hex
VOUT margin lo         : 0x0000 Raw Hex
VOUT scale              : 0xba00 Raw Hex
VOUT OV fault limit    : 0x0000 Raw Hex
VOUT OV warn limit     : 0x0000 Raw Hex
VOUT UV warn limit     : 0x0000 Raw Hex
VOUT UV fault limit    : 0x0000 Raw Hex
IOUT OC fault limit    : 0x8000 Raw Hex
IOUT OC warn limit     : 0x8000 Raw Hex
Power good on          : 0x0000 Raw Hex
Power good off         : 0x0000 Raw Hex
On delay               : 0xba00 Raw Hex
On time limit          : 0xda80 Raw Hex
Off delay              : 0xba00 Raw Hex
Off time limit         : 0x8000 Raw Hex
STATUS_VOUT            : 0x00 Raw Hex
STATUS_IOUT            : 0x00 Raw Hex
Output voltage         : 0x0000 Raw Hex
Output current         : 0x8000 Raw Hex

```

```

5V_EN      Voltage Output      : 0.00 Volts
Page       : 0x1f Raw Hex
OPERATION  : 0x00 Raw Hex
On Off Config : 0x14 Raw Hex
VOUT mode  : 0x14 Raw Hex
VOUT command : 0x0000 Raw Hex
VOUT margin hi : 0x0000 Raw Hex
VOUT margin lo : 0x0000 Raw Hex
VOUT scale  : 0xba00 Raw Hex
VOUT OV fault limit : 0x0000 Raw Hex
VOUT OV warn limit : 0x0000 Raw Hex
VOUT UV warn limit : 0x0000 Raw Hex
VOUT UV fault limit : 0x0000 Raw Hex
IOUT OC fault limit : 0x8000 Raw Hex
IOUT OC warn limit : 0x8000 Raw Hex
Power good on : 0x0000 Raw Hex
Power good off : 0x0000 Raw Hex
On delay     : 0xba00 Raw Hex
On time limit : 0xda80 Raw Hex
Off delay    : 0xba00 Raw Hex
Off time limit : 0x8000 Raw Hex
STATUS_VOUT : 0x00 Raw Hex
STATUS_IOUT : 0x00 Raw Hex
Output voltage : 0x0001 Raw Hex
Output current : 0x8000 Raw Hex

```

PSEQ log

```

Fault Info Reg (0xb5):
12 9a 00 00 4f a9 33 48 7f ff ff ff ff ff ff ff ff 7f ff

```

```

Fault Rails Warning Reg (0xb6):
20 00 00 00 00 00 00 00 7f ff ff ff ff ff ff ff ff
7f ff ff ff ff ff ff ff 7f ff ff ff ff ff ff ff ff

```

```

Rails Value Reg (0xb7) page 0:
07 00 d0 2f 00 00 00

```

```

Rails Value Reg (0xb7) page 1:
07 00 45 34 00 00 00

```

```

Rails Value Reg (0xb7) page 2:
07 00 54 4c 00 00 00

```

```

Rails Value Reg (0xb7) page 3:
07 00 7d 4f 00 00 00

```

```

Rails Value Reg (0xb7) page 4:
07 00 10 36 00 00 00

```

```

Rails Value Reg (0xb7) page 5:
07 00 6c 39 00 00 00

```

```

Rails Value Reg (0xb7) page 6:
07 00 44 39 00 00 00

```

```

Rails Value Reg (0xb7) page 7:
07 00 18 4c 00 00 00

```

```

Rails Value Reg (0xb7) page 8:
07 00 22 39 00 00 00

```

```
Rails Value Reg (0xb7) page 9:
07 00 80 3e 00 00 00

Rails Value Reg (0xb7) page 10:
07 00 80 3e 00 00 00

Rails Value Reg (0xb7) page 11:
07 00 12 39 00 00 00

Rails Value Reg (0xb7) page 12:
07 00 a0 39 00 00 00

Rails Value Reg (0xb7) page 13:
07 00 b8 3f 00 00 00

Rails Value Reg (0xb7) page 14:
07 00 36 39 00 00 00

Rails Value Reg (0xb7) page 15:
07 00 3c 39 00 00 00

Rails Value Reg (0xb7) page 16:
07 00 22 39 00 00 00

Rails Value Reg (0xb7) page 17:
07 00 74 35 00 00 00

Rails Value Reg (0xb7) page 18:
07 00 3e 4f 00 00 00

Rails Value Reg (0xb7) page 19:
07 00 37 4f 00 00 00

Rails Value Reg (0xb7) page 20:
07 00 7c 4c 00 00 00

Rails Value Reg (0xb7) page 21:
07 00 7c 4c 00 00 00

Rails Value Reg (0xb7) page 22:
07 00 74 4c 00 00 00

Rails Value Reg (0xb7) page 23:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 24:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 25:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 26:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 27:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 28:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 29:
07 00 00 00 00 00 00
```

```
Rails Value Reg (0xb7) page 30:
07 00 00 00 00 00 00

Rails Value Reg (0xb7) page 31:
07 00 01 00 00 00 00

Logged Fault Reg (0xea):
25 03 00 00 08 02 82 00 7f ff ff ff ff ff ff ff
7f ff ff ff ff ff ff ff 7f ff ff ff ff ff ff ff
00 00 00 00 00

Fault Details Index Reg (0xeb):
00 64

Fault Details Reg (0xec) index 0:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 1:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 2:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 3:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 4:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 5:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 6:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 7:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 8:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 9:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 10:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 11:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 12:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 13:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 14:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 15:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 16:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff
```

```
Fault Details Reg (0xec) index 17:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 18:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 19:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 20:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 21:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 22:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 23:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 24:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 25:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 26:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 27:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 28:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 29:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 30:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 31:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 32:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 33:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 34:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 35:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 36:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 37:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff
```



```
Fault Details Reg (0xec) index 38:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 39:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 40:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 41:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 42:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 43:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 44:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 45:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 46:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 47:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 48:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 49:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 50:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 51:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 52:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 53:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 54:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 55:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 56:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 57:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 58:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 59:
```

```
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 60:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 61:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 62:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 63:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 64:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 65:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 66:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 67:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 68:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 69:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 70:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 71:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 72:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 73:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 74:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 75:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 76:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 77:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 78:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 79:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 80:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff
```

```
Fault Details Reg (0xec) index 81:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 82:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 83:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 84:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 85:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 86:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 87:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 88:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 89:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 90:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 91:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 92:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 93:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 94:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 95:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 96:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 97:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 98:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Fault Details Reg (0xec) index 99:
0c 02 66 2c 4e 88 04 e9 7f ff ff ff

Logged Page Peaks Reg (0xed) page 0:
05 00 4b 31 00

Logged Page Peaks Reg (0xed) page 1:
05 00 fa 35 00
```

```
Logged Page Peaks Reg (0xed) page 2:
05 00 08 4f 00

Logged Page Peaks Reg (0xed) page 3:
05 00 25 52 00

Logged Page Peaks Reg (0xed) page 4:
05 00 fc 37 00

Logged Page Peaks Reg (0xed) page 5:
05 00 58 3b 00

Logged Page Peaks Reg (0xed) page 6:
05 00 24 3b 00

Logged Page Peaks Reg (0xed) page 7:
05 00 e8 4e 00

Logged Page Peaks Reg (0xed) page 8:
05 00 06 3b 00

Logged Page Peaks Reg (0xed) page 9:
05 00 c8 41 00

Logged Page Peaks Reg (0xed) page 10:
05 00 c8 41 00

Logged Page Peaks Reg (0xed) page 11:
05 00 16 3b 00

Logged Page Peaks Reg (0xed) page 12:
05 00 d8 3b 00

Logged Page Peaks Reg (0xed) page 13:
05 00 dc 41 00

Logged Page Peaks Reg (0xed) page 14:
05 00 10 3b 00

Logged Page Peaks Reg (0xed) page 15:
05 00 1c 3b 00

Logged Page Peaks Reg (0xed) page 16:
05 00 2a 3b 00

Logged Page Peaks Reg (0xed) page 17:
05 00 3e 37 00

Logged Page Peaks Reg (0xed) page 18:
05 00 ce 51 00

Logged Page Peaks Reg (0xed) page 19:
05 00 ce 51 00

Logged Page Peaks Reg (0xed) page 20:
05 00 4c 4f 00

Logged Page Peaks Reg (0xed) page 21:
05 00 58 4f 00

Logged Page Peaks Reg (0xed) page 22:
05 00 44 4f 00

Logged Page Peaks Reg (0xed) page 23:
```

```

05 00 00 00 00

Logged Page Peaks Reg (0xed) page 24:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 25:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 26:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 27:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 28:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 29:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 30:
05 00 00 00 00

Logged Page Peaks Reg (0xed) page 31:
05 00 00 00 00

Fault Detail Enable Reg (0xef):
25 ff ff ff f7 fd 07 07 7f ff ff ff ff ff ff ff
7f ff ff ff ff ff ff 7f ff ff ff ff ff ff ff
00 00 00 00 00

***** EPM Data *****
EPM0 is present
EPM0 Card power is okay
EPM0 Card is ready
EPM0 temperature is 32 degrees Celsius

***** Fans *****
FanMod 1 Fan 1 rotating
FanMod 1 Fan 1 RPM = 21720
FanMod 1 Fan 2 rotating
FanMod 1 Fan 2 RPM = 19380
FanMod 1 Fan 3 rotating
FanMod 1 Fan 3 RPM = 21900
FanMod 1 Fan 4 rotating
FanMod 1 Fan 4 RPM = 19320
FanMod 2 Fan 1 rotating
FanMod 2 Fan 1 RPM = 21720
FanMod 2 Fan 2 rotating
FanMod 2 Fan 2 RPM = 19260
FanMod 2 Fan 3 rotating
FanMod 2 Fan 3 RPM = 21540
FanMod 2 Fan 4 rotating
FanMod 2 Fan 4 RPM = 19440

Environmental Fan FPGA Control : 0x00000107
Environmental Fan Status      : 0x00000003
Environmental Fan Enable Control : 0x00110700
Fanmod1 PWM Slope            : 0x00000108
Fanmod1 Speed                 : 0x000003e8
Fanmod1 Smartfan Control     : 0x00000000
Fanmod1 Smartfan Status      : 0x00540000
Fanmod1 Smartfan PWM         : 0x000000f0

```

show environment

```

Fanmod1 Smartfan Debug      : 0x00003aee
Fanmod2 PWM Slope          : 0x00000108
Fanmod2 Speed              : 0x000003e8
Fanmod2 Smartfan Control   : 0x00000000
Fanmod2 Smartfan Status    : 0x00540000
Fanmod2 Smartfan PWM       : 0x000000f0
Fanmod2 Smartfan Debug     : 0x00003b14
T2/T1 Temp                 : 0x0088007c
T4/T3 Temp                 : 0x0098008c
T6/T5 Temp                 : 0x00a8009c
T8/T7 Temp                 : 0x00b800ac
Level 1 Speed              : 0x000004b0
Level 2 Speed              : 0x00000550
Level 3 Speed              : 0x000005b4
Level 4 Speed              : 0x00000640
Level 5 Speed              : 0x000007d0
Minimal Speed Threshold    : 0x00000054
Fan Controller Speed = automatic

```

```
***** Disks *****
```

```
***** SSD Data *****
```

Related Commands

Command	Description
show server environment	Shows server hardware information.

show eth-uplink

To display Ethernet uplink information, use the **show eth-uplink** command.

show eth-uplink [**detail** | **expand** | **fsm**]

Syntax Description	detail	(Optional) Displays details about the Ethernet uplink.
	expand	(Optional) Displays expanded information about the Ethernet uplink.
	fsm status	(Optional) Displays the finite state machine status.
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Unidirectional link detection (UDLD) is not supported by FXOS; ignore any references to UDLD.	

Example

This example shows how to display expanded Ethernet uplink information:

```
firepower# show eth-uplink expand

Ethernet Uplink:
  Mode          MAC Table Aging Time (dd:hh:mm:ss)  VLAN Port Count Optimization
  -----
  Security Node 00:04:01:40                        Disabled
firepower# show eth-uplink expand

Ethernet Uplink:
  Mode: Security Node
  MAC Table Aging Time (dd:hh:mm:ss): 00:04:01:40
  VLAN Port Count Optimization: Disabled

Ethernet Link Profile:
  Name          UDLD link policy name  Oper UDLD link policy name
  -----
  default      default                    fabric/lan/udld-link-pol-default

Fabric:
  Fabric ID: A

Interface:
  Port Name: Ethernet1/1
  Port Type: Mgmt
  Admin State: Enabled
  Oper State: Link Down
  State Reason: Link failure or not-connected

<--- intevening lines removed for brevity --->

  Port Name: Ethernet2/6
```

```

Port Type: Data
Admin State: Disabled
Oper State: Admin Down
State Reason: Administratively down

Port Name: Ethernet2/7
Port Type: Data
Admin State: Disabled
Oper State: Sfp Not Present
State Reason: Unknown

Port Name: Ethernet2/8
Port Type: Data
Admin State: Disabled
Oper State: Sfp Not Present
State Reason: Unknown

Port Channel:
Port Channel Id: 48
Name: Port-channel48
Port Type: Cluster
Admin State: Enabled
Oper State: Failed
State Reason: No operational members

Member Port:
      Port Name      Membership      Oper State      State Reason
-----
not-connected      Ethernet1/5      Down            Link Down       Link failure or
not-connected      Ethernet1/6      Down            Link Down       Link failure or

Stats Threshold Policy:
Name: default
Full Name: fabric/lan/thr-policy-default
Policy Owner: Local

UDLD link policy:
Name      Admin State  UDLD mode
-----
default   Disabled    Normal
firepower#

```

Related Commands

Command	Description
scope eth-uplink	Enters Ethernet uplink mode.

show event

To display FSM event information, use the **show event** command.

show event [*event_id* | **detail**]

Syntax Description	
<i>event_id</i>	(Optional) Displays information for a specific event.
detail	(Optional) Displays detailed information for all events.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines You can use the **show event** command without any arguments or keywords to display a list of events.

Example

This example shows how to display a list of events:

```

FP9300-A# show event
Creation Time          ID      Code      Description
-----
2025-12-23T04:17:00.678  176144 E4195253 [FSM:STAGE:SKIP]: keyring configuration on
secondary(FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingPeer)
2025-12-23T04:17:00.678  176145 E4195253 [FSM:STAGE:END]: keyring configuration on
secondary(FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingPeer)
2025-12-23T04:17:00.678  176146 E4197130 [FSM:STAGE:SKIP]: post processing after keyring
configuration on primary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingLocal)
2025-12-23T04:17:00.678  176147 E4197130 [FSM:STAGE:END]: post processing after keyring
configuration on primary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingLocal)
2025-12-23T04:17:00.678  176148 E4197131 [FSM:STAGE:SKIP]: post processing after keyring
configuration on secondary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingPeer)
2025-12-23T04:17:00.678  176149 E4197131 [FSM:STAGE:END]: post processing after keyring
configuration on secondary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingPeer)
2025-12-23T04:17:00.678  176150 E4195525 [FSM:END]: keyring
configuration(FSM:sam:dme:PkiEpUpdateEp)
2025-12-23T04:17:00.677  176142 E4195252 [FSM:STAGE:STALE-SUCCESS]: keyring configuration
on primary(FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingLocal)

<--- remaining lines removed for brevity --->

FP9300-A#

```

Related Commands	Command	Description
	show sel	Shows the contents of the system event log (SEL) of a server.

show fabric

To view fabric cabling information, use the **show fabric** command in cabling mode.

show fabric [**breakout** | **detail** | **expand**]

Syntax Description	
a	(Optional) Displays cabling information specific to Fabric A. Note There is no Fabric B.
detail	(Optional) Displays detailed cabling information. The expand keyword is available with this option.
expand	(Optional) Displays expanded cabling information including port breakouts. The detail keyword is available with this option.

Command Modes scope cabling/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command displays general fabric cabling information.

Example

This example shows how to display expanded cabling information:

```
firepower# scope cabling
firepower /cabling # show fabric expand

cabling on switch:
  Id: A

  port breakout:
    Slot ID   Port ID   breakout type
    -----
             3         1 10g 4x
             3         2 10g 4x
firepower /cabling #
```

Related Commands	Command	Description
	create breakout	Creates a new interface breakout.

show fabric-interconnect

To display fabric interconnect information, use the **show fabric-interconnect** command.

show fabric-interconnect [**a** | **b** | **detail** | **environment** | **firmware** | **fsm** | **inventory** | **mac-aging** | **mode** | **version**]

Syntax	Description
a	(Optional) Displays fabric interconnect information for Fabric A. Use the optional detail keyword to show detailed information for the fabric. Note There is only one fabric; it is labeled A. Thus, there is no need to enter this keyword.
b	(Optional) Do not use: there is no Fabric B.
detail	(Optional) Displays detailed fabric interconnect information.
environment	(Optional) Displays information about installed fabric cards. These optional keywords are available: <ul style="list-style-type: none"> • a—Displays information for only Fabric A. This keyword is optional—there is only one fabric. • b—Do not use: there is no Fabric B. • detail—Displays detailed environment information. • expand—Displays expanded environment information. The detail keyword is available with this option. • fan—Displays fan-specific information. The keywords detail and psu available with this option. • psu—Displays power-supply-unit-specific information. The keywords detail and fan available with this option.
firmware	(Optional) Displays firmware information.
fsm status	(Optional) Displays finite state machine status information.
inventory	(Optional) Displays basic hardware information about the fabric. The keywords detail , expand and id available with this option.
mac-aging	(Optional) Displays MAC table aging time.
mode	(Optional) Displays fabric interconnect mode information.
version	(Optional) Displays firmware version information.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines This command does not require a license.

Example

This example shows how to display base fabric interconnect information:

```
FP9300-A# show fabric-interconnect
```

```
Fabric Interconnect:
  ID   OOB IP Addr   OOB Gateway   OOB Netmask   OOB IPv6 Address OOB IPv6 Gateway
  Prefix Operability
-----
  A    10.201.153.14 10.201.153.1  255.255.255.0  ::              ::
  64   Operable
FP9300-A#
```

Related Commands	Command	Description
	scope fabric-interconnect	Enters fabric interconnect mode.

show fan-module

To view information about installed fan modules, use the **show fan-module** command in chassis mode.

show fan-module [**[1 module_id]** | **detail** | **expand**]

Syntax Description	
<i>tray_id module_id</i>	(Optional) To display information for a specific module, use <i>tray_id module_id</i> to identify the module. The <i>tray_id</i> is always 1; the <i>module_id</i> can be 1 through 8.
detail	(Optional) Use this keyword to display detailed status information about each fan module.
expand	(Optional) Use this keyword to display overall status information for each fan module.

Command Modes scope chassis/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines You can use this command without any arguments or keywords to display basic fan module information.

Example

This example shows how to show detailed information for a specific fan module:

```
firepower# scope chassis
firepower /chassis # show fan-module 1 2 detail

Fan Module:
  Tray: 1
  Module: 2
  Overall Status: Operable
  Operability: Operable
  Threshold Status: OK
  Power State: On
  Presence: Equipped
  Thermal Status: OK
  Product Name: Cisco Firepower 9000 Series Fan
  PID: FPR9K-FAN
  VID: 01
  Part Number: 73-17509-01
  Vendor: Cisco Systems Inc
  Serial (SN): NWG194500D8
  HW Revision: 0
  Mfg Date: 2015-11-07T00:00:00.000
firepower /chassis #
```

Related Commands	Command	Description
	scope fan	Scopes into a specific fan.

show fault

To display fault information, use the **show fault** command.

show fault [*ID* | **cause** | **detail** | **severity** | **suppressed**]

Syntax	Description				
<i>ID</i>	(Optional) Display information for the specified fault only.				
cause <i>label</i>	(Optional) Display faults with the specified cause label; for example, <code>set-user-local-failed</code> .				
detail	(Optional) Display detailed information about each fault.				
severity { cleared condition critical info major minor warning }	(Optional) Displays all faults of the specified severity: <ul style="list-style-type: none"> • cleared • condition • critical • info • major • minor • warning 				
suppressed	(Optional) Displays all suppressed faults. You also can optionally append the cause , detail , or severity keyword.				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>1.0(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	1.0(1)	This command was introduced.
Release	Modification				
1.0(1)	This command was introduced.				

Example

This example shows how to display the fault list:

```
FP9300-A# show fault
Severity Code      Last Transition Time      ID      Description
-----
Major    F0276    2025-12-16T07:08:08.542    52605    ether port 1/1 on fabric interconnect
A oper state: link-down, reason: Link failure or not-connected
Major    F0276    2025-12-16T07:08:08.542    78300    ether port 1/5 on fabric interconnect
A oper state: link-down, reason: Link failure or not-connected
Major    F0276    2025-12-16T07:08:08.542    78301    ether port 1/6 on fabric interconnect
A oper state: link-down, reason: Link failure or not-connected
Warning  F16683    2025-12-16T07:08:00.670    78430    [FSM:STAGE:FAILED]: internal system
backup (FSM-STAGE:sam:dme:MgmtBackupBackup:upload)
```

```
Warning F78123 2025-12-16T07:08:00.670 78428 [FSM:STAGE:REMOTE-ERROR]: Result:
end-point-failed Code: unspecified
Message: End point timed out. Check for IP, port, password, disk space or network access
related issues.#(sam:dme:MgmtBackupBackup:upload)
```

```
<--- remaining lines removed for brevity --->
```

```
FP9300-A#
```

Related Commands

Command	Description
show server status	Shows information on the status of a server.

show fc

To display the information of fc class available on the system, use the **show fc** command.

show fc [detail]

Syntax Description	detail	Lists detailed fc class information.
Command Modes	scope eth-server, scope qos	
Command History	Release	Modification
	2.3.1	This command was introduced.
Usage Guidelines	This is a subcommand of the show command in scope eth-server, scope qos	

Example

This example shows how to display system fc class information:

```
Firepower # scope eth-server
Firepower /eth-server # scope qos
Firepower /eth-server/qos # show fc
```

```
FC Class:
  Priority: Fc
  Cos: 3
  Weight: 5
  Bw Percent: 50
  Drop: No Drop
  Mtu: Fc
  Admin State: Enabled
```

This example shows how to display detailed information of ethernet classified class:

```
Firepower /eth-server/qos # show eth-classified
```

```
Ethernet Classified Class:
  Priority: Platinum
  CoS: 5
  Weight: 10
  BW Percent: Not Applicable
  Drop: No Drop
  MTU: Normal
  Multicast Optimize: No
  Admin State: Disabled

  Priority: Gold
  CoS: 4
  Weight: 9
  BW Percent: Not Applicable
  Drop: Drop
  MTU: Normal
  Multicast Optimize: No
  Admin State: Disabled
```

```
Priority: Silver
CoS: 2
Weight: 8
BW Percent: Not Applicable
Drop: Drop
MTU: Normal
Multicast Optimize: No
Admin State: Disabled
```

This example shows how to display detailed information of ethernet best effort class:

```
Firepower /eth-server/qos # show eth-best-effort
```

```
Ethernet Best-Effort Class:
  Priority: Best Effort
  Cos: Any
  Weight: 5
  Bw Percent: 50
  Drop: Drop
  Mtu: 9198
  Multicast Optimize: No
  Admin State: Enabled
```

This example shows how to display the detailed information of ethernet best effort class:

```
Firepower /eth-server/qos # show eth-best-effort detail
```

```
Ethernet Best-Effort Class:
  Priority: Best Effort
  Cos: Any
  Weight: 5
  Bw Percent: 50
  Drop: Drop
  Mtu: 9198
  Multicast Optimize: No
  Admin State: Enabled
```

show fips-mode

To display current FIPS (Federal Information Processing Standard) mode status information, use the **show fips-mode** command.

show fips-mode

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	Security mode
----------------------	---------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines	Enabling certification compliance on a Firepower 4100/9300 chassis does not automatically propagate compliance to any of its attached logical devices.
-------------------------	--

Example

This example shows how to enter security mode and display current FIPS mode status information:

```
FP9300-A # scope security
FP9300-A /security # show fips-mode
FIPS Mode Admin State: Disabled
FIPS Mode Operational State: Disabled
FP9300-A /security #
```

Related Commands	Command	Description
	disable fips-mode	Disables FIPS mode.
	enable fips-mode	Enables FIPS mode.

show firmware

To view system firmware information, use the **show firmware** command.

show firmware [**detail** | **expand** | **monitor** | **package-version**]

Syntax Description	detail	(Optional) Use this keyword to display the current firmware and start-up versions for the device, as well as the running version, its activate status, and the start-up version for the service manager.
	expand	(Optional) Use this keyword to list an extensive list of version and status information for the various system components.
	monitor	(Optional) Use this keyword to display current package version and upgrade status for the device manager, fabric interconnect, and chassis server(s).
	package-version	(Optional) Use this keyword to display current package version for the device manager.

Command Modes System mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines You can use **show firmware monitor** repeatedly to monitor the status of a firmware upgrade download and activation.

Example

This example shows how to monitor firmware version and upgrade status:

```
FP9300-A# scope system
FP9300-A /system # show firmware monitor
FPRM:
  Package-Vers: 2.4 (1.52)
  Upgrade-Status: Ready

Fabric Interconnect A:
  Package-Vers: 2.4 (1.52)
  Upgrade-Status: Ready

Chassis 1:
  Server 1:
    Package-Vers: 2.4 (1.52)
    Upgrade-Status: Ready
  Server 2:
    Package-Vers: 2.4 (1.52)
    Upgrade-Status: Ready

FP9300-A /system #
```

Related Commands	Command	Description
	activate firmware	Activates a firmware package.
	show server firmware	Shows server firmware versions and status information.

show (firmware-install)

To display current firmware package information, use the **show** command in firmware-install mode.

show [**detail** | **event** | **fsm**]

Syntax Description	detail	(Optional) Use this keyword to display detailed firmware package information.
	event [<i>event_ID</i> detail]	(Optional) Use this keyword to display events logged during firmware upgrade; the detail keyword is available. Provide a specific <i>event_ID</i> to view information for only that event.
	fsm { status task }	(Optional) Use these keywords to show firmware upgrade-related finite state machine (FSM) status- or task-related information.

Command Modes Firmware installation mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command shows information about the most-recently installed firmware package.

Example

This example shows how to display detailed information about the installed firmware package:

```
FP9300-A# scope firmware
FP9300-A /firmware # scope firmware-install
FP9300-A /firmware-install # show detail

Firmware Pack Install:
  Upgrade Package Version: 1.0.16
  Oper State: Ready
  Upgrade Status: Upgrade Complete Successful
  Current Task:
FP9300-A /firmware-install #
```

Related Commands	Command	Description
	install firmware	Installs a firmware package.
	show download-task	Shows information about firmware-package download operations
	show firmware	Shows system firmware information.

show fsm status

To display contents of fsm details available on the system, use the **show fsm status** command.

show fsm status [**expand**]

Syntax Description	expand	Displays expanded information for fsm status. The expand keyword is available with this option.
Command Modes	scope fabric-interconnect a	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope fabric-interconnect a.	

Example

This example shows how to display fsm status information:

```
Firepower # scope fabric-interconnect a
QPl /fabric-interconnect # show fsm status
```

ID: A

```
FSM 1:
Remote Result: Not Applicable
Remote Error Code: None
Remote Error Description:
Status: Nop
Previous Status: Update Switch Success
Timestamp: 2012-07-05T23:47:10.032
Try: 0
Flags: 0
Progress (%): 100
Current Task:

FSM 2:
Status: Nop
Previous Status: SW Mgmt Oob Ipv6 If Config Success
Timestamp: 2012-07-05T23:47:10.017
Try: 0
Progress (%): 100
Current Task:

FSM 3:
Status:
Previous Status:
Timestamp:
Try:
Progress (%):
Current Task:
```

This example shows how to display detailed information of fsm status:

```
Firepower /fabric-interconnect # show fsm status expand detail
```

```
ID: A
```

```
FSM Status:
```

```
Affected Object: sys/switch-A/mgmt/fsm
Current FSM: Update Switch
Status: Success
Completion Time: 2012-07-05T23:47:10.033
Progress (%): 100
Description:
Remote Result: Not Applicable
Error Code: None
Error Description:
```

```
FSM Stage:
```

```
Order: 1
Stage Name: UpdateSwitchCopyToLocal
Status: Skip
Try: 0
Last Update Time: 2012-07-05T23:46:54.941
Stage Description: copying image from external repository to local repository
(FSM-STAGE: sam: dme: MgmtControllerUpdateSwitch: copyToLocal)

Order: 2
Stage Name: UpdateSwitchCopyToPeer
Status: Skip
Try: 0
Last Update Time: 2012-07-05T23:46:54.942
Stage Description: copying image from external repository to local repository
of peer (FSM-STAGE: sam: dme: MgmtControllerUpdateSwitch: copyToPeer)

Order: 3
Stage Name: UpdateSwitchUpdateLocal
Status: Success
Try: 1
Last Update Time: 2012-07-05T23:47:10.016
Stage Description: updating local fabric interconnect (FSM-STAGE: sam:
dme: MgmtControllerUpdateSwitch: update Local)

Order: 4
Stage Name: UpdateSwitchVerifyLocal
Status: Success
Try: 1
Last Update Time: 2012-07-05T23:47:10.027
```


show fw-infra-pack

To view a list of firmware infrastructure package available on the system, use the **show fw-infra-pack** command.

show fw-infra-pack [**detail**]

Syntax Description	detail	Lists detailed firmware package infrastructure information.
Command Modes	scope org	
Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope org.

Example

This example shows how to display information of all the system firmware infrastructure packages:

```
Firepower /fabric-interconnect # scope org
Firepower /org # show fw-infra-pack
Infra Pack:
  Name                Description Infrastructure Bundle Version
  -----
  default              Infrastructure Pack
                        92.14 (0.0808g_libtirpc)
```

Example

This example shows how to display detailed information of all the available system firmware infrastructure packages:

```
Firepower /org # show fw-infra-pack expand detail
Infra Pack:
  Name: default
  Description: Infrastructure Pack
  Infrastructure Bundle Version: 92.14(0.0808g_libtirpc)

  Pack Image:
HW Vendor: Cisco Systems
  HW Model: FPR-Manager
  Type: System
  Version: 92.13(0.0808g)
  Presence: Present

  HW Vendor: Cisco Systems
  HW Model: MGMTEXT
  Type: 17
  Version: 92.13(0.107g)
  Presence: Present
```

HW Vendor: Cisco Systems, Inc.
HW Model: F9K-C9300-SUP-K9
Type: Fabric Interconnect Kernel
Version: 5.0(3)N2(92.130.0808g)
Presence: Present

HW Vendor: Cisco Systems, Inc.
HW Model: F9K-C9300-SUP-K9
Type: Fabric Interconnect System
Version: 5.0(3)N2(92.130.0808g)
Presence: Present

HW Vendor: Cisco Systems, Inc.
HW Model: FPR-4110-SUP
Type: Fabric Interconnect Kernel
Version: 5.0(3)N2(92.130.0808g)
Presence: Present

HW Vendor: Cisco Systems, Inc.
HW Model: FPR-4110-SUP
Type: Fabric Interconnect System
Version: 5.0(3)N2(92.130.0808g)
Presence: Present

HW Vendor: Cisco Systems, Inc.
HW Model: FPR-4112-SUP
Type: Fabric Interconnect Kernel
Version: 5.0(3)N2(92.130.0808g)
Presence: Present

HW Vendor: Cisco Systems, Inc.
HW Model: FPR-4112-SUP
Type: Fabric Interconnect System
Version: 5.0(3)N2(92.130.0808g)
Presence: Present

HW Vendor: Cisco Systems, Inc.
HW Model: FPR-4115-SUP
Type: Fabric Interconnect Kernel
Version: 5.0(3)N2(92.130.0808g)
Presence: Present

show hardware-bypass-ports

To display hardware bypass ports information, use the **show hardware-bypass-ports** command.

show hardware-bypass-ports

Syntax Description	show hardware-bypass-ports (Optional) Displays hardware bypass information.				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>2.6(1)</td> <td>Command added.</td> </tr> </tbody> </table>	Release	Modification	2.6(1)	Command added.
Release	Modification				
2.6(1)	Command added.				
Usage Guidelines	This command does not require a license.				

Example

This example shows how to display bypass port pairs information:

```
FPR # scope fabric-interconnect
FPR /fabric-interconnect # show hardware-bypass-ports
```

hardware-bypass port pairs:

```
Port1                Port2                Mode                Oper Mode          WDT          WDT Val
-----
Ethernet2/1          Ethernet2/2          Standby             Standby             Enabled 1000 <-----Pair
Ethernet 2/1-2 is in standby mode
Ethernet2/3          Ethernet2/4          Disabled            Disabled            Disabled 0
Ethernet2/5          Ethernet2/6          Disabled            Disabled            Disabled 0
Ethernet2/7          Ethernet2/8          Disabled            Disabled            Disabled 0
Ethernet3/1          Ethernet3/2          Disabled            Disabled            Disabled 0
Ethernet3/3          Ethernet3/4          Switch Bypass       Switch Bypass       Enabled 1000
<-----Pair Ethernet 3/3-4 is in bypass mode (bypass is active)
Ethernet3/5          Ethernet3/6          Switch Bypass       Switch Bypass       Enabled 1000 <-----Pair
Ethernet 3/5-6 is in bypass mode (bypass is active)
```

Related Commands	Command	Description
	scope fabric-interconnect	Enters fabric interconnect mode.

show https

To display the current HTTPS service configuration, use the **show https** command.

show https

Syntax Description	This command has no arguments or keywords.	
Command Modes	Services mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to display the current HTTPS service configuration:

```

FP9300-A# scope system
FP9300-A /system # scope services
FP9300-A /system/services # show https
Name: https
  Admin State: Enabled
  Port: 443
  Operational port: 443
  Key Ring: default
  Cipher suite mode: Medium Strength
  Cipher suite: ALL:!EDH-RSA-DES-CBC3-SHA:!EDH-DSS-DES-CBC3-SHA:!DES-CBC3-SHA:
  !ADH:!3DES:!EXPORT40:!EXPORT56:!LOW:!RC4:!MD5:!IDEA:+HIGH:+MEDIUM:+EXP:+eNULL
  Hhttps authentication type: Cred Auth
  Crl mode: Relaxed
FP9300-A /system/services #

```

Related Commands	Command	Description
	set https auth-type	Specifies the type of authentication for HTTPS access.

show hw-crypto

To show the status of TLS crypto acceleration, use the **show hw-crypto** command. For more information about TLS crypto acceleration, see the *Management Center Configuration Guide*.

show hw-crypto

Command Modes connect module

Command History	Release	Modification
	2.7.1	This command was introduced.

Usage Guidelines This command displays the status of TLS crypto acceleration for a container instance.

Examples

Following is an example of showing the status of TLS crypto acceleration:

```
scope ssa
/ssa # show app-instance
```

App Name	Identifier	Slot ID	Admin State	Oper State	Running Version	Startup Version
Deploy Type	Turbo Mode	Profile Name	Cluster	State	Cluster Role	
ftd	FTD-FDM	1	Enabled	Online	6.5.0.1159	6.5.0.1159
	Native	No		Not Applicable	None	
ftd	ftd2	2	Enabled	Online	6.5.0.1159	6.5.0.1159
	Container	No	Default-Small	Not Applicable	None	

```
/ssa # sc slot 2
/ssa/slot # scope app-instance ftd ftd2
/ssa/slot/app-instance # show hw-crypto
```

Hardware Crypto:

Admin State	Hardware Crypto Size	Hardware Crypto Version
Enabled	13%	2

Related Commands	Command	Description
	create hw-crypto	Create a TLS crypto acceleration configuration for a container instance.
	delete hw-crypto	Delete a TLS crypto acceleration configuration for a container instance.
	scope hw-crypto	Enable or disable TLS crypto acceleration configuration on a container instance.

show image

To display a list of images available on the system, use the **show image** command.

show image [**detail** | **type** | **version**]

Syntax Description	detail	Lists detailed image information.
	type	(Optional) Displays information about the current image type.
	version	(Optional) Displays firmware version information.

Command Modes scope firmware

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope firmware.

Example

This example shows information of all the system images:

```
Firepower # scope firmware
Firepower /firmware# show image
```

Name	Type	Version
fxos-b200-m5-brdprog.11.0.bin	Board Controller	11.0
fxos-b200-m5-brdprog.5.0.bin	Board Controller	5.0
fxos-k9-compatibility.2.10.1. 1102.json	FXOS CSP Compatibility	2.10 (1.1102)
fxos-k9-compatibility.2.10.1. 159.json	FXOS CSP Compatibility	2.10 (1.159)
fxos-k9-compatibility.2.10.1.175_r. json	FXOS CSP Compatibility	2.10 (1.175_r)
fxos-k9-compatibility.2.10.1. 177.json	FXOS CSP Compatibility	2.10 (1.177)
fxos-k9-compatibility.2.10.1. 179.json	FXOS CSP Compatibility	2.10 (1.179)
fxos-k9-compatibility.2.10.1.192_fix. json	FXOS CSP Compatibility	2.10 (1.192_fix)
x)		
fxos-k9-compatibility.2.10.1. 193.json	FXOS CSP Compatibility	2.10 (1.193)
fxos-k9-compatibility.2.10.1.198_rf. json	FXOS CSP Compatibility	2.10 (1.198_rf)
)		
fxos-k9-compatibility.2.10.1. 199.json	FXOS CSP Compatibility	2.10 (1.199)
fxos-k9-compatibility.2.10.1. 207.json	FXOS CSP Compatibility	2.10 (1.207)

```
fxos-k9-compatibility.2.11.1.156.json          FXOS CSP Compatibility
                                                2.11(1.156)
fxos-k9-compatibility.2.11.1.1922f_dpivev. json
                                                FXOS CSP Compatibility
                                                2.11(1.1922f_
dpivev)
fxos-k9-compatibility.2.11.1.2022f_cpio. json FXOS CSP Compatibility
                                                2.11(1.2022f_
cpio)
fxos-k9-compatibility.2.11.1.2022f_modsec. json
                                                FXOS CSP Compatibility
```

This example shows detailed information of images:

```
Firepower/firmware# show image detail
```

```
Image fxos-b200-m5-brdprog.11.0.bin:
  Type: Board Controller
  Version: 11.0
  Size: 1391730
  Supported Models:
    Vendor: Cisco Systems Inc
    Model: FPR4K-SM-12S

    Vendor: Cisco Systems Inc
    Model: FPR4K-SM-24S

    Vendor: Cisco Systems Inc
    Model: FPR4K-SM-32S

    Vendor: Cisco Systems Inc
    Model: FPR4K-SM-44S

    Vendor: Cisco Systems Inc
    Model: FPR9K-SM-40

    Vendor: Cisco Systems Inc
    Model: FPR9K-SM-48

    Vendor: Cisco Systems Inc
```

show image detail

To display a list of kick-start and system images available on the system, use the **show image** command.

show image detail

Syntax Description	detail	Lists detailed image information.
Command Modes	scope fabric-interconnect	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope fabric-interconnect mode.	

Example

This example shows information of all the kickstart and system images:

```
firepower# /system/services # scope fabric-interconnect
firepower# /fabric-interconnect # show image
Name                                     Type                               Version
-----
fxos-k9-kickstart.5.0.3.N2.4.111.85.SPA  Fabric Interconnect Kernel
                                         5.0(3)N2(4.11
1.85)
fxos-k9-kickstart.5.0.3.N2.92.130.257g.gSSB  Fabric Interconnect Kernel
                                         5.0(3)N2(92.1
30.257g)
fxos-k9-system.5.0.3.N2.4.111.85.SPA         Fabric Interconnect System
                                         5.0(3)N2(4.11
1.85)
fxos-k9-system.5.0.3.N2.92.130.257g.gSSB    Fabric Interconnect System
                                         5.0(3)N2(92.1
30.257g)
Mahendra-QPD /fabric-interconnect #
```


show identity

To display a variety of system information, use the **show identity** command.

```
show identity { ip-addr | ipv6-addr | iqn | mac-addr | uuid | wwn }
```

Syntax	Description
ip-addr	<p>(Optional) Lists information for all available IP addresses.</p> <p>The following optional keywords are available:</p> <ul style="list-style-type: none">• <i>IPv4_address</i>—Displays identity information for the specified IPv4 address.• detail —Displays detailed IPv4 address identity information.• pool-info —Displays IPv4 address information for the pool. The detail keyword is also available.• profile-info —Displays IPv4 address information for the profile. The detail keyword is also available.
ipv6-addr	<p>(Optional) Lists information for all available IPv6 addresses.</p> <p>The following optional keywords are available:</p> <ul style="list-style-type: none">• detail —Displays detailed IPv6-address identity information.• pool-info —Displays IPv6-address information for the pool. The detail keyword is also available.• profile-info —Displays IPv6-address information for the profile. The detail keyword is also available.• <i>IPv6_address</i>—Displays identity information for the specified IPv6 address.

iqn	<p>(Optional) Displays information on the iSCSI Qualified Name (IQN) identities for a system.</p> <p>The following optional keywords are also available:</p> <ul style="list-style-type: none"> • detail —Displays details about the identity information in list format. • pool-info —Displays IQN identity information for the pool. The detail keyword is also available. • profile-info —Displays IQN identity information for the profile. The detail keyword is also available. • <i>prefix</i> —Displays information for the specified IQN prefix. • <i>name</i> —Displays information for the named IQN identity; can be a maximum of 510 characters. <p>By default, this command lists information on all IQN identities configured for an IQN pool.</p>
mac-addr	<p>(Optional) Displays MAC-address identity information for a system.</p> <p>The following optional keywords are also available:</p> <ul style="list-style-type: none"> • <i>id</i> —Displays identity information for a specific MAC address. Specify a MAC address in the format AA:BB:CC:DD:EE:FF. • detail —Displays details about the identity information in list format. • pool-info —Displays MAC-address identity information for the pool. The detail keyword is also available. • profile-info —Displays MAC-address identity information for the profile. The detail keyword is also available.
uuid	<p>(Optional) Displays the universally unique identifier (UUID) identity information for a system.</p> <p>The following optional keywords are also available:</p> <ul style="list-style-type: none"> • derived <i>id</i>—Displays derived identity information for the specified UUID; entered in the form <code>FFFF-FFFFFFFFFFFFFF</code>. • detail —Displays detailed UUID identity information. • <i>uuid_prefix</i> —Displays identity information for the specified UUID prefix; entered in the form <code>FFFFFFFF-FFFF-FFFF</code>. • <i>uuid</i> —Displays identity information for the specified UUID; entered in the form <code>FFFFFFFF-FFFF-FFFF-FFFF-FFFFFFFFFFFFFF</code>. • pool-info —Displays UUID identity information for the pool. The detail keyword is also available. • profile-info —Displays UUID identity information for the profile. The detail keyword is also available.

wwn	<p>(Optional) Displays the world-wide name (WWN) information for a system.</p> <p>The following optional keywords are also available:</p> <ul style="list-style-type: none"> • detail —Displays details about the identity information in list format. • <i>id</i> —Displays identity information for a specific WWN; provide a unique WWN identifier in the form <code>FF:FF:FF:FF:FF:FF:FF:FF</code>. • pool-info —Displays identity information for the pool. The detail keyword is also available. • profile-info —Displays identity information for the profile. The detail keyword is also available.
------------	--

Command Modes	Any command mode
----------------------	------------------

Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>1.1(1)</td> <td>Command added.</td> </tr> </tbody> </table>	Release	Modification	1.1(1)	Command added.
Release	Modification				
1.1(1)	Command added.				

Usage Guidelines	IQN pools and prefixes must be configured in order to use the show identity iqn command.
-------------------------	---

Example

This example shows how to display detailed identity information for the device's IPv4 addresses:

```

FP9300-A# show identity ip-addr detail
IP Address: 192.0.2.9
  Assigned: No
  Assigned Service Profile:
  Owner: Pool
IP Address: 192.0.2.10
  Assigned: No
  Assigned Service Profile:
  Owner: Pool
IP Address: 192.0.2.11
  Assigned: No
  Assigned Service Profile:
  Owner: Pool
IP Address: 192.0.2.12
  Assigned: No
  Assigned Service Profile:
  Owner: Pool

  <--- remaining lines removed for brevity --->

FP9300-A#

```

Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>show server identity</td> <td>Shows identity information for a servers, adapters and interfaces.</td> </tr> </tbody> </table>	Command	Description	show server identity	Shows identity information for a servers, adapters and interfaces.
Command	Description				
show server identity	Shows identity information for a servers, adapters and interfaces.				

show interface

To view Ethernet interface status, use the **show interface** command.

show interface [**detail** | **expand** | **fsm status** | *interface_id*]

Syntax Description	Option	Description
	detail	Shows detailed interface information.
	expand	Shows information about interfaces in a non-tabular view, as well as information about subinterfaces.
	fsm status	Shows Finite State Machine (FSM) status.
	<i>interface_id</i>	Shows information about a particular Ethernet interface, for example, Ethernet1/4.

Command Modes scope eth-uplink/scope fabric a/

Command History	Release	Modification
	2.4(1)	Additional fields were added for VLAN subinterfaces.
	1.1(1)	Command added.

Usage Guidelines This command only applies to Ethernet interfaces. For EtherChannels, see the **show port-channel** command. For subinterfaces, see the **show subinterface** command.



Note Unidirectional link detection (UDLD) is not supported by FXOS; ignore any references to UDLD.

Example

The following is sample output from the **show interface** command.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # show interface
```

```
Interface:
  Port Name      Port Type      Admin State Oper State      Allowed Vlan State
Reason
-----
Ethernet1/2     Data           Enabled      Up              All
Ethernet1/4     Mgmt          Enabled      Up              All
Ethernet1/5     Data           Enabled      Up              Untagged
Ethernet1/7     Firepower Eventing Enabled      Up              All
Ethernet1/8     Data           Disabled     Sfp Not Present All              Unknown
Ethernet2/1     Data           Disabled     Sfp Not Present All              Unknown
Ethernet2/2     Data           Disabled     Sfp Not Present All              Unknown
```

Ethernet2/3	Data	Disabled	Sfp Not Present	All	Unknown
Ethernet2/4	Data	Disabled	Sfp Not Present	All	Unknown
Ethernet2/5	Data	Disabled	Sfp Not Present	All	Unknown
Ethernet2/6	Data	Disabled	Sfp Not Present	All	Unknown
Ethernet2/7	Data	Disabled	Sfp Not Present	All	Unknown
Ethernet2/8	Data	Disabled	Sfp Not Present	All	Unknown

The following is sample output from the **show interface detail** command.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # show interface detail

Interface:
  Port Name: Ethernet1/2
  User Label:
  Port Type: Data
  Admin State: Enabled
  Oper State: Up
  State Reason:
  flow control policy: default
  Auto negotiation: No
  Admin Speed: 1 Gbps
  Oper Speed: 1 Gbps
  Admin Duplex: Full Duplex
  Oper Duplex: Full Duplex
  Ethernet Link Profile name: default
  Oper Ethernet Link Profile name: fabric/lan/eth-link-prof-default
  Uddl Oper State: Admin Disabled
  Inline Pair Admin State: Enabled
  Inline Pair Peer Port Name:
  Allowed Vlan: All
  Network Control Policy: default
  Current Task:

  Port Name: Ethernet1/4
  User Label:
  Port Type: Mgmt
  Admin State: Enabled
  Oper State: Up
  State Reason:
  flow control policy: default
  Auto negotiation: No
  Admin Speed: 1 Gbps
  Oper Speed: 1 Gbps
  Admin Duplex: Full Duplex
  Oper Duplex: Full Duplex
  Ethernet Link Profile name: default
  Oper Ethernet Link Profile name: fabric/lan/eth-link-prof-default
  Uddl Oper State: Admin Disabled
  Inline Pair Admin State: Enabled
  Inline Pair Peer Port Name:
  Allowed Vlan: All
  Network Control Policy: default
  Current Task:

[...]
```

The following is sample output from the **show interface expand** command.

```
firepower# scope eth-uplink
```

show interface

```
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # show interface expand
```

Interface:

```
Port Name: Ethernet1/2
Port Type: Data
Admin State: Enabled
Oper State: Up
Allowed Vlan: All
State Reason:
```

```
Port Name: Ethernet1/4
Port Type: Mgmt
Admin State: Enabled
Oper State: Up
Allowed Vlan: All
State Reason:
```

```
Port Name: Ethernet1/5
Port Type: Data
Admin State: Enabled
Oper State: Up
Allowed Vlan: Untagged
State Reason:
```

Sub Interface:

```
Sub-If Id  Sub-Interface Name  VLAN  Port Type
-----
          100 Ethernet1/5.100    500   Data Sharing
```

Related Commands

Command	Description
show port-channel	Shows EtherChannel status.
show subinterface	Shows subinterface status.

show interface counter errors (connect fxos)

To view the interface counter errors, use the **show interface counter errors** command.

show interface counter errors

Syntax	Description
Align-Err	<p>Alignment errors are a count of the number of frames received that don't end with an even number of octets and have a bad Cyclic Redundancy Check (CRC).</p> <p>Common Causes: Alignment errors are usually the result of a duplex mismatch or a physical problem (such as cabling, a bad port, or a bad NIC). When the cable is first connected to the port, some of these errors can occur. Also, if there is a hub connected to the port, collisions between other devices on the hub can cause these errors.</p>
FCS-Err	<p>The number of valid size frames with Frame Check Sequence (FCS) errors but no framing errors.</p> <p>Common Causes: This is typically a physical issue (such as cabling, a bad port, or a bad Network Interface Card (NIC)) but can also indicate a duplex mismatch.</p>
Xmit-Err	<p>This is an indication that the internal send (Tx) buffer is full.</p> <p>Common Causes: A common cause of Xmit-Err can be traffic from a high-bandwidth link that is switched to a lower bandwidth link, or traffic from multiple inbound links that are switched to a single outbound link. For example, if a large amount of bursty traffic comes in on a gigabit interface and is switched out to a 100Mbps interface, this can cause Xmit-Err to increment on the 100Mbps interface. This is because the output buffer of the interface is overwhelmed by the excess traffic due to the speed mismatch between the inbound and outbound bandwidths.</p>
Rcv-Err	<p>A receive error (that is, Rcv-Err) occurs when a port receives buffer overflows. Congestion on a switch's backplane could cause the receive buffer on a port to fill to capacity, as frames await access to the switch's backplane. However, most likely, an Rcv-Err is indicating a duplex mismatch.</p>
Undersize	<p>The frames received that are smaller than the minimum IEEE 802.3 frame size of 64 bytes (which excludes framing bits but includes FCS octets) that are otherwise well formed.</p> <p>Common Causes: Check the device that sends out these frames.</p>
Out-Discard	<p>The number of outbound packets chosen to be discarded even though no errors have been detected.</p> <p>Common Causes: One possible reason to discard such a packet can be to free up buffer space.</p>

Single-Col	<p>The number of times one collision occurred before the interface transmitted a frame to the media successfully.</p> <p>Common Causes: Collisions are normal for interfaces configured as half duplex but must not be seen on full duplex interfaces. If collisions increase dramatically, this points to a highly utilized link or possibly a duplex mismatch with the attached device.</p>
Multi-Col	<p>The number of times multiple collisions occurred before the interface transmitted a frame to the media successfully.</p> <p>Common Causes: Collisions are normal for interfaces configured as half duplex but must not be seen on full duplex interfaces. If collisions increase dramatically, this points to a highly utilized link or possibly a duplex mismatch with the attached device.</p>
Late-Col	<p>The number of times a collision is detected on a particular interface late in the transmission process. For a 10 Mbit/s port this is later than 512 bit-times into the transmission of a packet. Five hundred and twelve bit-times corresponds to 51.2 microseconds on a 10 Mbit/s system.</p> <p>Common Causes: This error can indicate a duplex mismatch among other things. For the duplex mismatch scenario, the late collision is seen on the half duplex side. As the half duplex side is transmitting, the full duplex side does not wait its turn and transmits simultaneously which causes a late collision. Late collisions can also indicate an Ethernet cable or segment that is too long. Collisions must not be seen on interfaces configured as full duplex.</p>
Excess-Col	<p>A count of frames for which transmission on a particular interface fails due to excessive collisions. An excessive collision happens when a packet has a collision 16 times in a row. The packet is then dropped.</p> <p>Common Causes: Excessive collisions are typically an indication that the load on the segment needs to be split across multiple segments but can also point to a duplex mismatch with the attached device. Collisions must not be seen on interfaces configured as full duplex.</p>
Carri-Sen	<p>The Carri-Sen (carrier sense) counter increments every time an Ethernet controller wants to send data on a half-duplex connection. The controller senses the wire and checks if it is not busy before transmitting.</p> <p>Common Causes: This is normal on a half-duplex Ethernet segment.</p>

Runts	<p>The frames received that are smaller than the minimum IEEE 802.3 frame size (64 bytes for Ethernet), and with a bad CRC.</p> <p>Common Causes: This can be caused by a duplex mismatch and physical problems, such as a bad cable, port, or NIC on the attached device. Platform Exceptions: Catalyst 4000 Series that run Cisco IOS Previous to software Version 12.1(19)EW, a runt = undersize. Undersize = frame < 64bytes. The runt counter only incremented when a frame less than 64 bytes was received. After 12.1(19)EW, a runt = a fragment. A fragment is a frame < 64 bytes but with a bad CRC. The result is the runt counter now increments in show interfaces, along with the fragments counter in show interfaces counters errors when a frame <64 bytes with a bad CRC is received. Cisco Catalyst 3750 Series Switches In releases prior to Cisco IOS 12.1(19)EA1, when dot1q is used on the trunk interface on the Catalyst 3750, runs can be seen on show interfaces output because valid dot1q encapsulated packets, which are 61 to 64 bytes and include the q-tag, are counted by the Catalyst 3750 as undersized frames, even though these packets are forwarded correctly. In addition, these packets are not reported in the appropriate category (unicast, multicast, or broadcast) in receive statistics. This issue is resolved in Cisco IOS release 12.1(19)EA1 or 12.2(18)SE or later.</p>
Giants	<p>Frames received that exceed the maximum IEEE 802.3 frame size (1518 bytes for non-jumbo Ethernet) and have a bad Frame Check Sequence (FCS).</p> <p>Common Causes: In many cases, this is the result of a bad NIC. Try to find the offending device and remove it from the network. Platform Exceptions: Catalyst Cat4000 Series that run Cisco IOS Previous to software Version 12.1(19)EW, the giants counter incremented for a frame > 1518bytes. After 12.1(19)EW, a giant in show interfaces increments only when a frame is received >1518bytes with a bad FCS.</p>
IntMacTx-Er	Interface mac TX - Transmission error
IntMacRx-Er	Interface mac RX - Reception error
Symbol-Err	<p>Symbol-Err is seen when the Mac sees "invalid" symbols. In most cases, this is a physical problem - Gbics, fiber, etc. These errors also increment when the link is not up because the Mac isn't synchronized and receives noise. Small amounts of symbol errors can be ignored. Large amounts of symbol errors can indicate a bad device, cable, or hardware.</p>
Deferred-tx	Deferred-tx increments every sec. Number of first transmission attempts delayed because the medium was busy.

SQETest-Err SQE stands for "Signal Quality Error" and may also be referred to the Ethernet "heartbeat". With early Ethernet cards that required transceivers, the transceiver would send a "Signal Quality Error" back to the Ethernet card after each frame was transmitted to insure that the collision detection circuitry was working. With modern network cards, this SQE test can cause network cards to believe that an actual collision occurred, and a collision is sent out on the network when a SQE test is detected. This can seriously degrade network performance, as each frame successfully transmitted on the network is followed by a collision caused by the SQE test. Cause 1: SQE Test Errors can be caused by a transceiver that have the "SQE test" dip switch turned on (it should be turned off). Check the switch settings on all transceivers on the segment. Cause 2: SQE Test errors can be caused by broken transceivers. Check for failed transceivers on the segment.

Command Modes connect fxos

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This command displays the interface counter errors.

Example

This example shows how to display the interface counter errors information:

```
firepower#
firepower# connect fxos
...
firepower(fxos)# show interface counters errors
```

Port	Align-Err	FCS-Err	Xmit-Err	Rcv-Err	UnderSize	OutDiscards
Eth1/1	0	0	0	0	0	0
Eth1/2	0	0	0	0	0	0
Eth1/3	0	0	0	0	0	0
Eth1/4	0	0	0	0	0	0
Eth1/5	0	0	0	0	0	0
Eth1/6	0	0	0	0	0	0
Eth1/7	0	0	0	0	0	0
Eth1/8	0	0	0	0	0	0
Eth1/9	0	1378344622	0	1384807633	0	0
Eth1/10	0	0	0	0	0	0
Eth1/11	0	0	0	0	0	0
Eth1/12	0	0	0	0	0	0
Eth2/1	0	0	0	0	0	0
Eth2/2	0	0	0	0	0	0
Eth2/3	0	0	0	0	0	0
Eth2/4	0	0	0	0	0	0
Eth2/5	0	0	0	0	0	0
Eth2/6	0	0	0	0	0	0
Eth2/7	0	0	0	0	0	0
Eth2/8	0	0	0	0	0	0
Po1	0	0	0	0	0	0
Po48	0	0	0	0	0	0
Veth687	--	--	--	--	--	0

Veth688	--	--	--	--	--	0
Veth689	--	--	--	--	--	0
Veth690	--	--	--	--	--	0
Veth691	--	--	--	--	--	0
Veth692	--	--	--	--	--	0
Veth693	--	--	--	--	--	0
Veth694	--	--	--	--	--	0
Veth695	--	--	--	--	--	0
Veth696	--	--	--	--	--	0
Veth697	--	--	--	--	--	0
Veth698	--	--	--	--	--	0
Veth718	--	--	--	--	--	0
Veth736	--	--	--	--	--	0
Veth737	--	--	--	--	--	0
Veth772	--	--	--	--	--	0
Veth773	--	--	--	--	--	0
Veth774	--	--	--	--	--	0
Veth775	--	--	--	--	--	0
Veth776	--	--	--	--	--	0
Veth777	--	--	--	--	--	0
Veth855	--	--	--	--	--	0
Veth856	--	--	--	--	--	0
Veth857	--	--	--	--	--	0
Veth858	--	--	--	--	--	0
Veth859	--	--	--	--	--	0
Veth860	--	--	--	--	--	0
Veth861	--	--	--	--	--	0
Veth862	--	--	--	--	--	0

Port	Single-Col	Multi-Col	Late-Col	Exces-Col	Carri-Sen	Runts
Eth1/1	0	0	0	0	0	0
Eth1/2	0	0	0	0	0	0
Eth1/3	0	0	0	0	0	0
Eth1/4	0	0	0	0	0	0
Eth1/5	0	0	0	0	0	0
Eth1/6	0	0	0	0	0	0
Eth1/7	0	0	0	0	0	0
Eth1/8	0	0	0	0	0	0
Eth1/9	0	0	0	0	0	0
Eth1/10	0	0	0	0	0	0
Eth1/11	0	0	0	0	0	0
Eth1/12	0	0	0	0	0	0
Eth2/1	0	0	0	0	0	0
Eth2/2	0	0	0	0	0	0
Eth2/3	0	0	0	0	0	0
Eth2/4	0	0	0	0	0	0
Eth2/5	0	0	0	0	0	0
Eth2/6	0	0	0	0	0	0
Eth2/7	0	0	0	0	0	0
Eth2/8	0	0	0	0	0	0
Po1	0	0	0	0	0	0
Po48	0	0	0	0	0	0
Veth687	--	--	--	--	--	--
Veth688	--	--	--	--	--	--
Veth689	--	--	--	--	--	--
Veth690	--	--	--	--	--	--
Veth691	--	--	--	--	--	--
Veth692	--	--	--	--	--	--
Veth693	--	--	--	--	--	--
Veth694	--	--	--	--	--	--
Veth695	--	--	--	--	--	--
Veth696	--	--	--	--	--	--

show interface counter errors (connect fxos)

```

Veth697          --          --          --          --          --          --
Veth698          --          --          --          --          --          --
Veth718          --          --          --          --          --          --
Veth736          --          --          --          --          --          --
Veth737          --          --          --          --          --          --
Veth772          --          --          --          --          --          --
Veth773          --          --          --          --          --          --
Veth774          --          --          --          --          --          --
Veth775          --          --          --          --          --          --
Veth776          --          --          --          --          --          --
Veth777          --          --          --          --          --          --
Veth855          --          --          --          --          --          --
Veth856          --          --          --          --          --          --
Veth857          --          --          --          --          --          --
Veth858          --          --          --          --          --          --
Veth859          --          --          --          --          --          --
Veth860          --          --          --          --          --          --
Veth861          --          --          --          --          --          --
Veth862          --          --          --          --          --          --

```

```

-----
Port             Giants  SQETest-Err  Deferred-Tx  IntMacTx-Er  IntMacRx-Er  Symbol-Err
-----
Eth1/1           0         --           0             0             0             0
Eth1/2           0         --           0             0             0             0
Eth1/3           0         --           0             0             0             0
Eth1/4           0         --           0             0             0             0
Eth1/5           0         --           0             0             0             0
Eth1/6           0         --           0             0             0             0
Eth1/7           0         --           0             0             0             0
Eth1/8           0         --           0             0             0             0
Eth1/9           0         --           0             6463011      0             0
Eth1/10          0         --           0             0             0             0
Eth1/11          0         --           0             0             0             0
Eth1/12          0         --           0             0             0             0
Eth2/1           0         --           0             0             0             0
Eth2/2           0         --           0             0             0             0
Eth2/3           0         --           0             0             0             0
Eth2/4           0         --           0             0             0             0
Eth2/5           0         --           0             0             0             0
Eth2/6           0         --           0             0             0             0
Eth2/7           0         --           0             0             0             0
Eth2/8           0         --           0             0             0             0
Po1              0         --           0             0             0             0
Po48             0         --           0             0             0             0
Veth687         --          --           --            --            --            --
Veth688         --          --           --            --            --            --
Veth689         --          --           --            --            --            --
Veth690         --          --           --            --            --            --
Veth691         --          --           --            --            --            --
Veth692         --          --           --            --            --            --
Veth693         --          --           --            --            --            --
Veth694         --          --           --            --            --            --
Veth695         --          --           --            --            --            --
Veth696         --          --           --            --            --            --
Veth697         --          --           --            --            --            --
Veth698         --          --           --            --            --            --
Veth718         --          --           --            --            --            --
Veth736         --          --           --            --            --            --
Veth737         --          --           --            --            --            --
Veth772         --          --           --            --            --            --
Veth773         --          --           --            --            --            --
Veth774         --          --           --            --            --            --
Veth775         --          --           --            --            --            --

```

```
Veth776      --      --      --      --      --      --
Veth777      --      --      --      --      --      --
Veth855      --      --      --      --      --      --
Veth856      --      --      --      --      --      --
Veth857      --      --      --      --      --      --
Veth858      --      --      --      --      --      --
Veth859      --      --      --      --      --      --
Veth860      --      --      --      --      --      --
Veth861      --      --      --      --      --      --
Veth862      --      --      --      --      --      --
firepower (fxos) #
```

show interface transceiver (connect fxos)

To view the transceiver details and calibrations, use the **show interface transceiver** command.

show interface transceiver | **details** | **calibrations**

Syntax Description	details	Shows detailed interface transceiver information.
	calibrations	Shows detailed calibration information.
Command Modes	connect fxos	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	This command is a subcommand of the show interface command in the connect fxos shell.	

Example

This example shows how to display a brief set of interface transceiver-related information:

```
firepower#
firepower# connect fxos
...
firepower(fxos)# show interface transceiver calibrations
Ethernet1/1
    transceiver is present
    type is 1000base-T
    name is CISCO-METHODE
    part number is SP7041-R
    revision is
    serial number is ABCD1234
    nominal bitrate is 1300 MBit/sec
    Link length supported for copper is 100 m
    cisco id is --
    cisco extended id number is 4

firepower(fxos)# show interface transceiver details
Ethernet1/1
    transceiver is present
    type is 1000base-T
    name is CISCO-METHODE
    part number is SP7041-R
    revision is
    serial number is ABCD1234
    nominal bitrate is 1300 MBit/sec
    Link length supported for copper is 100 m
    cisco id is --
    cisco extended id number is 4

DOM is not supported
```

show interface brief (connect fxos)

To view or save a reduced set of interface status and other other information, use the **show interface brief** command.

show interface brief

Syntax Description

This command has no arguments or keywords.

Command Modes

connect fxos/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

This command is a subcommand of the **show interface** command in the **connect fxos** shell.

Example

This example shows how to display a brief set of interface-related information:

```
firepower # connect fxos
firepower (fxos) # show interface brief
```

```
-----
Ethernet      VLAN   Type Mode   Status Reason                               Speed   Port
Interface                                           Ch #
-----
Eth1/1        1      eth  lqtunl up     none                               1000 (D) 48
Eth1/2        1      eth  lqtunl up     none                               1000 (D) --
Eth1/3        1      eth  lqtunl down  suspended(no LACP PDU)           1000 (D) 1
Eth1/4        1      eth  lqtunl up     none                               1000 (D) --
Eth1/5        1      eth  lqtunl up     none                               1000 (D) --
Eth1/6        1      eth  lqtunl up     none                               1000 (D) 2
Eth1/7        1      eth  lqtunl up     none                               1000 (D) --
Eth1/8        1      eth  lqtunl down  SFP not inserted                 10G (D) --
Eth1/9        1      eth  vntag up     none                               40G (D) --
Eth1/10       1      eth  vntag up     none                               40G (D) --
Eth1/11       1      eth  vntag up     none                               40G (D) --
Eth1/12       1      eth  vntag up     none                               40G (D) --
Eth1/13       1      eth  access down  Administratively down            40G (D) --
Eth1/14       1      eth  access down  Administratively down            40G (D) --
Eth1/15       1      eth  access down  Administratively down            1000 (D) --
Eth1/16       1      eth  access down  Administratively down            1000 (D) --
Eth2/1        1      eth  lqtunl down  SFP not inserted                 10G (D) --
Eth2/2        1      eth  lqtunl down  SFP not inserted                 10G (D) --
Eth2/3        1      eth  lqtunl down  SFP not inserted                 1000 (D) --
Eth2/4        1      eth  lqtunl down  SFP not inserted                 1000 (D) --
Eth2/5        1      eth  lqtunl down  SFP not inserted                 10G (D) --
Eth2/6        1      eth  lqtunl down  SFP not inserted                 10G (D) --
Eth2/7        1      eth  lqtunl down  SFP not inserted                 10G (D) --
Eth2/8        1      eth  lqtunl down  SFP not inserted                 10G (D) --
-----
```

```
-----
Port-channel VLAN   Type Mode   Status Reason                               Speed   Protocol
-----
```

show interface brief (connect fxos)

```

Interface
-----
Po1          1          eth  lqtunl  down  No operational members  1000(D)  lacp
Po2          1          eth  lqtunl  up    none                a-1000(D) lacp
Po48        1          eth  lqtunl  up    none                a-1000(D) lacp
-----

Port   VRF      Status IP Address      Speed  MTU
-----
mgmt0  --      down  --              --     1500
-----

Vethernet  VLAN  Type Mode  Status Reason          Speed
-----
Veth721    4047  virt trunk up    none           auto
Veth722    1      virt trunk up    none           auto
Veth723    1      virt trunk up    none           auto
Veth724    1      virt trunk up    none           auto
Veth725    1      virt trunk up    none           auto
Veth726    4047  virt trunk up    none           auto
Veth727    4047  virt trunk up    none           auto
Veth728    4047  virt trunk up    none           auto
Veth736    1      virt trunk up    none           auto
Veth737    1      virt trunk down  Administratively down  auto
Veth738    1      virt trunk down  Administratively down  auto
Veth739    4047  virt trunk up    none           auto
Veth740    4047  virt trunk up    none           auto
Veth741    4047  virt trunk up    none           auto
Veth757    4047  virt trunk up    none           auto
Veth758    1      virt trunk up    none           auto
Veth759    1      virt trunk up    none           auto
Veth760    1      virt trunk up    none           auto
Veth761    1      virt trunk up    none           auto
Veth762    4047  virt trunk up    none           auto
Veth763    4047  virt trunk up    none           auto
Veth764    4047  virt trunk up    none           auto
Veth772    1      virt trunk down  Administratively down  auto
Veth773    1      virt trunk down  Administratively down  auto
Veth774    1      virt trunk down  Administratively down  auto
Veth775    4047  virt trunk up    none           auto
Veth776    4047  virt trunk up    none           auto
Veth777    4047  virt trunk up    none           auto
Veth792    1      virt trunk up    none           auto
Veth793    1      virt trunk up    none           auto
Veth794    1      virt trunk up    none           auto
Veth797    1      virt trunk up    none           auto
Veth798    1      virt trunk up    none           auto
Veth800    1      virt trunk up    none           auto
Veth801    1      virt trunk up    none           auto
Veth802    1      virt trunk up    none           auto
Veth805    1      virt trunk up    none           auto
Veth806    1      virt trunk up    none           auto
Veth2182   1      virt trunk up    none           auto
Veth2328   1      virt trunk up    none           auto
Veth2482   1      virt trunk up    none           auto
Veth2502   1      virt trunk up    none           auto
Veth2503   1      virt trunk down  nonParticipating      auto
Veth2504   1      virt trunk up    none           auto
Veth2636   1      virt trunk up    none           auto
Veth2637   1      virt trunk up    none           auto
Veth2638   1      virt trunk down  nonParticipating      auto
Veth2639   1      virt trunk up    none           auto
Veth2640   1      virt trunk up    none           auto
Veth2660   1      virt trunk up    none           auto

```



```

Veth2661      1      virt trunk down nonParticipating auto
Veth2662      1      virt trunk up none auto
Veth2788      1      virt trunk up none auto
Veth2789      1      virt trunk down nonParticipating auto
Veth2790      1      virt trunk up none auto
Veth2791      1      virt trunk up none auto
firepower (fxos) #

```

The following table describes the columns displayed by the `show interface brief` command.

Table 5: show interface brief Fields

Field	Description
Interface ID	<i>Interface or port identifier</i>
VLAN	<i>VLAN identifier</i>
Type	Interface type: eth – dedicated Ethernet interface virt – virtual interface
Mode	Operational port mode: layer3 – Layer 3 interface access – access port trunk – trunk port pvlan – private VLAN fabric – fabric port (F_port) lqtun1 – lq-tunnel (802.1Q tunnel) port f-path – fabric path
Status	Interface state: up – port is operationally up down – port is operationally down testing – interface is in test mode; no operational packets can be passed trunking – trunking is enabled link up – link is up, but port is not yet fully operational for traffic to the data plane, although it is operational for control protocols

Field	Description
Reason	

Field	Description
	Detailed interface state reason:
	Transceiver Initializing
	Other
	None
	Hardware failure
	Diag failure
	Error disabled
	Port Software failure
	Link failure or not connected
	offline
	Non participating
	Initializing
	Inactive
	Administratively down
	Channel admin down
	Suspended (interface)
	Suspended (port)
	Channel membership update in progress
	RCF is in progress
	Isolation due to ELP failure
	Isolation due to ESC failure
	Isolation due to domain overlap
	Isolation due to domain id assignment failure
	Isolation due to domain other side eport isolated
	Isolation due to invalid fabric reconfiguration
	Isolation due to domain manager disabled
	Isolation due to zone merge failure
	Isolation due to vsan not configured on peer
	Parent Interface Admin Down
	Tunnel port src interface unbound
	Interface is removed
	SFP not present
	Error disabled due to SFP vendor not supported

Field	Description
	Error disabled due to incompatible admin port mode
	Error disabled due to incompatible admin port speed
	Suspended due to incompatible mode
	Suspended due to incompatible speed
	Suspended due to incompatible remote switch WWN
	Isolation due to domain manager other side not responding
	Error Disabled due to EPP Failure
	Isolation due to port vsan mismatch
	Isolation due to port loopback to same switch
	Linecard upgrade in progress
	Error disabled due to incompatible admin port rxbbcredit
	Error disabled due to incompatible admin port rxbufsize
	No operational members
	Isolation due to remote zone server not responding
	Error disabled due to first interface in this group is E
	Error disabled due to other interfaces in this group are not shut
	TCP connection closed by peer
	TCP connection rest by peer
	TCP max retransmission reached
	TCP keep alive timer expired
	TCP persist timer expired
	Parent ethernet link down
	Parent ethernet down
	Admin config change
	Tunnel src port removed
	Tunnel source module not online
	Possible port channel misconfiguration
	Isolation due to port security failure
	Isolation due to fabric bind failure
	Isolation due to no common vsans with peer on trunk
	Ficon vsan down
	Invalid attachment Ficon not configured on peer
	Port blocked due to Ficon

Field	Description
	<p>Error disabled due to incompatible admin port rxbbcredit performance buffers</p> <p>Suspended due to too many invalid flogis</p> <p>Suspended due to port security</p> <p>Isolation due to ELP failure revision mismatch</p> <p>Isolation due to ELP failure class F param error</p> <p>Isolation due to ELP failure class N param error</p> <p>Isolation due to ELP failure invalid flow control code</p> <p>Isolation due to ELP failure invalid flow control param</p> <p>Isolation due to ELP failure invalid port name</p> <p>Isolation due to ELP failure invalid switch name</p> <p>Isolation due to ELP failure R_A_TOV or E_D_TOV mismatch</p> <p>Isolation due to ELP failure loopback detected</p> <p>Isolation due to ELP failure invalid transmit B2B credit</p> <p>Isolation due to ELP failure invalid payload size</p> <p>Error Disabled due to portchannel misconfiguration</p> <p>Link failure Port unusable</p> <p>Link failure loss of signal</p> <p>Link failure loss of sync</p> <p>Link failure NOS received</p> <p>Link failure OLS received</p> <p>Link failure renegotiation failed</p> <p>Link failure Link Reset failed nonempty recv queue</p> <p>Link failure Excessive credit loss indications</p> <p>Link failure receive queue overflow</p> <p>Error disabled due to excessive port interrupts</p> <p>Link failure Loop initialization failed nonempty recv queue</p> <p>Link failure Link reset failed queue not empty</p> <p>Link failure OPNy timeout while receive queue not empty</p> <p>Link failure OPNy returned while receive queue not empty</p> <p>Link failure Link reset failed queue not empty</p> <p>Link failure or notconnected</p> <p>Isolation due to FCSP failure</p> <p>SFP checksum error</p>

Field	Description
	<p>Suspended due to external Loopback diagnostics failure</p> <p>Invalid fabric binding exchange</p> <p>Isolation due to TOV Mismatch</p> <p>Error disabled due to ficon not enabled</p> <p>Error disabled due to no ficon portnumber for logical interface</p> <p>Ficon being enabled</p> <p>Port down because prohibit mask in place for E TE port</p> <p>Gracefully shutdown</p> <p>Not all VSANs UP on the trunk</p> <p>Isolation due to fabric binding peer switch WWN not found</p> <p>Isolation due to fabric binding peer domain mismatch</p> <p>Isolation due to fabric binding database mismatch</p> <p>Isolation due to fabric binding no response from peer</p> <p>Suspended due to dynamic vsan suspension</p> <p>Suspended due to dynamic vsan not found</p> <p>All tracked ports down</p> <p>Suspended as extended credit mode not allowed for loop ports</p> <p>Isolation due to portchannel misconfiguration</p> <p>Peer device does not support portchannels</p> <p>Isolation during port bringup</p> <p>Isolation due to domain not allowed</p> <p>Isolation due to virtual IVR domain overlap</p> <p>Out of service</p> <p>Authentication failed</p> <p>Unidirectional UDLD detected</p> <p>Note Unidirectional link detection (UDLD) is not supported by FXOS; ignore any references to UDLD.</p> <p>UDLD Tx Rx loop</p> <p>UDLD neighbor mismatch</p> <p>UDLD empty echo</p> <p>UDLD detected link failure in aggressive mode</p> <p>Port connector type error</p> <p>Error disabled due to reinit limit reached</p>

Field	Description
	Duplicate port num in VSAN
	Internal RCF in progress
	Duplicate WWN
	Invalid other princ epp req received
	Isolated due to unknown reason
	Incomplete tunnel configuration
	Hardware programming failed
	No route to tunnel destination address
	Module removed
	MTU allocation failed
	All parameters have not been configured
	SFP is not inserted
	Transceiver is not inserted
	SFP is not Cisco certified
	Transceiver is not Cisco certified
	Bit error rate threshold exceeded
	Link failure link reset
	Link failure port initialization failed
	ELP failure, all zero peer WWN received
	Isolation due to preferred path
	FC redirect isolation
	Port activity license not available
	SDM isolation
	FCID allocation failed
	Externally disabled
	Authorization pending
	Hot standby in bundle
	Channel error-disabled
	Port capabilities not known
	Mismatch in source and transport VRF
	Forward referencing transport VRF
	two tunnel interface with same configuration is not allowed
	Too many link flaps in a short interval

Field	Description
	<p>Primary vlan is down.</p> <p>VRF Unusable</p> <p>Internal handshake failure</p> <p>BPDUGuard triggered error disable</p> <p>Port is disabled</p> <p>error disabled due to security violation</p> <p>tunnel interface is down because mode is not configured</p> <p>tunnel interface is down because source is not configured</p> <p>tunnel interface is down because destination is not configured</p> <p>tunnel interface is down because could not resolved ip-address associated with tunnel source interface</p> <p>tunnel interface is down because could not resolved ip-address associated with tunnel destination</p> <p>tunnel interface is down because vrf configured to tunnel interface is down</p> <p>Interface is error disabled because of STP inconsistency on VPC peer-link</p> <p>Interface is error disabled because of STP set port state failure</p> <p>port channel is down because it was suspended by vpc</p> <p>vpc configuration is in progress</p> <p>vpc peer-link is down</p> <p>vpc down because failed to receive response from peer</p> <p>vpc down because compatibility check failed</p> <p>Not enough free entries in TCAM bank</p> <p>tunnel interface is down because tunnel source interface is down</p> <p>Error disabled due to IP address conflict</p> <p>Pinned fabric port is down</p> <p>Invalid fabric port</p> <p>FEX fabric sfp invalid</p> <p>SDP timeout/SFP Mismatch</p> <p>FEX identity mismatch</p> <p>FEX ID not configured on fabric port</p> <p>Error disabled due to IP QoS policy application failure</p> <p>Router mac allocation failed</p> <p>VLAN/BD does not exist</p> <p>VLAN/BD is down</p>

Field	Description
	<p>VLAN type is invalid</p> <p>DCX Multiple MSAP IDs recieved for the port</p> <p>DCX Recieved 100 PDUs without ACK</p> <p>IP QOS DCBXP compat check failed</p> <p>Suspended due to minlinks</p> <p>parent interface down</p> <p>Inactive - M1 port not allowed in FabricPath-mode VLAN</p> <p>The speed supported by the transceiver does not match the speed configured on the port</p> <p>Transceiver authentication failed on the port</p> <p>Failed to bring up vPC+ peer link Fabric Path switch ID not configured</p> <p>Failed to bring up vPC+ peer link port is not configured as a Fabric Path port</p> <p>The transceiver has failed ethernet compliance</p> <p>Speed-Group config does not match type of transceiver</p> <p>Suspended due to no LACP PDUs received from peer</p>
Speed	<p>Interface speed:</p> <p>Auto – auto-negotiated</p> <p>10 – 10 Mbps</p> <p>100 – 100 Mbps</p> <p>Auto110 – auto-negotiated between 10 and 100 Mbps</p> <p>1000 – 1 Gbps</p> <p>10G – 10 Gbps</p> <p>a-10 – auto-negotiated, 16 Mbps</p> <p>a-100 – auto-negotiated, 106 Mbps</p> <p>a-1000 – auto-negotiated, 1006 Mbps</p> <p>a-10G – auto-negotiated, 10006 Mbps</p> <p>40G – 40000 Mbps</p> <p>100G – 100000 Mbps</p> <p>a-40G – auto-negotiated, 40006 Mbps</p> <p>a-100G – auto-negotiated, 100006 Mbps</p> <p>Note A (D) appended to a speed entry indicates a dedicated interface, while (S) indicates it is shared.</p>
Port channel #	ID number of the port channel to which interface is assigned, if any.

show interface brief (connect fxos)

Field	Description
Protocol	Port channel protocol: <i>none</i> – Link Aggregation Control Protocol (LCAP) is not enabled <i>lcap</i> – LCAP is enabled
VRF	Name of virtual routing and forwarding (VRF) instance to which port is assigned, if any.
IP Address	Port IP address
MTU	Port MTU (maximum transmission unit) size

Related Commands

Command	Description
show port	In connect fxos mode, shows port information.
show vlan	In connect fxos mode, shows VLAN information.

show inventory

To view information about the chassis and its installed modules, use the **show inventory** command in chassis mode.

show inventory [**detail** | **expand** | **fabric** | **fan** | **fi-iom** | **iom** | **psu** | **server** | **unspecified**]

Syntax Description	Keyword	Description
	detail	(Optional) Use this keyword to display detailed information about the chassis itself.
	expand	(Optional) Use this keyword to display expanded information for each component on the chassis.
	fabric	(Optional) Use this keyword to display fabric transport information. The keyword detail is also available.
	fan	(Optional) Displays information about each fan module on the chassis. The keyword detail is also available.
	fi-iom	(Optional) Displays information about fabric-interconnect switch I/O modules. The keyword detail is also available.
	iom	(Optional) Displays information about chassis input/output modules. The keyword detail is also available.
	psu	(Optional) Displays information about installed power-supply units. The keyword detail is also available.
	server	(Optional) Lists information for each server component. The keyword detail is also available.
	unspecified	(Optional) Lists information for the chassis component. The keyword detail is also available.

Command Modes scope chassis/

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines You can use this command without any arguments or keywords to display basic chassis information.

Example

This example shows how to view expanded chassis inventory information:

```

firepower# scope chassis
firepower /chassis # show inventory expand
Chassis 1:
  Servers:
    Server 1/1:
      Equipped Product Name: Cisco Firepower 9000 Series Security Module
      Equipped PID: FPR9K-SM-24
      Equipped VID: V01
      Equipped Serial (SN): FCH19057S0L
      Slot Status: Equipped
      Acknowledged Product Name: Cisco Firepower 9000 Series Security Module
      Acknowledged PID: FPR9K-SM-24
      Acknowledged VID: V01
      Acknowledged Serial (SN): FCH19057S0L
      Acknowledged Memory (MB): 262144
      Acknowledged Effective Memory (MB): 262144
      Acknowledged Cores: 24
      Acknowledged Adapters: 2

    Server 1/2:
      Equipped Product Name: Cisco Firepower 9000 Series Security Module
      Equipped PID: FPR9K-SM-24
      Equipped VID: V01
      Equipped Serial (SN): FCH19057RTY
      Slot Status: Equipped
      Acknowledged Product Name: Cisco Firepower 9000 Series Security Module
      Acknowledged PID: FPR9K-SM-24
      Acknowledged VID: V01
      Acknowledged Serial (SN): FCH19057RTY
      Acknowledged Memory (MB): 262144
      Acknowledged Effective Memory (MB): 262144
      Acknowledged Cores: 24
      Acknowledged Adapters: 2

    Server 1/3:
      Equipped Product Name:
      Equipped PID:
      Equipped VID:
      Equipped Serial (SN):
      Slot Status: Empty
      Acknowledged Product Name:
      Acknowledged PID:
      Acknowledged VID:
      Acknowledged Serial (SN):
      Acknowledged Memory (MB):
      Acknowledged Effective Memory (MB):
      Acknowledged Cores:
      Acknowledged Adapters:

  PSU 1:
    Presence: Equipped
    Product Name: Cisco Firepower 9000 Series AC Power Supply
    PID: FPR9K-PS-AC
    VID: V00
    Vendor: Cisco Systems Inc
    Serial (SN): DTM190705G3
    HW Revision: 0

  PSU 2:
    Presence: Equipped
    Product Name: Cisco Firepower 9000 Series AC Power Supply
    PID: FPR9K-PS-AC
    VID: V00
    Vendor: Cisco Systems Inc

```

Serial (SN): DTM190705J8
HW Revision: 0

Fan Modules:

Tray 1 Module 1:

Presence: Equipped

ID	PID	Vendor	Serial (SN)	HW Revision
1	FPR9K-FAN	Cisco Systems I	NWG190200LD	0
2	FPR9K-FAN	Cisco Systems I	NWG190200LD	0

Tray 1 Module 2:

Presence: Equipped

ID	PID	Vendor	Serial (SN)	HW Revision
1	FPR9K-FAN	Cisco Systems I	NWG190200ML	0
2	FPR9K-FAN	Cisco Systems I	NWG190200ML	0

Tray 1 Module 3:

Presence: Equipped

ID	PID	Vendor	Serial (SN)	HW Revision
1	FPR9K-FAN	Cisco Systems I	NWG190200KZ	0
2	FPR9K-FAN	Cisco Systems I	NWG190200KZ	0

Tray 1 Module 4:

Presence: Equipped

ID	PID	Vendor	Serial (SN)	HW Revision
1	FPR9K-FAN	Cisco Systems I	NWG190200L8	0
2	FPR9K-FAN	Cisco Systems I	NWG190200L8	0

Switch IOCard 1:

Side: Left
Fabric ID: A
Product Name: Cisco FPR9K-SUP
PID: FPR9K-SUP
VID: V01
Vendor: Cisco Systems, Inc.
Serial (SN): JAD190800VU
HW Revision: 0

Fabric Card 1:

Description: Firepower 9300 Supervisor
Number of Ports: 8
State: Online
Vendor: Cisco Systems, Inc.
Model: FPR9K-SUP
HW Revision: 0
Serial (SN): JAD190800VU
Perf: N/A
Power State: Online
Presence: Equipped
Thermal Status: N/A
Voltage Status: N/A

Fabric Card 2:

Description: Firepower 4x100G QSFP28 NM
Number of Ports: 4
State: Online
Vendor: Cisco Systems, Inc.
Model: FPR-NM-4X100G
HW Revision: 0

```

Serial (SN): JAD2151037Z
Perf: N/A
Power State: Online
Presence: Equipped
Thermal Status: N/A
Voltage Status: N/A

```

```

Fabric Card 3:
  Description: Firepower 4x40G QSFP NM
  Number of Ports: 16
  State: Online
  Vendor: Cisco Systems, Inc.
  Model: FPR9K-NM-4X40G
  HW Revision: 0
  Serial (SN): JAD191601DK
  Perf: N/A
  Power State: Online
  Presence: Equipped
  Thermal Status: N/A
  Voltage Status: N/A

```

```

firepower /chassis #

```

Related Commands

Command	Description
show environment	Shows chassis hardware status information.

show inventory (connect fxos)

To view information about chassis inventory including the name, description, PID, and serial number of the supervisor and network modules, use the **show inventory** command in connect fxos mode.

show inventory

Syntax Description	This command has no arguments or keywords.	
Command Modes	connect fxos	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You can use this command without any arguments or keywords to display chassis or module information.	

Example

This example shows how to view chassis inventory or module information:

```
firepower#
firepower# connect fxos
...
firepower (fxos)# show inventory
NAME: "Chassis", DESCR: "Cisco Firepower 9300 Security Appliance"
PID: FPR9K-SUP          , VID: V08 , SN: ABCD123456

NAME: "Module 1", DESCR: "Firepower 9300 Supervisor"
PID: FPR9K-SUP          , VID: V08 , SN: CBDA123456

NAME: "Module 2", DESCR: "Firepower 4x40G QSFP NM"
PID: FPR-NM-4X40G      , VID: V01 , SN: CBDA654321
```

show ip-block

To display a list of IPv4 address blocks currently defined for service access, use the **show ip-block** command.

show ip-block [[*ip_address prefix_length* {**https** | **snmp** | **ssh**}]] [**detail**]

Syntax Description

<i>ip_address prefix_length</i> { https snmp ssh }	(Optional) To display a specific IPv4 address block, enter that address information: <ul style="list-style-type: none"> The starting address for the IPv4 address block. The prefix length; determines the number of addresses in the block. Value can be 0 to 32. The service (HTTPS, SNMP, or SSH) to which the address block is assigned.
--	---

detail	(Optional) Appending the detail keyword displays the address, prefix and service for each IPv4 block as separate lines.
---------------	--

Command Modes

Services mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use this command to list the currently permitted blocks of IPv4 addresses. Up to 25 different blocks can be configured for each service.

Example

This example shows how to display detailed IPv4 address block information:

```
FP9300-A # scope system
FP9300-A /system # scope services
FP9300-A /system/services # show ip-block detail

    IP Address: 209.165.201.1
    Prefix Length: 24
    Protocol: https

Permitted IP Block:
    IP Address: 0.0.0.0
    Prefix Length: 0
    Protocol: snmp

    IP Address: 209.165.202.129
    Prefix Length: 24
    Protocol: ssh
FP9300-A /system/services #
```


Related Commands	Command	Description
	create ip-block	Creates an IPv4 block.
	delete ip-block	Deletes an existing IPv4 block.

show ip-pool

To display a list of IP pool available on the system, use the **show ip-pool** command.

show ip-pool [*detail* | *expand* | *name*]

Syntax Description	detail	(Optional) Displays IP pool information of a specific pool. The expand and expand keywords are available with this option.
	expand	(Optional) Displays expanded information of IP pool. The detail keyword is available with this option.
	name	Lists detailed IP pool information.
Command Modes	scope org	
Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope org.

Example

This example shows how to display IP pool information:

```
Firepower /fabric-interconnect # scope org
Firepower /org # show ip-pool
IP Pool:
  Name                Size      Assigned  Management mode
  -----
  ext-mgmt             0         0 Internal
  iscsi-initiator-pool 0         0 Internal
  ssp-ippool-app-ccl   126      0 Internal
  ssp-ippool-inter-mgmt 117      0 Internal
```

Example

This example shows how to display detailed information of all the available IP pools:

```
Firepower /org # show ip-pool expand detail

IP Pool:
  Name: ext-mgmt
  Size: 0
  Assigned: 0
  IPv4 Size: 0
  IPv4 Assigned: 0
  IPv6 Size: 0
  IPv6 Assigned: 0
  Descr:
```

```
Assignment Order: Default
Management mode: Internal
Guid: 00000000-0000-0000-0000-000000000000
Net bios enabled or disabled: Not Active
DHCP enaled or disabled: Not Supported
Name: iscsi-initiator-pool
Size: 0
Assigned: 0
IPv4 Size: 0
IPv4 Assigned: 0
IPv6 Size: 0
IPv6 Assigned: 0
Descr:
Assignment Order: Default
Management mode: Internal
Guid: 00000000-0000-0000-0000-000000000000
Net bios enabled or disabled: Not Active
DHCP enaled or disabled: Not Supported
Name: ssp-ippool-app-ccl
Size: 126
Assigned: 0
IPv4 Size: 126
IPv4 Assigned: 0
IPv6 Size: 0
IPv6 Assigned: 0
Descr: SSP service profile IP Pool for app ccl vlan
Assignment Order: Default
Management mode: Internal
Guid: 00000000-0000-0000-0000-000000000000
Net bios enabled or disabled: Not Active
DHCP enaled or disabled: Not Supported
```

show ipsec-log

To view IPSec connection logs, use the **show ipsec-log** command.

show ipsec-log

Syntax Description	This command has no arguments or keywords.	
Command Modes	IPSec mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use the set log-level command to change the amount of information displayed by these logs.	

Example

This example shows how to display the contents of the IPSec log file:

```

FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # show ipsec-log
Feb 10 23:40:02 15[CFG] <test-connection|69> using trusted ca certificate "C=US, ST=CA,
L=SJC, O=Cisco, OU=STBU, CN=CA, E=ssp@ssp.net"
Feb 10 23:40:02 15[CFG] <test-connection|69> reached self-signed root ca with a path
length of 0
Feb 10 23:40:02 15[CFG] <test-connection|69> crl correctly signed by "C=US, ST=CA, O=CA1,
OU=cal, CN=InterCA1, E=cal@ca.net"
Feb 10 23:40:02 15[CFG] <test-connection|69> crl is valid: until Mar 12 22:30:51 2017
Feb 10 23:40:02 15[CFG] <test-connection|69> using cached crl
Feb 10 23:40:02 15[CFG] <test-connection|69> certificate status is good
Feb 10 23:40:02 15[CFG] <test-connection|69> using trusted ca certificate "C=US, ST=CA,
L=SJC, O=Cisco, OU=STBU, CN=CA, E=ssp@ssp.net"
Feb 10 23:40:02 15[CFG] <test-connection|69> checking certificate status of "C=US, ST=CA,
O=CA1, OU=cal, CN=InterCA1, E=cal@ca.net"
Feb 10 23:40:02 15[CFG] <test-connection|69> fetching crl from
'file:///opt/certstore/ssp2-tp.crl' ...
Feb 10 23:40:02 15[CFG] <test-connection|69> issuer of fetched CRL 'C=US, ST=CA, O=CA1,
OU=cal, CN=InterCA1, E=cal@ca.net' does not match CRL issuer
'56:71:f1:d9:b1:62:fd:c3:2b:4d:cb:6b:01:85:ea:75:e5:0e:99:0d'
Feb 10 23:40:02 15[CFG] <test-connection|69> fetching crl from
'http://192.168.0.81/interca_inuse.crl.pem' ...
Feb 10 23:40:02 15[CFG] <test-connection|69> using trusted certificate "C=US, ST=CA,
L=SJC, O=Cisco, OU=STBU, CN=CA, E=ssp@ssp.net"
Feb 10 23:40:02 15[CFG] <test-connection|69> crl correctly signed by "C=US, ST=CA, L=SJC,
O=Cisco, OU=STBU, CN=CA, E=ssp@ssp.net"
Feb 10 23:40:02 15[CFG] <test-connection|69> crl is valid: until Mar 12 22:30:49 2017
Feb 10 23:40:02 15[CFG] <test-connection|69> certificate status is good
Feb 10 23:40:02 15[CFG] <test-connection|69> reached self-signed root ca with a path
length of 1
Feb 10 23:40:02 15[IKE] <test-connection|69> authentication of 'C=US, ST=CA, O=Cisco,
OU=STBU, CN=SSP, E=ssp@ssp.net' with RSA signature successful
Feb 10 23:40:02 15[IKE] <test-connection|69> IKE_SA test-connection[69] established between
192.168.0.174[C=US, ST=CA, O=Cisco, OU=STBU, CN=SSP]

```

```
FP9300-A /security/ipsec #
```

Related Commands

Command	Description
set log-level	Sets the IPSec log verbosity.

show ipv6-block

To display a list of IPv6 address blocks currently defined for service access, use the **show ipv6-block** command.

show ipv6-block [[*ipv6_address prefix_length* {**https** | **snmp** | **ssh**}] | **detail**]

Syntax Description

ipv6_address prefix_length (Optional) To display a specific IPv6 address block, enter that address information:
{ **https** | **snmp** | **ssh** }

- The starting address for the IPv6 address block.
- The prefix length; determines the number of addresses in the block. Value can be 0 to 128.
- The service (HTTPS, SNMP, or SSH) to which the address block is assigned.

detail (Optional) Appending the **detail** keyword displays the address, prefix and service for each IPv6 block as separate lines.

Command Modes

Services mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use this command to list the currently permitted blocks of IPv6 addresses. Up to 25 different blocks can be configured for each service.

Example

This example shows how to display detailed IPv4 address block information:

```
FP9300-A # scope system
FP9300-A /system # scope services
FP9300-A /system/services # show ip-block detail

    IP Address: 2001:DB8:1::1
    Prefix Length: 64
    Protocol: https

Permitted IP Block:
    IP Address: 0:0:0:0:0:0:0:0
    Prefix Length: 0
    Protocol: snmp

    IP Address: 2001:DB8:0:ABCD::1
    Prefix Length: 64
    Protocol: ssh
FP9300-A /system/services #
```

Related Commands	Command	Description
	create ipv6-block	Creates an IPv6 block.
	delete ipv6-block	Deletes an existing IPv6 block.

show ipv6-if

To view current IPv6 management-interface information, use the **show ipv6-if** command.

Syntax Description	detail	Lists detailed IPv6 management-interface information.
	fsm status	Lists finite state machine (FSM) status information related to the IPv6 management interface.
Command Modes	IPv6 configuration (fabric-interconnect/ipv6-config) mode	
Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command displays only IPv6 management-interface information.

Example

This example shows how to display IPv6 management-interface information:

```
FP9300-A# scope fabric-interconnect
FP9300-A# scope ipv6-config
FP9300-A /fabric-interconnect/ipv6-config # show ipv6-if
```

```
Management IPv6 Interface:
IPv6 Address                               Prefix      IPv6 Gateway
-----
2001::8998                                 64          2001::1
FP9300-A /fabric-interconnect/ipv6-config #
```

```
FP9300-A# scope fabric-interconnect
FP9300-A# scope ipv6-config
FP9300-A /fabric-interconnect/ipv6-config # show ipv6-if
Management IPv6 Interface:
  IPv6 Address                               Prefix      IPv6 Gateway
  AutoCfg-method ReadyCfg-method IPv6 state   ND state
  -----
  ::                                           64          2008::1
  Stablesec          Notset          Enable      Enable
```

Related Commands	Command	Description
	scope fabric-interconnect	Enters fabric interconnect mode.
	scope ipv6-config	Enters IPv6 configuration mode.

show keyring

To view the imported certificate information, use the **show keyring** command.

show keyring [**detail** | **name**]

Syntax Description	detail	Displays the imported certificates information.
	name	(Optional) Displays content for the specified imported certificate.
Command Modes	scope security	
Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines **show keyring** is a subcommand of the **show** command in scope security.

Example

This example shows how to display imported certificates and verifies the certificate status value:

```
Firepower# scope security
Firepower# show keyring
Name                Key pair type   RSA key modulus Elliptic Curve TrustpointCA
-----
default            Rsa             Mod2048         Ec             invalid
```

This example shows how to display the contents of the imported certificates.

```
Firepower /security # show keyring detail
Keyring default:
  RSA key modulus: Mod2048
  Trustpoint CA:
  Certificate status: Self Signed Certificate
  Certificate:
  Data:
    Version: 3 (0x2)
    Serial Number:
      6f:fe:83:56:a2:60:da:fd:66:f9:50:75:47:bd:48:da:86:dc:81:81
    Signature Algorithm: sha256WithRSAEncryption
    Issuer: CN = MOIO-2
  Validity
    Not Before: May 26 12:14:42 2012 GMT
    Not After : May 26 12:14:42 2014 GMT
  Subject: CN = MOIO-2
  Subject Public Key Info:
    Public Key Algorithm: rsaEncryption
    RSA Public-Key: (2048 bit)
    Modulus:
      00:d0:78:39:a6:c3:b7:dd:f3:c8:8c:90:5e:6c:43:
      9b:a0:d3:40:15:06:c9:cc:3b:d8:6c:f1:51:fc:5a:
      09:2c:7c:eb:f7:74:25:aa:1d:94:5c:d7:6e:95:61:
      6b:8d:d7:52:23:c8:6c:c7:86:ef:a9:cf:f4:41:65:
      2a:7f:9d:f9:b5:d3:1e:15:91:6e:b5:3d:4a:a7:49:
      d5:a0:cb:4e:8e:1a:e7:55:f3:aa:f9:f3:2a:e8:36:
```

show keyring

```

b6:e8:a8:15:ad:54:b2:8a:f8:f3:b1:2f:ab:8f:df:
c8:28:a6:1d:08:df:25:bd:58:8c:e0:8e:8f:ce:db:
5a:68:68:ce:9a:37:37:66:a8:fa:8c:50:4f:54:0e:
e8:cf:10:a3:70:6a:f9:08:c5:45:5d:38:4f:70:2f:
7a:85:ca:37:e6:67:bf:63:77:c1:24:89:8f:d0:7f:
1d:a2:db:08:ad:33:33:53:ee:95:a9:2f:a3:d6:c1:
bf:d7:de:cd:ac:60:e6:db:2c:1f:20:81:14:c8:f5:
ce:3b:ea:aa:ed:c6:d9:c3:32:5f:f7:e7:36:ce:79:
31:19:18:43:42:62:4a:fa:f6:77:36:85:04:49:e2:
e7:40:0e:f6:9f:a9:a3:9c:c5:23:5e:c8:bc:50:fd:
f6:36:7f:e0:46:59:70:3d:82:84:45:a7:59:23:35:
80:bd
Exponent: 65537 (0x10001)
X509v3 extensions:
X509v3 Subject Alternative Name:
DNS:MOIO-2, IP Address:10.0.0.6
Signature Algorithm: sha256WithRSAEncryption
cb:b6:f5:2a:96:4d:b9:a9:18:9f:00:fa:b6:e0:c0:0e:50:51:
79:74:ca:21:25:e5:ae:e1:fe:03:dc:0b:9b:f7:c0:02:d2:72:
e7:da:fd:f2:76:25:12:27:5f:bc:38:14:80:31:8c:e1:8b:5f:
f8:7b:14:28:7a:be:2a:22:b8:b5:ea:90:1d:69:af:38:1b:ae:
5e:c3:3c:95:f3:9b:32:0b:af:cb:2a:0b:5d:d7:57:77:25:df:
26:ef:5b:ec:fb:09:6e:87:60:fb:3a:14:de:09:5e:13:f6:a8:
10:70:50:e0:dd:cf:6d:78:4f:5e:27:d0:ad:92:db:65:fe:d7:
81:cf:fb:93:d3:1f:21:e1:3f:20:50:62:5b:d3:7d:80:49:82:
99:fc:74:9a:c3:d8:29:bf:2a:cb:a5:33:4d:dd:04:d2:fe:2c:
1d:81:27:cc:56:70:9d:3e:f0:5c:ef:3a:86:ef:21:0a:6b:da:
6c:7a:aa:1a:43:86:8c:f0:89:92:38:71:83:d9:8a:6c:47:22:
03:4d:84:05:69:57:e9:a4:e5:2b:e2:3c:de:63:a9:10:3c:19:
f2:2e:55:de:04:3a:6f:f1:e4:20:1b:2f:2f:38:b6:96:9f:7a:
6b:18:09:f5:89:cd:8a:bc:95:59:b0:91:e9:61:46:7f:6e:6a:
7c:0e:95:d7
-----BEGIN CERTIFICATE-----
MIICyzCCAbOgAwIBAgIUb/6DVqJg2v1m+VB1R71I2obcgYEwDQYJKoZIhvcNAQEL
BQAwETEPMA0GA1UEAwGTU9JTy0yMB4XDTEyMDUyNjE5MTQ0M1oXDTE0MDUyNjE5
MTQ0M1owETEPMA0GA1UEAwGTU9JTy0yMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8A
MIIBCgKCAQEAAHg5psO33fPIjJBebEOboNNAFQbJzDvYbPFR/FoJLHzr93Q1qh2U
XNdulWFrjddSI8hsx4bvqc/0QWUqf535tdMeFZFutT1Kp0nVoMtOjhrnVfOq+fMq
6Da26KgVrVSyivjzS+rj9/IKKYdCN8lvViM4I6PzttaaGjOmc3Zqj6jFBPVA7o
zxCjcGr5CMVFXThPc96hco35me/Y3fBJImP0H8dotsIrTMzU+6VqS+j1sG/197N
rGDm2ywfIIEUyPXOO+qq7cbZwzJf9+c2znkxGRhDQmJK+vZ3NoUESeLnQA72n6mj
nMUjXsi8UP32Nn/gR1lwPYKERadZiZwAvQIDAQABoxswGTAXBgNVHREEDAOggZNT01
PLTKHBAoAAAYwDQYJKoZIhvcNAQELBQADggEBAMu29SqWtBmpGJ8A+rbgwA5Q
UX10yiEl5a7h/gPcC5v3wALScufa/fJ2JRInX7w4FIaxjOGLX/h7FCh6vioiuLXq
kB1przgb17DPJXzmzILr8sqC13XV3c13ybvW+z7CW6HYPs6FN4JXhP2qBBwUODd
z214T14n0K2S22X+14HP+5PTHyHhPyBQYlvtfYBJgpn8dJrD2Cm/KsulM03dBNL+
LB2BJ8xWcJ0+8FzvOobvIQpr2mx6qhpDhozwiZI4cYPZimxHIgNNhAVpV+mk5Svi
PN5jqRA8GfIuVd4EOm/x5CABLy84tpafemsYCFWJzYq8lVmwkelhRn9uanw0ldc=
-----END CERTIFICATE-----

Zeroized: No

```

show lacp (connect fxos)

To display Link Aggregation Control Protocol (LACP) information, use the **show lacp** command.

show lacp { **counters** | **interface** | **internal** | **issu-impact** | **neighbor** [**port-channel**] | **system-identifier** }

Syntax Description

counters [interface port-channel <i>number</i>]	Displays LACP traffic statistics. (Optional) You can specify a particular port-channel to view statistics for only that port-channel; valid port-channel numbers are 1 to 4096.
interface [br-ethernet <i>slot/chassis_num</i> ethernet <i>slot/chassis_num</i>]	Displays LACP information for the Ethernet interfaces. (Optional) You can specify a break-out Ethernet interface, or an Ethernet interface, to view information about the specific interface.

internal { debug buffer event-history info mem-stats }	Displays internal LCAP information and statistics, according to the provided keyword:
	<ul style="list-style-type: none"> • debug buffer – Shows LACP debug information. • event-history – Shows LACP event logs; one of the following event-type keywords is required: <ul style="list-style-type: none"> • errors – Displays LCP error logs. • global – Displays global event transactions. • ifindex <i>index_ID</i> – Displays LACP interface logs for the specified interface index; valid values are 0 to 2147483647. • interface { br-ethernet <i>slot/chassis_num</i> ethernet <i>slot/chassis_num</i> } – Displays LACP events for the specified Ethernet interface. • lock – Displays LACP lock logs. • msgs – Displays LACP event-message logs. • info – Shows general internal LACP information. The following optional keywords are available to specify specific types of information: <ul style="list-style-type: none"> • all – Displays all internal LACP information. • global – Displays global LACP information. • ifindex <i>index_ID</i> – Displays LACP statistics for the specified interface index; valid values are 0 to 2147483647. • interface { br-ethernet <i>slot/chassis_num</i> ethernet <i>slot/chassis_num</i> } – Displays LACP information for the specified Ethernet interface. • log – Displays LACP information logs. • pc-db interface port-channel <i>number</i> – Displays virtual-port-channel database (2lvpc) status for the specified port-channel. • pss – Displays global Persistent Storage Service (PSS) information. • mem-stats – Shows LACP memory allocation statistics.
issu-impact	The in-service software upgrade (ISSU) option does not apply to FXOS.
neighbor [interface port-channel <i>number</i>]	Displays information about LACP neighbors. (Optional) You can specify a particular port-channel to view information for only that port-channel; valid port-channel numbers are 1 to 4096.
port-channel [interface port-channel <i>number</i>]	Displays information about all port-channels. (Optional) You can specify a particular port-channel to view the information for only that port-channel; valid port-channel numbers are 1 to 4096.

system-identifier	Displays the LACP system identification. This is a combination of the port priority and the MAC address of the device.
--------------------------	--

Command Modes	connect fxos/
----------------------	---------------

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines	Use this command to troubleshoot problems related to LACP in a network.
-------------------------	---



Note	When you connect to the FXOS command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to the default prompt with (fxos) appended; see the following example.
-------------	---

Examples

This example shows how to display the LACP counters:

```
firepower# connect fxos
firepower (fxos) # show lacp counters
Response LACPDU          LACPDU          Marker          Marker
Port      Sent   Recv   Sent   Recv   Sent   Recv   Pkts Err
-----
port-channel1
Ethernet1/3      20552782218005  0    0    0    0    0
port-channel2
Ethernet1/6      671621 724750  0    0    0    0    0
port-channel48
Ethernet1/1      23974772587653  0    0    0    0    0
firepower (fxos) #
```

This example shows how to display the LACP information for a particular port-channel:

```
firepower# connect fxos
firepower (fxos) # show lacp port-channel interface port-channel 48
port-channel48
  System Mac=b0-aa-77-2f-f0-af
  Local System Identifier=0x8000,b0-aa-77-2f-f0-af
  Admin key=0x2f
  Operational key=0x2f
  Partner System Identifier=0x8000,78-ba-f9-e2-60-c0
  Operational key=0x30
  Max delay=0
  Aggregate or individual=1
  Member Port List=
firepower (fxos) #
```

Related Commands	Command	Description
	clear lacp counters	Clears LACP counters.

show license

To display the usage of some or all license packages, use the **show license** command.

show license { **all** | **resvcode** | **status** | **summary** | **techsupport** | **udi** | **usage** }

Syntax Description	all	Displays the Smart Licensing status and usage information for all licenses.
	resvcode	Displays generated reservation-code information.
	status	Displays Smart Licensing status information.
	summary	Displays Smart Licensing summary information.
	techsupport	Displays a complete set of Smart Licensing information for transmission to Cisco TAC.
	udi	Displays the FXOS universal device identifier (UDI).
	usage	Displays current license usage.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines You must purchase permanent licenses so they are available in Smart Software Manager. Not all accounts are approved for permanent license reservation.

Example

This example shows how to display current status and usage of all license packages:

```
FP9300-A# show license all

Smart Licensing Status
=====

Smart Licensing is ENABLED

Registration:
  Status: REGISTERED
  Smart Account: Cisco SVS temp
  Virtual Account: Escalations
  Export-Controlled Functionality: Allowed
  Initial Registration: SUCCEEDED on Feb 10 18:55:08 2016 CST
  Last Renewal Attempt: SUCCEEDED on Jun 27 06:11:11 2017 CDT
  Next Renewal Attempt: Jul 28 03:02:49 2017 CDT
  Registration Expires: Jun 27 06:05:09 2018 CDT

License Authorization:
  Status: AUTHORIZED on Jul 05 18:19:38 2017 CDT
  Last Communication Attempt: SUCCESS on Jul 05 18:19:38 2017
```

```
CDT
Next Communication Attempt: Aug 08 14:50:41 2017 CDT

<--- remaining lines removed for brevity --->

FP9300-A#
```

Related Commands

Command	Description
<code>scope license</code>	Enters license mode.

show load-stats

To display the list of load stats capabilities available on the system, use the **show load-stats** command.

show load-stats detail

Syntax Description	detail	Lists detailed load stats capabilities information.
Command Modes	scope system, scope capability	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope system, scope capability	

Example

This example shows how to display load stats capabilities:

```
Firepower # scope system
Firepower /system # scope capability
Firepower /system/capability # show load-stats

Capability:
  Load Errors: 0
  Load Warnings: 4
  Providers Loaded: 128
  Provider Load Failures: 0
  Files Parsed: 17
  File Parse Failures: 0

Firepower /system/capability # show load-stats detail
Capability:
  Load Errors: 0
  Load Warnings: 4
  Providers Loaded: 126
  Provider Load Failures: 0
  Files Parsed: 17
  File Parse Failures: 0
```

show local-user

To display information about a specific user or all local users, use the **show local-user** command.

show local-user [**detail** | *user_name*]

Syntax Description	detail	(Optional) Displays detailed local user information.
	<i>user_name</i>	(Optional) Displays information for the specified local user.

Command Modes Security mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines In security mode, information for all local users is listed by default unless you enter a specific *user_name*.
In local user mode, you can use the **show** command to display information for the connected user.

Example

This example shows how to display detailed user information for a specific local user:

```
FP9300-A /security # show local-user test_user detail
Local User test_user:
  First Name: test
  Last Name: user
  Email: test_user@testuser.com
  Phone:
  Expiration: Never
  Password: ****
  User lock status: Not Locked
  Account status: Active
  User Roles:
    Name: admin
    Name: read-only
  User SSH public key:
FP9300-A /security #
```

Related Commands	Command	Description
	create local-user	Creates a new local user account.
	delete local-user	Deletes an existing local user account.
	enter local-user	Enters an existing local user account.

show local-user tech-support

To display the local user admin, use the **show local-user tech-support** command.

show local-user tech-support detail

Syntax Description	detail	Detailed information of local user tech support.
Command Modes	scope security	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope security.	

Example

This example shows how to display the local user admin information:

```
Firepower # scope security
Firepower /security # show local-user-tech support
```

```
Local User admin:
  Expiration: Never
  Password: ****
  User lock status: Not Locked
  Account status: Active
  User Roles:
    Name: admin
    Name: read-only
  User SSH public key:
```

show logical-device

To display the information of logical devices available on the system, use the **show** command.

show [**expand**] [**detail**] [**fsm**]

Syntax Description	detail	Displays detailed network feature's information.
	expand	(Optional) Displays expanded information for the current application instance. This keyword is also available with many of the other command options to display expanded information about the specified option.
	fsm	It displays the information of fsm status.

Command Modes Scope ssa

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope ssa:

Example

This example shows information for all available logical devices:

```
firepower # scope ssa
firepower /ssa # show logical-device

Logical Device:
  Name      Description Slot ID   Mode      Oper State      Template Name
  -----
  ftd              1      Standalone Incomplete Configuration ftd
```

This example shows detailed information of logical devices:

```
firepower /ssa # show logical-device detail
Logical Device:
  Name: ftd
  Description:
  Slot ID: 1
  Mode: Standalone
  Oper State: Incomplete Configuration
  Template Name: ftd
  Error Msg: Missing bootstrap keys MANAGEMENT_TYPE in ftd mgmt bootstrap
  Switch Configuration Status: Ok
  Current Task:
```

This example shows expand detailed information of logical devices:

```
firepower /ssa # show logical-device expand detail

Logical Device:
```

```
Name: ftd
Description:
Slot ID: 1
Mode: Standalone
Oper State: Incomplete Configuration
Template Name: ftd
Error Msg: Missing bootstrap keys MANAGEMENT_TYPE in ftd mgmt bootstrap
Switch Configuration Status: Ok
Current Task:
```

External-Port Link:

```
Name: Ethernet11_ftd
Port or Port Channel Name: Ethernet1/1
Port Type: Mgmt
App Name: ftd
Description:
Link Decorator:
```

```
Name: Ethernet12_asa
Port or Port Channel Name: Ethernet1/2
Port Type: Data
```

show logical-device-template

To display the template of logical devices like ASA and FTD available on the system, use the **show logical-device-template** command.

show logical-device-template [**detail** | *expand* | *name*]

Syntax Description	detail	Displays the list of detailed logical device template information.
	<i>name</i>	Displays logical device template information for a specific logical device. The <i>expand</i> and <i>expand</i> keywords are available with this option.
	<i>expand</i>	(Optional) Displays expanded information of the logical device template.

Command Modes scope ssa

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope ssa.

Example

This example shows how to display template information of all the logical device:

```
Firepower /fabric-interconnect # scope ssa
Firepower /ssa # show logical-device-template
```

```
Logical Device Template:
  Name      Version  Description
  -----
  asa       1
  ftd       1
Firepower /ssa # show logical
```

Example

This example shows how to display the detailed template information of all the available logical devices in the system:

```
Firepower /ssa # show logical-device-template detail
Logical Device Template:
  Name: asa
  Version: 1
  Description:
  Name: ftd
  Version: 1
  Description:
```

Example

This example shows how to display the detailed template information of all available logical device expand detail in system:

```
Firepower /ssa # show logical-device-template expand detail
  QP1 /ssa # show logical-device-template expand detail
Logical Device Template:
  Name: asa
  Version: 1
  Description:
  Template Applications:
    App Name: asa
    Application can be a decorator: No
  Name: ftd
  Version: 1
  Description:
  Template Applications:
    App Name: ftd
    Application can be a decorator: No
```

show mac-address

To view MAC address assignments for container instance interfaces, use the **show mac-address** command.

show mac-address [**detail** | *mac_address*]

Syntax Description	detail	Shows the MAC addresses in a non-table format.
	<i>mac_address</i>	Shows information about a specific MAC address.

Command Modes scope ssa/scope auto-macpool/

Command History	Release	Modification
	2.4(1)	Command added.

Usage Guidelines This command only applies to container instance interfaces, and it does not show MAC addresses for native instances.

Example

The following is sample output from the **show mac-address** command.

```
firepower# scope ssa
firepower /ssa # scope auto-macpool
firepower /ssa/auto-macpool # show mac-address
Mac Address Item:
  Mac Address      Owner Profile      Owner Name
  -----
  A2:46:C4:00:00:1E  ftd13              Port-channel14
  A2:46:C4:00:00:20  ftd14              Port-channel15
  A2:46:C4:00:01:7B  ftd1               Ethernet1/3
  A2:46:C4:00:01:7C  ftd12              Port-channel11
  A2:46:C4:00:01:7D  ftd13              Port-channel14
  A2:46:C4:00:01:7E  ftd14              Port-channel15
  A2:46:C4:00:01:7F  ftd1               Ethernet1/2
  A2:46:C4:00:01:80  ftd12              Ethernet1/2
  A2:46:C4:00:01:81  ftd13              Ethernet1/2
  A2:46:C4:00:01:82  ftd14              Ethernet1/2
  A2:46:C4:00:01:83  ftd2               Ethernet3/1/4
  A2:46:C4:00:01:84  ftd2               Ethernet3/1/1
  A2:46:C4:00:01:85  ftd2               Ethernet3/1/3
  A2:46:C4:00:01:86  ftd2               Ethernet3/1/2
  A2:46:C4:00:01:87  ftd2               Ethernet1/2
  A2:46:C4:00:01:88  ftd1               Port-channel21
  A2:46:C4:00:01:89  ftd1               Ethernet1/8
```

The following is sample output from the **show mac-address detail** command.

```
firepower# scope ssa
firepower /ssa # scope auto-macpool
firepower /ssa/auto-macpool # show mac-address detail
```



```

Mac Address Item:
  Mac Address: A2:F0:B0:00:00:16
  Owner Profile: ftdl
  Owner Name: Ethernet1/5

  Mac Address: A2:F0:B0:00:00:17
  Owner Profile: ftdl
  Owner Name: Port-channel1

  Mac Address: A2:F0:B0:00:00:18
  Owner Profile: ftdl
  Owner Name: Ethernet1/4

  Mac Address: A2:F0:B0:00:00:19
  Owner Profile: ftdl
  Owner Name: Ethernet1/4

```

Related Commands

Command	Description
create port-channel	Creates an EtherChannel (port channel).
create subinterface	Adds a subinterface.
scope interface	Enters the physical interface object.
set port-type	Sets the interface type.

show member-port

To display status information for the port channel's member port(s), use the **show member-port** command.

show member-port [*slot_id port_id* | **detail** | **Ethernet***slot_id/port_id* | **expand** | **fsm status**]

Syntax Description	Description
<i>slot_id port_id</i>	(Optional) You can view status information for a single member port by specifying its slot and port number. The detail and expand keywords are available with this option.
detail	(Optional) Use this keyword to view detailed information for all member ports. The expand keyword is available with this option.
Ethernet <i>slot_id/port_id</i>	(Optional) You can view status information for a single member port by specifying its Ethernet port label. The detail keyword is available with this option.
expand	(Optional) Use this keyword to view an expanded list of information for all member ports. The detail keyword is available with this option.
fsm status	(Optional) Use this keyword to view finite state machine (FSM) status information for the member ports. You can add a slot and port number (<i>slot_id port_id</i>) to limit the information display to the specified member port. The expand keyword is available with this option.

Command Modes scope eth-uplink/scope fabric a/port-channel

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines You must create or enter a port-channel before you can use this command.
This is a subcommand of the **show** command in scope eth-uplink/scope fabric/port-channel mode.

Example

This example shows expanded member port information for a specific port-channel:

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # enter port-channel 3
firepower /eth-uplink/fabric/port-channel # show member-port expand
```

```
Member Port:
  Port Name      Membership      Oper State      State Reason
  -----
  Ethernet1/1    Up              Up
  Ethernet2/3    Suspended      Failed          Suspended
  Ethernet2/4    Down           Sfp Not Present Unknown
```

```
firepower /eth-uplink/fabric/port-channel #
```

Related Commands

Command	Description
create member-port	Creates a port-channel member port.
create port-channel	Creates a new port-channel.

show mac-pool

To view the list of mac pool available on the system, use the **show mac-pool** command.

show mac-pool [**detail** | **expand** | **name**]

Syntax Description	detail	Lists detailed mac-pool information.
	expand	(Optional) Displays mac-pool information for a specific pool. The expand and expand keywords are available with this option.
	name	(Optional) Displays expanded information of mac pool. The detail keyword is available with this option.
Command Modes	scope org	
Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope org.

Example

This example shows how to display information of available mac pool:

```
Firepower /fabric-interconnect # scope org
Firepower /org # show mac-pool

MAC Pool:
  Name                Size      Assigned
  -----
  default              0         0
  ssp-macpool-ccl     200       0
  ssp-macpool-inter-vnics
                        300       81
  ssp-macpool-mio-external-ports
                        76        3
```

Example

This example shows how to display detailed information of the mac pool expand detail:

```
Firepower /org # show mac-pool expand detail

MAC Pool:
  Name: default
  Size: 0
  Assigned: 0
  Descr:
  Assignment Order: Default
```

```
Name: ssp-macpool-ccl
Size: 200
Assigned: 0
Descr: SSP service profile MAC Pool for ccl
Assignment Order: Default

Block of MAC Addresses:
  From: 00:15:C5:00:00:00
  To: 00:15:C5:00:00:C7

Pooled:
  Id: 00:15:C5:00:00:00
  Assigned: No
Assigned To Dn:
  Poolable Dn: mac/00:15:C5:00:00:00/pool-31022
  Prev Assigned To Dn:

  Id: 00:15:C5:00:00:01
  Assigned: No
  Assigned To Dn:
  Poolable Dn: mac/00:15:C5:00:00:01/pool-31025
  Prev Assigned To Dn:

  Id: 00:15:C5:00:00:02
  Assigned: No
  Assigned To Dn:
  Poolable Dn: mac/00:15:C5:00:00:02/pool-31028
  Prev Assigned To Dn:
```

show memory

To display the information of a memory module, use the **show memory** command.

show memory [*details*]

Syntax Description	detail	You can view detailed version information.
Command Modes	scope chassis/scope server	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope server 1 under scope chassis 1.	

Example

This example shows how to display the available memory module information for a specific server:

```
firepower# scope chassis 1
firepower /chassis # scope server 1
firepower /chassis/server # show memory
```

DIMM	Location	Presence	Overall Status	Type	Capacity (MB)	Clock
1	DIMM_A1	Equipped	Operable	DDR4	16384	2666
2	DIMM_A2	Missing	Removed	Undisc	Unknown	Unknown
3	DIMM_B1	Equipped	Operable	DDR4	16384	2666
4	DIMM_B2	Missing	Removed	Undisc	Unknown	Unknown
5	DIMM_C1	Equipped	Operable	DDR4	16384	2666
6	DIMM_C2	Missing	Removed	Undisc	Unknown	Unknown
7	DIMM_D1	Equipped	Operable	DDR4	16384	2666
8	DIMM_D2	Missing	Removed	Undisc	Unknown	Unknown
9	DIMM_E1	Equipped	Operable	DDR4	16384	2666
10	DIMM_E2	Missing	Removed	Undisc	Unknown	Unknown
11	DIMM_F1	Equipped	Operable	DDR4	16384	2666
12	DIMM_F2	Missing	Removed	Undisc	Unknown	Unknown
13	DIMM_G1	Equipped	Operable	DDR4	16384	2666
14	DIMM_G2	Missing	Removed	Undisc	Unknown	Unknown
15	DIMM_H1	Equipped	Operable	DDR4	16384	2666
16	DIMM_H2	Missing	Removed	Undisc	Unknown	Unknown
17	DIMM_J1	Equipped	Operable	DDR4	16384	2666
18	DIMM_J2	Missing	Removed	Undisc	Unknown	Unknown
19	DIMM_K1	Equipped	Operable	DDR4	16384	2666
20	DIMM_K2	Missing	Removed	Undisc	Unknown	Unknown
21	DIMM_L1	Equipped	Operable	DDR4	16384	2666

```

22 DIMM_L2    Missing          Removed          Undisc          Unknown          Unknown
23 DIMM_M1    Equipped             Operable        DDR4            16384            2666
24 DIMM_M2    Missing             Removed          Undisc          Unknown          Unknown
firepower /chassis/server #

```

Example

This example shows how to display the detailed information of all the available memory modules on a specific server:

```

firepower# scope chassis 1
KSEC-FPR4115-3 /chassis # scope server 1
KSEC-FPR4115-3 /chassis/server # show memory detail
ID 1:
  Location: DIMM_A1
Presence: Equipped
  Overall Status: Operable
  Visibility: Yes
  Vendor: 0x2C00
  Vendor Part Number: 18ASF2G72PDZ-2G6E1
  Vendor Serial (SN): 43585030
  HW Revision: 0
  Form Factor: DIMM
  Type: DDR4
  Capacity (MB): 16384
  Clock: 2666
  Latency: 0.400000
  Width: 64
ID 2:
  Location: DIMM_A2
Presence: Missing
Overall Status: Removed
Visibility: No
Vendor:
Vendor Part Number:
Vendor Serial (SN):
HW Revision: 0
Form Factor: Undisc
Type: Undisc
Capacity (MB): Unknown
Clock: Unknown
Latency: Unknown
Width: Unknown
ID 3:
  Location: DIMM_B1
Presence: Equipped
Overall Status: Operable
Visibility: Yes
Vendor: 0x2C00
Vendor Part Number: 18ASF2G72PDZ-2G6E1
Vendor Serial (SN): 4358534D
HW Revision: 0
Form Factor: DIMM
Type: DDR4
Capacity (MB): 16384
Clock: 2666
Latency: 0.400000
Width: 64
  .....
  .....

```

```
firepower /chassis/server #
```


show (management interface)

To view current management-interface information, use the **show** command in fabric interconnect mode.

show

Syntax Description

In fabric interconnect mode, this command has a number of keywords, but entering **show** without any modifiers displays the current fabric management-interface information.

Command Modes

scope fabric-interconnect/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

By default, this command displays IPv4 and IPv6 management-interface information. Appending the **detail** keyword displays this interface information, along with some additional fabric-specific information.

Example

This example shows how to display management-interface information:

```
firepower# scope fabric-interconnect
firepower /fabric-interconnect # show

Fabric Interconnect:
ID   OOB IP Addr      OOB Gateway      OOB Netmask      OOB IPv6 Address OOB IPv6 Gateway
Prefix Operability
-----
A   192.0.2.112     192.0.2.1       255.255.255.0   ::               ::               64
    Operable
firepower /fabric-interconnect #
```

Related Commands

Command	Description
scope fabric-interconnect	Enters fabric interconnect mode.
show ipv6-if	Shows the current device management IPv6 address.

show mgmt-port

To view status information for the device management port, use the **show mgmt-port** command.

```
(local-mgmt) # show mgmt-port
```

Syntax Description

This command has no arguments or keywords.

Command Modes

connect local-mgmt

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use this command to view information about configuration and status of the device management interface.

Example

This example shows how to display management port information:

```
firepower # connect local-mgmt
firepower(local-mgmt) # show mgmt-port
eth0      Link encap:Ethernet HWaddr b0:aa:77:2f:f0:a9
          inet addr:10.89.5.14 Bcast:10.89.5.63 Mask:255.255.255.192
          inet6 addr: fe80::b2aa:77ff:fe2f:f0a9/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
          RX packets:174151 errors:0 dropped:0 overruns:0 frame:0
          TX packets:101268 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:15273492 (14.5 MiB)  TX bytes:80246582 (76.5 MiB)

firepower(local-mgmt) #
```

Related Commands

Command	Description
show open-network-ports	Shows all open network ports.

show monitor

To view information and resources per security module, use the **show monitor** command.

show monitor [**detail** | **expand**]

Syntax Description	detail	Shows detailed resource usage for the module.
	expand	Shows detailed information about the disk file system.
Command Modes	scope ssa/scope slot/	
Command History	Release	Modification
	2.4(1)	Additional fields were added to show CPU cores, memory, and disk usage.
	1.1(1)	Command added.

Usage Guidelines You can view information about the security module, including the OS version, memory, and uptime. This command is useful for container instances to track resource availability.

Example

The following is sample output from the **show monitor** command.

```
firepower# scope ssa
firepower /ssa # scope slot 1
firepower /ssa/slot # show monitor

Monitor:
  OS Version Memory Total (MB) Memory Free (MB) Memory Used (MB) CPU Cores Available Blade
  Uptime Last Updated Timestamp
  -----
  2.4(1.101)          251844          222089          29755          22 up
  19 days,  2:06
  2018-11-27T18:11:34.155
```

The following is sample output from the **show monitor detail** command.

```
firepower# scope ssa
firepower /ssa # scope slot 1
firepower /ssa/slot # show monitor detail

Monitor:
  OS Version: 2.4(1.101)
  CPU Total Load 1 min Avg: 4.790000
  CPU Total Load 5 min Avg: 4.790000
  CPU Total Load 15 min Avg: 4.780000
  Memory Total (MB): 251844
  Memory Free (MB): 222084
```

```

Memory Used (MB): 29760
CPU Cores Total: 48
CPU Cores Available: 22
Memory App Total (MB): 226886
Memory App Available (MB): 108514
Data Disk Total (MB): 699651
Data Disk Available (MB): 535811
Secondary Disk Total (MB): 0
Secondary Disk Available (MB): 0
Disk File System Count: 5
Blade Uptime: up 19 days, 1:55
Last Updated Timestamp: 2018-11-27T18:00:04.560

```

The following is sample output from the **show monitor expand** command.

```

firepower# scope ssa
firepower /ssa # scope slot 1
firepower /ssa/slot # show monitor expand
Monitor:
  OS Version: 2.4(1.101)
  Memory Total (MB): 251844
  Memory Free (MB): 222089
  Memory Used (MB): 29755
  CPU Cores Available: 22
  Blade Uptime: up 19 days, 2:06
  Last Updated Timestamp: 2018-11-27T18:11:34.155

Disk File System:
  File System Mount Point Disk Total (MB) Disk Free (MB) Disk Used (MB)
  -----
  /dev/sda1 /mnt/boot 7614 7451 163
  /dev/sda2 /opt/cisco/config 1846 1707 43
  /dev/sda3 /opt/cisco/platform/logs 4565 4278 49
  /dev/sda5 /var/data/cores 46807 44368 54
  /dev/sda6 /opt/cisco/csp 699651 653295 46356

```

Related Commands

Command	Description
show resource	Shows resource usage.

show nfs-mount-def

To display the information of mount def available on the system, use the **show nfs-mount-def** command.

show [**detail**]

Syntax Description	detail	List detailed information of mount def.
Command Modes	Scope monitoring	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope monitoring:	

Example

This example shows information for all available mount def:

```
firepower # scope monitoring
firepower /monitoring # show nfs-mount-def
Mount Def:
  Name: external Backup Repository
  Admin State: Disabled
  Local dir: /boot flash/externalcfg
  policy owner: Local
  Purpose: Backup
  Remote dir:
  server:

  Name: external Image Repository
  Admin State: Disabled
  Local dir: /boot flash/external
  policy owner: Local
  Purpose: Image
  Remote dir:
  server:
```

This example shows detailed information of mount def:

```
firepower /monitoring # show nfs-mount-def detail
Mount Def:
  Admin State: Disabled
  Name: external Backup Repository
  Local dir: /boot flash/externalcfg
  policy owner: Local
  Purpose: Backup
  Remote dir:
  server:
  Current Task:

  Admin State: Disabled
  Name: external Image Repository
  Local dir: /boot flash/externalrep
  policy owner: Local
```

```
Purpose: Image
Remote dir:
server:
Current Task:
```

This example shows expand detailed information of mount def status:

```
firepower /monitoring # show nfs-mount-def fsm status
```

```
FSM 1:
Remote Result: Not Applicable
Remote Error Code: None
Remote Error Description:
Status: Nop
Previous Status: Nop
Timestamp: Never
Try: 0
Progress (%): 100
Current Task:
```

```
FSM 1:
Remote Result: Not Applicable
Remote Error Code: None
Remote Error Description:
Status: Nop
Previous Status: Nop
Timestamp: Never
Try: 0
Progress (%): 100
Current Task:
```

show nm-fpga-version

To display a fpga version of network adapter, use the **show nm-fpga-version** command.

show nm-fpga-version [**detail**]

Syntax Description	detail	Detailed version information.
Command Modes	scope chassis 1	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	Subcommand of the show command in scope chassis 1.	

Example

This example shows version information of the network module fpga version:

```
firepower/fabric-interconnect # scope chassis 1
firepower /chassis # show nm-fpga-version

Network Module Version:
  Network Module Slot: 2
  Running-Vers: 0.6.0
  Package-Vers: 0.0
  Activate-Status: Ready
firepower/chassis #
```

show ntp-overall-status

To display overall Network Time Protocol synchronization status for the system, use the **show ntp-overall-status** command.

show ntp-overall-status

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to display current clock-synchronization status for chassis and any logical devices installed on the chassis:

```
FP9300-A# show ntp-overall-status

      NTP Overall Time-Sync Status: Time Synchronized
FP9300-A#
```

Related Commands

Command	Description
show clock	Displays the system clock.

show ntp server

To display the NTP server, use the **show ntp-server** command.

show ntp-server

Syntax Description	show ntp-server	This command displays the NTP server in FXOS.
Command Modes	scope system/scope services/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command displays the NTP server.	

Example

This example shows how to display the NTP server:

```
firepower# scope system;scope services
firepower /system/services # show ntp-server

NTP server hostname:
  Name                               Time Sync Status
  -----
  192.0.2.1                          Time Synchronized

firepower /system/services # show ntp-server expand detail

NTP server hostname:
  Name: 192.0.2.1
  Time Sync Status: Time Synchronized
  NTP SHA-1 key id: 0
  Error Msg:
```

show org

To display current organization information, use the **show org** command.

show org [**detail** | *name*]

Syntax Description	detail	(Optional) Displays details for all currently defined organizations.
	<i>name</i>	(Optional) Displays information for the specified organization; maximum of 16 characters for this identifier.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to display current organization information:

```
FP9300-A# show org
```

```
Organizations:
  Name: / (root)
FP9300-A#
```

Related Commands	Command	Description
	scope org	Enters organization (/org) mode.

show package

To display downloaded package information, use the **show package** command.

show package [**detail** | **expand** | **type** *endpoint_type* | *name*]

Syntax	Description				
detail	(Optional) Displays detailed package information, including version number and time and date stamps.				
expand	(Optional) Lists the images bundled in each package. The detail keyword is also available.				
type <i>endpoint_type</i>	<p>(Optional) Displays information for the specified package end-point type:</p> <ul style="list-style-type: none"> • b-series-bundle—Lists information for any available B Series Bundles. • c-series-bundle—Lists information for any available C Series Bundles. • catalog—Lists information for the FXOS image catalog which is a list of images and packages. • firmware-fpr4k-bundle—Lists information for any available FP4100-series firmware bundles. • firmware-fpr9k-bundle—Lists information for any available FP9300 firmware bundles. • image—Lists available firmware images. • full-bundle—Lists information for any downloaded full bundles. • infrastructure-bundle—Lists information for any downloaded infrastructure bundles. • platform-bundle—Lists information for any downloaded platform bundles. • unknown—Lists information for any downloaded bundles of unknown type. <p>The detail and expand keywords are also available with this option.</p>				
<i>name</i>	<p>(Optional) Displays information for the specified package.</p> <p>The detail, expand and type keywords are also available with this option.</p>				
Command Modes	Firmware mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>1.1(1)</td> <td>Command added.</td> </tr> </tbody> </table>	Release	Modification	1.1(1)	Command added.
Release	Modification				
1.1(1)	Command added.				

Usage Guidelines

If you do not include a *name*, the **show package** command lists information for every firmware package on the appliance.

Example

This example shows how to list detailed and expanded information for a specific firmware package:

```

FP9300-A# scope firmware
FP9300-A /firmware # show package fxos-k9.2.3.1.51.SPA detail
Firmware Package fxos-k9.2.3.1.51.SPA:
  Version: 2.3(1.51)
  Type: Platform Bundle
  State: Active
Time Stamp: 2017-10-25T16:53:30.000
Build Date: 2017-10-21 09:10:36 UTC
FP9300-A /firmware # show package fxos-k9.2.3.1.51.SPA expand
Package fxos-k9.2.3.1.51.SPA:
  Images:
    fxos-k9-bundle-infra.2.3.1.51.SPA
    fxos-k9-bundle-server.2.3.1.51.SPA
FP9300-A /firmware #

```

Related Commands

Command	Description
show server firmware	Shows server firmware versions and status information.
verify platform-pack	Verifies a specified FXOS platform image.

show password-profile

To display password profile information, use the **show password-profile** command.

show password-profile [**detail**]

Syntax Description	detail	(Optional) Displays detailed password profile information.
Command Modes	Security mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command lists information for the current security password profile.	

Example

This example shows how to display detailed password profile information:

```
FP9300-A# scope security
FP9300-A /security # show password-profile detail
```

```
Password profile:
  Password history count: 5
  No password changes allowed (in Hours): 24
  Password change during interval: Enable
  Password change interval (in Hours): 48
  Password change count: 2
FP9300-A#
```

Related Commands	Command	Description
	scope password-profile	Enters password profile mode.

show pki fsm status

To display the FSM information, use the **show pki fsm status** command.

show pki fsm status [**expand** | **detail**]

Syntax Description	expand	Displays the FSM status.
	Detail	Displays detailed content of FSM status.

Command Modes scope security

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines By default, this is a subcommand of the **show** command in scope security.

Example

This example shows how to display the FSM status:

```
Firepower# scope security
Firepower # show pki fsm status expand detail
  FSM Status:
    Affected Object: sys/pki-ext/fsm
    Current FSM: updateEp
    Status: Success
    Completion Time: 2022-08-23T05:14:02.628
    Progress (%): 100
    Description:
    Remote Result: Not Applicable
    Error Code: None
    Error Description:

    FSM Stage:

      Order: 1
      Stage Name: updateEpSetKeyRingLocal
      Status: Success
      Try: 1
      Last Update Time: 2022-08-23T05:14:02.626
      Stage Description: keyring configuration on
primary (FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingLocal)

      Order: 2
      Stage Name: updateEpSetKeyRingPeer
      Status: Skip
      Try: 0
      Last Update Time: 2022-08-23T05:14:02.626
      Stage Description: keyring configuration on
secondary (FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingPeer)

      Order: 3
      Stage Name: updateEpPostSetKeyRingLocal
```

```
Status: Skip
Try: 0
Last Update Time: 2022-08-23T05:14:02.627
Stage Description: post processing after keyring configuration on
primary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingLocal)

Order: 4
Stage Name: updateEpPostSetKeyRingPeer
Status: Skip
Try: 0
Last Update Time: 2022-08-23T05:14:02.628
condary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingPeer)g configuration on se--More-
```

show pmon state

To view the status of the processes in local management mode, use **show pmon state** command.

show pmon state

Syntax Description	show pmon state	Displays the status of the processes in local management mode.
Command Modes	connect local-mgmt	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command lists the status of processes in local management mode.	

Example

This example shows how to display the status of processes information in local management mode:

```
firepower#
firepower# connect local-mgmt
...
firepower(local-mgmt)#(local-mgmt)# show pmon state
```

SERVICE NAME	STATE	RETRY (MAX)	EXITCODE	SIGNAL	CORE
svc_sam_controller	running	0(4)	0	0	no
smConLogger	running	0(4)	0	0	no
svc_sam_dme	running	0(4)	0	0	no
svc_sam_dcosAG	running	0(4)	0	0	no
svc_sam_bladeAG	running	0(4)	0	0	no
svc_sam_portAG	running	0(4)	0	0	no
svc_sam_statsAG	running	0(4)	0	0	no
svc_sam_hostagentAG	running	0(4)	0	0	no
svc_sam_nicAG	running	0(4)	0	0	no
svc_sam_licenseAG	running	0(4)	0	0	no
svc_sam_extvmmAG	running	0(4)	0	0	no
httpd.sh	running	0(4)	0	0	no
...					

show post

To display any errors that occurred during the most-recent BIOS power-on self-test (POST), use the **show post** command.

show post [*id* | **detail** | **expand** | **no-errors**]

Syntax Description		
<i>id</i>	(Optional) Show POST information for a specific server; valid values are 0 to 42949667295.	
detail	(Optional) Show additional POST details.	
expand	(Optional) Show all POST information.	
no-errors	(Optional) Show POST information without errors.	

Command Modes Any command mode; most relevant in server (/chassis/server) mode.

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command in server mode.

Example

This example shows how to display POST information:

```
FP9300-A# scope server 1/1
FP9300-A /chassis/server # show post

POST:
  Global ID Code      Severity  Affected Object      Description
  -----
  608      Post 608  Info      sys/chassis-1/blade-1  Invalid DIMM Configuration
```

Related Commands	Command	Description
	show server bios	Shows server BIOS firmware information.

show pre-login-banner

To display the pre-login banner, use the **show pre-login-banner** command.

show pre-login-banner

Command Modes scope security

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command displays the pre-login banner information.

Example

This example displays the pre-login banner information:

```
firepower# scope security
firepower /security # scope banner
firepower /security/banner # show pre-login-banner
```

```
Pre login banner:
  Message
  -----
  TEST
```

show provider-load-stats

To display the information of provider capabilities available on the system, use the **show provider-load-stats** command.

show provider-load-stats

Command Modes scope system, scope capability

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope system, scope capability.

Example

This example shows how to display the provider capabilities information:

```
Firepower # scope system
Firepower/system # scope capability
Firepower /system/capability # show provider-load-stats

Provider: capabilities/bundle-type-cap
  Vendor:
  Model:
  Load Errors: 0
  Load Warnings: 0
  Elements Loaded: 8
  Element Load Failures: 0

Provider: capabilities/manufacturer-Cisco Systems Inc-model-CHORLEYWOOD-revision-0
-0
  Vendor: Cisco Systems Inc
  Model: CHORLEYWOOD
  Load Errors: 0
  Load Warnings: 1
  Elements Loaded: 5
  Element Load Failures: 0

Provider: capabilities/manufacturer-Cisco Systems Inc-model-F9K-C9300-revision-0
  Vendor: Cisco Systems Inc
  Model: F9K-C9300
  Load Errors: 0
  Load Warnings: 0
  Elements Loaded: 5
  Element Load Failures: 0

TEST
```

This example shows how to display the detailed information of provider capabilities:

```
Firepower /system/capability # show provider-load-stats detail

Provider: capabilities/bundle-type-cap
  Vendor:
  Model:
  Load Errors: 0
```

```
Load Warnings: 0
Elements Loaded: 8
Element Load Failures: 0

Provider: capabilities/manufacturer-Cisco Systems Inc-model-CHORLEYWOOD-revision-0
-0
  Vendor: Cisco Systems Inc
  Model: CHORLEYWOOD
  Load Errors: 0
  Load Warnings: 1
  Elements Loaded: 5
  Element Load Failures: 0

Provider: capabilities/manufacturer-Cisco Systems Inc-model-F9K-C9300-revision-0
  Vendor: Cisco Systems Inc
  Model: F9K-C9300
  Load Errors: 0
  Load Warnings: 0
  Elements Loaded: 5
  Element Load Failures: 0

Provider: capabilities/manufacturer-Cisco Systems Inc-model-FPR-4110-K9-revision-0
-0
  Vendor: Cisco Systems Inc
  Model: FPR-4110-K9
  Load Errors: 0
  Load Warnings: 0
  Elements Loaded: 5
  Element Load Failures: 0
```

show port-channel (connect fxos)

To display information about configured port channels, use the **show port-channel** command.

show port-channel { **capacity** | **compatibility-parameters** | **database** | **internal** | **load-balance** | **summary** | **traffic** | **usage** }

Syntax	Description
capacity	Shows device port-channel capacity information, including total available and total in use.
compatibility-parameters	Lists port-channel interface compatibility requirements and status.
database [interface port-channel <i>number</i>]	<p>Lists port-channel configuration and status information, including first operational port and age of the port-channel.</p> <p>(Optional) You can specify a particular port-channel to view the information for only that port-channel; valid port-channel numbers are 1 to 4096.</p> <p>You can specify a subinterface by appending a dot and the subinterface number (. <i>subinterface_num</i>) after the port-channel number.</p> <p>You also can specify a range of port-channels or multiple ranges to view:</p> <ul style="list-style-type: none"> To specify a single range, enter <i>start_num</i> - <i>end_num</i> To specify a multiple ranges, enter <i>start_num</i> - <i>end_num</i> , <i>start_num</i> - <i>end_num</i> , and so on
internal { event-history info max-channels mem-stat sdb }	<p>Show port-channel information for various internal statistics, using one of the following keywords:</p> <ul style="list-style-type: none"> event-history – You can display logs for a variety of port-channel event types. info – You can display all global internal port-channel information, or interface-specific port-channel information. max-channels – Displays the maximum number of port-channels allowed on this device. mem-stats – Show private memory allocation statistics. The optional keyword detail is available to display detailed statistics. sdb – Dumps port-channel internal status information. <p>Most options have additional options and keywords; use the show port-channel internal keyword ? command to view the options.</p>
load-balance	Configure port-channel load balance.

summary [interface port-channel <i>number</i>]	Show port-channel summary. (Optional) You can specify a particular port-channel to view the information for only that port-channel; valid port-channel numbers are 1 to 4096. You can specify a subinterface by appending a dot and the subinterface number (. <i>subinterface_num</i>) after the port-channel number.
traffic [interface port-channel <i>number</i>]	Show port-channel traffic statistics. (Optional) You can specify a particular port-channel to view the information for only that port-channel; valid port-channel numbers are 1 to 4096. You can specify a subinterface by appending a dot and the subinterface number (. <i>subinterface_num</i>) after the port-channel number.
usage	Lists current used and unused port-channel ID numbers.

Command Modes

connect fxos/

Command History

Release	Modification
1.1.1	Command added.

Usage Guidelines

This command is a subcommand of the **show** command in the **connect fxos** shell.



Note When you connect to the FXOS command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to the default prompt with (fxos) appended; see the following examples.

Examples

This example shows port-channel summary information:

```
firepower # connect fxos
firepower(fxos)# show port-channel summary
Flags:  D - Down           P - Up in port-channel (members)
        I - Individual    H - Hot-standby (LACP only)
        s - Suspended     r - Module-removed
        S - Switched      R - Routed
        U - Up (port-channel)
        M - Not in use. Min-links not met
-----
Group Port-      Type   Protocol  Member Ports
Channel
-----
1     Po1 (SU)    Eth    LACP      Eth1/3 (P)
2     Po2 (SU)    Eth    LACP      Eth1/6 (P)
48    Po48 (SU)   Eth    LACP      Eth1/1 (P)
firepower(fxos)#
```

This example shows port-channel traffic information:

```

firepower # connect fxos
firepower (fxos) # show port-channel traffic
ChanId      Port  Rx-Ucst  Tx-Ucst  Rx-Mcst  Tx-Mcst  Rx-Bcst  Tx-Bcst
-----
      1    Eth1/3    0.0%    0.0% 100.00% 100.00%    0.0%    0.0%
-----
      2    Eth1/6    0.0%    0.0% 100.00% 100.00%    0.0%    0.0%
-----
     48    Eth1/1    0.0%    0.0% 100.00% 100.00%    0.0% 100.00%
firepower (fxos) #

```

Related Commands

Command	Description
enter member-port	Enters an existing member port, or creates it if it doesn't exist.
enter port-channel	Enters an existing port-channel, or creates it if it doesn't exist.

show port-channel (scope fabric)

To display a list of current port-channels with status information, use the **show port-channel** command.

show port-channel [**detail** | **expand** | *port_channel_num*]

Syntax Description	detail	List detailed port-channel information. The expand keyword is available with this option.
	expand	List expanded port-channel information. The detail keyword is available with this option.
	<i>port_channel_num</i>	Show status information for only the specified port-channel. The detail and expand keywords are available with this option.

Command Modes scope eth-uplink/scope fabric/

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope eth-uplink/scope fabric mode. If you do not specify a port-channel number, information for all port-channels is listed.

Example

This example shows detailed information for a specific port-channel:

```
firepower /eth-uplink/fabric # show port-channel 48 detail
```

```
Port Channel:
  Port Channel Id: 48
  Name: Port-channel48
  Port Type: Cluster
  Description:
  Admin State: Enabled
  Oper State: Up
  Port Channel Mode: Active
  Port Channel Mode State: Enabled
  Auto negotiation: No
  Speed: 1 Gbps
  Duplex: Full Duplex
  Oper Speed: 1 Gbps
  Band Width (Gbps): 1
  State Reason:
  flow control policy: default
  LACP policy name: default
  Oper LACP Policy Name: org-root/lACP-default
  Inline Pair Admin State: Enabled
  Inline Pair Peer Port Name:
  Allowed Vlan: All
  Network Control Policy: default
firepower /eth-uplink/fabric #
```


Related Commands

Command	Description
create port-channel	Creates a new port-channel.
scope port-channel	Scopes into an existing port-channel where you can configure and manage the port-channel.

show power-control-policy

To display the list of power policies available on the system, use the **show power-control-policy** command.

show power-control-policy [**detail** | **expand**]

Syntax Description	detail	Lists detailed power control policies information.
	expand	(Optional) Displays expanded information for the current application instance.

Command Modes scope org

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope org.

Example

This example shows information of all the system power policies:

```

QP1 # scope org
QPD /org # show power-control-policy

Power Policy:
  Name
  ----
  default
  ssp-default

QP1 /org # show power-control-policy detail

Power Policy:
  Name: default
  Admin Priority: 5
  Oper Priority: 5
  Description:
  Policy Owner: Local

  Name: ssp-default
  Admin Priority: No Cap
  Oper Priority: No Cap
  Description: ssp default power policy
  Policy Owner: Local

QP1 /org # show power-control-policy detail expand

Power Policy:
  Name: default
  Admin Priority: 5
  Oper Priority: 5
  Description:
  Policy Owner: Local

```

```
Name: ssp-default  
Admin Priority: No Cap  
Oper Priority: No Cap  
Description: ssp default power policy  
Policy Owner: Local
```

show psu

To view information about the installed power supply units, use the **show psu** command in chassis mode.

show psu [*unit_id* | **detail** | **expand**]

Syntax Description	<i>unit_id</i>	(Optional) Enter a power-supply unit number to list information for that unit.
	detail	(Optional) Use this keyword to list detailed information about each installed power supply unit.
	expand	(Optional) Use this keyword to display expanded power-supply information.
Command Modes	scope chassis/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You can use this command without any arguments or keywords to display basic power-supply unit information.	

Example

This example shows how to view detailed power-supply unit information:

```
firepower# scope chassis
firepower /chassis # show psu detail

PSU:
  PSU: 1
  Overall Status: N/A
  Operability: N/A
  Threshold Status: N/A
  Power State: Off
  Presence: Equipped
  Thermal Status: OK
  Voltage Status: N/A
  Product Name: Cisco Firepower 9000 Series AC Power Supply
  PID: FPR9K-PS-AC
  VID: V00
  Part Number: 341-0723-01
  Vendor: Cisco Systems Inc
  Serial (SN): DTM190705G3
  HW Revision: 0
  Firmware Version: N/A
  Type: DV
  Wattage (W): 0
  Input Source: Unknown

  PSU: 2
  Overall Status: Operable
  Operability: Operable
  Threshold Status: OK
  Power State: On
  Presence: Equipped
```

```
Thermal Status: OK
Voltage Status: OK
Product Name: Cisco Firepower 9000 Series AC Power Supply
PID: FPR9K-PS-AC
VID: V00
Part Number: 341-0723-01
Vendor: Cisco Systems Inc
Serial (SN): DTM190705J8
HW Revision: 0
Firmware Version: N/A
Type: DV
Wattage (W): 2500
Input Source: 210AC 50 380DC
```

```
firepower /chassis #
```

Related Commands

Command	Description
show inventory	Shows information about the chassis and its installed modules.

show psu-policy

To display the contents of psu policies available on the system, use the **show psu-policy** command.

show psu-policy [**detail**]

Syntax Description	detail	Lists detailed psu policies information.
Command Modes	scope org	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope org.	

Example

This example shows how to view psu policies unit information:

```
firepower# scope org
firepower /chassis # show psu-policy
```

```
PSU Policy:
  Redundancy Description
  -----
  NonRedund
```

```
QP1 /org # show psu-policy detail
```

```
PSU Policy:
  Redundancy: NonRedund
  Description:
```

show registry-repository

To display service registry information, use the **show registry-repository** command.

show registry-repository

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to view service registry information:

```
FP9300-A# show registry-repository
```

```
Service Registry:
```

```

  Name:
  ID: 1000
  IP: 0.0.0.0
  Type: Service Reg
  Version:
  Capability: Unspecified
FP9300-A#
```

Related Commands

Command	Description
show service-profile	Shows service profile information.

show remote-user

To display the remote user details, use the **show remote-user** command.

show remote-user

Command Modes	scope security
----------------------	----------------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines	By default, this command displays the remote user information.
-------------------------	--

Example

This example displays the remote user information:

```
firepower# scope security
firepower /ssa # show remote-user
User Name
-----
test1

firepower /security # show remote-user test1 detail
Remote User test1:
  Description:
  User Roles:
    Name: read-only
firepower /security # show remote-user detail
Remote User test1:
  Description:
  User Roles:
    Name: read-only
```


show resource

To view resource allocation for the application instance, use the **show resource** command.

show resource [**detail**]

Syntax Description	detail	Shows resource allocation in a text format instead of a table format.
Command Modes	scope ssa/scope slot/create app-instance/	
Command History	Release	Modification
	2.4(1)	Command added.
Usage Guidelines	To view available resources, enter show monitor detail .	

Example

The following is sample output from the **show resource** command.

```
firepower# scope ssa
firepower /ssa # scope slot 1
firepower /ssa/slot # scope app-instance ftd LD1
firepower /ssa/slot/app-instance # show resource

Resource:
  Allocated Core NR Allocated RAM (MB) Allocated Data Disk (MB) Allocated Binary Disk
  (MB)
  -----
                                6                29593                40960
3907
```

The following is sample output from the **show resource detail** command.

```
firepower# scope ssa
firepower /ssa # scope slot 1
firepower /ssa/slot # scope app-instance ftd LD1
firepower /ssa/slot/app-instance # show resource detail

Resource:
  Allocated Core NR: 6
  Allocated RAM (MB): 29593
  Allocated Data Disk (MB): 40960
  Allocated Binary Disk (MB): 3907
  Allocated Secondary Disk (MB): 0
```

Related Commands	Command	Description
	show monitor detail	Shows resource usage.

Command	Description
show resource-profile	Shows resource profile information.
show resource-profile user-defined	Views resource profile assignments.

show resource-profile

To show vDP resource profiles and resource profiles for use with container instances, use the **show resource-profile** command.

show resource-profile [**system** [*name*] | **user-defined** [*name*] | **vdp** [*version* [*name*]]] [**detail**]

Syntax Description	Parameter	Description
	<i>name</i>	Specifies the name of the profile.
	system	Shows only system-defined resource profiles.
	user-defined	Shows user-defined container instance profiles profiles, including the default resource profile.
	vdp	Shows system-defined vDP profiles.
	<i>version</i>	Shows vDP for a particular version.
	detail	Shows details about the resource profiles.

Command Modes scope ssa/

Command History	Release	Modification
	2.4(1)	Added the user-defined keyword.
	1.1(3)	Command added.

Usage Guidelines Specify the resource profile to use with an application instance using the **set resource-profile-name** command. You can add resource profiles for container instances using the **create resource-profile** command. vDP resource profiles are created automatically by the system. The chassis includes a default container instance resource profile called "Default-Small," which includes the minimum number of cores. You can change the definition of this profile, and even delete it if it is not in use. Note that this profile is created when the chassis reloads and no other profile exists on the system.

Example

The following is sample output from the **show resource-profile** command:

```
firepower# scope ssa
firepower /ssa # show resource-profile
Profile Name      App Name  App Version  Is In Use  Security Model  CPU Logical Core Count
RAM Size (MB)   Default Profile Profile Type Description
-----
bronze            N/A      N/A          No         all
6                0 No     User Defined low end device
DEFAULT-4110-RESOURCE
                  vdp      8.13.01.09-2 No         FPR4K-SM-12
4                16384 Yes   System
DEFAULT-RESOURCE vdp      8.13.01.09-2 No         FPR9K-SM-56, FPR9K-SM-44, FPR9K-SM-36,
```

show resource-profile

```

FPR9K-SM-24, FPR4K-SM-44, FPR4K-SM-36, FPR4K-SM-24

6          24576 Yes          System
gold      N/A          N/A          No          all
14         0 No          User Defined highest
silver    N/A          N/A          No          all
8         0 No          User Defined mid-level
Default-Small N/A      N/A          Yes          all
6         N/A No          User Defined
VDP-10-CORES vdp      8.13.01.09-2 No          FPR9K-SM-56, FPR9K-SM-44, FPR9K-SM-36,
FPR9K-SM-24, FPR4K-SM-44, FPR4K-SM-36, FPR4K-SM-24

10        40960 No          System
VDP-2-CORES vdp      8.13.01.09-2 No          all
2         8192 No          System
VDP-4-CORES vdp      8.13.01.09-2 No          all
4         16384 No         System
VDP-8-CORES vdp      8.13.01.09-2 No          FPR9K-SM-56, FPR9K-SM-44, FPR9K-SM-36,
FPR9K-SM-24, FPR4K-SM-44, FPR4K-SM-36, FPR4K-SM-24

8          32768 No          System
firepower /ssa #

```

The following is sample output from the **show resource-profile user-defined** command:

```

firepower# scope ssa
firepower /ssa # show resource-profile user-defined
Profile Name      Is In Use  CPU Logical Core Count Description
-----
bronze            No         6             low end device
gold              No         14            highest
silver            No         10            mid-level
firepower /ssa #

```

Related Commands

Command	Description
create resource-profile	Adds a container instance resource profile.
set cpu-count	Sets the number of CPUs for the resource profile.
set resource-profile-name	Assigned the resource profile to the application instance.
show monitor detail	Shows resource usage for the security module/engine slot.
show resource detail	Shows resource allocation for the application instance.

show role

To display the list of the roles and its privileges, use the **show role** command.

show role [**detail** | **name**]

Syntax Description	detail	Description
	detail	Display the list of the roles.
	name	(Optional) Displays content for the specified role.

Command Modes scope security

Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines By default, this is a subcommand of the **show** command in scope security.

Example

This example shows how to display imported certificates and how to verify the certificate status value:

```
firepower# scope security
firepower /ssa # show roleRole:
  Role Name  Priv
  -----  ---
  aaa        aaa
  admin      admin
  operations fault, operations
  read-only  read-only
```

This example shows how to display the contents of the roles in a system:

```
firepower /security # show role detail
Role:
  Role Name: aaa
  Priv: aaa

  Role Name: admin
  Priv: admin

  Role Name: operations
  Priv: fault, operations

  Role Name: read-only
  Priv: read-only
```

This example shows how to display the contents of the selected role:

```
firepower /security # show role aaa
Role:
  Role Name Priv
  -----  ---
  aaa        aaa
```

show (scope fabric)

To view information on a port channel, use the **show** command.

show

Command Modes scope eth-uplink/scope fabric a/

Command History	Release	Modification
	2.0.1	Command added.

Usage Guidelines You must create port channels before you use this command.

Example

This example shows how to view detailed information on all port channels:

```
firepower-9300# scope eth-uplink
firepower-9300 /eth-uplink # scope fabric a
firepower-9300 /eth-uplink/fabric # create port-channel 3
firepower-9300 /eth-uplink/fabric/port-channel* # show
  Port Channel:
Port Channel Id Name Port Type Admin
State Oper State State Reason
-----
-----
10 Port-channel10 Data Enabled Failed No operational members

firepower-9300 /eth-uplink/fabric/port-channel #
```

Related Commands	Command	Description
	create port-channel	Creates the port-channel.
	scope port-channel	Displays individual port-channel and port information.

show schedule infra-fw

To view a list of schedule infrastructure firmware, use the **show schedule infra-fw** command.

show schedule infra-fw [**detail**]

Syntax Description	detail	Displays detailed schedule infrastructure firmware information.
Command Modes	scope system	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope system.	

Example

This example shows how to display all the system show schedule infrastructure firmware information:

```
Firepower /fabric-interconnect # scope system
Firepower /system # show schedule infra-fw
Schedule:
  Name
  ----
  infra-fw
```

Example

This example shows how to display detailed information of all the available system show schedule infrastructure firmware:

```
Firepower # show schedule infra-fw detail
Schedule:
  Name: infra-fw
  Description: Auto created by the system for Infrastructure upgrade
```

Example

This example shows how to display detailed information of all the scheduled infrastructure firmware:

```
Firepower /system # show schedule infra-fw expand detail
Schedule:
  Name: infra-fw
  Description: Auto created by the system for Infrastructure upgrade

  One-Time Occurrence:
  Name: infra-fw
  Start Date: 2012-07-05T23:27:33.148
  Max Duration (dd hh mm ss): None
  Max Concur Tasks: Unlimited
  Max Tasks: Unlimited
```

```
Min Interval (dd hh mm ss): None  
Executed Tasks: 19
```


show security

To display password-related and FSM status-related security information, use the **show security** command.

show security [**detail** | **fsm**]

Syntax Description	detail	(Optional) Displays detailed password-related security information.
	fsm status	(Optional) Displays finite state machine status information. The status keyword is required.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to display expanded information for security mode:

```
FP9300-A# show security detail
```

```
security mode:
  Password Strength Check: No
  Minimum Password Length: 8
  Current Task:
FP9300-A#
```

Related Commands	Command	Description
	scope security	Enters security mode.

show sel

To display the contents of the system event log (SEL) for a server, use the **show sel** command.

```
show sel server_id
```

Syntax Description	<i>server_id</i>	The server identifier, expressed as chassis-number/server-number (rack ID is not a valid option).
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to display the contents of the SEL for server 1 in chassis 1:

```
FP9300-A# show sel 1/1
show sel 1/1
1 | 12/16/2015 23:09:55 | CIMC | Event Logging Disabled DDR4_
P2_H2_ECC #0x99 | Log Area Reset/Cleared | | Asserted
2 | 12/16/2015 23:09:56 | CIMC | Processor P2_THERMTRIP_N #0x
7a | Limit Not Exceeded | Asserted
3 | 12/16/2015 23:09:57 | CIMC | Processor P1_THERMTRIP_N #0x
79 | Limit Not Exceeded | Asserted
4 | 12/16/2015 23:10:00 | CIMC | Platform alert LED_SYS_ACT #
0xa4 | LED is on | Asserted
5 | 12/16/2015 23:10:00 | CIMC | Platform alert LED_SYS_ACT #
0xa4 | LED color is green | Asserted
6 | 12/16/2015 23:10:01 | CIMC | Processor DDR4_P2_H3_TMP #0x
73 | Limit Not Exceeded | Asserted
7 | 12/16/2015 23:10:01 | CIMC | Platform alert LED_LOM_FAULT
#0xa3 | LED is off | Asserted
8 | 12/16/2015 23:10:01 | CIMC | Platform alert LED_LOM_FAULT
#0xa3 | LED color is blue | Asserted
9 | 12/16/2015 23:10:03 | CIMC | Processor DDR4_P2_H2_TMP #0x
72 | Limit Not Exceeded | Asserted
--More--
```

<--- remaining lines removed for brevity --->

```
FP9300-A#
```

Related Commands	Command	Description
	scope server	Enters server mode.

show server actual-boot-order

To display the server boot order actually used by the BIOS when the server last booted, use the **show server actual-boot-order** command.

show server actual-boot-order [*server_id* | **uuid** *dynamic_uuid*]

Syntax Description	Parameter	Description
	<i>server_id</i>	(Optional) Displays the actual boot order for a specific server, expressed as chassis-number/server-number (rack ID is not a valid option).
	uuid <i>dynamic_uuid</i>	(Optional) Displays the actual boot order for a server specified using its dynamic universally unique identifier (UUID); specified in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command displays actual boot order information for all servers.

Example

This example shows how to display the actual boot order of all servers:

```
firepower# show server actual-boot-order
Server 1/1:
  Last Update: 2017-07-19T17:43:14.982
  LocalStorageAny
    (1) Not found. Please verify presence of device and p
resence of UEFI loader on device

Server 1/2:
  Last Update: 2017-07-19T17:43:14.980
  LocalStorageAny
    (1) Not found. Please verify presence of device and p
resence of UEFI loader on device

firepower#
```

Related Commands	Command	Description
	show server boot-order	Shows server boot order.

show server adapter

To display information about network adapters in a server, use the **show server adapter** command.

show server adapter [*server_id* | **detail** | **identity** | **inventory** | **status** | **uuid** *dynamic_uuid*]

Syntax Description		
<i>server_id</i>	(Optional) Displays information about network adapters in a specific server, expressed as chassis-number/server-number (rack ID is not a valid option). The keyword detail is available with this option.	
detail	(Optional) Displays detailed information in list form.	
identity	(Optional) Displays complete identity information for each available adapter. The keywords uuid and <i>server_id</i> are available with this option.	
inventory	(Optional) Lists installed network adapters. The keywords detail , uuid and <i>server_id</i> are available with this option.	
status	(Optional) Displays overall status of installed network adapters. The keywords detail , uuid and <i>server_id</i> are available with this option.	
uuid <i>dynamic_uuid</i>	(Optional) Displays information about network adapters in a particular server, specified using its dynamic universally unique identifier (UUID); entered in the form <code>NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN</code> . The keyword detail is available with this option.	

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this commands lists the adapters available on each server. This is the same information displayed with the **inventory** keyword.

Example

This example shows how to display identity information about the installed network adapters:

```
firepower# show server adapter identity
Server 1/1:
  Burned-In UUID: 84928111-2710-4e7c-b664-91bce5b5dfbd
  Dynamic UUID: 84928111-2710-4e7c-b664-91bce5b5dfbd
  Adapter 1:
    Product Name: Cisco Firepower 9000 series MLOM Adapter
    PID: FPR-C9300-MP
    VID: V01
    Vendor: Cisco Systems Inc
    Serial: JAD190702J1
    Revision: 0

    Eth Interface:
```

```

Adapter Interface Dynamic MAC Address
-----
1 1 00:15:A5:01:01:00
1 2 00:15:A5:00:00:8E
1 3 B0:AA:77:2F:5A:4C
1 4 B0:AA:77:2F:5A:7C
1 5 B0:AA:77:2F:5A:6C
1 6 00:15:A5:00:00:CF
1 7 00:15:A5:00:00:DF
1 8 00:15:A5:00:01:0F
1 9 00:15:A5:00:00:BF
1 10 00:15:A5:00:00:6E
1 11 00:15:A5:00:01:0C
1 12 00:15:A5:00:00:EF
1 13 00:15:A5:00:01:1F
1 14 00:15:A5:00:00:1F
1 15 00:15:A5:00:00:3F

```

Ext Interface:

```

Adapter Interface Mac
-----
1 1 BA:DB:AD:BA:D6:08
1 5 BA:DB:AD:BA:D6:09

```

Adapter 2:

Product Name: Cisco Firepower 9000 series MEZZ Adapter

<--- remaining lines removed for brevity --->

firepower#

Related Commands

Command	Description
scope adapter	Enters adapter mode.

show server assoc

To view the service profile associated with each server, use the **show server assoc** command.

show server assoc [*server_id* | **uuid** *dynamic_uuid*]

Syntax Description		
<i>server_id</i>	(Optional) Displays information for a particular server, specified by chassis-number/server-number (rack ID is not a valid option).	
uuid <i>dynamic_uuid</i>	(Optional) Displays information for a particular server, specified using its dynamic universally unique identifier (UUID), entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.	

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this commands lists the service profile associations on each server.

Example

This example shows how to display service profiles associated with the system servers:

```
FP9300-A# show server assoc
Server Association Service Profile
-----
1/1      Associated   ssp-sprof-1
1/2      Associated   ssp-sprof-2

FP9300-A#
```

Related Commands	Command	Description
	show service-profile	Shows service profile information.

show server bios

To view server BIOS firmware information, use the **show server bios** command.

show server bios [*server_id* | **detail** | **uuid** *dynamic_uuid*]

Syntax Description		
<i>server_id</i>	(Optional) Displays information for a particular server, specified using chassis-number/server-number (rack ID is not a valid option). The keyword detail is available with this option.	
detail	(Optional) Displays detailed BIOS information.	
uuid <i>dynamic_uuid</i>	(Optional) Displays information for a particular server, specified with its dynamic universally unique identifier (UUID), entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN. The keyword detail is available with this option.	

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this commands lists the BIOS information for each server.

Example

This example shows how to display detailed BIOS firmware information for all servers:

```
FP9300-A# show server bios detail
Server 1/1:
  Model: FPR9K-SM-24
  Revision: 0
  Serial:
  Vendor: Cisco Systems, Inc.
  Running-Vers: FXOSSM1.1.2.1.3.031420161207
  Package-Vers: 2.0(1.135)
  Init Sequence: 0x0a:0x0a:0x0d:0x0d:0x0b:0x0b:0x01:0x01:0x
00:0x00:0x03:0x03:0x00:0x00:0x02:0x02:0x83:0x83:0xae:0xad
  Init Time: 2015-11-23T19:24:13.159

Server 1/2:
  Model: FPR9K-SM-24
  Revision: 0
  Serial:
  Vendor: Cisco Systems, Inc.
  Running-Vers: FXOSSM1.1.2.1.3.031420161207
  Package-Vers: 2.0(1.135)
  Init Sequence: 0x0a:0x0a:0x0d:0x0d:0x0b:0x0b:0x01:0x01:0x
00:0x00:0x03:0x03:0x00:0x00:0x02:0x02:0x83:0x83:0xae:0xad
  Init Time: 2015-11-23T18:56:23.148
FP9300-A#
```

Related Commands	Command	Description
	show server version	Shows current server software versions and status information.

show server boot-order

To display the boot order of a server, use the **show server boot-order** command.

show server boot-order [*server_id* | **detail** | **uuid** *dynamic_uuid*]

Syntax Description	
<i>server_id</i>	(Optional) Displays the boot order for a specific server, expressed as chassis-number/server-number (rack ID is not a valid option). The keyword detail is available with this option.
detail	(Optional) Displays detailed boot order information.
uuid <i>dynamic_uuid</i>	(Optional) Displays the boot order for a particular server, specified with its dynamic universally unique identifier (UUID); entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN. The keyword detail is available with this option.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command displays boot order information for all servers.

Example

This example shows how to display the boot order of all servers:

```
FP9300-A# show server boot-order
Boot Definition:
  Full Name: sys/chassis-1/blade-1/boot-policy
  Reboot on Update: No
  Boot Mode: Uefi

  Boot Storage:
    Order: 1

    Local Storage:
      Name: local-storage

    Boot Any Local Device:
      Order: 1
      Type: Local Any

  Full Name: sys/chassis-1/blade-2/boot-policy
  Reboot on Update: No
  Boot Mode: Uefi

  Boot Storage:
    Order: 1

    Local Storage:
      Name: local-storage
```

```
Boot Any Local Device:
Order: 1
Type: Local Any

<--- remaining lines removed for brevity --->

FP9300-A#
```

Related Commands

Command	Description
show server actual-boot-order	Shows actual server boot order.

show server cpu

To display information about the server CPUs, use the **show server cpu** command.

show server cpu [*server_id* | **detail** | **uuid** *dynamic_uuid*]

Syntax Description	server_id	(Optional) Displays the CPU information for a specific server, expressed as chassis-number/server-number (rack ID is not a valid option). The keyword detail is available with this option.
	detail	(Optional) Displays detailed CPU information in list form.
	uuid <i>dynamic_uuid</i>	(Optional) Displays the CPU information for a particular server, specified with its dynamic universally unique identifier (UUID); entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN. The keyword detail is available with this option.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command displays CPU information for all servers.

Example

This example shows how to display information about the CPUs in server 1 in chassis 1:

```
FP9300-A# show server cpu 1/1
```

```
Server 1/1:
```

```
   ID  Presence           Architecture      Socket Cores
   Speed (GHz)
-----
```

```
   1  Equipped           Xeon             CPU1      12
   2.200000
   2  Equipped           Xeon             CPU2      12
   2.200000
```

```
FP9300-A#
```

Related Commands	Command	Description
	show server inventory	Displays information about the servers installed in this device.

show server decommissioned

To display a list of decommissioned servers, use the **show server decommissioned** command.

show server decommissioned

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to display a list of decommissioned servers:

```
FP9300-A# show server decommissioned
Vendor           Model           Serial (SN) Server
-----
Cisco Systems Inc R210-2121605W QCI1442AHFX 2

FP9300-A #
```

Related Commands	Command	Description
	show server inventory	Displays information about the servers installed in this device.

show server environment

To display current server status information, use the **show server environment** command.

show server environment [*server_id* | **adapter** | **board** | **cpu** | **detail** | **expand** | **memory** | **uuid** *dynamic_uuid*]

Syntax Description	
<i>server_id</i>	(Optional) Displays status information for a particular server, specified by chassis-number/server-number (rack ID is not a valid option).
adapter	(Optional) Displays server status and status information for each adapter. The keywords board , cpu , detail , and memory are also available.
board	(Optional) Displays server status and status information for each motherboard. The keywords adapter , cpu , detail , and memory are also available.
cpu	(Optional) Displays server status, motherboard information, and status information for each CPU. The keywords adapter , board , detail , and memory are also available.
detail	(Optional) Displays detailed status information in list form.
expand	(Optional) Displays expanded status information, including adapter, motherboard, memory array, DIMM, and CPU information. The detail keyword is also available.
memory	(Optional) Lists status information for servers, motherboards, memory arrays, and DIMMs. The keywords adapter , board , cpu , and detail are also available.
uuid <i>dynamic_uuid</i>	(Optional) Displays status information for a particular server, specified with its dynamic universally unique identifier (UUID), entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command lists basic environment information for each server.

Example

This example shows how to display detailed status information for installed network adapters on all servers:

```
FP9300-A# show server environment adapter detail

Server 1/1:
  Overall Status: Ok
  Operability: Operable
  Oper Power: On
```

```

Adapter 1:
  Threshold Status: N/A
  Overall Status: Operable
  Operability: Operable
  Power State: On
  Thermal Status: N/A
  Voltage Status: N/A

Adapter 2:
  Threshold Status: N/A
  Overall Status: Operable
  Operability: Operable
  Power State: On
  Thermal Status: N/A
  Voltage Status: N/A

Server 1/2:
  Overall Status: Ok
  Operability: Operable
  Oper Power: On

Adapter 1:
  Threshold Status: N/A
  Overall Status: Operable
  Operability: Operable

<--- remaining lines removed for brevity --->

FP9300-A#

```

Related Commands

Command	Description
show system	Shows information about the systems configured on this device.

show server firmware

To display server firmware versions and status information, use the **show server firmware** command.

show server firmware [*server_id* | **adapter** | **bios** | **boardcontroller** | **cimc** | **detail** | **fxos** | **storage** | **uuid** *dynamic_uuid*]

Syntax	Description
<i>server_id</i>	(Optional) Displays firmware and status information for a particular server, specified by chassis-number/server-number (rack ID is not a valid option).
adapter	(Optional) Displays firmware version and status information for each adapter. The keyword detail is also available.
bios	(Optional) Displays server BIOS firmware versions and status. The keyword detail is also available.
boardcontroller	(Optional) Displays management-controller versions and status. The keyword detail is also available.
cimc	(Optional) Displays Cisco Integrated Management Controller versions and status. The keyword detail is also available.
detail	(Optional) Displays detailed firmware and status information in list form.
fxos	(Optional) Displays version and status information for installed Security Services Processors (SSPs) operating systems. The keyword detail is also available.
storage	(Optional) Lists version and status information for local-disk and RAID controllers. The keyword detail is also available.
uuid <i>dynamic_uuid</i>	(Optional) Displays firmware and status information for a particular server, specified using its dynamic universally unique identifier (UUID), entered in the form <code>NNNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN</code> .

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command lists basic firmware information for each server.

Example

This example shows how to display firmware and status information for local-disk and RAID controllers on all servers:

```
FP9300-A# show server firmware storage
Server 1/1:
  RAID Controller 1:
```

```

Running-Vers: 24.5.0-0021
Package-Vers:
Activate-Status: Ready

Server 1/2:
  RAID Controller 1:
    Running-Vers: 24.5.0-0021
    Package-Vers:
    Activate-Status: Ready

  Local Disk 1:
    Running-Vers: EM14
    Package-Vers:
    Activate-Status: Ready

  Local Disk 2:
    Running-Vers: EM14
    Package-Vers:
    Activate-Status: Ready

  Local Disk 1:
    Running-Vers: EM14
    Package-Vers:
    Activate-Status: Ready

  Local Disk 2:
    Running-Vers: EM14
    Package-Vers:
    Activate-Status: Ready

FP9300-A#

```

Related Commands

Command	Description
scope firmware	Enters firmware mode.

show server identity

To display identity information for a servers, adapters and interfaces, use the **show server identity** command.

show server identity [*server_id* | **uuid** *dynamic_uuid*]

Syntax Description	<i>server_id</i>	(Optional) Displays identifying information for a particular server, specified as chassis-number/server-number (rack ID is not a valid option).
	uuid <i>dynamic_uuid</i>	(Optional) Displays identifying information for a particular server, specified with its dynamic universally unique identifier (UUID), entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command lists identifying information for each server.	

Example

This example shows how to display identity information about server 2 in chassis 1:

```
FP9300-A# show server identity 1/2
Server 1/2:
  Burned-In UUID: b3fd461c-b1c7-437b-ab08-c5cb28a84132
  Dynamic UUID: b3fd461c-b1c7-437b-ab08-c5cb28a84132

  Eth Interface:

  Adapter Interface Dynamic MAC Address
  -----
    1          1 00:15:A5:01:02:00
    1          2 00:15:A5:00:00:7D
    1          3 B0:AA:77:2F:F0:CD
    1          4 B0:AA:77:2F:F0:ED
    1          5 B0:AA:77:2F:F0:DD
    1          6 00:15:A5:00:00:9D
    1          7 00:15:A5:00:00:BE
    1          8 00:15:A5:00:00:FE
    1          9 00:15:A5:00:00:8D
    1         10 00:15:A5:00:00:5D
    1         11 00:15:A5:00:00:6D
    1         12 00:15:A5:00:00:CE
    1         13 00:15:A5:00:00:DE
    1         14 00:15:A5:00:01:1E
    1         15 00:15:A5:00:00:1E
    2           1 B0:AA:77:2F:F0:FD
    2           2 B0:AA:77:2F:F0:CE
    2           3 B0:AA:77:2F:F0:EE
    2           4 00:15:A5:00:01:0E
    2           5 00:15:A5:00:00:0E
    2           6 00:15:A5:00:00:3E
```

show server identity

```

2          7 00:15:A5:00:00:EE
2          8 00:15:A5:00:00:4D
2          9 00:15:A5:00:00:AE
2         10 00:15:A5:00:00:2E
2         11 00:15:A5:00:00:5E
2         12 00:15:A5:00:00:4E
2         13 00:15:A5:00:00:7E

```

Ext Interface:

Adapter Interface Mac

```

-----
1          1 B0:AA:77:21:19:1E
1          5 B0:AA:77:21:19:1F
2          1 B0:AA:77:21:19:42
2          5 B0:AA:77:21:19:43

```

FP9300-A#

Related Commands	Command	Description
	scope server	Enters server mode.

show server inventory

To display information about the servers installed in this device, use the **show server inventory** command.

show server inventory

[*id* | *server_id* | **adapter** | **bios** | **board** | **cpu** | **detail** | **expand** | **memory** | **mgmt** | **storage** | **uuid** *dynamic_uuid*]

Syntax	Description
<i>id</i>	(Optional) Displays information for the specified server. The ID must be a number between 1 and 255.
<i>server_id</i>	(Optional) Displays inventory information for a particular server, specified using chassis-number/server-number.
adapter	(Optional) Displays server information along with information for each adapter. The keywords bios , board , cpu , detail , memory , mgmt , and storage are also available with this keyword.
bios	(Optional) Displays server information along with BIOS information. The keywords adapter , board , cpu , detail , memory , mgmt , and storage are also available with this keyword.
board	(Optional) Displays server information along with motherboard information. The keywords adapter , bios , cpu , detail , memory , mgmt , and storage are also available with this keyword.
cpu	(Optional) Displays server information along with CPU information. The keywords adapter , bios , board , detail , memory , mgmt , and storage are also available with this keyword.
detail	(Optional) Displays detailed inventory information for each server.
expand	(Optional) Displays expanded system information for each server. The keyword detail is also available.
memory	(Optional) Displays server information along with DIMM information. The keywords adapter , bios , board , cpu , detail , mgmt , and storage are also available with this keyword.
mgmt	(Optional) Displays server-management information. The keywords adapter , bios , board , cpu , detail , memory , and storage are also available with this keyword.
storage	(Optional) Displays server information along with disk and RAID information. The keywords adapter , bios , board , cpu , detail , memory , and mgmt are also available with this keyword.
uuid <i>dynamic_uuid</i>	(Optional) Displays firmware and status information for a particular server, specified with its dynamic universally unique identifier (UUID), entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.

Command Modes

Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command lists inventory information for each server.

Example

This example shows how to display basic inventory information:

```

FP9300-A# show server inventory
Server  Equipped PID Equipped VID Equipped Serial (SN) Slot S
tatus   Ackd Memory (MB) Ackd Cores
-----
1/1     FPR9K-SM-24 V01           FLM1949C6J5      Equipp
ed      262144          24
1/2     FPR9K-SM-24 V01           FLM1949C6J1      Equipp
ed      262144          24
1/3                                     Empty

FP9300-A#

```

Related Commands	Command	Description
	show server environment	Shows current server status information.

show server memory

To display information about the server dual in-line memory modules (DIMMs) installed in this device, use the **show server memory** command.

show server memory [*server_id* | **detail** | **uuid** *dynamic_uuid*]

Syntax Description		
<i>server_id</i>	(Optional) Displays memory information for a specific server, specified by chassis-number/server-number (rack ID is not a valid option).	
detail	(Optional) Displays detailed memory information for each server.	
uuid <i>dynamic_uuid</i>	(Optional) Displays memory information for a particular server, specified using its dynamic universally unique identifier (UUID), entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.	

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command lists memory information for each server.

Example

This example shows how to display detailed memory information:

```
FP9300-A# show server memory detail
Server 1/1:
  Array 1:
    CPU ID: 1
    Current Capacity (MB): 262144
    Error Correction: Undisc
    Max Capacity (MB): 1572864
    Max Devices: 24
    Populated: 16

  DIMMS:

  ID 1:
    Location: A1
    Presence: Equipped
    Overall Status: Operable
    Visibility: Yes
    Vendor: 0xAD00
    Vendor Part Number: HMA42GR7MFR4N-TF
    Vendor Serial (SN): 244BC0A6
    HW Revision: 0
    Form Factor: DIMM
    Type: Undisc
    Capacity (MB): 16384
    Clock: 2133
    Latency: 0.500000
```

```

Width: 64

ID 2:
Location: A2
Presence: Equipped
Overall Status: Operable
Visibility: Yes
Vendor: 0xAD00
Vendor Part Number: HMA42GR7MFR4N-TF
Vendor Serial (SN): 245C4A07
HW Revision: 0
Form Factor: DIMM
Type: Undisc
Capacity (MB): 16384
Clock: 2133
Latency: 0.500000
Width: 64

ID 3:
Location: A3
Presence: Missing
Overall Status: Removed
Visibility: No
Vendor:
Vendor Part Number:
Vendor Serial (SN):
HW Revision: 0
Form Factor: Undisc
Type: Undisc
Capacity (MB): Unknown
Clock: Unknown
Latency: Unknown
Width: Unknown

<--- remaining lines removed for brevity --->

FP9300-A#

```

Related Commands

Command	Description
show server identity	Shows identity information for a servers, adapters and interfaces.

show server status

To display information on the status of a server, use the **show server status** command.

show server status [*id* | *server_id* | **detail** | **uuid** *dynamic_uuid*]

Syntax Description		
<i>id</i>	(Optional) Displays information for the specified server. The ID must be a number between 1 and 255.	
<i>server_id</i>	(Optional) Displays status information for a particular server, specified as chassis-number/server-number.	
detail	(Optional) Displays detailed status information for each server.	
uuid <i>dynamic_uuid</i>	(Optional) Displays status information for a particular server, specified with its dynamic universally unique identifier (UUID), entered in the form NNNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.	

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, the command lists status information for all servers.

Example

This example shows how to display status information for a specific server using the chassis and blade IDs:

```
FP9300-A# show server status 1/1
Server      Slot Status      Overall Status      Discovery
-----
1/1         Equipped         Ok                   Complete
1/2         Equipped         Ok                   Complete
1/3         Empty

FP9300-A#
```

Related Commands	Command	Description
	show server inventory	Shows information about the servers installed in this device.

show server storage

To display server disk and RAID information, use the **show server storage** command.

show server storage [*server_id* | **detail** | **uuid** *dynamic_uuid*]

Syntax Description	<i>server_id</i>	(Optional) Displays storage information for a particular server, specified as chassis-number/server-number (rack ID is not a valid option).
	detail	(Optional) Displays detailed storage information for each server.
	uuid <i>dynamic_uuid</i>	(Optional) Displays storage information for a particular server, specified using its dynamic universally unique identifier (UUID), entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command lists storage information for each server.	

Example

This example shows how to display basic storage information:

```
firepower# show server storage
Server 1/1:
  RAID Controller 1:
    Type: SAS
    Vendor: Cisco Systems Inc
    Model: UCSB-MRAID12G
    Serial: LSV194501YW
    HW Revision: C0
    PCI Addr: 01:00.0
    Raid Support: RAID0, RAID1
    OOB Interface Supported: Yes
    Rebuild Rate: 30
    Controller Status: Optimal

  Local Disk 1:
    Vendor: SAMSUNG
    Model: MZIES800HMHP/003
    Serial: S1N2NYAG800062
    HW Rev: 0
    Operability: Operable
    Presence: Equipped
    Size (MB): 761985
    Drive State: Online
    Power State: Active
    Link Speed: 12 Gbps
    Device Type: SSD
```



```
Local Disk 2:  
Vendor: SAMSUNG  
Model: MZIES800HMHP/003  
Serial: S1N2NYAG800100  
HW Rev: 0
```

```
<--- remaining lines removed for brevity --->
```

```
firepower#
```

Related Commands	Command	Description
	show server inventory	Shows information about the servers installed in this device.

show server version

To display current server software versions and status information, use the **show server version** command.

show server version [*server_id* | **adapter** | **bios** | **boardcontroller** | **cimc** | **detail** | **fxos** | **storage** | **uuid** *dynamic_uuid*]

Syntax Description		
<i>server_id</i>	(Optional) Displays firmware and status information for a particular server, specified as chassis-number/server-number or rack ID.	
adapter	(Optional) Displays firmware version and status information for each adapter. The keyword detail is also available.	
bios	(Optional) Displays server BIOS firmware versions and status. The keyword detail is also available.	
boardcontroller	(Optional) Displays management-controller versions and status. The keyword detail is also available.	
cimc	(Optional) Displays Cisco Integrated Management Controller versions and status. The keyword detail is also available.	
detail	(Optional) Displays detailed firmware and status information in list form.	
fxos	(Optional) Displays version and status information for installed Security Services Processors (SSPs) operating systems. The keyword detail is also available.	
storage	(Optional) Lists version and status information for local-disk and RAID controllers. The keyword detail is also available.	
uuid <i>dynamic_uuid</i>	(Optional) Displays firmware and status information for a particular server, specified with its dynamic universally unique identifier (UUID), entered in the form <code>NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN</code> .	

Command Modes Any command mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command lists basic software information for each server.

Example

This example shows how to display software versions and status information for local-disk and RAID controllers on all servers:

```
FP9300-A# show server version storage
Server 1/1:
  RAID Controller 1:
```

```

Running-Vers: 24.5.0-0021
Package-Vers:
Activate-Status: Ready

Server 1/2:
  RAID Controller 1:
    Running-Vers: 24.5.0-0021
    Package-Vers:
    Activate-Status: Ready

  Local Disk 1:
    Running-Vers: EM14
    Package-Vers:
    Activate-Status: Ready

  Local Disk 2:
    Running-Vers: EM14
    Package-Vers:
    Activate-Status: Ready

  Local Disk 1:
    Running-Vers: EM14
    Package-Vers:
    Activate-Status: Ready

  Local Disk 2:
    Running-Vers: EM14
    Package-Vers:
    Activate-Status: Ready

FP9300-A#

```

Related Commands

Command	Description
show server firmware	Shows server firmware versions and status.

show service-profile

To display service profile information, use the **show service-profile** command.

show service-profile { **assoc** | **circuit** | **connectivity** | **identity** | **inventory** | **path** | **status** }

Syntax Description

assoc

Displays server and association information for each service profile. The following optional keywords are available:

- **detail**—Displays detailed association information for the service profiles.
- **org name**—Displays service-profile association information for the specified organization.
- **server** { *id* | *server_id* }—Displays service-profile association information for the specified server.
- **uuid** { **derived** | *dynamic_uuid* }—Displays service-profile association information for the specified UUID.

circuit

Displays network circuit information for the service profiles. The following optional keywords are available:

- **detail**—Displays detailed network-circuit information for the service profiles.
 - **name name**—Displays network-circuit information for the specified service profile.
 - **org org_name**—Displays service-profile circuit information for the specified organization.
 - **server** { *id* | *server_id* }—Displays service-profile circuit information for the specified server; *id* is a value between 1 and 255; *server_id* is specified as chassis-number/blade-number.
 - **uuid** { **derived** | *dynamic_uuid* }—Displays service-profile circuit information for the specified UUID, entered in the form
NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.
-

identity	<p>Displays service-profile identity (UUID pool) information. These optional keywords are available:</p> <ul style="list-style-type: none">• name <i>name</i>—Displays identity information for the specified service profile.• org <i>org_name</i>—Displays service-profile identity information for the specified organization.• server {<i>id</i> <i>server_id</i>}—Displays service-profile identity information for the specified server; <i>id</i> is a value between 1 and 255; <i>server_id</i> is specified as chassis-number/blade-number.• uuid {derived <i>dynamic_uuid</i>}—Displays service-profile identity information for the specified UUID, entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.
-----------------	--

inventory

Lists the current service-profile inventory, with type, assigned-server and association-status information. The following optional keywords are available:

- **adapter**—Displays information about the adapters associated with the service profiles.
- **bios**—Displays server and BIOS information associated with the service profiles.
- **board**—Displays server and motherboard information associated with the service profiles.
- **cpu**—Displays information about servers and CPUs associated with the service profiles.
- **detail**—Displays detailed inventory information for the service profiles.
- **expand**—Displays expanded inventory information for the service profiles.
- **memory**—Displays server and DIMM information associated with the service profiles.
- **mgmt**—Displays server configuration information associated with the service profiles.
- **name** *name*—Displays inventory information for the specified service profile.
- **org** *org_name*—Displays service-profile inventory information for the specified organization.
- **server** { *id* | *server_id* }—Displays service-profile inventory information for the specified server; *id* is a value between 1 and 255; *server_id* is specified as chassis-number/blade-number.
- **storage**—Displays server, local disk and RAID information associated with the service profiles.
- **uuid** { **derived** | *dynamic_uuid* }—Displays service-profile inventory information for the specified UUID, entered in the form

NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.

path	<p>Displays service profile network-path information, including connection type and port information. The following optional keywords are available:</p> <ul style="list-style-type: none"> • detail—Displays detailed network-path information for the service profiles. • name <i>name</i>—Displays path information for the specified service profile. • org <i>org_name</i>—Displays network-path information for the specified organization. • server { <i>id</i> <i>server_id</i> }—Displays service-profile network-path information for the specified server; <i>id</i> is a value between 1 and 255; <i>server_id</i> is specified as chassis-number/blade-number. • uuid { derived <i>dynamic_uuid</i> }—Displays network-path information for the service profile specified by the given UUID, entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN.
status	<p>Displays service-profile status, with operational status, assigned server and association status information. The following optional keywords are available:</p> <ul style="list-style-type: none"> • detail—Displays detailed status information for the service profiles. • expand—Displays expanded status information for the service profiles. • name <i>name</i>—Displays status information for the specified service profile. • org <i>org_name</i>—Displays service-profile status information for the specified organization. • power—Displays server power and status information for the service profiles. • server { <i>id</i> <i>server_id</i> }—Displays service-profile status information for the specified server; <i>id</i> is a value between 1 and 255; <i>server_id</i> is specified as chassis-number/blade-number. • thermal—Displays server status, temperature and thermal information for the service profiles. • uuid { derived <i>dynamic_uuid</i> }—Displays status information for the service profile specified by the given UUID, entered in the form NNNNNNNN-NNNN-NNNN-NNNN-NNNNNNNNNNNN. • voltage —Displays server status, power and voltage information for the service profiles.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

By default, this command lists information for each service profile.

Examples

This example shows how to display inventory information for a specific service profile:

```
FP9300-A# show service-profile inventory name ssp-sprof-1

Service Profile Name Type          Server  Assignment Association
-----
ssp-sprof-1          Instance  1/1    Assigned  Associated

FP9300-A#
```

This example shows how to display power status information for the service profiles:

```
FP9300-A# show service-profile status power
Service Profile Name: ssp-sprof-1
Type: Instance
Server: 1/1
Description: ssp service profile
Assignment: Assigned
Association: Associated
Power State: On
Op State: Ok
Oper Qualifier: N/A
Conf State: Applied
Config Qual (Deprecated): N/A
Server Config Issues: N/A
Network Config Issues: N/A
Storage Config Issues: N/A
vNIC Config Issues: N/A
iSCSI Config Issues: N/A
Current Task:
  Server 1/1:
    Overall Status: Ok
    Operability: Operable
    Oper Power: On

    Motherboard:
      Threshold Status: OK
      Overall Status: N/A
      Operability: N/A
      Oper Power: On
      Power State: Ok
      Thermal Status: OK
      Voltage Status: OK
      CMOS Battery Voltage Status: Ok
      Mother Board Power Usage Status: Ok

      Motherboard Temperature Statistics:
        Motherboard Front Temperature (C): 42.000000
        Motherboard Rear Temperature (C): 57.000000

    <--- remaining lines removed for brevity --->

FP9300-A#
```


Related Commands	Command	Description
	scope service-profile	Enters service profile mode.

show shell-session-limits

To display the list of shell sessions available on the system, use the **show shell-session-limits** command.

show shell-session-limits [**detail**]

Syntax Description	detail	Displays detailed information on shell sessions limits.
Command Modes	scope system/scope services	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope system, scope services.	

Examples

This example shows how to display information on system shell session limits:

```
Firepower /fabric-interconnect # scope system
Firepower /system #scope services
Firepower /system/services # show shell-session-limits
Shell Sessions:
  Maximum logins for single user Maximum Sessions
  -----
  32                               32
```

Example

This example shows how to display detailed information on all shell sessions:

```
Firepower /system/services # show shell-session-limits detail
Shell Sessions:
  Maximum logins for single user: 32
  Maximum Sessions: 32
```

show (slot)

To view current SSP information, use the **show** command in slot mode.

show [**app-instance** | **detail** | **event** | **expand** | **fault** | **fsm** | **heartbeat** | **heartbeat-config** | **monitor**]

Syntax	Description
app-instance	(Optional) Displays information about the module application instance. The following options are also available: <ul style="list-style-type: none"> • <i>app-name</i>—Shows information for only the specified instance. • detail—Shows detailed application instance information. The expand keyword is available with this option. • expand—Shows expanded application instance information. The detail keyword is available with this option. • fsm—Shows finite state machine information for the application instance.
detail	(Optional) Displays detailed information for the module application instance. The expand keyword is available with this option.
event	(Optional) Displays event management information for the application. The detail and expand keywords are available with this option.
expand	(Optional) Displays expanded information for the module application instance. The detail keyword is available with this option.
fault	(Optional) Displays information about faults that have occurred on the SSP. The following options are also available with this keyword: <ul style="list-style-type: none"> • <i>fault_ID</i>—Shows information for the specified fault. • cause—Shows information for only the specified cause type. • detail—Shows detailed fault information. • severity—Shows information for only the specified severity level. • suppressed—Lists suppressed faults. The cause, detail and severity keywords are available with this option.
fsm task	(Optional) Displays FSM task information for the SSP. The detail keyword is available with this option.
heartbeat	(Optional) Displays information about the last-received heartbeat. The detail and expand keywords are available with this option.
heartbeat-config	(Optional) Displays information about the current heartbeat configuration for the SSP. The detail and expand keywords are available with this option.
monitor	(Optional) Displays monitoring information for the SSP. The detail and expand keywords are available with this option.

Command Modes scope ssa/scope slot

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command displays general module configuration information.

Example

This example shows how to display general slot information:

```
firepower# scope ssa
firepower /ssa # scope slot 2
firepower /ssa/slot # show
Slot:
  Slot ID   Log Level Admin State Oper State
  -----
      2       Info      Ok         Online
firepower /ssa/slot #
```

Related Commands	Command	Description
	scope slot	Enters module configuration mode for a specific slot.

show slot

To view the list of slots like admin state and operstate available on the system, use the **show slot** command.

show [**detail** | **expand**]

Syntax Description	detail	Displays detailed slots information.
	expand	(Optional) Displays expanded information for slots.
Command Modes	scope ssa	
Command History	Release	Modification
	2.3.1	Command added.

Usage Guidelines This is a subcommand of the **show** command in scope ssa mode

Example

This example shows how to display information of all slots in the system:

```
Firepower / fabric-interconnect # scope ssa
Firepower /ssa # show slot
```

```
Slot ID      Log Level Admin State Oper State
-----
1           Info      Ok           Online
```

This example shows detailed information for all available slots.

```
Firepower /ssa # show slot detail
Slot ID: 1
Log Level: Info
Admin State: Ok
Oper State: Online
Disk Format State: Ok
Disk Format Status: 100%
Clear Log Data: Available
Error Msg:
#
```

Example

This example shows how to display detailed information of all available slots detail expand:

```
Firepower /ssa #show slot detail expand
Slot:
Slot ID: 1
Log Level: Info
Admin State: Ok
Oper State: Online
Disk Format State: Ok
Disk Format Status: 100%
```

```
Clear Log Data: Available
Error Msg:

Heartbeat:
  Last Received Time: 2012-07-04T22:43:13.030
  Heartbeat Interval: 5
  Max Number of Missed heartbeats Permitted: 3

Monitor:
  OS Version: 82.14(0.48i)
  CPU Total Load 1 min Avg: 0.360000
  CPU Total Load 5 min Avg: 0.360000
  CPU Total Load 15 min Avg: 0.360000
  Memory Total (MB): 64221
  Memory Free (MB): 54576
  Memory Used (MB): 8584
  CPU Cores Total: 24
  CPU Cores Available: 22
  Memory App Total (MB): 52957
  Memory App Available (MB): 52957
  Data Disk Total (MB): 128727
  Data Disk Available (MB): 128727
  Secondary Disk Total (MB): 0
  Secondary Disk Available (MB): 0
  Disk File System Count: 5
  Blade Uptime: up 6 days, 12:04
  Last Updated Timestamp: 2012-07-04T22:42:52.566

Disk File System:
  File System: /dev/sda1
  Mount Point: /mnt/boot
  Disk Total (MB): 7614
  Disk Free (MB): 7447
  Disk Used (MB): 167

  File System: /dev/sda2
  Mount Point: /opt/cisco/config
  Disk Total (MB): 1846
  Disk Free (MB): 1736
  Disk Used (MB): 15

  File System: /dev/sda3
  Mount Point: /opt/cisco/platform/logs
  Disk Total (MB): 4629
  Disk Free (MB): 4329
  Disk Used (MB): 62

  File System: /dev/sda5
  Mount Point: /var/data/cores
  Disk Total (MB): 46679
  Disk Free (MB): 28868
  Disk Used (MB): 15427

  File System: /dev/sda6
  Mount Point: /opt/cisco/csp
  Disk Total (MB): 128727
  Disk Free (MB): 128566
  Disk Used (MB): 161
```

show snmp (connect fxos)

To display extensive information about the current Simple Network Management Protocol (SNMP) configuration, use the **show snmp** command when connected to the FXOS command shell.

show snmp [**community** | **context** | **engineID** | **group** | **host** | **internal** | **mib** | **sessions** | **source-interface** | **trap** | **user**]

Syntax Description	Parameter	Description
	community	(Optional) Display the current SNMP community string and groups assigned access.
	context	(Optional) List the SNMP context mapping entries.
	engineID	(Optional) Display the local SNMP engine ID.
	group	(Optional) List the SNMP roles and their access permissions.
	host	(Optional) Display the currently defined SNMP destinations.
	internal	(Optional) Display a variety of SNMP internal information. Use the ? keyword to view additional options.
	mib	(Optional) Display the SNMP MIB cache or interface tables. Use the ? keyword to view additional options.
	sessions	(Optional) Display the current SNMP sessions.
	source-interface	(Optional) Display the SNMP source interface for both notification types.
	trap	(Optional) List all enabled SNMP trap types.
	user	(Optional) List all currently defined SNMPv3 users and their parameters. Use the <i>name</i> option to view information for a specific user.

Command Modes connect fxos/

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines By default, this command displays current SNMP configuration information, including community string, system contact and system location, as well as listing SNMP input and output packet types.

Example

The following example shows you how to connect to the FXOS shell and use the **show snmp** command to view current SNMP information:

```
firepower # connect fxos
firepower(fxos) # show snmp
Community          Group / Access      context  acl_filter
```

show snmp (connect fxos)

```

-----
SNMPcommunity      network-operator
sys contact: R_Admin
sys location:

0 SNMP packets input
  0 Bad SNMP versions
  0 Unknown community name
  0 Illegal operation for community name supplied
  0 Encoding errors
  0 Number of requested variables
  0 Number of altered variables
  0 Get-request PDUs
  0 Get-next PDUs
  0 Set-request PDUs
398 SNMP packets output
  0 Too big errors
  0 No such name errors
  0 Bad values errors
  0 General errors
  0 In No such name PDU
  0 In Bad vlaue PDU
  0 In Read only PDU
  0 In General errors
  0 In Get Responses
  0 Unknown Context name
  398 Out Traps PDU
  0 Out Get Requests
  0 Out Get Next Requests
  0 Out Set Requests
  0 Out Get Responses
  0 Silent Drops

```

 SNMP USERS

User	Auth	Priv(enforce)	Groups
test1	sha	no	network-operator
snmp-user1	sha	no	network-operator
snmp-user2	sha	no	network-operator

 NOTIFICATION TARGET USERS (configured for sending V3 Inform)

User	Auth	Priv
-----	-----	-----

SNMP Tcp Authentication Flag : Enabled.

 Port Monitor : unset

Policy Name : default


```
Admin Status: Not Active
Oper Status: Not Active
Port type   : All Ports
```

```
-----
Counter          Threshold Interval Rising Threshold event Falling Threshold event
  In Use
-----
-----
Link Loss        Delta      60      5          4      1          4
  Yes
Sync Loss        Delta      60      5          4      1          4
  Yes
Invalid Words    Delta      60      5          4      1          4
  Yes
Invalid CRC's    Delta      60      1          4      0          4
  Yes
RX Performance   Delta      60      5          4      1          4
  Yes
LR RX            Delta      60     200         4     10         4
  Yes
LR TX            Delta      60      5          4      1          4
  Yes
Timeout Discards Delta      60      5          4      1          4
  Yes
Credit Loss Reco Delta      60     200         4     10         4
  Yes
TX Credit Not Available Delta    1      1          4      0          4
  Yes
RX Datarate      Delta      1      10         4      0          4
  Yes
TX Datarate      Delta      60     80         4     20         4
  Yes
ASIC Error Pkt from Port Delta    60     80         4     20         4
  Yes
-----
```

```
SNMP protocol : Enabled
```

```
-----
Context          [Protocol instance, VRF, Topology]
                 [vlan, MST]
-----
```

```
1                ,
                 ,
                 ,
                 1,
```

```
-----
101              ,
                 ,
                 ,
                 101,
```

```
-----
102              ,
                 ,
                 ,
                 102,
```

```
-----
<--- remaining lines removed for brevity --->
```

```
firepower(fxos) #
```

Related Commands	Command	Description
	enable snmp	Enables SNMP.
	set snmp	Sets SNMP configuration parameters.
	show snmp (monitoring)	Shows basic information about the current SNMP configuration.

show snmp (monitoring)

To display basic information about the current Simple Network Management Protocol (SNMP) configuration, use the **show snmp** command.

show snmp [**community**]

Syntax Description	community	(Optional) Displays the current SNMP community name. Note This keyword has been deprecated, since for security, only an empty field is displayed.
Command Modes	scope monitoring/	
Command History	Release	Modification
	1.1.1	Command added.
Usage Guidelines	By default, this command displays current SNMP configuration information, including admin state, system contact and system location.	

Example

The following example shows you how to scope into monitoring mode and use the **show snmp** command to view current SNMP configuration:

```
firepower# scope monitoring
firepower /monitoring # show snmp
Name: snmp
  Admin State: Enabled
  Port: 161
  Is Community Set: Yes
  Sys Contact: R_Admin
  Sys Location:
firepower /monitoring #
```

Related Commands	Command	Description
	enable snmp	Enables SNMP.
	set snmp	Sets SNMP configuration parameters.
	show snmp (connect fxos)	Shows extensive information about the current SNMP configuration.

show snmp-trap

To display information about currently defined SNMP traps, enter the **show snmp-trap** command.

show snmp-trap [**detail** | *trap_ID*]

Syntax Description	detail	(Optional) Use this keyword to view detailed information about the SNMP trap(s).
	<i>trap_ID</i>	(Optional) Specify the host name or IP address of a particular SNMP trap destination to view information about that trap. (This option is available only in scope monitoring/ mode.) The detail keyword is available with this option.

Command Modes	scope monitoring/ scope monitoring/snmp-trap/
---------------	--

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines	In scope monitoring/ mode, by default, this command displays a current list of SNMP traps. In scope monitoring/snmp-trap/ mode, this command displays information about the current trap.
------------------	--

Example

The following example shows you how to scope into monitoring mode and use the **show snmp-trap** command to view a list of current SNMP traps:

```
firepower# scope monitoring
firepower /monitoring # show snmp-trap

SNMP Trap:
  SNMP Trap          Port    Community  Version V3 Privilege Notification Type
  -----
  trap1_informs     162    ****      V2c     Noauth   Informs
  192.168.10.100    162    ****      V3      Noauth   Traps
firepower /monitoring #
```

Related Commands	Command	Description
	create snmp-trap	Creates a new SNMP trap.
	enable snmp	Enables SNMP.
	set (snmp-trap)	Specifies parameters for an existing SNMP trap.
	show snmp (monitoring)	Shows basic information about the current SNMP configuration.

Command	Description
show snmp (connect fxos)	Shows extensive information about the current SNMP configuration.

show snmp-user

To display information about currently defined SNMPv3 users, enter the **show snmp** command.

show snmp-user [**detail** | **fault** | *user_name*]

Syntax Description	detail	(Optional) Use this keyword to view detailed information about the SNMPv3 user(s).
	fault	(Optional) Use this keyword to view fault information for this user. The following optional keywords are available with this option: <ul style="list-style-type: none"> • cause – Use this keyword to filter fault information by cause. • detail – Use this keyword to view detailed fault information. • severity – Use this keyword to filter fault information by severity. • suppressed – Use this keyword to view only suppressed faults. • <i>fault_ID</i> – You can specify a particular fault by entering its ID number; valid values are 0 to 18446744073709551615. <p>Note This option is available only in scope monitoring/snmp-user/ mode.</p>
	<i>user_name</i>	(Optional) Specify the name of a particular SNMP user to view information about that user. (This option is available only in scope monitoring/ mode.) The detail keyword is available with this option.

Command Modes
scope monitoring/ scope monitoring/snmp-user/

Command History	Release	Modification
	1.1.1	Command added.

Usage Guidelines
In scope monitoring/ mode, by default, this command displays a current list of SNMPv3 users with authentication type for each.
In scope monitoring/snmp-trap/ mode, this command displays information about the current SNMPv3 user.

Example

The following example shows you how to scope into monitoring mode and use the **show snmp-user** command to view a list of current SNMPv3 users, as well as detailed configuration information for a specific user:

```
firepower# scope monitoring
firepower /monitoring # show snmp-user

SNMPv3 User:
```

```

Name                               Authentication type
-----
snmp-user1                         Sha
testuser                           Sha
snmp-user2                         Sha
firepower /monitoring # show snmp-user snmp-user1 detail

```

```

SNMPv3 User:
  Name: snmp-user1
  Authentication type: Sha
  Password: ****
  Privacy password: ****
  Use AES-128: Yes
firepower /monitoring #

```

Related Commands

Command	Description
create snmp-user	Creates a new SNMPv3 user.
enable snmp	Enables SNMP.
set (snmp-user)	Specifies parameters for an existing SNMPv3 user.
show snmp (monitoring)	Shows basic information about the current SNMP configuration.
show snmp (connect fxos)	Shows extensive information about the current SNMP configuration.

show ssh-server

To display information about the SSH server, use the **show ssh-server** command.

show server [**host-key**]

Syntax Description	host-key	(Optional) Displays SSH server host key size, and whether the key has been deleted.
Command Modes	Services mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command to view SSH connection and authentication information.	

Example

This example shows how to display SSH server information:

```

FP9300-A # scope system
FP9300-A /system # scope services
FP9300-A /system/services # show ssh-server
Name: ssh
  Admin State: Enabled
  Port: 22
  Kex algorithm: diffie-hellman-group14-sha1
  Mac algorithm: hmac-sha1,hmac-sha2-256,hmac-sha2-512
  Encrypt algorithm:
aes128-ctr,aes192-ctr,aes256-ctr,3des-cbc,aes128-cbc,aes192-cbc,aes256-cbc
  Authentication algorithm: Rsa
  Host Key Size: 2048
  Rekey Limit Volume: None Time: None
FP9300-A /system/services #

```

Command	Description
create ssh-server	Creates a new SSH server host key.
delete ssh-server	Deletes the existing SSH server host key.
set ssh-server	Sets the SSH host key size.

show stats

To display IPsec statistics, use the **show stats** command.

show stats [**detail** | **listauthor** | **listcert** | **listconn** | **listsa** | **status**]

Syntax Description	detail	(Optional) Shows additional IPsec statistics.
	listauthor	(Optional) Shows all available trustpoints. The detail keyword is available with this option.
	listcert	(Optional) Shows all available certifications. The detail keyword is available with this option.
	listconn	(Optional) Shows the operational state of all connections. The detail keyword is available with this option.
	listsa	(Optional) Shows the operational state of all IPsec security associations (SAs). The detail keyword is available with this option.
	status	(Optional) Shows overall IPsec status. The detail keyword is available with this option.

Command Modes IPsec mode

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to display IPsec statistics.

Example

This example shows how to display IPsec connection information for a specified connection:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # show stats
```

```
Ipssec Stats:
  Stats Type: Status
  Stats Data: Status of IKE charon daemon (strongSwan 5.3.5, Linux 3.14.39ltsi, i686):
    uptime: 11 days, since Jun 29 17:36:39 2018
    malloc: sbrk 2289664, mmap 0, used 199808, free 2089856
    worker threads: 11 of 16 idle, 5/0/0/0 working, job queue: 0/0/0/0, scheduled: 0
    loaded plugins: charon aes des rc2 sha1 sha2 md5 random nonce x509 revocation constraints
    pubkey pkcs1 pkcs7 pkcs8 pkcs12 pgp dnskey sshkey pem openssl fips-prf xcbc hmac files
    attr kernel-netlink resolve socket-default stroke vici updown xauth-generic
Listening IP addresses:
  10.122.150.220
  192.15.1.250
  192.15.1.251
  192.3.0.254
```

```
192.5.254.1
192.5.1.254
192.7.254.1
192.9.0.1
192.128.254.1
203.0.113.126
192.16.254.1
Connections:
Security Associations (0 up, 0 connecting):
  none

      Time Stamp: 2018-07-11T17:20:17.542
FP9300-A /security/ipsec #
```

Related Commands

Command	Description
show connection	Shows configuration information for the current IPSec connections.
show ipsec-log	Shows IPSec connection logs.

show storage

To display all the partitions and their current disk usage in a disk, use the **show storage** command.

show storage

Command Modes scope fabric-interconnect

Command History	Release	Modification
	2.11.1	Command added.

Usage Guidelines Use this command to display the disk usage.

Example

Following example displays the storage on a local flash drive of fabric interconnect:

```
firepower /fabric-interconnect # show storage
Storage on local flash drive of fabric interconnect:
  Partition          Size (MBytes)  Used Percentage
  -----
  bootflash          106540         43
  callhome            128            Empty
  dev-shm             512            59
  isan                4000           36
  mnt-cfg-0           73             3
  mnt-cfg-1           73             3
  mnt-plog            47             3
  mnt-pss             73             41
```

show subinterface

To show information about the subinterface, use the **show subinterface** command.

show subinterface [**detail**]

Syntax Description	detail	Shows information for each subinterface in a non-table format.
Command Modes	scope eth-uplink/scope fabric a/scope interface/ scope eth-uplink/scope fabric a/create port-channel/	
Command History	Release	Modification
	2.4(1)	Command added.
Usage Guidelines	Subinterfaces are supported for container instances only.	

Example

The following is sample output from the **show subinterface** command.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # enter interface ethernet1/8
firepower /eth-uplink/fabric/interface # show subinterface

Sub Interface:
  Sub-If Id  Sub-Interface Name  VLAN      Port Type
  -----
           100 Ethernet1/5.100      100      Data
```

The following is sample output from the **show subinterface detail** command.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # enter interface ethernet1/8
firepower /eth-uplink/fabric/interface # show subinterface detail

Sub Interface:
  Sub-If Id: 100
  Sub-Interface Name: Ethernet1/5.100
  VLAN: 100
  Port Type: Data
```

Related Commands	Command	Description
	create port-channel	Creates an EtherChannel (port channel).
	create subinterface	Adds a subinterface.

Command	Description
scope interface	Enters the physical interface object.
set port-type	Sets the interface type.

show sup

To view chassis supervisor version information, use the **show sup version** command.

show sup version [**detail**]

Syntax Description	detail	(Optional) Displays detailed supervisor version information.
Command Modes	Chassis mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this commands lists the supervisor ROMMON and FPGA version information.	

Example

This example shows how to display detailed supervisor firmware information for all servers:

```
FP9300-A /chassis # show sup version detail
SUP FIRMWARE:
  ROMMON:
    Running-Vers: 1.0.11
    Package-Vers: 1.0.11
    Activate-Status: Ready
    Upgrade Status: SUCCESS
  FPGA:
    Running-Vers: 1.05
    Package-Vers: 1.0.11
    Activate-Status: Ready

FP9300-A /chassis #
```

Related Commands	Command	Description
	show version	Shows current software versions and status information for each server on the chassis.

show system

To display information about the systems configured on this device, use the **show system** command.

show system [**detail** | **firmware** | **version**]

Syntax Description	detail	(Optional) Displays detailed system information.
	firmware	(Optional) Displays system firmware-version and status information. The optional keywords detail and expand are also available.
	version	(Optional) Displays system version and status information. The optional keywords detail and expand are also available.
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command displays name, mode and IP addresses for each configured system.	

Example

This example shows how to display expanded system version information:

```

FP9300-A# show system version expand
FPRM:
  Running-Vers: 4.2(1.62)
  Package-Vers: 2.2(1.63)
  Activate-Status: Ready

Catalog:
  Running-Vers: 4.2(1.62)T
  Package-Vers: 2.2(1.63)
  Activate-Status: Ready

Management Extension:
  Running-Vers: 2.2(1.8)
  Package-Vers: 2.2(1.63)
  Activate-Status: Ready

Fabric Interconnect A:
  Running-Kern-Vers: 5.0(3)N2(4.21.62)
  Running-Sys-Vers: 5.0(3)N2(4.21.62)
  Package-Vers: 2.2(1.63)
  Startup-Kern-Vers: 5.0(3)N2(4.21.62)
  Startup-Sys-Vers: 5.0(3)N2(4.21.62)
  Act-Kern-Status: Ready
  Act-Sys-Status: Ready
  Bootloader-Vers:

Chassis 1:

```

```
Server 1:
  CIMC:
    Running-Vers: 3.1(20a)
    Package-Vers: 2.2(1.63)
    Update-Status: Ready
    Activate-Status: Ready

  Adapter 1:
    Running-Vers: 4.0(1.57)
    Package-Vers: 2.2(1.63)
    Update-Status: Ready
    Activate-Status: Ready
  Adapter 2:
    Running-Vers: 4.0(1.57)

<--- remaining lines removed for brevity --->

FP9300-A#
```

Related Commands	Command	Description
	scope system	Enters system mode.

show system reset-reason

To display information about the system reset reason, use the **show system reset-reason** command.

show system reset-reason

Syntax Description	reset-reason	(Optional) Displays detailed reset reason information.
Command Modes	connect fxos	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command displays the reset reason information.	

Example

This example shows how to display reset reason information for a module:

```
firepower#
firepower# connect fxos
...
firepower(fxos)# show system reset-reason
----- reset reason for Supervisor-module 1 (from Supervisor in slot 1) ---
1) At 826701 usecs after Sun Jul 11 09:14:12 2021
   Reason: Reset Requested by CLI command reload <=====Manual reboot requested from
   CLI.
   Service:
   Version: 5.0(3)N2(4.81)

2) At 865598 usecs after Wed Apr 21 17:10:58 2021
   Reason: Reset Requested by CLI command reload
   Service:
   Version: 5.0(3)N2(4.61)
```

show stats system-stats

To display the information of system stats available on the system, use the **show stats system-stats** command.

show stats system-stats detail

Syntax Description	detail	(Optional) Shows additional IPSec statistics.
Command Modes	scope fabric-interconnect a	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope fabric-interconnect a.	

Example

This example shows how to display system stats information:

```
FP9300-A # scope fabric-interconnect a
FP9300-A /fabric-interconnect # show stats system-stats
System Stats:
  Time Collected: 2012-07-15T06:55:00.187
  Monitored Object: sys/switch-A
  Suspect: No
  Load: 3.800000
  Mem Available (MB): 11762
  Mem Cached (MB): 2008
  Thresholded: 0
```

This example shows detailed information of stats history system stats:

```
QP1 /fabric-interconnect # show stats history system-status
System Stats:
  Time Collected: 2012-07-15T06:54:00.249
  Monitored Object: sys/switch A/sysstats
  Suspect: No
  Load: 3.930000
  Mem Available (MB): 11814
  Mem Cached (MB): 2008
  Thresholder: 0

  Time Collected: 2012-07-15T06:46:30.804
  Monitored Object: sys/switch A/sysstats
  Suspect: No
  Load: 3.480000
  Mem Available (MB): 11814
  Mem Cached (MB): 2009
  Thresholded: 0

  Time Collected: 2012-07-15T06:39:00.173
  Monitored Object: sys/switch-A/sysstats
  Suspect: No
  Load: 3.780000
  Mem Available (MB): 11758
  Mem Cached (MB): 2009
```

This example shows how to display detailed information of stats history system stats detail:

```
FP9300-A /fabric-interconnect # show stats history system-status detail
```

```
System Stats:
  Time Collected: 2012-07-15T06:54:00.249
  Monitored Object: sys/switch-A/sysstats
  Suspect: No
  Load: 3.930000
  Load Min: 3.380000
  Load Max: 5.300000
  Load Avg: 4.320666
  Mem Available (MB): 11814
  Mem Available Min (MB): 11796
  Mem Available Max (MB): 11815
  Mem Available Avg (MB): 11804
  Mem Cached (MB): 2008
  Mem Cached Min (MB): 2008
  Mem Cached Max (MB): 2010
  Mem Cached Avg (MB): 2008
  Thresholded: 0

  Time Collected: 2012-07-15T06:46:30.804
  Monitored Object: sys/switch-A/sysstats
  Suspect: No
  Load: 3.480000
  Load Min: 3.480000
```

show system uptime (connect fxos)

To display information about the system uptime for each configured system, use the **show system uptime** command.

show system uptime

Syntax Description	system uptime	Displays system uptime information.
Command Modes	connect fxos	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	By default, this command displays system uptime for the configured system.	

Example

This example shows how to display system uptime information:

```
firepower#
firepower# connect fxos
...
firepower(fxos)# show system uptime
System start time:      Sun Jul 11 09:19:55 2021
System uptime:         89 days, 23 hours, 20 minutes, 21 seconds
Kernel uptime:        89 days, 23 hours, 22 minutes, 59 seconds
Active supervisor uptime: 89 days, 23 hours, 20 minutes, 21 seconds
```

show tech-support

To view or save troubleshooting information about the device hardware and software, use the **show tech-support** command.

```
(module)# show tech-support
```

```
(local-mgmt)# show tech-support { chassis chassis_ID | fprm | module module_ID [
app-instance application_name application_ID | brief | detail ] }
```

Syntax Description

	In module mode, this command has no arguments or keywords.
chassis <i>chassis_ID</i> [brief detail]	<p>Collects chassis-related troubleshooting data; the <i>chassis_ID</i> is always 1.</p> <p>The following options are available:</p> <ul style="list-style-type: none"> • brief – Use this keyword to list a condensed set of troubleshooting information on your terminal. <p>You can use the > and >> operators to save this information to a file; see Save Show Command Output, on page 17 for more information.</p> <ul style="list-style-type: none"> • detail – Use this keyword to save detailed troubleshooting information to a file in the <code>techsupport</code> directory on the device. <p>If you do not enter either keyword, the brief output is displayed on your terminal screen.</p>
fprm [brief detail]	The fprm option was deprecated in version 2.8(1) and can no longer be used.
module <i>module_ID</i> [app-instance <i>application_name</i> <i>application_ID</i> brief detail]	<p>Collects troubleshooting data for the module specified by <i>module_ID</i>. The following options are available:</p> <ul style="list-style-type: none"> • app-instance – In a multiple-instance environment, you can use this keyword to list information for the application instance specified by <i>application_name</i> and <i>application_ID</i>. • brief – Use this keyword to list a condensed set of troubleshooting information on your terminal. • detail – Use this keyword to list detailed troubleshooting information on your terminal. <p>You can use the > and >> operators to save this information to a file; see Save Show Command Output, on page 17 for more information.</p> <p>If you do not enter a keyword, the brief output is displayed on your terminal screen.</p>

Command Modes

```
connect local-mgmt
connect module
```

Command History	Release	Modification
	1.1(1)	Command added.
	2.4(1)	The app-instance keyword was added to the module option.
	2.8(1)	The fprm option was deprecated in version 2.8(1) and can no longer be used. Use show tech-support {chassis} command instead.

Usage Guidelines

Use this command to view or save a collection of log messages, configuration information, and command output for transmission to Cisco Technical Assistance; this data is used to determine the status of the device hardware and software.

Use the **copy** command in local management mode to transfer a troubleshooting file to another device or location.



Note In module mode, this command simply lists the collected troubleshooting information for the specified module on your terminal

Examples

This example shows how to generate a file of detailed chassis-related troubleshooting information:

```
firepower # connect local-mgmt
Firepower(local-mgmt)# show tech-support chassis 1 detail
```

```
The show tech support file will be located at
/workspace/techsupport/20191105041703_firepower-9300_BC1_all.tar
```

```
Initiating tech-support information task on FABRIC A ...
```

```
Initiating tech-support information task on Chassis 1 Fabric Extender 1 ...
Initiating tech-support information task on Chassis 1 CIMC 1 ...
Initiating tech-support information task on Adaptor 1 on Chassis/Server 1/1 ...
Initiating tech-support information task on Adaptor 2 on Chassis/Server 1/1 ...
Initiating tech-support information task on Chassis 1 CIMC 2 ...
Initiating tech-support information task on Adaptor 1 on Chassis/Server 1/2 ...
Initiating tech-support information task on Adaptor 2 on Chassis/Server 1/2 ...
Completed initiating tech-support subsystem tasks (Total: 8)
Waiting (Timeout: 900 Elapsed: 30) for completion of subsystem tasks (1/8).
Waiting (Timeout: 900 Elapsed: 50) for completion of subsystem tasks (2/8).
Waiting (Timeout: 900 Elapsed: 70) for completion of subsystem tasks (5/8).
Waiting (Timeout: 900 Elapsed: 90) for completion of subsystem tasks (6/8).
Waiting (Timeout: 900 Elapsed: 110) for completion of subsystem tasks (6/8).
Waiting (Timeout: 900 Elapsed: 130) for completion of subsystem tasks (6/8).
Waiting (Timeout: 900 Elapsed: 150) for completion of subsystem tasks (6/8).
Waiting (Timeout: 900 Elapsed: 170) for completion of subsystem tasks (6/8).
Waiting (Timeout: 900 Elapsed: 190) for completion of subsystem tasks (6/8).
Waiting (Timeout: 900 Elapsed: 210) for completion of subsystem tasks (6/8).
Waiting (Timeout: 900 Elapsed: 230) for completion of subsystem tasks (7/8).
--More--
```

```
The detailed tech-support information is located at workspace:///techsupport/201--More--
91105041703_firepower-9300_BC1_all.tar
```

This example shows how to save a file of troubleshooting information for the Security Module, and confirm its location on the device:

```
firepower # connect local-mgmt
firepower(local-mgmt)# show tech-support module 1 detail
The show tech support file will be located at
/workspace/techsupport/20191107082242_firepower-9300_BC_CIMC1.tar

Try connecting to Firepower-module 1...
Last login: Wed Oct 23 09:03:56 CDT 2019 from 127.128.254.1 on pts/0
Cisco Firepower Extensible Operating System (FX-OS) Software. TAC support:
http://www.cisco.com/tac Copyright (c) 2009-2016, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained in this software are owned by other third parties
and used and distributed under license. Certain components of this software are licensed
under the 'GNU General Public License, version 3' provided with ABSOLUTELY NO WARRANTY under
the terms of 'GNU General Public License, Version 3', available here:
http://www.gnu.org/licenses/gpl.html. See User Manual ('Licensing') for details. Certain
components of this software are licensed under the 'GNU General Public License, version
2' provided with ABSOLUTELY NO WARRANTY under the terms of 'GNU General Public License,
version 2', available here: http://www.gnu.org/licenses/old-licenses/gpl-2.0.html. See User
Manual ('Licensing') for details. Certain components of this software are licensed under
the 'GNU LESSER GENERAL PUBLIC LICENSE, version 3' provided with ABSOLUTELY NO WARRANTY
under the terms of 'GNU LESSER GENERAL PUBLIC LICENSE' Version 3, available here:
http://www.gnu.org/licenses/lgpl.html. See User Manual ('Licensing') for details. Certain
components of this software are licensed under the 'GNU Lesser General Public License,
version 2.1' provided with ABSOLUTELY NO WARRANTY under the terms of 'GNU Lesser General
Public License, version 2', available here:
http://www.gnu.org/licenses/old-licenses/lgpl-2.1.html. See User Manual ('Licensing') for
details. Certain components of this software are licensed under the 'GNU Library General
Public License, version 2' provided with ABSOLUTELY NO WARRANTY under the terms of 'GNU
Library General Public License, version 2', available here:
http://www.gnu.org/licenses/old-licenses/lgpl-2.0.html. See User Manual ('Licensing') for
details.
```

```

Cisco Security Services Platform
Type ? for list of commands
Firepower-module1>support send_diag_archive
Creating default Archive...
Archive created in 11 secs.
Starting to transfer Firepower-Module1_11_07_2019_08_22_44.tar of 5109760 bytes.
Transferred Firepower-Module1_11_07_2019_08_22_44.tar successfully to MIO at
/bladelog/blade-1/ in 1 sec(s).
Firepower-module1>support send_allcontainerlogs size 3063
Upload container logs triggered from Supervisor Module, Starting upload ....
No container instances running, skipping container logs
```

```
The detailed tech-support information is located at
workspace:/techsupport/Firepower-Module1_11_07_2019_08_22_44.tar
```

Running **show tech-support module 1|2|3 [detail]** may timeout when the blade is in offline or other error states. In such scenarios, please follow the below steps to collect the module tech-support (detail):

1. Connect to the intended blade by connect module 1|2|3 console|telnet

```
FPR4110# connect module 1 console
Telnet escape character is '~'.
Trying 127.5.1.1...
Connected to 127.5.1.1.
Escape character is '~'.

CISCO Serial Over LAN:
Close Network Connection to Exit
```

2. Generate the Diag Bundle

```
Firepower-module1>support diagnostic

===== Diagnostic =====

  1. Create default diagnostic archive
  2. Manually create diagnostic archive
  3. Exit

Please enter your choice: 1

Creating Default archive

ASA running ...

Done with extracting tech support information from ASA. Log file saved as
asa_tech_support.log

1. Added file: cspCfg_cisco-asa.9.16.1__asa_001_JMX2309L046K6AY356.xml
2. Added file: tech_support_report.txt
3. Added file: ssp-cardmgmt.log
4. Added file: ssp_ntp.log.2
5. Added file: ssp_tz.log
6. Added file: ssp_ntp.log.1
7. Added file: ssp-pm.log
```

3. Copy the diag bundle to Supervisor(MIO)

```
Firepower-module1>support fileupload
Please choose from following:
=====
1. Archive Files
2. View selected files
3. Start upload and Exit
4. View transfer Status
Please enter your choice [x] to Exit:1
-----files-----
2021-09-29 17:24:36.571927 | 4065280      | Firepower-Module1_09_29_2021_17_23_17.tar
2021-09-29 17:27:34.094890 | 4065280      | Firepower-Module1_09_29_2021_17_26_15.tar
2021-09-29 17:24:38.211954 | 10240        |
Firepower-module1_09_29_2021_17_24_38_container.tar

([s] to select files or [x] to Exit):s

Type the partial name of the file to add, [<] to cancel
> Firepower-Module1_09_29_2021_17_26_15.tar
Firepower-Module1_09_29_2021_17_26_15.tar
Are you sure you want to add these files? (y/n) y
=== Package Contents ===
[Added] Firepower-Module1_09_29_2021_17_26_15.tar
=====

Type the partial name of the file to add, [<] to cancel
> <
Please choose from following:
=====
1. Archive Files
2. View selected files
3. Start upload and Exit
4. View transfer Status
Please enter your choice [x] to Exit:3
Transfer of Firepower-Module1_09_29_2021_17_26_15.tar started.
Firepower-module1>support fileupload
Please choose from following:
```



```

=====
1. Archive Files
2. View selected files
3. Start upload and Exit
4. View transfer Status
Please enter your choice [x] to Exit:4
File Transfer Status:
-----
Firepower-Module1_09_29_2021_17_26_15.tar          Status: Completed.

```

4. Exit out of Module console with ~ and exit, locate the file in MIO

```

Firepower-module1>
telnet> quit
Connection closed.
FPR4110# connect local-mgmt
FPR4110(local-mgmt)# dir workspace:/bladelog/blade-1/
<>
1 4065280 Sep 29 17:30:04 2021 Firepower-Module1_09_29_2021_17_26_15.tar <---
<>

```

Related Commands

Command	Description
copy	In local management mode, makes a copy of the specified file.
dir	In local management mode, lists the contents of the current directory.

show timezone

To display the currently configured time zone, use the **show timezone** command.

show timezone

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to display the current time zone:

```
FP9300-A# show timezone
Timezone: America/Chicago
FP9300-A#
```

Related Commands

Command	Description
set timezone	Sets the time zone for the device.

show trustpoint

```

BgUrDgMCGgQUj+XTGoasjY5rw8+AatRIGCx7GS4wJRYjaHR0cDovL2xvZ28udmVy
aXNpZ224uY29tL3ZzbG9nby5naWYwHQYDVR0OBByEFH/TzafC3ey78DAJ80M5+gKv
MzEzMA0GCSqGSIB3DQEBBQUAA4IBAQCTJEowX2LP2BqYLz3q3JktvXf2pXki0Oze
p6B4Eq1iDkVwZMXn12YtmAl+X6/WzChl8gGqCBpH3vn5fJJaCGkgDdk+bW48DW7Y
5gaRQBi5+Mht39tBquCWIMnZBU4gcmU7qKEKQsTb47bDN01Atukix1E0kF6BW1K
WE9gyn6CagsCqiUXObXbf+eEzSqVir2G3l6BFoMtEMze/aicKm0oHw0LxOXnGiYZ
4fQRbxCl1fznQgUy286dUV4otp6F01vvpX1FQHK0tw5rDgb7MzVICbidJ4vEZV8N
hnacRHr21Vz2XTIIM6RUthg/aFzyQkqFOFSDX9HoLPKsEdao7WNq
-----END CERTIFICATE-----
Valid

FP9300-A /security #

```

Command	Description
set certchain	Enters a list (or chain) of certificates for a trustpoint.
set trustpoint	Sets the certificate trustpoint for a keyring.

show user-sessions

To display information about the local and the remote user sessions, use the **show user-sessions** command.

show user-sessions

Command Modes scope security

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines By default, this command displays user sessions information.

Example

This example shows how to display the local and remote user sessions information:

```
firepower# scope security
firepower /security # show user-sessions local
Session Id      User          Host          Login Time
-----
pts_0_1_24360*  admin        192.0.2.1    2021-10-11T20:46:16.000
```

```
firepower# show user-sessions local detail
Session Id pts_0_1_24360*:
  Fabric ID: A
  Term: pts/0
  User: admin
  Host: 192.0.2.1
  Pid: 24360
  Login Time: 2021-10-11T20:46:16.000
  Refresh Period (in secs): 0
  Session Timeout (in secs) for web, ssh, telnet sessions: 0
  Absolute Session Timeout (in secs) for web, ssh, telnet sessions: 0
```

```
firepower /security # show user-sessions remote

Session Id      User          Host          Login Time
-----
pts_1_1_9578    test1        192.0.2.2    2021-10-11T21:39:52.000
```

```
firepower /security # show user-sessions remote detail
Session Id pts_1_1_9578:
  Fabric ID: A
  Term: pts/1
  User: test1
  Host: 192.0.2.2
  Pid: 9578
  Login Time: 2021-10-11T21:39:52.000
  Refresh Period (in secs): 0
  Session Timeout (in secs) for web, ssh, telnet sessions: 0
  Absolute Session Timeout (in secs) for web, ssh, telnet sessions: 0
```

show validate-task

To check the status of a manually initiated image verification, use the **show validate-task** command.

show validate-task [**detail** | **fsm** | *pack_version*]

Syntax Description	detail	(Optional) Displays detailed package status information for all available platform packages.
	fsm status	(Optional) Lists the finite state machine validation status. The expand keyword and the <i>pack_version</i> variable are also available.
	pack_version	(Optional) Displays validation information for the specified package. The detail keyword is also available with this option.
Command Modes	Firmware mode	
Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines If you do not include a *pack_version*, the **show validate-task** command lists information for every firmware image on the appliance.

You can use this command or the **show validation package** command to determine the desired package version number.

Example

This example shows how to show validation history for a specific firmware package:

```
FP9300-A# scope firmware
FP9300-A /firmware # show validate-task 2.3(1.51)

Validate task:
  Pack Name: fxos-k9-bundle-infra.2.3.1.51.SPA
  Pack Version: 2.3(1.51)
  Validation Time Stamp: Never
  Validation State: None
  Overall Status String:

  Pack Name: fxos-k9-bundle-server.2.3.1.51.SPA
  Pack Version: 2.3(1.51)
  Validation Time Stamp: Never
  Validation State: None
  Overall Status String:

  Pack Name: fxos-k9.2.3.1.51.SPA
  Pack Version: 2.3(1.51)
  Validation Time Stamp: 2017-10-25T16:53:30.914
  Validation State: None
  Overall Status String: Ok
```

```
FP9300-A /firmware #
```

Related Commands	Command	Description
	download image	Downloads an FXOS software image to the Firepower 4100/9300 chassis.
	verify platform-pack	Verifies the integrity of a downloaded FXOS platform bundle.

show version

To display the current system software-version information, use the **show version** command.

show version [**detail**]

To display software-version and status information for all the chassis components, use the **show version** command in chassis mode.

show version [**detail** | **package-version**]

To display software-version and status information for a server's components, use the **show version** command in server mode. In server mode, you also can show version information for individual components.

show version [**adapter** | **bios** | **boardcontroller** | **cimc** | **detail** | **fxos** | **package-version** | **storage** |]

Syntax	Description
adapter	(Optional) Show version information for adapters installed in the connected server. This keyword is available only in server mode.
bios	(Optional) Show BIOS version information for the connected server. This keyword is available only in server mode.
boardcontroller	(Optional) Show Management Controller version information for the connected server. This keyword is available only in server mode.
cimc	(Optional) Show CIMC version and status information for the connected server. This keyword is available only in server mode.
detail	(Optional) Show additional version information.
fxos	(Optional) Show SSP operating system version information for the connected server. This keyword is available only in server mode.
package-version	(Optional) Show only package-version information. This keyword is available only in adapter, chassis, fabric-interconnect, server, and system modes.
storage	(Optional) Show version information for RAID and local disk controllers for the connected server. This keyword is available only in server mode.

Command Modes

Any command mode – shows system software-version information

Chassis mode – shows software-version and status information for all chassis components

Server mode – shows software-version and status information for the connected server's components

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

The **package-version** keyword is available only in adapter, chassis, fabric-interconnect, server, and system modes.

In fabric-interconnect mode, this command displays additional version information; see the following example.

Examples

This example shows how to display detailed management-system version information:

```
FP9300-A# show version detail
FPRM:
  Running-Vers: 4.2(1.62)
  Package-Vers: 2.2(1.63)
  Activate-Status: Ready
  Startup-Vers: 4.2(1.62)
```

```
FP9300-A#
```

This example shows how to display version information in fabric-interconnect mode:

```
FP9300-A# scope fabric-interconnect a
FP9300-A /fabric-interconnect #show version
Fabric Interconnect A:
  Running-Kern-Vers: 5.0(3)N2(4.31.60)
  Running-Sys-Vers: 5.0(3)N2(4.31.60)
  Package-Vers: 2.3(1.51)
  Startup-Kern-Vers: 5.0(3)N2(4.31.60)
  Startup-Sys-Vers: 5.0(3)N2(4.31.60)
  Act-Kern-Status: Ready
  Act-Sys-Status: Ready
  Bootloader-Vers:
```

```
FP9300-A /fabric-interconnect #
```

This example shows how to display chassis-component version information:

```
FP9300-A# scope chassis 1
FP9300-A /chassis # show version detail
Chassis 1:
  Server 1:
    CIMC:
      Running-Vers: 3.1(23a)
      Package-Vers: 2.3(1.51)
      Update-Status: Ready
      Activate-Status: Ready

    Adapter 1:
      Running-Vers: 4.0(1.67)
      Package-Vers: 2.3(1.51)
      Update-Status: Ready
      Activate-Status: Ready
      Bootloader-Update-Status: Ready

    Adapter 2:
      Running-Vers: 4.0(1.67)
      Package-Vers: 2.3(1.51)
      Update-Status: Ready
      Activate-Status: Ready
      Bootloader-Update-Status: Ready

  BIOS:
    Running-Vers: FXOSSM1.1.2.1.6.072020171212
    Package-Vers: 2.3(1.51)
    Update-Status: Ready
    Activate-Status: Ready

  SSP OS:
```

```

Running-Vers: 2.3(1.50)
Package-Vers: 2.3(1.51)
Update-Status: Ready
Activate-Status:

RAID Controller 1:
Running-Vers: 24.12.1-0203|6.30.03.0|NA
Package-Vers: 2.3(1.51)
Activate-Status: Ready

BoardController:
Running-Vers: 14.0
Package-Vers: 2.3(1.51)
Activate-Status: Ready

Local Disk 1:
Running-Vers: EM14
Package-Vers:
Activate-Status: Ready

Local Disk 2:
Running-Vers: EM14
Package-Vers:
Activate-Status: Ready

Server 2:
CIMC:
Running-Vers: 3.1(23a)
Package-Vers: 2.3(1.51)
Update-Status: Ready
Activate-Status: Ready

<--- remaining lines removed for brevity --->

FP9300-A /chassis #

```

Related Commands

Command	Description
show server version	Shows current server software versions and status information.

shutdown

To shutdown the device, use the **shutdown** command.

shutdown [**no-prompt** | *reason*]

Syntax Description	no-prompt	(Optional) Use this keyword to initiate shutdown immediately. Otherwise, a commit-buffer is required to initiate shutdown.
	<i>reason</i>	(Optional) A text string to be appended to the shutdown log; can be up to 510 characters.

Command Modes	Chassis mode Local management mode: obsolete
---------------	---

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines	We recommend backing up the system configuration before shutting down. This command is obsolete in local management mode; use shutdown in chassis mode.
------------------	---

Example

This example shows how to enter chassis mode and shut the system down:

```
Firepower # scope chassis 1
Firepower /chassis # shutdown no-prompt
Starting chassis shutdown. Monitor progress with the command "show fsm status".
Please set the power switch to the off position after "INIT: no more processes left in this
runlevel" message is seen.
Firepower /chassis #
Broadcast message from root@Firepower (Tue Jul 14 11:40:47 2020):

All shells being terminated due to system /sbin/shutdown

Cisco FPR Series Security Appliance
INIT: Sending processes the TERM signal
Jul 14 11:40:53 %TTYD-2-TTYD_ERROR TTYD Error ttyd bad select

INIT: no more processes left in this runlevel
```

Related Commands	Command	Description
	reboot	Restarts the chassis or fabric-interconnect.

show web-session-limits

To display a list of web sessions available on the system, use the **show web-session-limits** command.

show validate-task [**detail**]

Syntax Description	Detail	Displays list of detailed web session limits.
Command Modes	scope system/scope services	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	This is a subcommand of the show command in scope system, scope services	

Example

This example shows how to display information of system web session limits:

```
Firepower /fabric-interconnect # scope system
Firepower /system # scope services
Firepower /system/services # show web-session-limits
```

```
Web Sessions:
  Maximum logins for single user  Maximum Sessions
  -----
      32                          256
```

Example

This example shows how to display detailed information of the available web sessions detail:

```
Firepower /system/services # show web-session-limits detail
```

```
Web Sessions:
  Maximum logins for single user: 32
  Maximum Sessions: 256
```



PART **III**

T – W Commands

- [T – W Commands, on page 677](#)



T – W Commands

- [terminal](#), on page 678
- [top](#), on page 679
- [traceroute \(connect local-mgmt\)](#), on page 680
- [traceroute6 \(connect local-mgmt\)](#), on page 681
- [up](#), on page 682
- [verify platform-pack](#), on page 683
- [where](#), on page 685

terminal

To set the number of lines, and the width of the lines, displayed in the terminal window, use the **terminal** command.

terminal {**length** *lines* | **width** *characters*}

Syntax Description

length <i>lines</i>	The number of lines displayed in the terminal window. Valid values range from 0 to 511 lines. Enter 0 to eliminate pausing.
width <i>characters</i>	The number of characters per line displayed in the terminal window. Valid values range from 24 to 511 characters.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

Use this command to set the number of lines, and the number of characters per line, to be displayed in the terminal window.

Example

This example shows how to set the number of lines displayed in the terminal window to 12:

```
FP9300-A# terminal length 12
FP9300-A *# commit-buffer
FP9300-A#
```

Related Commands

Command	Description
set cli	Specifies whether command output lines wrap or truncate, whether table headers are displayed, and whether commas or spaces are used to separate fields in command output tables.

top

To enter root (EXEC) from any mode, use the **top** command.

top

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to enter root from any mode:

```
FP9300-A /system/services # top
```

```
FP9300-A#
```

Related Commands

Command	Description
up	Moves up one mode.

tracert (connect local-mgmt)

To trace the route to another device on the network using its host name or IPv4 address, use the **tracert** command.

```
tracert {hostname | IPv4_address} [source header_IP]
```

Syntax Description	hostname IPv4_address	The host name or IP address of the network device to be contacted. The maximum number of characters allowed for the host name is 510.
	source header_IP	(Optional) Use this keyword to specify the device IP address to be included in the packet headers.

Command Modes connect local-mgmt

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines Use this command to trace the route of IP packets to a network host.

If you do not specify the **source** IP address to be included in the packet headers, the management port address is used.

Example

This example shows how to connect to the local management CLI and then trace the route to another device on the network:

```
firepower# connect local-mgmt
firepower(local-mgmt)# tracert 198.51.100.10
tracert to 198.51.100.10 (198.51.100.10), 30 hops max, 40 byte packets
 1 198.51.100.57 (198.51.100.57) 0.640 ms 0.737 ms 0.686 ms
 2 net1-gw1-13.cisco.com (198.51.100.101) 2.050 ms 2.038 ms 2.028 ms
 3 net1-sec-gw2.cisco.com (198.51.100.201) 0.540 ms 0.591 ms 0.577 ms
 4 net1-fp9300-19.cisco.com (198.51.100.108) 0.336 ms 0.267 ms 0.289 ms

firepower(local-mgmt)#
```

Related Commands	Command	Description
	ping	Pings the device at a specified destination (IPv4 address).

traceroute6 (connect local-mgmt)

To trace the route to another device on the network using its host name or IPv6 address, use the **traceroute6** command.

```
traceroute6 {hostname | ipv6_address} [source header_ip]
```

Syntax Description	<i>hostname ipv6_address</i>	The host name or IPv6 address of the network device to be contacted. The maximum number of characters allowed for the host name is 510.
	source <i>header_ip</i>	(Optional) Use this keyword to specify the device IP address to be included in the packet headers.
Command Modes	connect local-mgmt	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this command to trace the route of IP packets to a network host. If you do not specify the source IP address to be included in the packet headers, the management port address is used.	

Example

This example shows how to connect to the local management CLI and then trace the route to another device on the network:

```
firepower# connect local-mgmt
firepower(local-mgmt)# traceroute 2001:DB8:1::1
traceroute to 2001:DB8:1::1 (2001:DB8:1::1), 30 hops max, 40 byte packets
 1 2001:DB8:1::4 (2001:DB8:1::4) 0.640 ms 0.737 ms 0.686 ms
 2 net1-gw1-13.cisco.com (2001:DB8:1::6) 2.050 ms 2.038 ms 2.028 ms
 3 net1-sec-gw2.cisco.com (2001:DB8:1::8) 0.540 ms 0.591 ms 0.577 ms
 4 net1-fp9300-19.cisco.com (2001:DB8:1::7) 0.336 ms 0.267 ms 0.289 ms

firepower(local-mgmt)#
```

Related Commands	Command	Description
	ping6	Pings the device at a specified destination (IPv6 address).

up

To move up one level in the command-mode hierarchy, use the **up** command.

up

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to move up one mode:

```
FP9300-A /org/service-profile # up
FP9300-A /org #
```

Related Commands

Command	Description
exit	Exits the current CLI session and disconnects from the device, or exits from a connected object mode and returns to the root (EXEC) level.
top	Enters root (EXEC) from any mode.

verify platform-pack

To manually verify the integrity of a downloaded FXOS platform bundle, use the **verify platform-pack** command.

verify platform-pack version *version_number*

Syntax Description	version <i>version_number</i> Specifies the version number of the platform package to verify.				
Command Modes	Firmware mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>1.1(1)</td> <td>Command added.</td> </tr> </tbody> </table>	Release	Modification	1.1(1)	Command added.
Release	Modification				
1.1(1)	Command added.				

Usage Guidelines

The integrity of the image is automatically verified when a new image is downloaded to the Firepower 4100/9300 chassis; use this command to later manually verify the integrity of a downloaded image.

You can use the **show validate-task** or the **show validation package** command to determine the desired package version number.

You also can use the **show validate-task** command to monitor the verification process. The output display does not refresh automatically, so you may have to enter the command multiple times.

Example

This example shows how to verify a specific platform package:

```

FP9300-A# scope firmware
FP9300-A /firmware # show validation package
Firmware Package 2.2(2.19):
  Validation Time Stamp: 2017-10-26T14:34:24.925
  Pack Name: fxos-k9.2.2.2.19.SPA
  Validation State: None
  Overall Status Code: Ok

Firmware Package 2.3(1.51):
  Validation Time Stamp: 2017-10-25T16:53:30.914
  Pack Name: fxos-k9.2.3.1.51.SPA
  Validation State: None
  Overall Status Code: Ok
FP9300-A /firmware # verify platform-pack version 2.3(1.51)
The currently installed FXOS platform software package is 2.3(1.51)
All the Security Modules will be installed with these software components:
  Security Module Adapter  4.0(1.67)
  Security Module BIOS     FXOSSM2.1.3.1.13.0927171811
  Security Module FXOS     2.3(1.50)

INFO: There is no service impact to install this FXOS platform software 2.3(1.51)

Verifying FXOS platform software package 2.3(1.51). Verification could take several minutes.
Do you want to proceed? (yes/no) [yes]:

```

Related Commands	Command	Description
	download image	Downloads an FXOS software image to the Firepower 4100/9300 chassis.
	show validate-task	Displays the status of the image verification process.

where

To determine where you are in the CLI command hierarchy, use the **where** command.

where

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to determine where you are in the CLI:

```
FP9300-A /org/service-profile # where
Mode: /org/service-profile
Mode Data:
    scope org
    enter org org10
    enter service-profile sp10 instance
FP9300-A /org/service-profile #
```

Related Commands

Command	Description
top	Moves to top (EXEC) level from any mode.
up	Moves up one mode.

where



PART **IV**

connect *shell* Commands

- [connect *shell* Commands, on page 689](#)



connect *shell* Commands

- [connect adapter: Command List, on page 690](#)
- [connect cimc: Command List, on page 694](#)
- [connect fxos: Command List, on page 698](#)
- [connect local-mgmt: Command List, on page 712](#)
- [connect module: Command List, on page 718](#)

connect adapter: Command List

After you have used the Supervisor **connect adapter** command to connect to the command shell for a specific adapter, the following commands are available in that shell. See [connect adapter, on page 40](#) for information about the **connect adapter** command.



Attention These commands should be used only when troubleshooting virtualized network adapters with Cisco TAC supervision.

Note that when you connect to an adapter command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to `adapter n/n/n`, where `n/n/n` is the adapter's chassis/server/ID combination you entered to connect.

To exit adapter mode, type **exit**.

Example

The following example shows how to connect to the adapter command shell, and view available commands:

```
firepower# connect adapter 1/2/1
adapter 1/2/1 # help
Available commands:
  connect          - Connect to remote debug shell
  exit             - Exit from subshell
  help            - List available commands
  history         - Show command history
  show-fwlist     - Show firmware versions on the adapter
  show-identity   - Show adapter identity
  show-phyinfo    - Show adapter phy info
  show-systemstatus - Show adapter status
adapter 1/2/1 # exit
firepower#
```

Table 6: Commands Available in the Adapter's Primary Command Shell

Command	Additional Information
connect	Connects to the debug shell; provides access to the commands listed in the following table.
exit	Exits from the adapter command shell.
help	Lists the commands available in this shell.
history	Shows a list of commands issued since entering this shell.
show-fwlist	Shows firmware versions on the adapter.

Command	Additional Information
show-identity	Show adapter identity
show-phyinfo	Show adapter phy info
show-systemstatus	Show adapter status

The following commands are available in the debug subshell; accessed by entering the **connect** command in the adapter's primary command shell.



Note When you connect to an adapter shell's debug subshell, the command-line prompt changes from the `adapter n/n/n prompt`, to `adapter n/n/n (top):n`, where `(top):` indicates you are in the top subshell of the adapter command shell, and `n` represents the number of command lines presented thus far in this debug session.

To exit the debug subshell, type **exit**.

Example

The following example shows how to connect to the adapter's debug subshell, and view available commands:

```
adapter 1/2/1 # connect
No entry for terminal type "dumb";
using dumb terminal settings.
adapter 1/2/1 (top):1# help
Available commands:
  attach-fls      - Attach to fls
  attach-mcp      - Attach to mcp
  estat          - Run fc performance monitor
  exit            - Exit from subshell
  help            - List available commands
  history         - Show command history
  phy-read        - Read PHY register
  show-acltab     - Show ACL table
  show-fru        - Show FRU contents
  show-fwddtab   - Show forwarding table
  show-log        - Show system log
  show-macstats   - Show MAC statistics
  show-pcisw      - Show PCIE switch status
adapter 1/2/1 (top):2# exit
adapter 1/2/1 #
```

Table 7: Commands Available in the Adapter Debug Subshell

Command	Additional Information
attach-fls	Attaches to the adapter's fabric login service; provides access to the commands listed in a following table.
attach-mcp	Attaches to the Master Control Program. A large number of debug-information commands are available; use the help command to view a list. Again, these commands are for use only with Cisco TAC guidance.
estat	Launches a Fibre Channel performance monitor.
exit	Exits from this subshell.
help	Lists the commands available in this subshell.
history	Shows a list of commands issued since entering this subshell.
phy-read	Read PHY register
show-acltab	Show ACL table
show-fru	Show FRU contents
show-fwdtab	Show forwarding table
show-log	Show system log
show-macstats	Show MAC statistics
show-pcisw	Show PCIE switch status

The following commands are available in the Fabric Login Service (FLS) subshell; accessed by entering the **attach-fls** command in the adapter's debug shell.



Note When you connect to the FLS subshell of an adapter's debug subshell, the command-line prompt changes from `adapter n/n/n (top):n`, to `adapter n/n/n (fls):n` where `(fls):` indicates you are in the FLS subshell of the debug subshell, and `n` represents the number of command lines presented thus far in this FLS session.

To exit the FLS subshell, type **exit**; you are returned to the debug subshell.

Example

The following example shows how to attach to the FLS subshell from the debug subshell, and view available commands:

```
adapter 1/2/1 # connect
No entry for terminal type "dumb";
```

```

using dumb terminal settings.
adapter 1/2/1 (top):1# attach-fls
No entry for terminal type "dumb";
using dumb terminal settings.
adapter 1/2/1 (fls):1# help
Available commands:
    d - dumps the contents of the last fw request
    exit - Exit from subshell
fwactive - retrieve active fcpu exchanges
fwcqs - retrieves fcpu cq information
fwexch - retrieves fcpu exchange data
fwlif - retrieves fcpu lif data
fwvnic - retrieves fcpu vnic data
help - List available commands
history - Show command history
lif - Show lif information
login - Show login information pertaining to vnic
lunlist - Show Nameserver and Report LUN's response information for vnic
lunmap - Show lunmap information pertaining to vnic
vnic - Show vnic information

adapter 1/2/1 (fls):2# exit
adapter 1/2/1 (top):2#

```

Table 8: Commands Available in the FLS Subshell

Command	Additional Information
d	Dumps the contents of the last firmware request.
exit	Exits from the FLS subshell.
fwactive	Retrieves active fcpu exchanges
fwcqs	Retrieves fcpu cq information
fwexch	Retrieves fcpu exchange data
fwlif	Retrieves fcpu lif data
fwvnic	Retrieves fcpu vnic data
help	Lists available commands
history	Shows command history
lif	Shows lif information
login	Shows login information pertaining to vnic
lunlist	Shows Nameserver and Report LUN's response information for vnic
lunmap	Shows lunmap information pertaining to vnic
vnic	Shows vnic information

connect cimc: Command List

After you have used the Supervisor **connect cimc** command to connect to the CIMC firmware debug utility for a specific module, the following commands are available in that shell. See [connect cimc, on page 44](#) for information about the **connect cimc** command.

This utility provides access to a read-only shell with commands that let you view real-time CIMC debug information. These commands are used mainly for troubleshooting CIMC issues: viewing alarms, system event logs, on-board failures, and power controls.



Note When you connect to the CIMC command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to [xxx], where xxx is the last command you entered; see the following example.

To exit the CIMC shell, type **exit**.

Example

The following example shows how to connect to CIMC mode and then list the available commands:

```
firepower# connect cimc 1/1
Trying 127.5.1.1...
Connected to 127.5.1.1.
Escape character is '^]'.

CIMC Debug Firmware Utility Shell [ support ]
[ help ]# help

-----
          Debug Firmware Utility
-----

Command List
-----

alarms
cores
dimmb1
exit
i2cstats
images
mctools
memory
messages
mrcout
network
obfl
post
power
programmables
sensors
sel
fru
tasks
top
update
users
version
```



```
cert
sldp
help
help [COMMAND]
```

Notes:
 "enter Key" will execute last command
 "COMMAND ?" will execute help for that command

```
[ help ]# power
OP:[ status ]
Power-State:          [ on ]
Master-State:         [ Master ]
VDD-Power-Good:       [ active ]
Power-On-Fail:        [ inactive ]
Power-Ctrl-Lock:      [ unlocked ]
Power-System-Status:  [ Good ]
Front-Panel Power Button: [ Disabled ]
Front-Panel Reset Button: [ Disabled ]
Source of Last Power Change: [ Software - "mcserver" ]
OP-CCODE:[ Success ]
[ power ]# exit
Connection closed by foreign host.
firepower#
```

Table 9: Commands Available in the CIMC Debug Shell

Command	Additional Information
alarms	Displays the current StatusLED state, and which sensors are in alarm, if any. Alarm Levels: 1 - OK (GREEN ON) 2 - Mem Init (GREEN BLINK) 3 - Mild Fault (AMBER ON) 4 - Severe Fault (AMBER BLINK)
cores	Lists the Core Dump Directory.
exit	Exits from the CIMC subshell.
fru	Lists all field-replaceable unit (FRU) device information.
help [COMMAND]	Entering just the command help lists all available commands. Entering help cmd_name , or cmd_name ? , shows help information for the specified command.
i2cstats	Displays I ² C controller register information, driver counters, and multi-primary debug trace data.
images	Displays software image version and status information.
mctools	Displays current MTools state information: socket and share-file cache size information.

Command	Additional Information
memory	Lists memory and load statistics.
messages	messages [dump follow tail] dump - Dump the /var/log/messages file follow - Tail and Follow /var/log/messages file tail - Dump the last 100 messages
mezz1fru	Show the mezz card 1 FRU information
mezz2fru	Show the mezz card 2 FRU information
mrcout	Dump MrcOut*.txt
network	view network status in realtime ; Dump Network information
obfl	Dump the OBFL - on-board fault log dump - Dump OBFL follow - Tail and Follow OBFL tail - Dump the last 100 messages
post	Dump BIOS Post Information
power	view power status in realtime Dump Blade Power Status
programmables	Dump Board Programmable Versions
sensors	view all sensors in realtime sensors [all power temp fault pres led] all - Dump all Sensors (default) power - Dump only Power Sensors temp - Dump only Temperature Sensors fault - Dump only Fault Sensors pres - Dump only Presence Sensors led - Dump only LED Sensors
sel	Show the Blade SEL Information - system event log
sldp	Cisco CIMC Interactive Debug This command performs interactive debug authentication with the aid of the user and Cisco support personnel.
tasks	Dump Running Task Information

Command	Additional Information
top	Run TOP Process Monitoring
update	Current Firmware Update Status
users	Dump IPMI Users
version	Get the Version Information

connect fxos: Command List

After you have used the Supervisor **connect fxos** command to connect to the FXOS CLI shell for the switching fabric, the following commands are available in that shell. See [connect adapter, on page 40](#) for information about the **connect fxos** command.



Note When you connect to the FXOS command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to the default prompt with (fxos) appended; see the following example.

To exit the FXOS shell, type **exit**.

Example

The following example shows how to connect to the FXOS command shell, and view available commands:

```
firepower# connect fxos
firepower(fxos)# ?
  clear          Reset functions
  cli            CLI commands
  debug         Debugging functions
  debug-filter  Enable filtering for debugging functions
  ethanalyzer   Configure cisco packet analyzer
  no            Negate a command or set its defaults
  ntp           NTP configuration
  show         Show running system information
  system      System management commands
  terminal    Set terminal line parameters
  test       Test command
  undebug   Disable Debugging functions (See also debug)
  end       Go to exec mode
  exit     Exit from command interpreter
  pop     Pop mode from stack or restore from name
  push   Push current mode to stack or save it under name
  where  Shows the cli context you are in

firepower(fxos)# exit
firepower#
```

Table 10: Commands Available in the FXOS Shell for the Switching Fabric

Command	Additional Information
clear	Reset functions counters - Clear counters logging - Clear logging information mac - MAC

Command	Additional Information
cli	CLI commands var - Define a variable
debug	Debugging functions; see following table
debug-filter	Enable filtering for debugging functions ip - IP events ipv6 - IPv6 events pktmgr - Pm debug-filter routing - Routing events
ethanalyzer	Configure Cisco packet analyzer local - Start local capture of frames to Sup
no	Negate a command or set its defaults debug - Debugging functions debug-filter - Enable filtering for debugging functions ethanalyzer - Configure cisco packet analyzer terminal - Set terminal line parameters test - Test command
ntp	NTP configuration sync-retry - Retry synchronization with configured servers
show	Show running system information; see following table
system	System management commands hap-reset - Enables resetting of local or remote sup on ha failures heartbeat - Enables heartbeat no - Negate a command or set its defaults
terminal	Set terminal line parameters; see the following table
test	Test command aaa - Aaa authentication eltn - Display eltn information forwarding - Fib information hardware - Test hardware parameters otv

Command	Additional Information
undebug	Disable Debugging functions (See also debug) all - Disable all debugging icmpv6 - ICMPv6 debug commands ip - IP events ipv6 - IPv6 events l2 - Layer2 l3vm - Debug L3VM information pktmgr - Packet manager debug/tunnel information rpm - Route Policy Manager (RPM) sockets - Sockets system - Enable debugging of system components
end	Go to exec mode
exit	Exit from command interpreter
pop	Pop mode from stack or restore from name <i>name</i> – Name (optional)
push	Push current mode to stack or save it under name <i>name</i> – Name (optional)
where	Shows the cli context you are in detail – Shows each entry on separate line (optional)

Table 11: Debug, Show and Terminal Commands Available in the FXOS Command Shell

Command	Additional Information
debug	

Command	Additional Information
	Debugging functions aaa – Enable debugging for aaa aclcomp – Configure aclcomp debug aclog – Configure aclog debug aclmgr – Configure aclmgr debug afm – Configure afm debug assoc – Original ID to Translated ID Association bcm-usd – BCM USD bootvar – Enable bootvar debugging callhome – Enable debugging for Callhome cdp – Configure CDP debugging cert-enroll – Configure debugging for cert enroll daemon cfs – Enable debugging for CFS cli – Debug cli clis – Debug cli server clk_mgr – Configure clk_mgr debug copp – Configure copp debug core – Configure core daemon debugging csm – Enable csm debugs device-alias – Configure debugs for Device Alias Distribution Service dstats – Configure delta statistics debugging eltm – Configure eltm debug ethpc – Configure ethpc debug ethpm – Configure ethpm debug evmc – Event manager client debugs fc-mac – Debug fcp information fc2 – Configure FC2 debugging fc2d – Configure fc2d debug fcdomain – Enable fcdomain debugging fcfwd – Enable fcfwd debugging fcns – Debug name server fcoe_klm – Configure FCOE_KLM debugging fcpc – Configure fcpc debug

Command	Additional Information
	<p>fcs – Configure Fabric Configuration Server Debugging</p> <p>fdmi – Configure fdmi debugging</p> <p>fex – Debug cli for FEX process</p> <p>fex – Configure fex debug</p> <p>flogi – Configure flogi debug</p> <p>fm – Configure feature manager debugging</p> <p>fspf – Configure FSPF debugging</p> <p>hardware – Debug hardware, kernel loadable module parameters</p> <p>icmpv6 – ICMPv6 debug commands</p> <p>idehsd – Configure Idehsd handler debugging</p> <p>im – Configure im debug</p> <p>ip – IP events</p> <p>ipconf – Configure ipconf debug</p> <p>ipfib – Configure ipfib debug</p> <p>ipqos – Configure IP QoS Manager debug</p> <p>ipv6 – IPv6 events</p> <p>klm – Debug kernel loadable module parameters</p> <p>l2 – Layer2</p> <p>l3vm – Debug L3VM information</p> <p>lacp – Configure lacp debug</p> <p>ldap – Configure debugging for ldap</p> <p>ledmgr – Configure LED manager debugging</p> <p>license – Enable debugging for Licensing</p> <p>lldp – Configure lldp debug</p> <p>logfile – Direct debug output to logfile</p> <p>logging – Configure logging or syslogd debug</p> <p>m2rib – Configure m2rib debug</p> <p>mcec – Configure MCEC debugging</p> <p>mcm – Configure mcm debug</p> <p>mfdm – Configure mfdm debug</p> <p>monitor – Configure Ethernet SPAN sessions</p> <p>msh – Configure msh debug</p> <p>mvsh – MVSH server debugs</p>

Command	Additional Information
	nf – Configure nf debug nohms – Configure nohms debug npacl – Configure NPACL feature nsmgr – Configure nsmgr debug ntp – Debug NTP module obfl – Configure obfl debugging pfm – Configure pfm debug pfstat – Configure pfstat debug pktmgr – Packet manager debug/tunnel information platform – Configure platform debugging platform – Platform internal information platform – Platform plog – Configure plog debugging pltfm_config – Configure pltfm_config debug plugin – Configure plugin debug port – Configure port debugging port-channel – Configure port-channel debug port-profile – Enable port-profile manager debugs port-resources – Configure prm debug port-security – Port security related command private-vlan – Configure debug flags for private VLAN process-sap – SAP of the process to be debugged provision – Configure provision debug psshelper – Psshelper debug psshelper_gsvc – Psshelper debug ptplc – Configure ptplc debug qd – Show information about qd radius – Configure debugging for radius daemon res_mgr – Configure res_mgr debug rib – Configure rib debugging rlir – Configure RLIR debugging rpm – Route Policy Manager (RPM) rscn – Configure RSCN debugging

Command	Additional Information
	<p>sal – Configure sal debug</p> <p>san-port-channel – Configure san-port-channel debug</p> <p>scsi-target – Configure scsi target daemon debugging</p> <p>security – Configure debugging for security</p> <p>session-mgr – Enable session manager debugs</p> <p>snm – Configure snm debug</p> <p>snmp – Configure snmp-server Debugging</p> <p>sockets – Sockets</p> <p>spm – Configure spm debug</p> <p>statsclient – Stats</p> <p>system – Enable debugging of system components</p> <p>system – Debug system</p> <p>tacacs+ – Configure debugging for TACACS+</p> <p>track – Configure track debug</p> <p>transceiver – FC transceiver debug commands</p> <p>tunnel – Configure tunnel debug</p> <p>udld – Configure udld debug</p> <p>Note Unidirectional link detection (UDLD) is not supported by FXOS; ignore any references to UDLD.</p> <p>ufdm – Configure ufdm debug</p> <p>vim – Configure vim debug</p> <p>vlan – Configure debug flags for vlan manager</p> <p>vmm – Configure vmm debug</p> <p>vms – Configure vms debug</p> <p>vsan – Enable VSAN manager debugging</p> <p>willesden – Configure willesden debugging</p> <p>wwn – Configure WWN Manager Debugging</p> <p>xml – XML agent</p> <p>zone – Zone server debug commands</p> <p>zschk – Configure zschk debug</p>

Command	Additional Information
show	

Command	Additional Information
	<p>Show running system information</p> <p>aaa – Show aaa information</p> <p>access-lists – List access lists</p> <p>accounting – Show accounting configuration</p> <p>banner – Show current motd banner message</p> <p>boot – Show Bootvar Variables</p> <p>callhome – Show callhome information</p> <p>cdp – Show Cisco Discovery Protocol information</p> <p>cfs – CFS Show Command handler</p> <p>class-map – Show class maps</p> <p>cli – Show CLI information</p> <p>clock – Display current Date</p> <p>cluster-state – View cluster state</p> <p>configuration – Show information about configuration sessions</p> <p>copyright – Copyright information</p> <p>debug – Show debug flags</p> <p>device-alias – Show information about Device Alias Distribution Service</p> <p>diagnostic – Diagnostic commands</p> <p>ecmp-groups – Display all ECMP groups</p> <p>environment – System environment information</p> <p>fc2 – Show fc2 tables and statistics</p> <p>fc2d – Show information about fc2d</p> <p>fcalias – Fcalias show commands</p> <p>fcdomain – Show fcdomain information</p> <p>fcdroplateny – Show switch or network latency</p> <p>fcflow – Show fcflow information</p> <p>fcid-allocation – Show information about fcid-allocation list</p> <p>fcns – Show name server tables</p> <p>fcroute – Show FC routes</p> <p>fcs – Show Fabric Configuration Server Information</p> <p>ftimer – Show Fibre Channel timers</p> <p>fdmi – Show fdmi information</p> <p>flogi – Show information about FLOGI</p>

Command	Additional Information
	<p>fp – Fp</p> <p>fspf – Show information about FSPF</p> <p>hardware – Show hardware information</p> <p>hostname – Show the system's hostname</p> <p>hosts – Show information about DNS</p> <p>in-order-guarantee – Show in-order delivery guarantee configuration</p> <p>incompatibility – Show incompatible configurations</p> <p>install – Show the software install impact between two images</p> <p>interface – Show interface status and information</p> <p>inventory – Show physical inventory</p> <p>ip – Display IP information</p> <p>ip – IP information</p> <p>ipmc-groups – Display all IPMC groups</p> <p>ipv6 – Display IPv6 information</p> <p>klm – Show kernel module information</p> <p>l2-class-id – L2 class ID allocation</p> <p>l2-table – Display all L2 entries</p> <p>lACP – Show LACP information</p> <p>ldap-server – Show LDAP configuration information</p> <p>line – Show the line configuration</p> <p>lldp – Show information about lldp</p> <p>loadbalancing – Show unicast loadbalancing of a certain flow or exchange</p> <p>locator-led – Display locator led status on the device</p> <p>logging – Show logging configuration and contents of logfile</p> <p>mac – MAC</p> <p>module – Show module information</p> <p>monitor – Show Ethernet SPAN information</p> <p>mSP – Msp commands</p> <p>nsm – Show Network Segment Manager information</p> <p>ntp – Show NTP information</p> <p>phy-bypass – Hardware Bypass</p> <p>platform – Shows list of events received by Platform Manager</p> <p>policy-map – Show policy maps</p>

Command	Additional Information
	<p>port – Show port information</p> <p>port-channel – Show port-channel information</p> <p>port-profile – Show port-profile</p> <p>port-security – Port security related command</p> <p>queuing – Show interface queuing information</p> <p>radius-server – Show RADIUS configuration information</p> <p>redundancy – Show system redundancy status</p> <p>resource – Show resource configuration for VDC</p> <p>rlir – Show RLIR information</p> <p>rmon – Display RMON statistics</p> <p>role – Show role configuration</p> <p>routing – Display routing information</p> <p>routing-context – Display the current routing context</p> <p>rscn – Show RSCN information</p> <p>running-config – Current running configuration</p> <p>san-port-channel – Show port-channel information</p> <p>scsi-target – Show discovered scsi target information</p> <p>snmp – Show snmp information</p> <p>sprom – SPROM contents</p> <p>ssh – Show SSH information</p> <p>startup-config – Current startup configuration</p> <p>svs – Show svcs information</p> <p>switchname – Show the system's hostname</p> <p>system – System-related show commands</p> <p>tacacs-server – Show TACACS+ configuration information</p> <p>tech-support – Gather information for troubleshooting</p> <p>telnet – Show telnet server configuration</p> <p>terminal – Display terminal configuration parameters</p> <p>topology – Show information of connected switches</p> <p>track – Tracking information</p> <p>trunk – Show trunk information</p> <p>udld – UDLD protocol</p>

Command	Additional Information
	<p>Note Unidirectional link detection (UDLD) is not supported by FXOS; ignore any references to UDLD.</p> <p>user-account – Show user information</p> <p>users – Show the current users logged in the system</p> <p>vdc – Show Virtual Device Contexts</p> <p>version – Show the software version</p> <p>vifs – Virtual interfaces</p> <p>vlan – Vlan commands</p> <p>vms – Vms commands</p> <p>vmware – Vmware related</p> <p>vrf – Display VRF information</p> <p>vsan – Show vsan information</p> <p>wwn – Show wwn information</p> <p>xml – XML agent</p> <p>zone – Zone show commands</p> <p>zoneset – Zoneset show commands</p>

Command	Additional Information
terminal	<p>Set terminal line parameters</p> <p>alias – Show aliases (if no arguments); create 'exec' aliases (not persistent). Persistent aliases are in config mode, see 'cli alias'</p> <p>color – Enable colorization of prompt(green if last command ok, red if error), command line (blue), output (default color)</p> <p>dont-ask – Don't ask 'are you sure' questions, take default answer instead</p> <p>edit-mode – Set command line edition keys (vi or emacs; emacs is default)</p> <p>event-manager – Event manager cli event</p> <p>history – Configure terminal history properties</p> <p>length – Set number of lines on a screen</p> <p>monitor – Copy Syslog output to the current terminal line</p> <p>no – Negate a command or set its defaults</p> <p>output – How output of show commands should be formatted</p> <p>prompt – Configure how the prompt should look like</p> <p>redirection-mode – Set the redirection mode</p> <p>session-timeout – Set session timeout</p> <p>sticky-mode – Search for the command match in current mode only</p> <p>terminal-type – Set the terminal type</p> <p>time – Save the current time under a variable</p> <p>tree-update – Updates the main parse tree</p> <p>verify-only – Verify command and do not execute</p> <p>width – Set width of the display terminal</p>

connect local-mgmt: Command List

After you have used the Supervisor **connect local-mgmt** command to connect to the local management shell, the following commands are available in that shell. See [connect adapter, on page 40](#) for information about the **connect local-mgmt** command.

In this shell, you can perform operations on the fabric interconnect, including copying files, rebooting the fabric interconnect, running ping and traceroute commands, and perhaps most importantly, generating troubleshooting files.



Note When you connect to the local-management command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to the default prompt with (local-mgmt) appended; see the following example.

To exit the local-management mode, type **exit**.

Example

The following example shows how to connect to the local-management command shell, and view available commands:

```
firepower# connect local-mgmt
firepower(local-mgmt)# ?
  cd                Change current directory
  clear             Clear managed objects
  cluster          Cluster mode
  connect          Connect to Another CLI
  copy             Copy a file
  cp              Copy a file
  delete          Delete managed objects
  dir             Show content of dir
  enable          Enable
  end             Go to exec mode
  erase           Erase
  erase-log-config Erase the mgmt logging config file
  exit           Exit from command interpreter
  fips           FIPS compliance
  ls            Show content of dir
  mgmt-port     Management Port
  mkdir         Create a directory
  move         Move a file
  mv          Move a file
  ping       Test network reachability
  ping6     Test IPv6 network reachability
  pwd       Print current directory
  reboot    Reboots Fabric Interconnect
  restore-check Check if in restore mode
  rm        Remove a file
  rmdir     Remove a directory
  run-script Run a script
  show      Show system information
  shutdown Shutdown
  ssh      SSH to another system
  tail-mgmt-log tail mgmt log file
```

```

telnet          Telnet to another system
terminal       Terminal
top            Go to the top mode
traceroute     Traceroute to destination
traceroute6    Traceroute to IPv6 destination
verify        Verify Application Image

```

```

firepower(local-mgmt)# exit
firepower#

```

Table 12: Commands Available in the Local Management Shell

Command	Additional Information
cd	Change current directory usbdrive: - File URI volatile: - File URI workspace: - File URI clear - Clear managed objects sshkey - Host public SSH key
cluster	Cluster mode force - Force local fabric interconnect to become primary lead - Make subordinate fabric interconnect primary
connect	Connect to Another CLI adapter - Mezzanine Adapter cimc - Cisco Integrated Management Controller fxos - Connect to FXOS CLI local-mgmt - Connect to Local Management CLI module - Security Module Console
copy	Copy a file ftp: - Source File URI scp: - Source File URI sftp: - Source File URI tftp: - Source File URI usbdrive: - Source File URI volatile: - Source File URI workspace: - Source File URI

Command	Additional Information
cp	Copy a file ftp: - Source File URI scp: - Source File URI sftp: - Source File URI tftp: - Source File URI usbdrive: - Source File URI volatile: - Source File URI workspace: - Source File URI
delete file	Delete managed objects usbdrive: - Source File URI volatile: - Source File URI workspace: - Source File URI
dir	Show content of dir order (Optional) - Order files by time usbdrive: (Optional) - File URI volatile: (Optional) - File URI workspace: (Optional) - File URI
enable cluster	Enable cluster mode a.b.c.d - Cluster IPv4 address ipv6 - IPv6 Cluster mode
end	Go to exec mode
erase	Erase configuration - System configuration
erase-log-config	Erase the mgmt logging config file
exit	Exit from command interpreter
fips	FIPS compliance fault-test - Execute FIPS fault tests self-test - Execute FIPS self-test on demand

Command	Additional Information
ls	Show content of dir order (Optional) - Order files by time usbdrive: (Optional) - File URI volatile: (Optional) - File URI workspace: (Optional) - File URI
mgmt-port	Management Port no-shut (Optional) - Management port up shut (Optional) - Management port down
mkdir	Create a directory usbdrive: (Optional) - File URI volatile: (Optional) - File URI workspace: (Optional) - File URI
move	Move a file usbdrive: (Optional) - File URI volatile: (Optional) - File URI workspace: (Optional) - File URI
mv	Move a file usbdrive: (Optional) - File URI volatile: (Optional) - File URI workspace: (Optional) - File URI
ping	remote_host - Hostname or IP addr (Min size 0, Max size 510)
ping6	Test network reachability Test IPv6 network reachability remote_host - Hostname or IP addr (Min size 0, Max size 510)
pwd	Print current directory
reboot	Reboots Fabric Interconnect
	Check if in restore mode
rm	Remove a file usbdrive: (Optional) - File URI volatile: (Optional) - File URI workspace: (Optional) - File URI

Command	Additional Information
rmdir	Remove a directory usbdrive: (Optional) - File URI volatile: (Optional) - File URI workspace: (Optional) - File URI
run-script	Run a script workspace: - Name of a script to run
show	Show system information cli - CLI Information clock - Clock file - File Commands license - Show license information mgmt-ip-debug - IP Debug Info mgmt-port - Management Port open-network-ports - Show open network ports pmon - Pmon processes - Processes sel - System Event Log software - Software sshkey - Sshkey tech-support - Tech Support
shutdown	Shutdown
ssh	SSH to another system remote_system - Enter hostname or user@hostname (Min size 0, Max size 510)
tail-mgmt-log	tail mgmt log file module - Module Name (Min size 0, Max size 510)
telnet	Telnet to another system remote_host - Hostname or IP addr (Min size 0, Max size 510)
terminal	Set terminal line parameters length - Set number of lines on a screen width - Set width of the display terminal
top	Go to the top mode

Command	Additional Information
traceroute	Traceroute to destination remote_host - Hostname or IP addr (Min size 0, Max size 510)
traceroute6	Traceroute to IPv6destination remote_host - Hostname or IP addr (Min size 0, Max size 510)
verify signature	Verify Application Image bootflash: - Image File Name usbdrive: - Image File Name volatile: - Image File Name workspace: - Image File Name



Note You will find differences in CPU usage values when you use **show processes** and **show system resources** CLIs simultaneously. The CPU usage values differ because of the number of iterations and intervals that each CLI uses by default to summarize the output after sampling through the iterations.

connect module: Command List

After you have used the Supervisor **connect module** command to connect to a specific module console, the following commands are available on that console. See [connect module, on page 52](#) for information about the **connect module** command.

In this shell, you can perform operations on the fabric interconnect, including copying files, rebooting the fabric interconnect, and running ping and traceroute commands.



Note When you connect to a module command shell, the command-line prompt changes from your default prompt, which is the name you assigned to the appliance, to `Firepower-module n` , where n is the number of the module to which you connected; see the following example.

Examples

The following example shows how to connect to the module 1 using Telnet, and view available commands:

```
firepower# connect module 1 telnet
Type exit or Ctrl-] followed by . to quit.
Firepower-module1>?
  secure-login      => Enable blade secure login
  show              => Display system information. Enter show ? for options
  config            => Configure the system. Enter config ? for options
  terminalLength    => Terminal settings. Enter terminal ? for options
  ping              => Ping a host to check reachability
  nslookup          => Look up an IP address or host name with the DNS servers
  traceroute        => Trace the route to a remote host
  connect           => Connect to specific csp console (asa, etc)
  support           => System file operations
  testcrashinfo     => Test crashinfo support
  exit              => Exit the session
  help              => Get help on command syntax
Firepower-module1> <Ctrl-], .>
firepower#
```

Table 13: Commands Available on a Module Console

Command	Additional Information
<code>secure-login</code>	Enable blade secure log in

Command	Additional Information
show	<p>Display system information. Enter show ? for options</p> <ul style="list-style-type: none"> diskusage – Display current disk space usage time – Display current system date and time faults – Display the security module faults if any memoryusage – Display the system Memory usage cpuinfo – Display the system CPU Information users – Display who is logged on and user operations uptime – Display system up time slot – Display the slot number of SSP to which this blade is connected processes – Display all system processes hosts – Show hosts route – Show configured routes interfaces – Show currently configured interfaces version – Display product version netstat – Show network connections vnicmap – Display VNICs with Ethernet interfaces platform – None memory – Display the memory monitor configuration disk – Display the disk monitor configuration cpu – Display the CPU monitor configuration ntp – Show NTP time sync information coredump – Show coredump configuration maxRestart – Show maxRestart turboBoost – Show turboBoost configuration services – Display status of the services process – Show process details cgroups – Display the cgroups tech-support – Generate system information report for troubleshooting purposes

Command	Additional Information
config	<p>Configure the system. Enter config ? for options</p> <ul style="list-style-type: none"> vnic – Configure specified VNIC memory – Configure memory monitor disk – Configure disk monitor process – Configure process cpu monitor maxRestart – Configure maximum restarts CSP. 0 shall Disable feature. Default 8 restartTimeInter – Configure time in seconds to block all CSPs from starting if server restarts maxRestart in this interval. Default 1200 restartCounters – To reset the restart_count coredump – config coredump {...} turboBoost – config turboBoost {...}
terminalLength	<p>Terminal settings. Enter terminal ? for options</p> <ul style="list-style-type: none"> enable – terminal length enable disable – terminal length disable
ping	<p>Ping a host to check reachability</p> <p><i>host</i></p>
nslookup	<p>Look up an IP address or host name with the DNS servers</p> <p><i>host</i></p>
traceroute	<p>Trace the route to a remote host</p> <p><i>host</i></p>
connect	<p>Connect to specific csp console (asa, etc)</p> <p><i>appname apphost</i></p>

Command	Additional Information
support	System file operations platform – Platform operations fileupload – Copy Archive files to MIO diagnostic – Create diagnostic Archive file filelist – List existing files in system directories fileview – View files in the system filetail – Tail files in the system deleteBootImage – Delete boot image certdownload – Download certificate from remote syslog server verify – verify image generate – support generate {command..} tunnel – support tunnel {command..} dplug-access – Enable dplug access send_diag_archiv – Uploads a Default Archive to MIO send_logs – Uploads select files to MIO
testcrashinfo	Test crashinfo support singleprocess – Test crashinfo support with single process multiprocess – Test crashinfo support with multiple processes multithread – Test crashinfo support with multiple threads
help	Get help on command syntax

